

ABB machinery drives

Supplement

ACS355 high speed program (+N826)



Power and productivity
for a better world™

ABB

List of related manuals

Drive manuals and guides	Code (English)
ACS355 user's manual	3AUA0000066143
ACS355 drives with IP66/67 / UL Type 4x enclosure supplement	3AUA0000066066
ACS355 quick installation guide	3AUA0000092940
ACS355 common DC application guide	3AUA0000070130
ACS355 enhanced sequence program (+N830) Supplement	3AXD50000017465
ACS355 high speed program (+N826) Supplement	3AXD50000017574
Option manuals and guides	
FCAN-01 CANopen adapter module user's manual	3AFE68615500
FDNA-01 DeviceNet adapter module user's manual	3AFE68573360
FECA-01 EtherCAT® adapter module user's manual	3AUA0000068940
FENA-01/-11 Ethernet adapter module user's manual	3AUA0000093568
FLON-01 LonWORKS® adapter module user's manual	3AUA0000041017
FMBA-01 Modbus adapter module user's manual	3AFE68586704
FPBA-01 PROFIBUS DP adapter module user's manual	3AFE68573271
FRSA-00 RS-485 adapter board user's manual	3AFE68640300
MFDT-01 FlashDrop user's manual	3AFE68591074
MPOT-01 potentiometer module instructions for installation and use	3AFE68591082
MREL-01 output relay module user's manual	3AUA0000035974
MTAC-01 pulse encoder interface module user's manual	3AFE68591091
MUL1-R1 installation instructions for ACS150, ACS310, ACS320, ACS350 and ACS355	3AFE68642868
MUL1-R3 installation instructions for ACS310, ACS320, ACS350 and ACS355	3AFE68643147
MUL1-R4 installation instructions for ACS310, ACS320, ACS350 and ACS355	3AUA0000025916
SREA-01 Ethernet adapter module quick start-up guide	3AUA0000042902
SREA-01 Ethernet adapter module user's manual	3AUA0000042896
ACS355 and AC500-eCo application guide	2CDC125152M0201
AC500-eCo PLC and ACS355 quick installation guide	2CDC125145M0201

Maintenance manuals and guides

Guide for capacitor reforming in ACS50, ACS55, ACS150, 3AFE68735190
ACS310, ACS350, ACS355, ACS550, ACH550 and R1-R4 OINT/SINT boards

You can find manuals and other product documents in PDF format on the Internet. See section [Document library on the Internet](#) on the inside of the back cover. For manuals not available in the Document library, contact your local ABB representative.

Supplement

ACS355 high speed program (+N826)

Table of contents



Table of contents

1. Introduction to the supplement

What this chapter contains	7
Safety	7
Scope	7
Applicability	8
Target audience	8
Purpose of the manual	8
Contents of this supplement	9
Related documents	9

2. Program features

What this chapter contains	11
Drive selection tables	11
Fault reaction for EM STOP	12
Settings	12
Fault reaction for Power loss	13
Settings	13
Smooth start ramp	13
Settings	13
Start enable	13
Settings	13
Fast user set change	14
Settings	14
.....	14



3. Actual signals and parameters

What this chapter contains	15
Actual signals	16
Parameters	17

Further information

Product and service inquiries	27
Product training	27
Providing feedback on ABB Drives manuals	27
Document library on the Internet	27



1

Introduction to the supplement

What this chapter contains

The chapter describes safety issues, scope of this supplement, applicability, target audience and purpose of this supplement. It describes the contents of this supplement and refers to a list of related manuals for more information.

Safety

Safety related instructions please refer to *ACS355 user's manual* (3AUA0000066143 [English]). The safety instructions must be followed when installing, operating and servicing the drive. Please study the complete safety instructions carefully.

Scope

This document is supplement of *ACS355 user's manual* (3AUA0000066143 [English]). This supplement covers all differences between high speed program and ACS355 standard firmware. Only the high speed program contents are given in each chapter of this supplement.

8 Introduction to the supplement

Following chapters please refer to *ACS355 user's manual* (3AUA0000066143 [English]):

- Operation principle and hardware description
- Mechanical installation
- Planning the electrical installation
- Electrical installation
- Installation checklist
- Control panels
- Application macros
- Startup, control with I/O and ID run
- Fieldbus control with fieldbus adapter
- Fault tracing
- Maintenance and hardware diagnostics
- Technical data
- Appendixes

Applicability

The manual is applicable to the ACS355 high speed program firmware version 6303 or later. See parameter *3301 FIRMWARE*. Option code +N826 in the drive type code shows that the drive has the high speed program installed.

Target audience

This supplement is intended for people who work with ACS355 high speed program. The reader of this supplement is expected to know the fundamentals of electricity, wiring, electrical components and electrical schematic symbols.

Purpose of the manual

This manual provides information needed for commissioning, operating and maintaining the ACS355 high speed program.

Contents of this supplement

The supplement consists of the following chapters:

- *Introduction to the supplement* (this chapter, page 7) describes safety issues, scope of supplement, applicability, target audience and purpose of this manual.
- *Program features* (page 11) describes program features. There are also lists of related user settings in each section.
- *Actual signals and parameters* (page 15) describes the actual signals and parameters related to high speed program and gives the fieldbus equivalent values for each signal/parameter.
- *Further information* (inside of the back cover) tells how to make product and service inquiries, get information on product training, provide feedback on ABB Drives manuals and how to find documents on the Internet.

Related documents

See *List of related manuals* on page 2 (inside of the front cover).

10 Introduction to the supplement

2

Program features

What this chapter contains

The chapter describes ACS355 high speed program features. There are also lists of related user settings in each section. Other standard program features please refer to chapter Program features in *ACS355 user's manual* (3AUA0000066143 [English]).

Control program introduction

Application specific firmware for high speed grinding and polishing machines. Spindles can operate up to 1400Hz output frequency in scalar mode and up to 32000rpm in vector mode.

Drive selection tables

Motor rated frequency range[Hz]		Min switching frequency	Recommended switching frequency	Switching frequency control (2607)	Minimum derating		Recommended derating		Max ambient temperature
					200V drive	400V drive	200V drive	400V drive	
0	300...600	4kHz	8kHz	0 = ON (LOAD)	No derating	No derating	90%	75%	40
300	800...1000	8kHz	12kHz	1 = ON	90%	75%	80%	50%	30
800	1400	12kHz	12kHz	1 = ON	80%	50%	80%	50%	30

Motor rated frequency range[Hz]		Minimum derating		Recommended derating		Max ambient temperature
		200V drive	400V drive	200V drive	400V drive	
0	300...600	No derating	No derating	90%	75%	40
300	800...1000	90%	75%	80%	50%	30
800	1400	80%	50%	80%	50%	30

Note: These derating rules do not consider R0 frame. Please check the user's manual for derating the R0 frame size.

Fault reaction for EM STOP

Emergency ramp stop in case of non critical faults and 500ms delayed fault for under voltage controller. Especially meant for blackouts. Spindle can keep on coasting for an hour in worst case.

- New parameter 30.29 added which enables emergency ramp stop when drive faults:
 - 30.29 = 0 Fault reaction same as in standard FW.
 - 30.29 = 1 Drive makes ramp stop during fault (except HW critical faults).
- Drive makes an emergency ramp stop when fault occurs using the emergency ramp stop deceleration time (par. 22.08).
- Hardware critical faults (“OVERCURRENT”, “DC OVERVOLT” and “SHORT CIRC”) will still make a coast stop in order to protect the drive. When hardware critical faults occur among several other faults, the drive will make a coast stop.
- “SAFE TORQUE OFF”, “STO1 LOST” and “STO2 LOST” faults will behave the same way as hardware critical faults since it is not possible to drive the motor anyway.

Related parameters are listed in the table below:

■ Settings

Parameter	Additional information
2208 EMERG DEC TIME	Time within which the drive is stopped if an emergency stop is activated.
3029 FAULT RAMP STOP	Enables emergency ramp stop when drive faults

Fault reaction for Power loss

When 20.06 UNDERVOLT CTRL = ENABLE(TIME) and 30.29 = ENABLE (fault ramp stop enabled) then drive faults after being in under-voltage control for 500ms. Fault will also trigger an emergency ramp stop.

Related parameters are listed in the table below:

■ Settings

Parameter	Additional information
2006 UNDERVOLT CTRL	Activates or deactivates the undervoltage control of the intermediate DC link.
3029 FAULT RAMP STOP	Enables emergency ramp stop when drive faults

Smooth start ramp

For PM motor there is possibility for different ramping during the smooth start period. This function can ensure successful start of PM motor in case of high inertia and encoderless operation.

When option "SMOOTH START"(11) of parameter 22.01 "ACC/DEC 1/2 SEL" is selected, then ramp 2 is used while smooth start is active and ramp 1 when smooth start is not active.

Related parameters are listed in the table below:

■ Settings

Parameter	Additional information
2201 ACC/DEC 1/2 SEL	Source from which the drive reads the signal that selects between the two ramp pairs.

Start enable

When start enable 1 or 2 is lost while drive is running, then drive will make the stop set by par. 21.02 STOP FUNCTION.

Related parameters are listed in the table below:

■ Settings

Parameter	Additional information
1608 START ENABLE 1	Selects the source for the Start enable 1 signal.
1609 START ENABLE 2	Selects the source for the Start enable 2 signal.
2102 STOP FUNCTION	Selects the motor stop function.

Fast user set change

Totally 6 user sets and possibility change quickly between them. User can switch from different ramp and controller values for different tools in case machine has several tools.

Parameter 0186 ACTIVE MACRO – shows which user set was last loaded, updated after start inhibits are removed. Parameter 0186 changes to 0, when user set load starts and drive is ready to start when parameter 0186 changes to loaded user set value.

Related parameters are listed in the table below:

■ Settings

Parameter	Additional information
0186 ACTIVE MACRO	Shows which user macro is actively loaded.
1605 USER PAR SET CHG	Enables the change of the User parameter set through a digital input.
1614 LOAD USER SET	Selects which user set will be loaded.
1615 SAVE USER SET	Selects which user set will be saved.
9902 APPLIC MACRO	Selects the application macro.

3

Actual signals and parameters

What this chapter contains

The chapter describes the actual signals and parameters related to high speed program and gives the fieldbus equivalent values for each signal/parameter.

Terms and abbreviations


Term	Definition
Actual signal	Sequence program related signals measured or calculated by the drive. Can be monitored by the user. No user setting possible.
Def	Parameter default value
Parameter	A user-adjustable sequence program operation instruction of the drive. Note: Parameter selections are shown on the basic control panel as integer values. Eg parameter 1001 EXT1 COMMANDS selection COMM is shown as value 10 (which is equal to the fieldbus equivalent FbEq).
FbEq	Fieldbus equivalent: The scaling between the value and the integer used in serial communication.

Note: More information about drive parameters please refer to the section Actual signal and parameters in ACS355 User's manual (3AUA0000066143 [English]).

Actual signals

Actual signals		
No.	Name/Value	Description
01	OPERATING DATA	Basic signals for monitoring the drive (read-only)
0186	ACTIVE MACRO	Shows which user macro is loaded.

Parameters


All parameters			
No.	Name/Value	Description	Def/FbEq
11 REFERENCE SELECT		Panel reference type, external control location selection and external reference sources and limits	
1104 REF1 MIN		Defines the minimum value for external reference REF1. Corresponds to the minimum setting of the used source signal.	0.0 Hz / 1 rpm
0.0...1400.0 Hz / 0...32000 rpm		Minimum value in rpm. Hz if parameter 9904 MOTOR CTRL MODE setting is SCALAR: FREQ. Example: Analog input AI1 is selected as the reference source (value of parameter 1103 is AI1). The reference minimum and maximum correspond to the 1301 MINIMUM AI1 and 1302 MAXIMUM AI1 settings as follows:  The graph plots REF (Hz/rpm) on the vertical axis against AI1 signal (%) on the horizontal axis. A solid line represents the AI1 signal. Two horizontal dashed lines indicate the reference range. The upper dashed line is labeled REF1 MAX (1105) and the lower dashed line is labeled -REF1 MIN (1104). The distance between these two dashed lines is labeled REF1 MIN (1104). The graph shows the AI1 signal starting at 1301% and rising to 1302%. The reference range is centered around the AI1 signal, with its width determined by the difference between REF1 MAX and -REF1 MIN.	1 = 0.1 Hz / 1 rpm
1105 REF1 MAX		Defines the maximum value for external reference REF1. Corresponds to the maximum setting of the used source signal.	E: 50.0 Hz U: 60.0 Hz
0.0...1400.0 Hz / 0...32000 rpm		Maximum value in rpm. Hz if parameter 9904 MOTOR CTRL MODE setting is SCALAR: FREQ. See the example for parameter 1104 REF1 MIN.	1 = 0.1 Hz / 1 rpm
12 CONSTANT SPEEDS		Constant speed selection and values.	
1202 CONST SPEED 1		Defines constant speed (or drive output frequency) 1.	E: 5.0 Hz U: 6.0 Hz
0.0...1400.0 Hz / 0...32000 rpm		Speed in rpm. Output frequency in Hz if parameter 9904 MOTOR CTRL MODE setting is SCALAR: FREQ.	1 = 0.1 Hz / 1 rpm
1203 CONST SPEED 2		Defines constant speed (or drive output frequency) 2.	E: 10.0 Hz U: 12.0 Hz
0.0...1400.0 Hz / 0...32000 rpm		Speed in rpm. Output frequency in Hz if parameter 9904 MOTOR CTRL MODE setting is SCALAR: FREQ.	1 = 0.1 Hz / 1 rpm
1204 CONST SPEED 3		Defines constant speed (or drive output frequency) 3.	E: 15.0 Hz U: 18.0 Hz

All parameters			
No.	Name/Value	Description	Def/FbEq
	0.0...1400.0 Hz / 0...32000 rpm	Speed in rpm. Output frequency in Hz if parameter 9904 MOTOR CTRL MODE setting is SCALAR: FREQ.	1 = 0.1 Hz / 1 rpm
1205	CONST SPEED 4	Defines constant speed (or drive output frequency) 4.	E: 20.0 Hz U: 24.0 Hz
	0.0...1400.0 Hz / 0...32000 rpm	Speed in rpm. Output frequency in Hz if parameter 9904 MOTOR CTRL MODE setting is SCALAR: FREQ.	1 = 0.1 Hz / 1 rpm
1206	CONST SPEED 5	Defines constant speed (or drive output frequency) 5.	E: 25.0 Hz U: 30.0 Hz
	0.0...1400.0 Hz / 0...32000 rpm	Speed in rpm. Output frequency in Hz if parameter 9904 MOTOR CTRL MODE setting is SCALAR: FREQ.	1 = 0.1 Hz / 1 rpm
1207	CONST SPEED 6	Defines constant speed (or drive output frequency) 6.	E: 40.0 Hz U: 48.0 Hz
	0.0...1400.0 Hz / 0...32000 rpm	Speed in rpm. Output frequency in Hz if parameter 9904 MOTOR CTRL MODE setting is SCALAR: FREQ. Constant speed 6 is used also as jogging speed.	1 = 0.1 Hz / 1 rpm
1208	CONST SPEED 7	Defines constant speed (or drive output frequency) 7. Constant speed 7 is used also as jogging speed or with fault functions (3001 AI<MIN FUNCTION and 3002 PANEL COMM ERR).	E: 50.0 Hz U: 60.0 Hz
	0.0...1400.0 Hz / 0...32000 rpm	Speed in rpm. Output frequency in Hz if parameter 9904 MOTOR CTRL MODE setting is SCALAR: FREQ. Constant speed 7 is used also as jogging speed.	1 = 0.1 Hz / 1 rpm
16 SYSTEM CONTROLS		Parameter view, Run enable, parameter lock etc.	
1605	USER PAR SET CHG	<p>Enables the change of the User parameter set through a digital input. See parameter 9902 APPLIC MACRO. The change is only allowed when the drive is stopped. During the change, the drive will not start.</p> <p>Note: Always save the User parameter set with parameter 9902 after changing any parameter setting, or reperforming the motor identification. The last settings saved by the user are loaded into use whenever the power is switched off and on again or the parameter 9902 setting is changed. Any unsaved changes will be lost.</p> <p>Note: The value of this parameter is not included in the User parameter sets. A setting once made remains despite User parameter set change.</p> <p>Note: Selection of User parameter set 2 can be supervised through relay outputs RO 1...4 and digital output DO. See parameters 1401 RELAY OUTPUT 1 ... 1403 RELAY OUTPUT 3, 1410 RELAY OUTPUT 4 and 1805 DO SIGNAL.</p>	NOT SEL

All parameters																																			
No.	Name/Value	Description	Def/FbEq																																
	NOT SEL	User parameter set change is not possible through a digital input. Parameter sets can be changed only from the control panel.	0																																
	DI1	User parameter set control through digital input DI1. Falling edge of digital input DI1: User parameter set 1 is loaded into use. Rising edge of digital input DI1: User parameter set 2 is loaded into use.	1																																
	DI2	See selection DI1 .	2																																
	DI3	See selection DI1 .	3																																
	DI4	See selection DI1 .	4																																
	DI5	See selection DI1 .	5																																
	DI1,2	User parameter set selection through digital inputs DI1 and DI2. 1 = DI active, 0 = DI inactive. <table border="1"> <thead> <tr> <th>DI1</th> <th>DI2</th> <th>User parameter set</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>User parameter set 1</td> </tr> <tr> <td>1</td> <td>0</td> <td>User parameter set 2</td> </tr> <tr> <td>0</td> <td>1</td> <td>User parameter set 3</td> </tr> <tr> <td>1</td> <td>1</td> <td>User parameter set 4</td> </tr> </tbody> </table>	DI1	DI2	User parameter set	0	0	User parameter set 1	1	0	User parameter set 2	0	1	User parameter set 3	1	1	User parameter set 4	7																	
DI1	DI2	User parameter set																																	
0	0	User parameter set 1																																	
1	0	User parameter set 2																																	
0	1	User parameter set 3																																	
1	1	User parameter set 4																																	
	DI2,3	See selection DI1,2 .	8																																
	DI3,4	See selection DI1,2 .	9																																
	DI4,5	See selection DI1,2 .	10																																
	DI1,2,3	User parameter set selection through digital inputs DI1, DI2 and DI3. 1 = DI active, 0 = DI inactive. <table border="1"> <thead> <tr> <th>DI1</th> <th>DI2</th> <th>DI3</th> <th>User parameter set</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>User parameter set 1</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>User parameter set 2</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>User parameter set 3</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>User parameter set 4</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>User parameter set 5</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>User parameter set 6</td> </tr> <tr> <td>x</td> <td>1</td> <td>1</td> <td>No reaction</td> </tr> </tbody> </table>	DI1	DI2	DI3	User parameter set	0	0	0	User parameter set 1	1	0	0	User parameter set 2	0	1	0	User parameter set 3	1	1	0	User parameter set 4	0	0	1	User parameter set 5	1	0	1	User parameter set 6	x	1	1	No reaction	12
DI1	DI2	DI3	User parameter set																																
0	0	0	User parameter set 1																																
1	0	0	User parameter set 2																																
0	1	0	User parameter set 3																																
1	1	0	User parameter set 4																																
0	0	1	User parameter set 5																																
1	0	1	User parameter set 6																																
x	1	1	No reaction																																
	DI2,3,4	See selection DI1,2,3 .	13																																
	DI3,4,5	See selection DI1,2,3 .	14																																
	DI1(INV)	User parameter set control through inverted digital input DI1. Falling edge of inverted digital input DI1: User parameter set 2 is loaded into use. Rising edge of inverted digital input DI1: User parameter set 1 is loaded into use.	-1																																
	DI2(INV)	See selection DI1(INV) .	-2																																
	DI3(INV)	See selection DI1(INV) .	-3																																
	DI4(INV)	See selection DI1(INV) .	-4																																

All parameters																																			
No.	Name/Value	Description	Def/FbEq																																
	DI1,2(INV)	User parameter set selection through inverted digital inputs DI1 and DI2. 1 = DI inactive, 0 =DI active. <table border="1"> <thead> <tr> <th>DI1</th> <th>DI2</th> <th>User parameter set</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>1</td> <td>User parameter set 1</td> </tr> <tr> <td>0</td> <td>1</td> <td>User parameter set 2</td> </tr> <tr> <td>1</td> <td>0</td> <td>User parameter set 3</td> </tr> <tr> <td>0</td> <td>0</td> <td>User parameter set 4</td> </tr> </tbody> </table>	DI1	DI2	User parameter set	1	1	User parameter set 1	0	1	User parameter set 2	1	0	User parameter set 3	0	0	User parameter set 4	-7																	
DI1	DI2	User parameter set																																	
1	1	User parameter set 1																																	
0	1	User parameter set 2																																	
1	0	User parameter set 3																																	
0	0	User parameter set 4																																	
	DI2,3(INV)	See selection <i>DI1,2</i> (INV).	-8																																
	DI3,4(INV)	See selection <i>DI1,2</i> (INV).	-9																																
	DI4,5(INV)	See selection <i>DI1,2</i> (INV).	-10																																
	DI1,2,3(INV)	User parameter set selection through inverted digital inputs DI1, DI2 and DI3. 1 = DI inactive, 0 =DI active. <table border="1"> <thead> <tr> <th>DI1</th> <th>DI2</th> <th>DI3</th> <th>User parameter set</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>1</td> <td>1</td> <td>User parameter set 1</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>User parameter set 2</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>User parameter set 3</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>User parameter set 4</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>User parameter set 5</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>User parameter set 6</td> </tr> <tr> <td>x</td> <td>0</td> <td>0</td> <td>No reaction</td> </tr> </tbody> </table>	DI1	DI2	DI3	User parameter set	1	1	1	User parameter set 1	0	1	1	User parameter set 2	1	0	1	User parameter set 3	0	0	1	User parameter set 4	1	1	0	User parameter set 5	0	1	0	User parameter set 6	x	0	0	No reaction	-12
DI1	DI2	DI3	User parameter set																																
1	1	1	User parameter set 1																																
0	1	1	User parameter set 2																																
1	0	1	User parameter set 3																																
0	0	1	User parameter set 4																																
1	1	0	User parameter set 5																																
0	1	0	User parameter set 6																																
x	0	0	No reaction																																
	DI2,3,4(INV)	See selection <i>DI1,2,3</i> (INV).	-13																																
	DI3,4,5(INV)	See selection <i>DI1,2,3</i> (INV).	-14																																
1614	LOAD USER SET	Selects which user set will be loaded	NOT SEL																																
	Done	No user set will be loaded.	0																																
	USER S1 LOAD	User set1 will be loaded.	1																																
	USER S2 LOAD	User set2 will be loaded.	2																																
	USER S3 LOAD	User set3 will be loaded.	3																																
	USER S4 LOAD	User set4 will be loaded.	4																																
	USER S5 LOAD	User set5 will be loaded.	5																																
	USER S6 LOAD	User set6 will be loaded.	6																																
1615	SAVE USER SET	Selects which user set will be saved	NOT SEL																																
	Done	No user set will be saved.	0																																
	USER S1 SAVE	User set1 will be saved.	1																																

All parameters			
No.	Name/Value	Description	Def/FbEq
	USER S2 SAVE	User set2 will be saved.	2
	USER S3 SAVE	User set3 will be saved.	3
	USER S4 SAVE	User set4 will be saved.	4
	USER S5 SAVE	User set5 will be saved.	5
	USER S6 SAVE	User set6 will be saved.	6
20 LIMITS		Drive operation limits. Speed values are used in vector control and frequency values are used in scalar control. The control mode is selected by parameter 9904 MOTOR CTRL MODE.	
2001 MINIMUM SPEED		<p>Defines the allowed minimum speed. A positive (or zero) minimum speed value defines two ranges, one positive and one negative. A negative minimum speed value defines one speed range.</p> <p>Note: Rotation direction can be fixed with parameter 1003 DIRECTION.</p>	0 rpm
-32000... 32000 rpm		Minimum speed	1 = 1 rpm
2002 MAXIMUM SPEED		Defines the allowed maximum speed. See parameter 2001 MINIMUM SPEED .	E: 1500 rpm / U: 1800 rpm
0...32000 rpm		Maximum speed	1 = 1 rpm

All parameters			
No.	Name/Value	Description	Def/FbEq
2007	MINIMUM FREQ	<p>Defines the minimum limit for the drive output frequency. A positive (or zero) minimum frequency value defines two ranges, one positive and one negative. A negative minimum frequency value defines one speed range.</p> <p>Note: <i>MINIMUM FREQ</i> \leq <i>MAXIMUM FREQ</i>.</p> 	0.0 Hz
-1400.0 ...1400.0 Hz		Minimum frequency	1 = 0.1 Hz
2008	MAXIMUM FREQ	Defines the maximum limit for the drive output frequency.	E: 50.0 Hz U: 60.0 Hz
0.0...1400.0 Hz		Maximum frequency	1 = 0.1 Hz
22 ACCEL/DECEL		Acceleration and deceleration times	
2201	ACC/DEC 1/2 SEL	<p>Defines the source from which the drive reads the signal that selects between the two ramp pairs, acceleration/deceleration pair 1 and 2.</p> <p>Ramp pair 1 is defined by parameters 2202...2204.</p> <p>Ramp pair 2 is defined by parameters 2205...2207.</p>	<i>DI5</i>
NOT SEL		Ramp pair 1 is used.	0
DI1		Digital input DI1. 1 = ramp pair 2, 0 = ramp pair 1.	1
DI2		See selection <i>DI1</i> .	2
DI3		See selection <i>DI1</i> .	3
DI4		See selection <i>DI1</i> .	4
DI5		See selection <i>DI1</i> .	5
COMM		<p>Fieldbus interface as the source for ramp pair 1/2 selection, ie Control word 0301 FB CMD WORD 1 bit 10. The Control word is sent by the fieldbus controller through the fieldbus adapter or embedded fieldbus (Modbus) to the drive. For the Control word bits.</p> <p>Note: This setting applies only for the DCU profile.</p>	7
SEQ PROG		Sequence programming ramp defined by parameter 8422 ST1 RAMP (or 8423/.../8492)	10

All parameters			
No.	Name/Value	Description	Def/FbEq
	SMOOTH START	Smooth start ramp time will be effect in ramp time according to settings of parameter 2621...2624.	11
	DI1(INV)	Inverted digital input DI1. 0 = ramp pair 2, 1 = ramp pair 1.	-1
	DI2(INV)	See selection DI1(INV) .	-2
	DI3(INV)	See selection DI1(INV) .	-3
	DI4(INV)	See selection DI1(INV) .	-4
	DI5(INV)	See selection DI1(INV) .	-5
25 CRITICAL SPEEDS	Speed bands within which the drive is not allowed to operate.		
2502 CRIT SPEED 1 LO	Defines the minimum limit for critical speed/frequency range 1.		0.0 Hz / 1 rpm
0.0...1400.0 Hz / 0...32000 rpm	Limit in rpm. Limit in Hz if parameter 9904 MOTOR CTRL MODE setting is SCALAR: FREQ. The value cannot be above the maximum (parameter 2503 CRIT SPEED 1 HI).		1 = 0.1 Hz / 1 rpm
2503 CRIT SPEED 1 HI	Defines the maximum limit for critical speed/frequency range 1.		0.0 Hz / 1 rpm
0.0...1400.0 Hz / 0...32000 rpm	Limit in rpm. Limit in Hz if parameter 9904 MOTOR CTRL MODE setting is SCALAR: FREQ. The value cannot be below the minimum (parameter 2502 CRIT SPEED 1 LO).		1 = 0.1 Hz / 1 rpm
2504 CRIT SPEED 2 LO	See parameter 2502 CRIT SPEED 1 LO .		0.0 Hz / 1 rpm
0.0...1400.0 Hz / 0...32000 rpm	See parameter 2502 .		1 = 0.1 Hz / 1 rpm
2505 CRIT SPEED 2 HI	See parameter 2503 CRIT SPEED 1 HI .		0.0 Hz / 1 rpm
0.0...1400.0 Hz / 0...32000 rpm	See parameter 2503 .		1 = 0.1 Hz / 1 rpm
2506 CRIT SPEED 3 LO	See parameter 2502 CRIT SPEED 1 LO .		0.0 Hz / 1 rpm
0.0...1400.0 Hz / 0...32000 rpm	See parameter 2502 .		1 = 0.1 Hz / 1 rpm
2507 CRIT SPEED 3 HI	See parameter 2503 CRIT SPEED 1 HI .		0.0 Hz / 1 rpm
0.0...1400.0 Hz / 0...32000 rpm	See parameter 2503 .		1 = 0.1 Hz / 1 rpm
26 MOTOR CONTROL	Motor control variables		
2611 USER DEFINED F1	Defines the first frequency point of the custom U/f curve.		10.0 Hz
0.0...1400.0 Hz	Frequency		1 = 0.1 Hz
2613 USER DEFINED F2	Defines the second frequency point of the custom U/f curve.		20.0 Hz

All parameters			
No.	Name/Value	Description	Def/FbEq
	0.0...1400.0 Hz	Frequency	1 = 0.1 Hz
2615	USER DEFINED F3	Defines the third frequency point of the custom U/f curve.	25.0 Hz
	0.0...1400.0 Hz	Frequency	1 = 0.1 Hz
2617	USER DEFINED F4	Defines the fourth frequency point of the custom U/f curve.	40.0 Hz
	0.0...1400.0 Hz	Frequency	1 = 0.1 Hz
30 FAULT FUNCTIONS		Programmable protection functions	
3029	FAULT RAMP STOP	Selects how the drive reacts when the drive trips to fault excepting Hardware critical faults (OVERCURRENT, DC OVERVOLT and SHORT CIRC), SAFE TORQUE OFF, STO1 LOST and STO2 LOST faults.	1
	DISABLE	Drive makes coast stop when drive trips fault.	0
	ENABLE	Drive makes emergency ramp stop when drive trips fault using the emergency ramp stop deceleration time (par. 22.08).	1
40 PROCESS PID SET 1		Process PID (PID1) control parameter set 1.	
4023	PID SLEEP LEVEL	<p>Defines the start limit for the sleep function. If the motor speed is below a set level (4023) longer than the sleep delay (4024), the drive shifts to the sleeping mode: The motor is stopped and the control panel shows alarm message PID SLEEP (2018).</p> <p>Parameter 4022 SLEEP SELECTION must be set to INTERNAL.</p>	0.0 Hz / 0 rpm
0.0...1400.0 Hz / 0...32000 rpm	Sleep start level		1 = 0.1 Hz 1 rpm

All parameters			
No.	Name/Value	Description	Def/FbEq
99 START-UP DATA	Language selection. Definition of motor set-up data.		
9902 APPLIC MACRO	Selects the application macro.		ABB STANDARD
ABB STANDARD	Standard macro for constant speed applications		1
3-WIRE	3-wire macro for constant speed applications		2
ALTERNATE	Alternate macro for start forward and start reverse applications		3
MOTOR POT	Motor potentiometer macro for digital signal speed control applications		4
HAND/AUTO	Hand/Auto macro to be used when two control devices are connected to the drive: <ul style="list-style-type: none"> Device 1 communicates through the interface defined by external control location EXT1. Device 2 communicates through the interface defined by external control location EXT2. EXT1 or EXT2 is active at a time. Switching between EXT1/2 through digital input.		5
PID CONTROL	PID control. For applications in which the drive controls a process value, eg pressure control by the drive running the pressure boost pump. Measured pressure and the pressure reference are connected to the drive.		6
TORQUE CTRL	Torque control macro		8
AC500 MODBUS	AC500 PLC macro.		10
LOAD FD SET	FlashDrop parameter values as defined by the FlashDrop file. Parameter view is selected by parameter 1611 PARAMETER VIEW. FlashDrop is an optional device for fast copying of parameters to unpowered drives. FlashDrop allows easy customization of the parameter list, eg selected parameters can be hidden. For more information, see <i>MFDT-01 FlashDrop user's manual</i> (3AFE68591074 [English]).		31
USER S1 LOAD	User 1 macro loaded into use. Before loading, check that the saved parameter settings and the motor model are suitable for the application.		0
USER S1 SAVE	Save User 1 macro. Stores the current parameter settings and the motor model.		-1
USER S2 LOAD	User 2 macro loaded into use. Before loading, check that the saved parameter settings and the motor model are suitable for the application.		-2

All parameters			
No.	Name/Value	Description	Def/FbEq
	USER S2 SAVE	Save User 2 macro. Stores the current parameter settings and the motor model.	-3
	USER S3 LOAD	User 3 macro loaded into use. Before loading, check that the saved parameter settings and the motor model are suitable for the application.	-4
	USER S3 SAVE	Save User 3 macro. Stores the current parameter settings and the motor model.	-5
	USER S4 LOAD	User 4 macro loaded into use. Before loading, check that the saved parameter settings and the motor model are suitable for the application.	-6
	USER S4 SAVE	Save User 4 macro. Stores the current parameter settings and the motor model.	-7
	USER S5 LOAD	User 5 macro loaded into use. Before loading, check that the saved parameter settings and the motor model are suitable for the application.	-8
	USER S5 SAVE	Save User 5 macro. Stores the current parameter settings and the motor model.	-9
	USER S6 LOAD	User 6 macro loaded into use. Before loading, check that the saved parameter settings and the motor model are suitable for the application.	-10
	USER S6 SAVE	Save User 6 macro. Stores the current parameter settings and the motor model.	-11
9907	MOTOR NOM FREQ	Defines the nominal motor frequency, ie the frequency at which the output voltage equals the motor nominal voltage: Field weakening point = Nom. frequency · Supply voltage / Motor nom. voltage	E: 50.0 Hz U: 60.0 Hz
0.0...1400.0 Hz	Frequency		1 = 0.1 Hz
9908	MOTOR NOM SPEED	Defines the nominal motor speed. Must be equal to the value on the motor rating plate.	Type dependent
50...32000 rpm	Speed		1 = 1 rpm

Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to www.abb.com/searchchannels.

Product training

For information on ABB product training, navigate to www.abb.com/drives and select *Training courses*.

Providing feedback on ABB Drives manuals

Your comments on our manuals are welcome. Go to www.abb.com/drives and select *Document Library – Manuals feedback form (LV AC drives)*.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet. Go to www.abb.com/drives and select *Document Library*. You can browse the library or enter selection criteria, for example a document code, in the search field.

Contact us

www.abb.com/drives
www.abb.com/drivespartners

3AXD50000017574 Rev A (EN) 2014-07-09