

User Interface Guide



ACS380

ABB

Control panel

- | | |
|--------------------|-------------------------------|
| 1. Status light | 7. Stop |
| 2. Local / remote | 8. Edit value / Move in menus |
| 3. Status icons | 9. OK / Select / Save / Menu |
| 4. Reference value | 10. Start |
| 5. Actual value | |
| 6. Back / Options | |




Status light

- green, steady: OK
- green, blinking: Warning
- red, steady: Fault
- red, blinking: Fault, turn power off to reset

🔧 Options

1. Control location
2. Active fault
3. Active warnings
4. Forward / Reverse
5. Reference




🏔 Motor control

1. Start mode
6. Deceleration time
7. Max. allowed current




2. Acceleration time

3. Max. allowed speed



4. Min. allowed speed
5. Stop mode



🔧 Diagnostics

1. Active fault
2. Active warnings
3. Fault history
4. Connection status



📊 Energy efficiency

1. Saved energy in kWh
2. Saved energy in MWh
3. Cost per kWh
4. Saved money
5. Saved money x1000



⚙️ Parameters

Direct access to all functions (advanced)

1. Complete list
2. Reset to factory defaults
3. Modified only



I/O Control macros

The menu content depends on the installed extension module.


I/O control:

1. I/O control macro



Fieldbus control:

1. Protocol
2. Address settings



1Φ 2Φ Standard (2-wire)

- AI1: Speed / freq.(0...10V)
DI1: Start / Stop
DI2: Forward / Reverse
DI3: Constant speed/freq. sel1
DI4: Constant speed/freq. sel2
DIO1: Ramp pair selection
DIO2: Ready run

AC500 Modbus RTU

Protocol: Modbus RTU
Node Address: 1
Baud rate: 3 (19.2 kbit/s)
Parity: 2 (8E1)

For the full manual, go to:



1Φ 2Φ Alternate

- AI1: Reference
DI1: Start forward
DI2: Start reverse
(if DI1 = DI2, stop)
DI3: Constant speed sel1
DI4: Constant speed sel2
DIO1: Ramp pair selection
DIO2: Ready run

Φ 2Φ Motor potentiometer

- + 4 -
DI1: Start / Stop
DI2: Forward / Reverse
DI3: Reference up
DI4: Reference down
DIO1: Constant sel1
DIO2: Ready run

PID PID

- AI1: Setpoint
AI2: Feedback
DI1: Start / Stop
DI2: Constant setpoint 1
DI3: Constant setpoint 2
DI4: Constant speed/freq. 1
DIO1: Run enable 1 source
DIO2: Ready run

Torque

- AI1: Ext1 speed reference
AI2: Torque reference
DI1: Start / Stop
DI2: Forward / Reverse
DI3: Speed/Torque control
DI4: Constant speed sel1
DIO1: Ramp pair selection
DIO2: Run enable source

Warnings/Faults

Warning Fault Description

- Ⓐ A2A1 ⚡ 2281 Warning: Current calibration is done at the next start.
Fault: Output phase current measurement fault
- Ⓐ A2B1 ⚡ 2310 Overcurrent. The output current is more than the internal limit. This can be caused by an earth fault or phase loss.
- Ⓐ A2B3 ⚡ 2330 Earth leakage. A load unbalance that is typically caused by an earth fault in the motor or the motor cable.
- Ⓐ A2B4 ⚡ 2340 Short circuit. There is a short circuit in the motor or the motor cable.
- ✖ 3130 Input phase loss. The intermediate DC circuit voltage oscillates.
- ✖ 3181 Cross connection. The input and motor cable connections are incorrect.
- Ⓐ A3A1 ⚡ 3210 DC link overvoltage. There is an overvoltage in the intermediate DC circuit.
- Ⓐ A3A2 ⚡ 3220 DC link undervoltage. There is an undervoltage in the intermediate DC circuit.
- ✖ 3381 Output phase loss. All three phases are not connected to the motor.
- Ⓐ A5A0 ⚡ 5091 Safe torque off. The Safe torque off (STO) function is on.
- Ⓐ AFF6 Identification run. The motor ID run occurs at the next start.
- ✖ FA81 Safe torque off 1. The Safe torque off circuit 1 is broken.
- ✖ FA82 Safe torque off 2. The Safe torque off circuit 2 is broken.