

ABB GENERAL PURPOSE DRIVES

ACS560 standard control program Firmware manual



List of related manuals

See section Related documents on page 14.

You can find manuals and other product documents in PDF format on the Internet. See section Document library on the Internet on the inside of the back cover. For manuals not available in the Document library, contact your local ABB representative.

The code below opens an online listing of the manuals applicable to the product:



ACS560 manuals

Firmware manual

ACS560 standard control program

Table of contents

2. Start-up, control with I/O and ID run



© 2022 ABB. All Rights Reserved.

3AXD50000044997 Rev J EN EFFECTIVE: 2022-11-28

Table of contents

1. Introduction to the manual

ontents of this chapter	
pplicability	
afety instructions	
arget audience	
urpose of the manual	
ontents of this manual	2
ategorization by frame (size)	5
elated documents	
erms and abbreviations	j
yber security disclaimer	;

2. Start-up, control with I/O and ID run

Contents of this chapter	9
How to start up the drive	20
How to start up the drive using the basic control panel	20
How to control the drive through the I/O interface	26
dentification (ID) run 2	27
ID run procedure	28

3. Using the control panel

4. Program features

What this chapter contains	3
Local control vs. external control	3
Local control	4
External control	4
Operating modes of the drive	7
Speed control mode	9
Torque control mode	9
Frequency control mode	9
Special control modes	9
Drive configuration and programming 4	0
Configuring via parameters	0
Control interfaces	1
Programmable analog inputs 4	1
Programmable analog outputs	1
Programmable digital inputs and outputs 4	1
Programmable relay outputs 4	1
Fieldbus control	1
Programmable I/O extensions	2
Application control	3
Reference ramping	3

6 Table of contents

Constant speeds/frequencies	. 44
Critical speeds/frequencies	
Speed controller autotune	
User Load Curve	
Process PID control	
PID trim function	. 54
Timed functions	. 60
Mechanical brake control	. 60
Motor control	
Motor types	. 65
Motor identification	
Scalar motor control	. 65
Vector control	
Speed control performance figures	. 67
Torque control performance figures	. 68
Power loss ride-through	
U/f ratio	
Flux braking	
DC magnetization	
Energy optimization	. 72
Switching frequency	
Rush control	
Jogging	
Speed compensated stop	
DC voltage control	. 77
Overvoltage control	
Undervoltage control (power loss ride-through)	
Voltage control and trip limits	
Brake chopper	
Safety and protections	
Fixed/Standard protections	. 81
Emergency stop	
Motor thermal protection	
Motor overload protection	
Programmable protection functions	
Automatic fault resets	. 92
Diagnostics	
Signal supervision	
Energy saving calculators	
Load analyzer	. 94
Diagnostics menu	
Miscellaneous	. 95
Backup and restore	
User parameter sets	
Data storage parameters	
User lock	
Sine filter support	
Dead-band function	
Short and Long menu	
Basic panel home view options	. 99

5. Control macros

Contents of this chapter	101
Overview	101
ABB standard macro	102
ABB standard macro (vector)	105
Default control connections for the ABB standard (Vector) macro	106
3-wire macro	108
Default control connections for the 3-wire macro	109
Motor potentiometer macro	111
Default control connections for the ABB potentiometer macro	114
PID macro	116
Default control connections for the ABB PID macro	117
Panel PID macro	119
Torque control macro	122
Default control connections for the Torque control macro	123
Pump and Fan Control (PFC) macro	125
Default control connections for the PFC macro	132
Soft Pump and Fan Control (SPFC) macro	134
Default control connections for the SPFC macro	141
Pharma macro	143
Default control connections for the Pharma macro	144
Plastic extrusion macro	146
Default control connections for the ABB Plastic extrusion macro	147
Jigar macro	149
Jigar machine sequence	149
Default control connections for the ABB Jigar macro	150
Parameter default values for different application macros	154

6. Parameters

Terms and abbreviations 162 Summary of parameter groups 163 Parameter listing 165 01 Actual values 165 03 Input references 168 04 Warnings and faults 169 05 Diagnostics 170 06 Control and status words 174 07 System info 179 10 Standard DI, RO 180 11 Standard DIO, FI, FO 188 12 Standard AI 189 13 Standard AO 194 19 Operation mode 200 20 Start/stop/direction 202 21 Start/stop mode 212 22 Speed reference selection 220 23 Speed reference conditioning 233	What this chapter contains	161
Parameter listing 165 01 Actual values 165 03 Input references 168 04 Warnings and faults 169 05 Diagnostics 170 06 Control and status words 174 07 System info 179 10 Standard DI, RO 180 11 Standard DIO, FI, FO 188 12 Standard AI 189 13 Standard AO 194 19 Operation mode 200 20 Start/stop/direction 202 21 Start/stop mode 212 22 Speed reference selection 220 23 Speed reference ramp 229	Terms and abbreviations	. 162
01 Actual values 165 03 Input references 168 04 Warnings and faults 169 05 Diagnostics 170 06 Control and status words 174 07 System info 179 10 Standard DI, RO 180 11 Standard DIO, FI, FO 188 12 Standard AI 189 13 Standard AO 194 19 Operation mode 200 20 Start/stop/direction 202 21 Start/stop mode 212 22 Speed reference selection 220 23 Speed reference ramp 229	Summary of parameter groups	. 163
03 Input references 168 04 Warnings and faults 169 05 Diagnostics 170 06 Control and status words 174 07 System info 179 10 Standard DI, RO 180 11 Standard DIO, FI, FO 188 12 Standard AI 189 13 Standard AO 194 19 Operation mode 200 20 Start/stop/direction 202 21 Start/stop mode 212 22 Speed reference selection 220 23 Speed reference ramp 229	Parameter listing	. 165
04 Warnings and faults 169 05 Diagnostics 170 06 Control and status words 174 07 System info 179 10 Standard DI, RO 180 11 Standard DIO, FI, FO 188 12 Standard AI 189 13 Standard AO 194 19 Operation mode 200 20 Start/stop/direction 202 21 Start/stop mode 212 22 Speed reference selection 220 23 Speed reference ramp 229	01 Actual values	165
05 Diagnostics 170 06 Control and status words 174 07 System info 179 10 Standard DI, RO 180 11 Standard DIO, FI, FO 188 12 Standard AI 189 13 Standard AO 194 19 Operation mode 200 20 Start/stop/direction 202 21 Start/stop mode 212 22 Speed reference selection 220 23 Speed reference ramp 229	03 Input references	168
06 Control and status words 174 07 System info 179 10 Standard DI, RO 180 11 Standard DIO, FI, FO 188 12 Standard AI 189 13 Standard AO 194 19 Operation mode 200 20 Start/stop/direction 202 21 Start/stop mode 212 22 Speed reference selection 220 23 Speed reference ramp 229	04 Warnings and faults	169
07 System info 179 10 Standard DI, RO 180 11 Standard DIO, FI, FO 188 12 Standard AI 189 13 Standard AO 194 19 Operation mode 200 20 Start/stop/direction 202 21 Start/stop mode 212 22 Speed reference selection 220 23 Speed reference ramp 229	05 Diagnostics	170
10 Standard DI, RO 180 11 Standard DIO, FI, FO 188 12 Standard AI 189 13 Standard AO 194 19 Operation mode 200 20 Start/stop/direction 202 21 Start/stop mode 212 22 Speed reference selection 220 23 Speed reference ramp 229	06 Control and status words	174
11 Standard DO, FI, FO 188 12 Standard AI 189 13 Standard AO 194 19 Operation mode 200 20 Start/stop/direction 202 21 Start/stop mode 212 22 Speed reference selection 220 23 Speed reference ramp 229	07 System info	179
12 Standard AI18913 Standard AO19419 Operation mode20020 Start/stop/direction20221 Start/stop mode21222 Speed reference selection22023 Speed reference ramp229	10 Standard DI, RO	180
13 Standard AO19419 Operation mode20020 Start/stop/direction20221 Start/stop mode21222 Speed reference selection22023 Speed reference ramp229	11 Standard DIO, FI, FO	. 188
19 Operation mode20020 Start/stop/direction20221 Start/stop mode21222 Speed reference selection22023 Speed reference ramp229	12 Standard Al	189
20Start/stop/direction20221Start/stop mode21222Speed reference selection22023Speed reference ramp229	13 Standard AO	194
21 Start/stop mode21222 Speed reference selection22023 Speed reference ramp229	19 Operation mode	. 200
22 Speed reference selection 220 23 Speed reference ramp 229	20 Start/stop/direction	. 202
23 Speed reference ramp	21 Start/stop mode	. 212
	22 Speed reference selection	. 220
24 Speed reference conditioning	23 Speed reference ramp	229
	24 Speed reference conditioning	. 233

1	

25 Speed control	233
26 Torque reference chain	
28 Frequency reference chain	244
30 Limits	255
31 Fault functions	262
32 Supervision	
34 Timed functions	277
35 Motor thermal protection	284
36 Load analyzer	295
37 User load curve	296
40 Process PID set 1	299
41 Process PID set 2	
43 Brake chopper	
44 Mechanical brake control	
45 Energy efficiency	
46 Monitoring/scaling settings	322
47 Data storage	
49 Panel port communication	
50 Fieldbus adapter (FBA)	
51 FBA A settings	
52 FBA A data in	
53 FBA A data out	
58 Embedded fieldbus	
70 Override	
71 External PID1	
76 PFC configuration	
77 PFC maintenance and monitoring	
90 Feedback selection	
95 HW configuration	
96 System	
97 Motor control	
98 User motor parameters	
99 Motor data	
Differences in the default values between 50 Hz and 60 Hz supply frequency settings	
Parameters supported by Modbus backwards compatibility with 550	
	0.0

7. Additional parameter data

What this chapter contains	377
Terms and abbreviations	377
Fieldbus addresses	378
Parameter groups 19	379
Parameter groups 1099	382

8. Fault tracing

What this chapter contains	411
Safety	411
Indications	
Warnings and faults	411
Pure events	412

Editable messages	 412
Warning/fault history	 412
Event log	 412
Viewing warning/fault information	 412
Warning messages	 414
Fault messages	 426

9. Fieldbus control through the embedded fieldbus interface (EFB)

What this chapter contains	441
System overview	
Connecting the fieldbus to the drive	
Setting up the embedded fieldbus interface	
Setting the drive control parameters	
Basics of the embedded fieldbus interface	
Control word and Status word	448
References	
Actual values	
Data input/outputs	448
Register addressing	
About the control profiles	
Control Word	451
Control Word for the ABB Drives profile	451
Control Word for the DCU Profile	452
Status Word	455
Status Word for the ABB Drives profile	455
Status Word for the DCU Profile	456
State transition diagrams	458
State transition diagram for the ABB Drives profile	
References	460
References for the ABB Drives profile and DCU Profile	460
Actual values	461
Actual values for the ABB Drives profile and DCU Profile	461
Modbus holding register addresses	
Modbus holding register addresses for the ABB Drives profile and DCU Profile	462
Modbus function codes	463
Exception codes	464
Coils (0xxxx reference set)	465
Discrete inputs (1xxxx reference set)	467
Error code registers (holding registers 400090400100)	469

10. Fieldbus control through a fieldbus adapter

What this chapter contains 47	'1
System overview	'2
Basics of the fieldbus control interface	'4
Control word and Status word	'5
References	'6
Actual values	7
Contents of the fieldbus Control word 47	'8
Contents of the fieldbus Status word 48	30
Control word and Status word 47 References 47 Actual values 47 Contents of the fieldbus Control word 47	777

10 Table of contents

The state diagram	481
Automatic drive configuration for fieldbus control	482
Setting up the drive for fieldbus control manually	486
Parameter setting example: FPBA (PROFIBUS)	487

11. Control chain diagrams

Contents of this chapter	489
Frequency reference selection	490
Frequency reference modification	491
Speed reference source selection I	492
Speed reference source selection II	493
Speed reference ramping and shaping	494
Speed feedback	495
Speed error calculation	496
Speed controller	497
Torque reference source selection and modification	498
	499
Torque limitation	500
Process PID setpoint and feedback source selection	501
Process PID controller	502
External PID setpoint and feedback source selection	503
External PID controller	504
Direction lock	505
Override	506
PID trim auto connection	507

12. Parameterization with drive composer

Contents of this chapter	509
Drive composer	509
How to connect the drive composer	510

13. Parameterization with automation builder drive manager

Contents of this chapter	513
Automation builder drive manager	513

Further information

1

Introduction to the manual

Contents of this chapter

The chapter describes applicability, target audience and purpose of this manual. It also describes the contents of this manual and refers to a list of related manuals for more information.

Applicability

The manual applies to the ACS560 standard control program IGPKX version 2.16.0.7. IGPKA is used for frames R0...R2, IGPK2 is used for frames R3...R5 and IGPK4 for frames R6...R8.

To check the firmware version of the control program in use, see system information parameter 07.05 *Firmware version* (see page 178) on the control panel.

Safety instructions

Follow all safety instructions.

- Read the **complete safety instructions** in the *Hardware manual* of the drive before you install, commission, or use the drive.
- Read the **firmware function-specific warnings and notes** before changing parameter values. These warnings and notes are included in the parameter descriptions presented in chapter *Parameters* on page *161*.

Target audience

The reader is expected to know the fundamentals of electricity, wiring, electrical components and electrical schematic symbols.

The manual is written for readers worldwide.

Purpose of the manual

This manual provides information needed for designing, commissioning, or operating the drive system.

Contents of this manual

The manual consists of the following chapters:

- *Introduction to the manual* (this chapter, page *11*) describes applicability, target audience, purpose and contents of this manual. At the end, it lists terms and abbreviations.
- Start-up, control with I/O and ID run (page 19) describes how to start up the drive as well as how to start, stop, change the direction of the motor rotation and adjust the motor speed through the I/O interface.
- Using the control panel (page 31) contains instructions for removing and reinstalling the assistant control panel and briefly describes its display, keys and key shortcuts.
- *Program features* (page 33) describes program features with lists of related user settings, actual signals, and fault and warning messages.
- Control macros (page 101) contains a short description of each macro together with a connection diagram. Macros are pre-defined applications which will save the user time when configuring the drive.
- Parameters (page 161) describes the parameters used to program the drive.
- Additional parameter data (page 377) contains further information on the parameters.
- *Fault tracing* (page 411) lists the warning and fault messages with possible causes and remedies.
- *Fieldbus control through the embedded fieldbus interface (EFB)* (page 441) describes the communication to and from a fieldbus network using the embedded fieldbus interface of the drive.
- *Fieldbus control through a fieldbus adapter* (page 471) describes the communication to and from a fieldbus network using an optional fieldbus adapter module
- *Control chain diagrams* (page 489) describes the parameter structure within the drive.
- *Parameterization with drive composer* (page 509) describes about managing the drive parameters with drive composer application.
- Parameterization with automation builder drive manager (page 513) describes about managing the drive parameters with automation builder drive manager application.
- *Further information* (inside of the back cover, page 517) describes how to make product and service inquiries, get information on product training, provide feedback on ABB Drives manuals and find documents on the Internet.

Categorization by frame (size)

The ACS560 is manufactured in several frames (frame sizes), which are denoted as RN, where N is an integer. Some information which only concern certain frames are marked with the symbol of the frame (RN).

The frame is marked on the type designation label attached to the drive, see chapter *Operation principle and hardware description*, section *Type designation label* in the *Hardware manual* of the drive.

Related documents

Drive manuals and guides	Code (English)	Code (Hindi)
ACS560 standard control program firmware manual	3AXD50000044997	3AXD50000045887
ACS560 (0.75 to 160 kW, 1.0 to 215 hp) hardware manual	3AXD50000044998	3AXD50000045888
ACS560 drives quick installation and start-up guide	3AXD50000042620	(Multi Lingual)
Optional manuals or guides		
ACS-AP-x Assistant control panels user's manual	3AUA0000085685	
ACS-BP-S Basic control panel user's manual	3AXD50000032527	
<i>CDPI-01/-02 communication adapter module user's manual</i>	3AXD5000009929	
<i>DPMP-01 mounting platform for ACS- AP control panel</i>	3AUA0000100140	
<i>DPMP-02/03 mounting platform for ACS-AP control panel</i>	3AUA0000136205	
FCAN-01 CANopen adapter module user's manual	3AFE68615500	
FECA-01 EtherCAT adapter module user's manual	3AUA0000068940	
<i>FENA-01/-11/-21 Ethernet adapter module user's manual</i>	3AUA0000093568	
<i>FPBA-01 PROFIBUS DP adapter module user's manual</i>	3AFE68573271	
FSCA-01 RS-485 adapter module user's manual	3AUA0000109533	
<i>FPNO-21 PROFINET IO fieldbus adapter module user's manual</i>	3AXD50000158614	
<i>FMBT-21 Modbus/TCP Adapter Module User's Manual</i>	3AXD50000158607	
FEIP-21 EtherNet/IP fieldbus adapter module User's manual	3AXD50000158621	
<i>CCA-01 communication adapter quick guide</i>	3AXD5000018457	
AOCH, NOCH du/dt filters hardware manual	3AFE58933368	
Sine filter hardware manual	3AXD50000016814	
<i>NBRA-6xx Braking Choppers Inst/Start-up Guide</i>	3AFY58920541	
Flange mounting kit installation supplement	3AXD50000019100	

Flange mounting kit quick installation 3AXD50000036610 *guide for ACX580-01 frames R0 to R5*

Flange mounting kit quick installation 3AXD50000019099 *guide for ACS880-01 and ACX580-01 frames R6 to R8*

Tool and maintenance manuals and guides

Drive composer PC tool user's manual3AUA0000094606Converter module capacitor38FE64059629reforming instructions3AUA0000096939NETA-21 remote monitoring tool3AUA0000096939user's manual3AUA0000096881NETA-21 remote monitoring tool3AUA0000096881installation and start-up guide3AUA0000096881

Terms and abbreviations

Term/abbreviation	Explanation
ACS-BP-S	Basic control panel, basic operator keypad for communication with the drive.
ACS-AP-x	Assistant control panel, advanced operator keypad for communication with the drive.
	The ACS560 supports types ACS-AP-I, ACS-AP-S and ACS-AP-W.
AI	Analog input; interface for analog input signals
AO	Analog output; interface for analog output signals
BACnet™	BACnet™ is a registered trademark of American Society of Heating, Refrigerating and Air-Conditioning Engineers (ASHRAE).
Brake chopper	Conducts the surplus energy from the intermediate circuit of the drive to the brake resistor when necessary. The chopper operates when the DC link voltage exceeds a certain maximum limit. The voltage rise is typically caused by deceleration (braking) of a high inertia motor.
Brake resistor	Dissipates the drive surplus braking energy conducted by the brake chopper to heat. Essential part of the brake circuit. See chapter <i>Brake chopper</i> in the <i>Hardware manual</i> of the drive.
BREL-01	Optional side-mounted relay output extension module
BIO-01	Optional I/O extension module underneath the fieldbus adapter module.
Control board	Circuit board in which the control program runs.
DC link	DC circuit between rectifier and inverter
DC link capacitors	Energy storage which stabilizes the intermediate circuit DC voltage
DI	Digital input; interface for digital input signals
DPMP-01	Mounting platform for ACS-AP control panel (flange mounting)
DPMP-02/03	Mounting platform for ACS-AP control panel (surface mounting)
Drive	Frequency converter for controlling AC motors
EFB	Embedded fieldbus

Term/abbreviation	Explanation
FBA	Fieldbus adapter
FCAN-01	Optional CANopen adapter module
FCNA-01	ControlNet adapter module
FECA-01	Optional EtherCAT adapter module
FENA-01/-11/-21	Optional Ethernet adapter module for EtherNet/IP, Modbus TCP and PROFINET IO protocols
FEPL-02	Ethernet POWERLINK adapter module
FLON-01	LONWORKS® adapter module
FPBA-01	Optional PROFIBUS DP adapter module
Frame (size)	Refers to drive physical size, for example R0 and R1. The type designation label attached to the drive shows the frame of the drive, see chapter <i>Operation principle and hardware description</i> , section <i>Type designation label</i> in the <i>Hardware manual</i> of the drive.
IGBT	Insulated gate bipolar transistor: used for high efficiency and fast switching
Intermediate circuit	See DC link.
Inverter	Converts direct current and voltage to alternating current and voltage.
I/O	Input/Output
LonWorks®	LONWORKS® (local operating network) is a networking platform specifically created to address the needs of control applications.
LSW	Least significant word
Macro	Pre-defined default values of parameters in drive control program. Each macro is intended for a specific application. See chapter <i>Control macros</i> on page <i>101</i> .
NETA-21	Remote monitoring tool
Network control	With fieldbus protocols based on the Common Industrial Protocol (CIP TM), such as Ethernet/IP, denotes the control of the drive using the Net Ctrl and Net Ref objects of the ODVAAC/DC Drive Profile. For more information, see <u>www.odva.org</u> , and the following manual: <i>FENA-01/-11/-21 Ethernet adapter module user's manual</i> (3AUA0000093568 [English]).
Parameter	User-adjustable operation instruction to the drive, or signal measured or calculated by the drive
PID/Loop controller	Proportional-integral-derivative controller. Drive speed control is based on PID algorithm.
PLC	Programmable logic controller
PROFIBUS, PROFIBUS DP, PROFINET IO	Registered trademarks of PI - PROFIBUS & PROFINET International
R0, R1,	Frame (size)
RO	Relay output; interface for a digital output signal. Implemented with a relay.

Term/abbreviation	Explanation	
Rectifier	nverts alternating current and voltage to direct current and voltage.	
STO Safe torque off. See chapter <i>The Safe torque off function</i> in the <i>Hardware manual</i> of the drive.		

Cyber security disclaimer

This product is designed to be connected to and to communicate information and data via a network interface. It is Customer's sole responsibility to provide and continuously ensure a secure connection between the product and Customer network or any other network (as the case may be). Customer shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc.) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information. ABB and its affiliates are not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.

2

Start-up, control with I/O and ID run

Contents of this chapter


The chapter describes how to:

- · perform the start-up
- start, stop, change the direction of the motor rotation and adjust the speed of the motor through the I/O interface
- perform an Identification run (ID run) for the drive.

How to start up the drive

How to start up the drive using the basic control panel

	Safety				
ſ	Do not start-up the drive unless you are a qualified electrician.				
	\swarrow Read and obey the instructions in chapter <i>Safety instructions</i> at the beginning of the <i>Hardware manual</i> of the drive. Ignoring the instructions can cause physical injury or death, or damage to the equipment				
	Check the installation. See chapter <i>Installation checklist</i> in the <i>Hardware manual</i> of the drive.				
	Make sure there that the active start command is not on (DI1 in factory settings, i.e. ABB standard macro). The drive will start up automatically at power-up if the external run command is on and the drive is in the remote control mode.				
		Check that the starting of the motor does not cause any danger.			
	De-couple the driven machine if				
	there is a risk of damage in case of an incorrect direction of rotation, or				
•		 a Normal ID run is required during the drive start-up, when the load torque is higher than 20% or the machinery is not able to withstand the nominal torque transient during the ID run. 			
	General Information				
		The settings and examples referred in this chapter are with respect to the basic control panel. For more information on basic control panel settings and menu details, see <i>Quick installation and start-up guide</i> (3AXD50000042620) or <i>ACS-BP-S basic control panel's user's manual</i> (3AXD50000032527 [English]).			
		If you are performing the procedure with assistant control panel, see ACS-AP-x assistant control panels user's manual (3AUA0000085685 [English]).			



Refer to the motor nameplate for the following nominal value settings of the motor. Enter the values <u>exactly</u> as shown on the motor nameplate.

Example of a nameplate of an induction (asynchronous) motor:

		(↔ ABB Motors CE ↔					
		3 ~ motor M2AA 200 MLA 4					
		IEC 200 M/L 55					
		Ins.cl. F IP 55					
		V Hz kW r/min A cos φ A/IN tE/s 690 Y 50 30 1475 32.5 0.83 Image: Second					
		400 D 50 30 1475 56 0.83					
		660 Y 50 30 1470 34 0.83					
		380 D 50 30 1470 59 0.83 415 D 50 30 1475 54 0.83					
		440 D 60 35 1770 59 0.83					
		Cat. no 3GAA 202 001 - ADA ·					
		6312/C3 - 6210/C3 180 kg					
		(-⊕- IEC 34-1 -⊕-)					
		Navigate to Main menu \equiv and select Motor data \blacksquare .					
		•					
>		Set the motor nominal current:	Scalar 2 20kW				
		 Use and b to move the cursor left and right. 	Scalar 2.20kW				
		 Use ▲ and ▼ to change the value. 	3A 400.0V				
		Press V (OK) to accept the new setting, or press	3A 400.0V				
		(Back) to go back to the previous view without making	96.06 —				
		changes.	3.0				
			A				
		Set the torque and motor $\cos \Phi$, if needed. Motor					
		nominal $\cos \Phi$ and nominal torque are optional.	0.000Nm U V W				
		 Use and to move the cursor left and right. 	Cos Φ				
		 Use A and v to change the value. 	0.00				
		Press (OK) to accept the new setting, or press					
		(Back) to go back to the previous view without making	0.000Nm U V W				
		changes.	Cos Φ				
		0.00					
		Set the desired motor control mode. If Vector motor					
		Scalar 2.20kW					
		control mode is selected, make sure that ID run is performed. See <i>ID run procedure</i> .					
			4.7A 400.0V				
		Navigate to Options menu $^{\bullet}_{a} \rightarrow \underbrace{?}_{a}$ and set the					
		direction.	Loc (* 110.13.04Hz				

	Navigate to the Options menu △ and set the frequency/speed reference. Use ▲ and ♥ to change the value. Press ✔ (OK) to accept the new setting, or press ◀ (Back) to go back to the previous view without making changes.	0.0Hz C ⊗ 0 ▲ 0				
П	Press Start					
	Make sure that the motor is running in the required direction. The direction symbol is displayed in the home page. The forward direction is indicated by and the reverse direction is indicated by .					
	Press Stop 🚫.					
	If you want to make a backup of the settings made so far, navigate to Main menu \equiv and select Backup $\blacksquare \leftarrow \square$. You can restore and back up the data between drive and panel. Select the option and press \checkmark (OK) to accept or press					
	 ◄¬ (Back) to go back to the previous view without making changes. 					
	The first start setup is complete and the drive is ready for use. The home view displays the values of selected signals.	Loc ◊ ↔ 10.0 Hz 0.00 Hz ≡				
	2 – Additional settings					
	Macro/start-stop reference, ramp, and					
	You can make any additional changes to the macro, ramp	o, and limits, if required.				
	Macro settings Navigate to the Main menu \equiv and select I/O connection $\frac{1}{22}$.	1⊕ 2⊷ ½0				
	Select the desired macro. Use ◀ and ▶ to move the cursor left and right.	1∲ 2⊕ ^{1⊕ 2} ⊕ rpm				
	Press ✔ (OK) to accept or press ◀¬ (Back) to go back to the previous view without making changes.	1 © 244 1 © 26 3 + 4- PID				
	Notes:					
	 Changing the macro resets all settings to the default values of the selected macro and updates the I/O signals used in the drive. You can see the currently used I/O signals in the 140 menu. 					
	 All macros, except the ABB standard (vector) and Pharma macro, use scalar motor control by default. You can change the motor control mode in the Motor data 4 					

	Start, stop, and reference values If you do not wish to use a macro, navigate to Main menu $\equiv \rightarrow$ Complete parameter list					
	\blacksquare \rightarrow Parameter groups 20, 21, and 23 and manually define the settings for start, stop and reference.					
	Notes:					
	 Changing the start, stop, and reference settings, changes the I/O signals used in the drive. You can see the currently used I/O signals in the 1/0 menu. 					
	 Make sure that the used I/O connection matches with the actual I/O wiring. See Control macros on page 101. 					
	Ramp settings Navigate to Main menu ≡ → Complete parameter list ☑ → Parameter group 23 and change the parameters according to your need. For example, acceleration time, deceleration time, emergency stop time etc. After making the changes, press ✓ OK to accept or press ← (Back) to the previous view without making changes.					
	Limit settings					
	Navigate to Main menu $\equiv \rightarrow$ Complete parameter list \rightarrow Parameter group 30 and change the parameters according to your need. For example, minimum speed, maximum speed, maximum current, etc.					
	After making the changes, press V OK to accept or press view without making changes.	After making the changes, press ✓ OK to accept or press ◄ ¬ (Back) to the previous view without making changes.				
	3 – I/O menu					
	After the additional changes, make sure that the used I/O connection matches with the actual I/O wiring. See <i>Control macros</i> on page 101. To see the currently used I/O signals, navigate to Main menu $\equiv \rightarrow I/O$ menu $\lim_{n \to \infty} \rightarrow I/O$ status $\lim_{n \to \infty} I_n$.					
	Use (▲) and (♥) to check the values.	1/0 86 0 DI1 0 DI2 0 DI3				
	4 – Diagnostics menu					
	After the additional adjustments and I/O connection validation, navigate to Main menu ≡ → Diagnostics v and make sure that the setup is functioning correctly.					
	Diagnostics menu displays the active faults ⊗, fault history 😋 , active warnings ⚠, and I/O status 1/0.					

5 – Backup	
After the start-up, it is recommended that you make a backup of the configured parameters.	□ ← □ □ → □
You can restore and back up the data between drive and panel.	
To backup the settings, navigate to Main menu	
$\equiv \rightarrow \blacksquare \leftarrow \blacksquare$	
Select . ← I or . → I as desired. Press ✓ Ok to	
accept or press Back to go back to the previous view without making changes.	



How to control the drive through the I/O interface

The table below describes how to operate the drive through the digital and analog inputs when:

- the motor start-up is performed, and
- the default parameter settings of the ABB standard macro are in use.

Preliminary settings					
If you need to change the direction of rotation, navigate to Menu $\equiv \rightarrow$ Motor control \longrightarrow and make sure that the minimum speed/frequency limit has a negative value and the maximum speed/frequency limit has a positive value.	Max Max 50.00Hz 50.00Hz Min -50.00Hz				
Make sure that the ABB standard macro control connections are correct. See <i>ABB standard macro</i> on page <i>102</i> . Make sure that the drive is in remote control. Press key Loc/Rem to switch between remote and local control.					
Starting and controlling the sp	Starting and controlling the speed of the motor				
Switch on the digital input DI1 on. Observe the rotating arrow next to Rem. The dotted arrow appears until the setpoint is reached. Regulate the drive output frequency (motor speed) by changing the voltage of analog input Al1.	Rem ; [™] 13.4 Hz 13.04 [™] =				
Changing the direction of the	e motor rotation				
 To change the direction, perform as follows For reverse direction, switch on the digital input DI2. For forward direction, switch off the digital input DI2. 	Rem,; 13.4 Hz 13.04 ≅ Hz ≡				
Stopping the motor					
To stop the motor, switch digital input DI1 to off. Observe that the arrow stops rotating.	Rem ►) 0.00 Hz 0.00 ∽ Hz ≡				

Identification (ID) run

During Identification (ID) run the drive identifies the characteristics of the motor for optimum motor control.

When the drive is started for the first time in vector control mode and after any parameter is changed in the parameter group *99 Motor data*, the drive automatically performs the *Standstill* ID run.

In most applications there is no need to perform a separate ID run. ID run needs to be performed manually if:

- vector control mode is used (parameter 99.04 Motor control mode is set to Vector [0]), and
- · drive operates near zero speed references, or
- operation at torque range above the motor nominal torque, over a wide speed range is needed.

To perform the ID run manually, see ID run procedure.



ID run procedure

	Pre-check					
	WARNING! The motor will run at up to approximately 5080% of the nominal speed during the ID run. The motor will rotate in the forward direction. Make sure that it is safe to run the motor before performing the ID run!					
	De-couple the motor from the driven equipment					
		 Check that the values of the motor data parameters are equivalent to those on the motor nameplate. Check that the STO circuit is closed. If parameter values (from group <i>10 Standard DI, RO</i> to group <i>99 Motor data</i>) are changed before the ID run, check that the new settings meet the following conditions: 				
□ 30.11 Minimum speed ≤ 0 rpm □ 30.12 Maximum speed = motor rated speed (Normal ID run procedure needs the mbe run at 100% speed.)						
		<i>30.20 Maximum torque 1 > 50%</i>				
		Check that signals				
		run enable (parameter 20.12 Run enable 1 source) is active				
		Make sure that the panel is in local control (text Local shown at the top left). Press key Loc/Rem to switch between local and remote control.				
		ID run				
		Navigate to Main menu $\equiv \rightarrow$ Complete parameter list $\textcircled{=} \rightarrow$ parameter 99.13 and select the type of ID run you want to do. Press \checkmark (OK)	99.13 [0] [1] [2]			
		Panel LED starts blinking green to indicate an active warning (<i>AFF6</i>). You can hide the warning view by pressing ◄ ¬ (Back). Press the start key (() to start the ID run. Note: In general, it is recommended not to press any control panel keys during the ID run. However, you can stop the ID run at any time by	Warning: AFF6 99.13 [0] [1] [2]			
		pressing the stop key (\bigcirc) .				

During the ID run the arrow rotates at the top. After the ID run is completed, the arrow stops rotating and the rpm turns to 0.00. If the ID run fails, fault <i>FF61 ID run</i> is shown. For	Rem	:≃ 1304 _{rpm}	1304rpm	
more information, see chapter <i>Fault tracing</i> on page <i>411</i> .	Rem	; ™ 0 00	0.0rpm	
Note: You must repeat the ID run procedure if you have changed the motor parameters (99 <i>Motor data</i>) after the ID run was competed.	٩٩	rpm	≡	



30 Start-up, control with I/O and ID run



3

Using the control panel

The ACS560 drive supports both basic and assistant control panels. For more information, refer:

• ACX-AP-x assistant control panel's user's manual (3AUA0000085685 [English])

and

• ACS-BP-S basic control panel's user's manual (3AXD50000032527 [English])

32 Using the control panel

4


Program features

What this chapter contains

This chapter describes some of the more important functions within the control program, how to use them and how to program them to operate. It also explains the control locations and operating modes.

Local control vs. external control

The AC560 drive has two main control locations, external and local. The control location is selected with the **Loc/Rem** key on the control panel or in the PC tool. The local control allows you to control the drive through control panel or drive composer and the remote control allows you to control the drive through PLC/fieldbus adapter/ I/O connections/embedded fieldbus controller.



Local control

The control commands are given from the control panel keypad or from a PC equipped with Drive composer when the drive is in local control. Speed control mode is available in vector motor control mode and frequency mode is available when scalar motor control mode is used (see parameter *19.16 Local control mode*).

Local control is mainly used during commissioning and maintenance. The control panel always overrides the external control signal sources when used in local control. Changing the control location to local can be prevented by parameter *19.17 Local control disable*.

You can use parameter 20.28 to select how the drive reacts when the control location is switched between local and external. The user can select by a parameter (49.05 *Communication loss action*) how the drive reacts to a control panel or PC tool communication break. (The parameter has no effect in external control.)

External control


When the drive is in external (remote) control, control commands are given through

- the I/O terminals (digital and analog inputs), or optional I/O extension modules
- the fieldbus interface (via the embedded fieldbus interface or an optional fieldbus adapter module).


Two external control locations, EXT1 and EXT2, are available. The user can select the sources of the start and stop commands separately for each location by setting parameters 20.01...20.10. Selection between EXT1 and EXT2 is done via any binary source such as a digital input or fieldbus control word (parameter 19.11 Ext1/Ext2 selection). The source of reference is selectable for each operating mode separately.

Communication fail functionality

The communication fail functionality ensures continuous process without interruptions. If there is a communication loss, the drive automatically changes the control location from EXT1 to EXT2. This enables process to be controlled, for example, with the drive PID controller. When the original control location recovers, the drive automatically switches control back to the communication network (EXT1).




EXT1/EXT2 selection for speed control



EXT1/EXT2 selection for frequency control

Block diagram: Run enable source for EXT1

The figure below shows the parameters that select the interface for run enable for external control location *EXT1*.




Settings


Parameters 19.11 Ext1/Ext2 selection (page 200); 20.01...20.10 (page 201).

Operating modes of the drive

The drive can operate in several operating modes with different types of reference. The mode is selectable for each control location (Local, EXT1 and EXT2) in parameter group *19 Operation mode*. An overview of the different reference types and control chains is shown below.



The following is a more detailed representation of the reference types and control chains. The page numbers refer to detailed diagrams in chapter *Control chain diagrams*.



Speed control mode

The motor follows a speed reference given to the drive. This mode can be used either with estimated speed used as feedback.

Speed control mode is available in both local and external control. It is supported in vector motor control only.

Speed control uses speed reference chain. You can select speed reference using parameters in group 22 Speed reference selection on page 219.

Torque control mode

Motor torque follows a torque reference given to the drive. Torque control mode is available in both local and external control. It is supported in vector motor control only.

Torque control uses torque reference chain. Select torque reference with parameters in group 26 Torque reference chain on page 239.

Frequency control mode

The motor follows a frequency reference given to the drive. Frequency control is available in both local and external control. It is supported in scalar motor control only.

Frequency control uses frequency reference chain. You can select frequency reference using parameters in group *28 Frequency reference chain* on page 243.


Special control modes

In addition to the above-mentioned control modes, the following special control modes are available:

- Process PID control. For more information, see section *Process PID control* (page 50).
- Emergency stop modes OFF1 and OFF3: Drive stops along the defined deceleration ramp and drive modulation stops.
- Jogging mode: Drive starts and accelerates to the defined speed when the jogging signal is activated. For more information, see section Jogging (page 72).
- Pre-magnetization: DC magnetization of the motor before start. For more information, see section *Pre-magnetization* (page 69).
- DC hold: Locking the rotor at (near) zero speed in the middle of normal operation. For more information, see section *DC hold* (page 69).
- Pre-heating (motor heating): Keeping the motor warm when the drive is stopped. For more information, see section *Pre-heating (Motor heating)* (page 70).

Drive configuration and programming

The drive control program performs the main control functions, including speed, torque and frequency control, drive logic (start/stop), I/O, feedback, communication and protection functions. Control program functions are configured and programmed with parameters.



Configuring via parameters

Parameters configure all of the standard drive operations and can be set via

- the control panel, as described in chapter Using the control panel
- the Drive composer PC tool, see chapter Parameterization with drive composer
- the automation builder drive manager, see *Parameterization with automation builder drive manager* or
- the fieldbus interface, as described in chapters *Fieldbus control through the embedded fieldbus interface (EFB)* and *Fieldbus control through a fieldbus adapter*.

All parameter settings are stored automatically to the permanent memory of the drive. However, if an external +24 V DC power supply is used for the drive control unit, it is highly recommended to force a save by using parameter *96.07 Parameter save manually* before powering down the control unit after any parameter changes have been made.

If necessary, the default parameter values can be restored by parameter <u>96.06</u> *Parameter restore*.

Control interfaces

Programmable analog inputs

The control unit has two programmable analog inputs. Each of the inputs can be independently set as a voltage (0/2...10 V) or current (0/4...20 mA) input by a switch on the control unit, or with parameters. Each input can be filtered, inverted and scaled.

Settings

Parameter group 12 Standard AI (page 188).

Programmable analog outputs

The control unit has two current (0...20 mA) analog outputs. Analog output 1 can be set as a voltage (0/2...10 V) or current (0/4...20 mA) output by a switch on the control unit, or with a parameter. Analog output 2 always uses current. Each output can be filtered, inverted and scaled.

Settings

Parameter group 13 Standard AO (page 193).

Programmable digital inputs and outputs

The control unit has six digital inputs.

Digital input DI5 can be used as a frequency input or digital input.

Settings

Parameter groups 10 Standard DI, RO (page 179) and 11 Standard DIO, FI, FO (page 187).

Programmable relay outputs

The control unit has three relay outputs. The signal to be indicated by the outputs can be selected by parameters.

Settings

Parameter group 10 Standard DI, RO (page 179).

Fieldbus control

The drive can be connected to several different automation systems through its fieldbus interfaces. See chapters *Fieldbus control through the embedded fieldbus interface (EFB)* (page 441) and *Fieldbus control through a fieldbus adapter* (page 471).

Programmable I/O extensions

Inputs and outputs can be added by using I/O extension modules.

The table below shows the number of I/O on the control unit as well as optional I/O extension modules.

Location	Digital inputs (DI)	Digital outputs (DO)	Digital I/Os (DIO)	Analog inputs (Al)	Analog outputs (AO)	Relay outputs (RO)
Base unit	2	-	-	-	-	1
BIO-01 (old)	3	1	-	1	-	-
BIO-01 (new)	Max. 3	Max. 1	-	1	Max. 1	-
BREL-01	-	-	-	-	-	4

New BIO-01 extension module

A new BIO-01 extension module has been introduced. The firmware supports both new and old BIO-01 extension modules.

The new BIO-01 has two DIP switches to specify the port usage. One switch changes S1 port from digital output (DO1) to analog output (AO1) and the second switch S2 port from digital input (DI3) to digital output (DO1).

Note that the new BIO-01 has maximum one digital output (DO1) (the combination of setting the DIP switches so that both ports would be digital outputs is not supported)

Settings

Parameter groups 50 Fieldbus adapter (FBA) (page 328), 51 FBA A settings (page 332), 52 FBA A data in (page 333), and 53 FBA A data out (page 334) and 58 Embedded fieldbus (page 334).

Parameter 05.99 BIO-01 DIP switch status.

Application control

Reference ramping

Acceleration and deceleration ramping times can be set individually for speed, torque and frequency reference (**Main menu** $\equiv \rightarrow$ **Motor control** $\mid \square$).

With a speed or frequency reference, the ramps are defined as the time it takes for the drive to accelerate or decelerate between zero speed or frequency and the value defined by parameter *46.01 Speed scaling* or *46.02 Frequency scaling*. The user can switch between two preset ramp sets using a binary source such as a digital input. For speed reference, the shape of the ramp also can be controlled.

With a torque reference, the ramps are defined as the time it takes for the reference to change between zero and nominal motor torque (parameter *01.30 Nominal torque scale*).

Variable slope

Variable slope controls the slope of the speed ramp during a reference change. With this feature a constantly variable ramp can be used.

Variable slope is only supported in remote external control.

Settings

Parameters 23.28 Variable slope (page 230) and 23.29 Variable slope rate (page 230).

Special acceleration/deceleration ramps

The acceleration/deceleration times for the jogging function can be defined separately; see section *Jogging* (page 72).

The change rate of the motor potentiometer function (page 75) is adjustable. The same rate applies in both directions.

A deceleration ramp can be defined for emergency stop ("Off3" mode).

Settings

- Menu $\equiv \rightarrow$ Motor control \square .
- Speed reference ramping: Parameters 23.11...23.15 and 46.01 (pages 228 and 321).
- Torque reference ramping: Parameters01.30, 26.18 and 26.19 (pages 166 and 241).
- Frequency reference ramping: Parameters 28.71...28.75 and 46.02 (pages 251 and 322).
- Jogging: Parameters 23.20 and 23.21 (page 229).
- Motor potentiometer: Parameter 22.78/22.79 (page 227).
- Emergency stop ("Off3" mode): Parameter 23.23 Emergency stop time (page 230).

Constant speeds/frequencies

Constant speeds and frequencies are predefined references that can be quickly activated, for example, through digital inputs. It is possible to define up to 7 speeds for speed control and 7 constant frequencies for frequency control.

WARNING: Speeds and frequencies override the normal reference irrespective of where the reference is coming from.

Settings

Parameter groups 22 Speed reference selection (page 219) and 28 Frequency reference chain (page 243).

Critical speeds/frequencies

Critical speeds (sometimes called "skip speeds") can be predefined for applications where it is necessary to avoid certain motor speeds or speed ranges because of, for example, mechanical resonance problems.

The critical speeds function prevents the reference from dwelling within a critical band for extended times. When a changing reference (22.87 Speed reference act 7) enters a critical range, the output of the function (22.01 Speed ref unlimited) freezes until the reference exits the range. Any instant change in the output is smoothed out by the ramping function further in the reference chain.


When the drive is limiting the allowed output speeds/frequencies, it limits to the absolutely lowest critical speed (critical speed low or critical frequency low) when accelerating from standstill, unless the speed reference is over the upper critical speed/ frequency limit.

The function is also available for scalar motor control with a frequency reference. The input of the function is shown by 28.96 *Frequency ref act* 7.

Example

A fan has vibrations in the range of 540...690 rpm and 1380...1560 rpm. To make the drive avoid these speed ranges,

- set the critical speeds function by turning on bit 0 of parameter 22.51 Critical speed function, and
- set the critical speed ranges as in the figure below.



Settings

- Critical speeds: parameters 22.51...22.57 (page 225)
- Critical frequencies: parameters 28.51...28.57 (page 250).


Speed controller autotune

The speed controller of the drive can be automatically adjusted using the autotune function. Autotuning is based on an estimation of the mechanical time constant (inertia) of the motor and machine.

The autotune routine will run the motor through a series of acceleration/deceleration cycles, the number of which can be adjusted by parameter *25.40*. Higher values will produce more accurate results, especially if the difference between initial and maximum speeds is small.

The maximum torque reference used during autotuning will be the initial torque (ie. torque when the routine is activated) plus 25.38, unless limited by the maximum torque limit (parameter group 30 Limits) or the nominal motor torque (99 Motor data). The calculated maximum speed during the routine is the initial speed (ie. speed when the routine is activated) + 25.39, unless limited by parameter 30.12 or 99.09.

The diagram below shows the behavior of speed and torque during the autotune routine. In this example, 25.40 is set to 2.



Notes:

- If the drive cannot produce the requested braking power during the routine, the results will be based on the acceleration stages only, and not as accurate as with full braking power.
- The motor will exceed the calculated maximum speed slightly at the end of each acceleration stage.

Before activating the autotune routine

The prerequisites for performing the autotune routine are:


- · The motor identification run (ID run) has been successfully completed
- Speed and torque limits (parameter group 30 Limits) have been set
- The drive has been started and is running in speed control mode.

After these conditions have been fulfilled, autotuning can be activated by parameter 25.33 (or the signal source selected by it).

Autotune modes

Autotuning can be performed in three different ways depending on the setting of parameter 25.34. The selections *Smooth*, *Normal* and *Tight* define how the drive torque reference should react to a speed reference step after tuning. The selection *Smooth* will produce a slow but robust response; *Tight* will produce a fast response

but possibly too high gain values for some applications. The figure below shows speed responses at a speed reference step (typically 1...20%).



- B: Normally tuned (autotuning)
- C: Normally tuned (manually). Better dynamic performance than with B
- D: Overcompensated speed controller


Autotune results

At the end of a successful autotune routine, its results are automatically transferred into parameters

- 25.02 (proportional gain of the speed controller)
- 25.03 (integration time of the speed controller)
- 25.37 (mechanical time constant of the motor and machine).

Nevertheless, it is still possible to manually adjust the controller gain, integration time and derivation time.

The figure below is a simplified block diagram of the speed controller. The controller output is the reference for the torque controller.



Warning indications

A warning message *AF90*, will be generated if the autotune routine does not complete successfully. See chapter *Fault tracing* (page *411*) for further information.

Settings and diagnostics

Parameters groups: 25 Speed control (page 232), 30 Limits (page 254) and 99 Motor data (page 369).

Parameters: 25.02 Speed proportional gain (page 233), 25.03 Speed integration time (page 234), 25.33 Speed controller autotune...25.40 Autotune repeat times (page 238), 30.12 Maximum speed (page 256) and 99.09 Motor nominal speed (page 370).

Events: AF90 Speed controller autotuning (page 424).

User Load Curve

The User Load Curve (ULC) provides a supervisory function that monitors an input signal as a function of speed and load. The ULC consists of an overload and an underload curve, or just one of them.


Note: This feature is available only in vector control mode.

Some of the salient features of the ULC are:

- Formed by five points -The underload and overload curve are formed by five points where the points represent monitored signal as a function of speed.
- Warning and/or fault for overload and underload A warning and/or fault can be displayed, if the monitored signal stays continuously over the overload/underload limit for a defined time. You can define the time in parameter 37.41 ULC overload timer/37.42 ULC underload timer and the action in parameter 37.03 ULC overload actions/37.04 ULC underload actions.
- Sector based warning / fault The five points makes four sectors and a warning and/or fault can be displayed at each sector. This helps to find the speed range that causes the fault or warning and the investigation can be performed accordingly.

For example, overload can be used to monitor for saw blade hitting a knot or fan load profiles becoming too high. Underload can be used to monitor for load dropping and breaking of conveyer belts or fan belts.

The below graph shows the underload and overload points in a user load curve.



Example

```
lf,
```

N1 = 300 rpm, defined by parameter 37.11 ULC speed table point 1

N2 = 600rpm, defined by parameter 37.12 ULC speed table point 2

OL1 = 10%, defined by parameter 37.31 ULC overload point 1

OL2 = 20%, defined by parameter 37.32 ULC overload point 2

Parameter 37.03 = Warning

Overload axis = torque%, defined by parameter 37.02 ULC supervision signal Drive speed = 450 rpm,

the drive generates *A8BE* (Aux code 0001) warning, if the actual torque exceeds 15% (calculated by leaner interpolation between point (N1, OL1) and (N2, Ol2) for the predefined time), after the time period mentioned in parameter *37.41 ULC overload timer*.

If the parameter 37.03 is set as Disabled, the drive does not generate any warning.

Settings

Parameter group 37 User load curve (page 295).


Process PID control

There are two built-in process PID controllers (PID set 1 and PID set 2) in the drive. The controller can be used to control process variables such as pressure or flow in the pipe or fluid level in the container.

In process PID control, a process reference (setpoint) is connected to the drive instead of a speed reference. An actual value (process feedback) is also brought back to the drive. The process PID control adjusts the drive speed in order to keep the measured process quantity (actual value) at the desired level (setpoint). This means that user does not need to set a frequency/speed/torque reference to the drive but the drive adjust its operation according to the process PID.

The simplified block diagram below illustrates the process PID control. For more detailed block diagrams, see pages 499 and 502.

The drive contains two complete set of process PID controller settings that can be used in place of the other as and when required. See parameter 40.57 PID set1/set2 selection.



Note: Process PID control is available only in external control location EXT2. See section *Local control vs. external control* (page 33).

Quick configuration of the process PID controller


- 1. Activate the process PID controller: Menu Primary settings PID PID controls
- 2. Select a feedback source: Menu Primary settings PID Feedback
- 3. Select a setpoint source: Menu Primary settings PID Setpoint
- 4. Set the gain, integration time, derivation time: **Menu Primary settings PID -Tuning**
- 5. Set the PID output limits: Menu Primary settings PID PID output
- Select the PID controller output as the source of, for example, 22.11 Ext1 speed ref122.11 Ext1 speed ref1: Menu - Primary settings - Start, stop, reference -Reference from

Sleep and boost functions for process PID control

The sleep function is suitable for PID control applications where the consumption varies, such as clean water pumping systems. When used, it stops the pump completely during low demand, instead of running the pump slowly below its efficient operating range. The following example visualizes the operation of the function.

Example: The drive controls a pressure boost pump. The water consumption falls at night. As a consequence, the process PID controller decreases the motor speed. However, due to natural losses in the pipes and the low efficiency of the centrifugal pump at low speeds, the motor would never stop rotating. The sleep function detects the slow rotation and stops the unnecessary pumping after the sleep delay has passed. The drive shifts into sleep mode, still monitoring the pressure. The pumping resumes when the pressure falls under the predefined minimum level and the wakeup delay has passed.

The user can extend the PID sleep time by the boost functionality. The boost functionality increases the process setpoint for a predetermined time before the drive enters the sleep mode.



Sleep and boost function - Timing diagram

Tracking

In tracking mode, the PID block output is set directly to the value of parameter 40.50 (or 41.50) Set 1 tracking ref selection. The internal I term of the PID controller is set so that no transient is allowed to pass on to the output, so when the tracking mode is left, normal process control operation can be resumed without a significant bump.

Settings

- Main menu ≡ → Connection macro I/0 = → PID or Main menu ≡ → Complete parameter list = → parameter 96.04 → PID.
- Parameter groups 40 Process PID set 1 (page 298) and 41 Process PID set 2 (page 312).

PID trim function


The PID trim function is used to maintain the set tension either by trimming the drive main speed reference or torque reference (speed controller output).

WARNING! Make sure that the drive acceleration and deceleration time is set to 0 when using PID trim function. This is required to perform quick tension control by speed correction.

PID trim is implemented as one of the Process PID functions (parameter group 40 *Process PID set 1* and 41 *Process PID set 2*). Both PID set1 and PID set 2 can be used for this functionality.

The trimmed output is calculated from parameter 40.01 Process PID output actual or 40.03 Process PID setpoint actual. This is based on the selection in parameter 40.56 Set 1 trim source (for process PID set 1) or 41.56 Set 2 trim source (for process PID set 2). In most of the use cases, 40.56 Set 1 trim source or 41.56 Set 2 trim source is set as PID output.

PID trim functionality in Variable Frequency Drive (VFD) is used in applications where tension control of the material is very essential. For example, auxiliary drives in metal process industries, infeed and outfeed of rotogravure printing machines, surface winder etc.



Note: The examples provided in this chapter are based on PID set 1. You can set the desired values for PID trim function's parameters to get the expected result.

The following modes are available:

- Direct
- Proportional, and
- Combined

Direct

The direct method is suitable where you need tension control at fixed rpm/line speed.


In this mode, the PID trimmed output (40.05 Process PID trim output act) is relative to the maximum speed (parameter 30.12 Maximum speed), torque (30.20 Maximum torque 1) or frequency (30.14 Maximum frequency). The selection between these can be made by parameter 40.52 Set 1 trim selection.

The calculated trimmed output is same throughout the speed range with respect to the stable PID output.

The 40.05 Process PID trim output act is calculated using below formula:

Par40.05 =
$$\left(\frac{\text{Par40.01}}{100}\right) \times (\text{Par30.12 or 30.20 or 30.14}) \times \text{Par40.55}$$

The below graph shows the PID trim output in direct mode throughout the speed range. A fixed trim speed reference is added throughout the speed range.



Note: In the above graph, it is assumed that the PID output is limited/stable at 100. This is for understanding purpose only. In real case scenario, PID output can vary based on the setpoint and actual.

Example

lf,

Par. 40.52 Set 1 trim selection = Speed

Par. 40.56 Set 1 trim source = PID output

Par. 30.12 Maximum speed = 1500 rpm

Par. 40.01 Process PID output actual = 100 (limited to 100)

Par. 40.55 Set 1 trim adjust = 0.5

Then,

Par40.05 = 750

$$\mathsf{Par40.05} = \left(\frac{100}{100}\right) \times 1500 \times 0.5$$

Proportional

The proportional method is suitable for applications where tension control is required throughout the speed range but not near to zero speed.

In this mode, the PID trimmed output (40.05 Process PID trim output act) is relative to the reference selected by parameter 40.53 Set 1 trimmed ref pointer and with 40.01 Process PID output actual or 40.03 Process PID setpoint actual.


It is recommended that the speed reference selected in 40.53 Set 1 trimmed ref pointer and the reference source selected in 22.11 Ext1 speed ref1 and 40.53 Set 1 trimmed ref pointer are same. This is required to make the proportional mode active.

In most of the use cases, the process speed reference is connected in 40.53 Set 1 trimmed ref pointer. For example, if EXT1 control mode is used and the reference source is Al scaled, then 22.11 Ext1 speed ref1 and 40.53 Set 1 trimmed ref pointer should be configured to Al1 scaled.

The 40.05 Process PID trim output act is calculated using below formula:

$$Par40.05 = \left(\frac{Par40.01}{100}\right) \times Par40.53 \times Par40.55$$

The below graph shows the PID trim output in proportional mode throughout the speed range. Here, the trimmed output is directly proportional to the value of parameter *40.53 Set 1 trimmed ref pointer*.



Note: In the above graph, it is assumed that the PID output is limited/stable at 100. This is for understanding purpose only. In real case scenario, PID output can vary based on the setpoint and actual.

Example

If, Par. 40.52 Set 1 trim selection = Speed Par. 40.56 Set 1 trim source = PID output Par. 40.53 Set 1 trimmed ref pointer = AI1 scaled Par. 22.11 Ext1 speed ref1 = AI1 scaled Par. 12.20 AI1 scaled at AI1 max = 1500 Par. 12.12 AI1 scaled value = 750 (AI1 actual scaled value) Par. 40.01 Process PID output actual = 100 Par. 40.55 Set 1 trim adjust = 0.5 Then.

Par40.05 = $\left(\frac{100}{100}\right) \times 750 \times 0.5$

Par40.05 = 375

Combined

The combined is suitable for applications where you need to maintain tension from zero speed to maximum speed


Combined method is a combination of direct and proportional mode. Here, the trim for zero speed is defined by 40.54 Set 1 trim mix and the trim for speed greater than zero speed is defined by 40.55 Set 1 trim adjust. The trim value is directly proportional to value of 40.53 Set 1 trimmed ref pointer.

The process speed reference is connected in 40.53 Set 1 trimmed ref pointer. For example, if EXT1 control mode is used and the reference source is AI scaled, then 22.11 Ext1 speed ref1 and 40.53 Set 1 trimmed ref pointer should be configured to AI1 scaled.

The 40.05 Process PID trim output act is calculated using below formula:

 $Par40.05 = \{(Par30.12 \times Par40.54) + [(1 - Par40.54) \times Par40.53]\} \times Par40.55$

The below graph shows the trim increase in combined mode.



Note: In the above graph, it is assumed that the PID output is limited/stable at 100. This is for understanding purpose only. In real case scenario, PID output can vary based on the setpoint and actual.

Example

lf, Par. 40.52 Set 1 trim selection = Speed Par. 40.56 Set 1 trim source = PID output Par. 30.12 Maximum speed = 1500 rpm Par. 40.53 Set 1 trimmed ref pointer = Al1 scaled Par. 22.11 Ext1 speed ref1 = Al1 scaled Par. 12.20 Al1 scaled at Al1 max = 1500 Par. 12.12 Al1 scaled value = 750 (Al1 actual scaled value) Par. 40.01 Process PID output actual = 100 (limited to 100) Par. 40.54 Set 1 trim mix = 0.1 Par. 40.55 Set 1 trim adjust = 0.5 Then. If 40.53 Set 1 trimmed ref pointer is 0. $Par40.05 = \{(1500 \times 0.1) + [(1 - 0.1) \times 0]\} \times 1$ Par40.05 = 150If 40.53 Set 1 trimmed ref pointer is 750. $Par40.05 = \{(1500 \times 0.1) + [(1 - 0.1) \times 750]\} \times 1$

Par40.05 = 825

If 40.53 Set 1 trimmed ref pointer is 1500. Par40.05 = {(1500 × 0.1) + [(1 - 0.1) × 1500]} × 1 Par40.05 = 1500

PID trim auto connection

PID trim auto connection (40.65 Trim auto connection) enables the connection of PID trim output actual (40.05 Process PID trim output act) to the respective speed, torque or frequency reference chains. You can use parameter 40.52 Set 1 trim selection (for PID set 1) or 41.52 Set 2 trim selection (for PID set 2) to select the respective trim (speed, torque or frequency).

The motor control mode (99.04 Motor control mode) also impacts the PID trim output actual (40.05 Process PID trim output act) added to the speed, torque or frequency reference chains. In scalar control mode, the speed trim and torque trim values are zero and in vector control mode, the frequency trim value is zero.

See the control chain diagram on page 507.

Note: If the parameter 40.65 *Trim auto connection* is disabled or the drive stops by 21.04 *Emergency stop mode*, *Ramp stop (Off1)* or *Eme ramp stop (Off3)*, the PID trim output actual (40.05 *Process PID trim output act*) is not added during the drive deceleration condition

Speed trim connection

Speed trim is added to 23.02 Speed ref ramp output. The parameter 24.01 Used speed reference displays the final speed reference after the addition of speed trim.

Torque trim connection

Torque trim is added to the parameter 26.75 Torque reference act 5. The parameter 26.76 Torque reference act 6 displays the final torque reference after the addition of torque trim.

Frequency trim connection

Frequency trim is added to the parameter 28.02 Frequency ref ramp output and generates the final frequency after the trim addition. At present, no parameter displays the final frequency reference after the addition of frequency trim.

Settings

- Parameter group 40 Process PID set 1 and parameters 40.51...40.56 (page 308).
- Parameter group 41 Process PID set 2 and parameters 41.51...41.56 (page 313).

Timed functions

Timed function enables to configure the drive to perform automated functions at a desired time on any day of a week. The function includes 12 timers, exception day settings, and boost time settings that help to configure the desired operation needed in the system.

Settings

Parameter group 34 Timed functions (page 276).

Mechanical brake control

A mechanical brake is used for holding the motor and driven machinery at zero speed when the drive is stopped, or not powered. The brake control logic observes the settings of parameter group *44 Mechanical brake control* as well as several external signals, and moves between the states presented in the diagram on page *61*. The tables below the state diagram detail the states and transitions. The timing diagram on page *62* shows an example of a close-open-close sequence.

Inputs of the brake control logic

The start command of the drive (bit 5 of *06.16 Drive status word 1*) is the main control source of the brake control logic.

Outputs of the brake control logic


The mechanical brake is to be controlled by bit 0 of parameter 44.01 Brake control status. This bit should be selected as the source of a relay output (or a digital input/output in output mode) which is then wired to the brake actuator through a relay. See the wiring example on page 62.

The brake control logic, in various states, will request the drive control logic to hold the motor or ramp down the speed. These requests are visible in parameter *44.01 Brake control status*.

Settings

Parameter group 44 Mechanical brake control (page 316).

Brake state diagram



State descriptions

State name	Description
BRAKE DISABLED	Brake control is disabled (parameter 44.06 Brake control enable = 0, and 44.01 Brake control status b4 = 0). The open signal is active (44.01 Brake control status b0 = 1).
BRAKE OPENING:	Brake has been requested to open. (44.01 Brake control status b2 = 1). Open signal has been activated (44.01 Brake control status b0 is set). The load is held in place by the speed control of the drive until 44.08 Brake open delay elapses.
BRAKE OPEN	The brake is open (44.01 Brake control status $b0 = 1$). Hold request is removed (44.01 Brake control status $b2 = 0$), and the drive is allowed to follow the reference.
BRAKE CLOSING:	
BRAKE CLOSING WAIT	Brake has been requested to close. The drive logic is requested to ramp down the speed to a stop (44.01 Brake control status $b3 = 1$). The open signal is kept active (44.01 Brake control status $b0 = 1$). The brake logic will remain in this state until the motor speed is below 44.14 Brake close level.
BRAKE CLOSING DELAY	Closing conditions have been met. The open signal is deactivated (44.01 Brake control status $b0 \rightarrow 0$). The ramp-down request is maintained (44.01 Brake control status $b3 = 1$). The brake logic will remain in this state until 44.13 Brake close delay has elapsed. At this point, the logic proceeds to BRAKE CLOSED state.
BRAKE CLOSED	The brake is closed (44.01 Brake control status b0 = 0). The drive is not necessarily modulating.


62 Program features

State change conditions ((n))

- 1 Brake control disabled (parameter 44.06 Brake control enable \rightarrow 0).
- 2 06.11 Main status word, bit 2 = 0.
- 3 Brake has been requested to open.
- 4 44.08 Brake open delay has elapsed.
- 5 Brake has been requested to close.
- 6 Motor speed is below closing speed 44.14 Brake close level.
- 7 44.13 Brake close delay has elapsed.
- 8 Brake has been requested to open.
- 9 Brake control enabled (parameter 44.06 Brake control enable \rightarrow 1).

Timing diagram

The simplified timing diagram below illustrates the operation of the brake control function. Refer to the state diagram above.Wiring example




The figure below shows a brake control wiring example. The brake control hardware and wiring is to be sourced and installed by the customer.

WARNING! Make sure that the machinery into which the drive with brake control function is integrated fulfills the personnel safety regulations. Note that

the frequency converter (a Complete Drive Module or a Basic Drive Module, as defined in IEC/EN 61800-2), is not considered as a safety device mentioned in the European Machinery Directive and related harmonized standards. Thus, the personnel safety of the complete machinery must not be based on a specific frequency converter feature (such as the brake control function), but it has to be implemented as defined in the application specific regulations.

The brake is controlled by bit 0 of parameter 44.01 Brake control status. In this example, parameter 10.24 RO1 source is set to Brake command (i.e. bit 0 of 44.01 Brake control status.



Motor control

Motor types

The drive supports asynchronous AC induction.

Motor identification

The performance of vector control is based on an accurate motor model determined during the motor start-up.

A motor Identification magnetization is automatically performed the first time the start command is given. During this first start-up, the motor is magnetized at zero speed for several seconds and the motor and motor cable resistance are measured to allow the motor model to be created. This identification method is suitable for most applications.

In demanding applications a separate Identification run (ID run) can be performed.

Settings

99.13 ID run requested (page 371).

Scalar motor control

Scalar motor control is the default motor control method. In scalar control mode, the drive is controlled with a frequency reference.

ABB recommends to activate the scalar motor control mode in the following situations:

- If the exact nominal motor values are not available or the drive needs to run different motors after commissioning.
- If a short commissioning time is needed.
- If ID run is not required.
- In multimotor systems:
 - · if the load is not equally shared between the motors
 - if the motors are of different sizes
 - if the motors are going to be changed after motor identification (ID run)
- If the nominal current of the motor is less than 1/6th of the nominal output current of the drive

Note: During this time, do not activate the motor phase loss fault (*31.19 Motor phase loss*) as the drive cannot measure the motor current accurately.

- If the drive is used without a motor connected (for example, for test purposes)
- · If the drive runs a medium-voltage motor through a step-up transformer.
- If the drive is equipped with a sine filter.


Note: Performance of the vector control is not achieved in scalar control.

See also section Operating modes of the drive (page 37).

IR compensation for scalar motor control

IR compensation (also known as voltage boost) is available only when the motor control mode is scalar. When IR compensation is activated, the drive gives an extra voltage boost to the motor at low speeds. IR compensation is useful in applications, such as positive displacement pumps, that require a high break-away torque.

Note: IR compensation is not possible or required in vector control. The compensation is applied automatically.



Settings

- Parameters 97.13 IR compensation (page 366)
- Main menu ≡ → Motor data (■) or Main menu = → Complete parameter list
 → Parameter 99.04.
- Parameter group 28 Frequency reference chain (page 243).

Vector control

Vector control is the motor control mode intended for applications where high control accuracy is needed. It offers better control over the whole speed range, in particular in applications where slow speed with high torque is needed. It requires an identification run at startup. Vector control cannot be used in all applications, e.g. sine filters.

Vector control is based on stator flux and motor torque values.

- Stator flux is calculated by integrating the motor voltage in vector space.
 - The estimate of stator flux can be improved by utilizing the identified motor model.
- Motor torque is calculated as a cross product of the stator flux and the rotor current.

Both values can be achieved by controlling the output semiconductors switching. The output frequency is changed only when the actual values of stator flux and motor torque are different from their reference values by more than the allowed hysteresis. The reference value for the torque controller comes from the speed controller or directly from an external torque reference source.

Notes:

- Actual motor shaft speed is not needed for motor control.
- Vector control also requires measurement of the DC voltage and two motor phase currents.

The difference of vector control from the traditional control are:

- Torque control operates at the same time level as the power switch control.
- There is no separate voltage and frequency controlled PWM modulator.
- The output stage switching is based on the electromagnetic state of the motor.

- The best motor control accuracy is achieved by activating a separate motor. identification run (normal ID run).

See also section Speed compensated stop (page 75).

Settings

- Main menu ≡ → Motor data 4≣) or Main menu ≡ → Complete parameter list = → parameter 99.04.
- Parameter 99.13 ID run requested (page 371).


Speed control performance figures

The table below shows typical performance figures for speed control.

		$\frac{T}{T_{\rm N}}$ (%)	T _{load}	
Speed control	Performance	100 +		
Static accuracy	20% of motor nominal slip			
Dynamic accuracy	< 10% s with 100% torque step (with default speed controller tuning)	nn .		
Tuned speed	< 2% s with 100%	n _{act} -n _{ref}	☐ Area < 10% s	
controller	torque step	n _N		
		$T_{\rm N}$ = rated motor torque $n_{\rm N}$ = rated motor speed $n_{\rm act}$ = actual speed $n_{\rm ref}$ = speed reference		

Torque control performance figures

The drive can perform precise torque control without any speed feedback from the motor shaft. The table below shows typical performance figures for torque control.



Power loss ride-through

See section Undervoltage control (power loss ride-through) on page 76.

U/f ratio

The function has the following modes:

- Linear
- · Squared.

Linear mode

In linear mode, the ratio of voltage to frequency is constant below the field weakening point. This is used in constant torque applications where it may be necessary to produce torque at or near the rated torque of the motor throughout the frequency range

Squared mode

In squared mode, the ratio of the voltage to frequency increases as the square of the frequency below the field weakening point. This is typically used in centrifugal pump or fan applications. For these applications, the torque required follows the square relationship with frequency. Therefore, if the voltage is varied using the square

relationship, the motor operates at improved efficiency and lower noise levels in these applications.


The *U*/f function cannot be used with energy optimization. If parameter 45.11 Energy optimizer is set to *Enable*, parameter 97.20 *U*/*F ratio* is ignored.

Settings

Parameter 97.20 U/F ratio (page 366).

Flux braking

The drive can provide greater deceleration by raising the level of magnetization in the motor. By increasing the motor flux, the energy generated by the motor during braking can be converted to motor thermal energy.



The drive monitors the motor status continuously, also during flux braking. Therefore, flux braking can be used both for stopping the motor and for changing the speed. The other benefits of flux braking are:

- The braking starts immediately after a stop command is given. The function does not need to wait for the flux reduction before it can start the braking.
- The cooling of the induction motor is efficient. The stator current of the motor increases during flux braking, not the rotor current. The stator cools much more efficiently than the rotor.
- · Flux braking can be used with induction motors.

Two braking power levels are available:

- Moderate braking provides faster deceleration compared to a situation where flux braking is disabled. The flux level of the motor is limited to prevent excessive heating of the motor.
- Full braking exploits almost all available current to convert the mechanical braking energy to motor thermal energy. Braking time is shorter compared to moderate braking. In cyclic use, motor heating may be significant.

WARNING: The motor needs to be rated to absorb the thermal energy generated by flux braking.

Settings

Parameter 97.05 Flux braking (page 365).

DC magnetization

The drive has different magnetization functions for different phases of motor start/rotation/stop: pre-magnetization, DC hold, post-magnetization and pre-heating (motor heating).

Pre-magnetization

Pre-magnetization refers to DC magnetization of the motor before start. Depending on the selected start mode (*21.01 Start mode* or *21.19 Scalar start mode*), pre-magnetization can be applied to guarantee the highest possible breakaway torque, up to 200% of the nominal torque of the motor. By adjusting the pre-magnetization time (*21.02 Magnetization time*), it is possible to synchronize the motor start and, for example, the release of a mechanical brake.


Settings

Parameters 21.01 Start mode, 21.19 Scalar start mode, 21.02 Magnetization time

DC hold

The function makes it possible to lock the rotor at (near) zero speed in the middle of normal operation. DC hold is activated by parameter 21.08 DC current control. When both the reference and motor speed drop below a certain level (parameter 21.09 DC hold speed), the drive will stop generating sinusoidal current and start to inject DC into the motor. The current is set by parameter 21.10 DC current reference. When the

reference exceeds parameter 21.09 DC hold speed, normal drive operation continues.



Settings

Parameters 21.08 DC current control and 21.09 DC hold speed

Post-magnetization

This function keeps the motor magnetized for a certain period (parameter 21.11 Post *magnetization time*) after stopping. This is to prevent the machinery from moving under load, for example before a mechanical brake can be applied. Post-magnetization is activated by parameter 21.08 DC current control. The magnetization current is set by parameter 21.10 DC current reference.

Note: Post-magnetization is only available when ramp stop is selected (see parameter *21.03 Stop mode*).

Settings

Parameters 21.03 Stop mode (page 212), 21.08 DC current control and 21.11 Preheating input source.

Pre-heating (Motor heating)

The pre-heating function keeps the motor warm and prevents condensation inside the motor by feeding it with DC current when the drive has been stopped. The heating can only be on when the drive is in the stopped state, and starting the drive stops the heating.

When pre-heating is activated and the stop command is given, pre-heating starts immediately if the drive is running below zero speed (see bit 0 in parameter *06.19 Speed control status word*). If the drive is running above zero speed, pre-heating is delayed by 60 seconds to prevent excessive current.

The function can be defined to be always active when the drive is stopped or it can be activated by a digital input, fieldbus, timed function or supervision function. For example, with the help of signal supervision function, the heating can be activated by a thermal measurement signal from the motor.

The pre-heating current fed to the motor can be defined as 0...30% of the nominal motor current.

Notes:

- In applications where the motor keeps rotating for a long time after the modulation is stopped, it is recommended to use ramp stop with pre-heating to prevent a sudden pull at the rotor when the pre-heating is activated.
- The heating function requires that the STO circuit is closed or not triggered open.
- The heating function requires that the drive is not faulted.
- Pre-heating uses DC hold to produce current.

Settings

Parameters 21.14 Pre-heating input source and 21.16 Pre-heating current (page 215)

Energy optimization

The energy optimization function optimizes the motor flux so that total energy consumption and motor noise level are reduced when the drive operates below the nominal load. The total efficiency (motor and drive) can be improved by 1...20% depending on load torque and speed.

Settings

- Menu ≡ → Energy efficiency Imp
- Parameter 45.11 Energy optimizer (page 319)

Switching frequency

The drive has two switching frequencies: reference switching frequency and minimum switching frequency. The drive tries to keep the highest allowed switching frequency (= reference switching frequency) if thermally possible, and then adjusts dynamically between the reference and minimum switching frequencies depending on the drive temperature. When the drive reaches the minimum switching frequency (= lowest allowed switching frequency), it starts to limit output current as the heating up continues.

For derating, see chapter *Technical data*, section *Switching frequency derating* in the *Hardware manual* of the drive.

Example 1: If you need to fix the switching frequency to a certain value as with some external filters, set both the reference and the minimum switching frequency to this value and the drive will retain this switching frequency.


Example 2: If the reference switching frequency is set to 12 kHz and the minimum switching frequency is set to the smallest available value, the drive maintains the highest possible switching frequency to reduce motor noise and only when the drive heats it will decrease the switching frequency. This is useful, for example, in applications where low noise is necessary but higher noise can be tolerated when the full output current is needed.

Settings

Parameter 97.01 Switching frequency reference and 97.02 Minimum switching frequency (page 355).

Rush control

In torque control, the motor could potentially rush if the load were suddenly lost. The control program has a rush control function that decreases the torque reference whenever the motor speed exceeds *30.11 Minimum speed* or *30.12 Maximum speed*.



The function is based on a PI controller. The program sets the proportional gain to 10.0 and integration time to 2.0 s.

Settings

Parameters 26.81 Rush control gain (page 242) and 26.82 Rush control integration time (page 242)

Jogging

The jogging function enables the use of a momentary switch to briefly rotate the motor. The jogging function is typically used during servicing or commissioning to control the machinery locally. The function is available in both scalar and vector control. In vector control mode, the jogging speed reference is provided by parameters 22.42 Jogging 1 ref and 22.43 Jogging 2 ref. In scalar control mode, the


jogging frequency reference is provided by 28.42 *Jogging 1 frequency ref* and 28.43 *Jogging 2 frequency ref*.

Two jogging functions (1 and 2) are available, each with their own activation sources and references. The signal sources are selected by parameters *20.26 Jogging 1 start source* and *20.27 Jogging 2 start source*. When jogging is activated, the drive starts and accelerates to the defined jogging speed or frequency along the defined jogging acceleration ramp (*23.20 Acc time jogging*). After the activation signal switches off, the drive decelerates to a stop along the defined jogging deceleration ramp (*23.21 Dec time jogging*).

The figure and table below provide an example of how the drive operates during jogging. In the example, the ramp stop mode is used (see parameter *21.03 Stop mode*).

Jog cmd = State of source set by 20.26 Jogging 1 start source or 20.27 Jogging 2 start source

Jog = State of source set by 20.25 Jogging enable Start cmd = State of drive start command.



Phase	Jog cmd	Jog	Start cmd	Description
1-2	1	1	0	Drive accelerates to the jogging speed along the acceleration ramp of the jogging function.
2-3	1	1	0	Drive follows the jog reference.
3-4	0	1	0	Drive decelerates to zero speed along the deceleration ramp of the jogging function.
4-5	0	1	0	Drive is stopped.
5-6	1	1	0	Drive accelerates to the jogging speed along the acceleration ramp of the jogging function.
6-7	1	1	0	Drive follows the jog reference.

Phase	Jog cmd	Jog	Start cmd	Description
7-8	0	1	0	Drive decelerates to zero speed/frequency along the deceleration ramp of the jogging function.
8-9	0	1->0	0	Drive is stopped. As long as the jog signal is on, start commands are ignored. After jog switches off, a fresh start command is required.
9-10	x	0	1	Drive accelerates to the speed/frequency reference along the selected acceleration ramp (parameters 23.1123.15).
10-11	х	0	1	Drive follows the speed/frequency reference.
11-12	х	0	0	Drive decelerates to zero speed/frequency along the selected deceleration ramp (parameters 23.1123.15).
12-13	х	0	0	Drive is stopped.
13-14	x	0	1	Drive accelerates to the speed/frequency reference along the selected acceleration ramp (parameters 23.1123.15).
14-15	x	0->1	1	Drive follows the speed/frequency reference. As long as the start command is on, the jog signal is ignored. If the jog signal is on when the start command switches off, jogging is enabled immediately.
15-16	0->1	1	0	Start command switches off. The drive starts to decelerate along the selected deceleration ramp (parameters 23.1123.15).
				When the jog command switches on, the decelerating drive adopts the deceleration ramp of the jogging function.
16-17	1	1	0	Drive follows the jog reference.
17-18	0	1->0	0	Drive decelerates to zero speed/frequency along the deceleration ramp of the jogging function.

See also the block diagram on page 496.

Notes:

- Jogging is not available when the drive is in local control.
- Jogging cannot be enabled when the drive start command is on, or the drive started when jogging is disabled. Starting the drive after the jog switches off requires a fresh start command.



WARNING! If jogging is enabled and activated while the start command is on, jogging will activate as soon as the start command switches off.


- · If both jogging functions are activated, the one that was activated first has priority.
- The inching functions activated through fieldbus (see *06.01 Main control word*, bits 8...9) use the references and ramp times defined for jogging, but do not require the jog signal.

Settings

Parameters 20.25 Jogging enable (page 209), 20.26 Jogging 1 start source (page 209), 20.27 Jogging 2 start source (page 210), 22.42 Jogging 1 ref (page 224), 22.43 Jogging 2 ref (page 224), 28.42 Jogging 1 frequency ref (page 249) 28.43 Jogging 2 frequency ref (page 249),23.20 Acc time jogging (page 229) and 23.21 Dec time jogging (page 229).

Speed compensated stop

Speed compensation stop is available for example for applications where a conveyer needs to travel a certain distance after receiving the stop command. At maximum speed, the motor is stopped normally along the defined deceleration ramp, after the application of a user defined delay to adjust the distance traveled. Below maximum speed, stop is delayed still more by running the drive at current speed before the motor is ramped to a stop. As shown in the figure, the distance traveled after the stop command is the same in both cases, that is, area A + area B equals area C. Speed compensation does not take into account shape times (parameters 23.32 Shape time 1 and 23.33 Shape time 2). Positive shape times lengthen the distance traveled.



Speed compensation can be restricted to forward or reverse rotating direction.

Speed compensation is supported in both vector and scalar motor control.

Settings

Parameters 21.30 Speed compensated stop mode (page 218), 21.31 Speed comp stop delay (page 218) and 21.32 Speed comp stop threshold (page 218).

DC voltage control


Overvoltage control

Overvoltage control of the intermediate DC link is typically needed when the motor is in generating mode. The motor can generate when it decelerates or when the load overhauls the motor shaft, causing the shaft to turn faster than the applied speed or frequency. To prevent the DC voltage from exceeding the overvoltage control limit, the overvoltage controller automatically decreases the generating torque when the limit is reached. The overvoltage controller also increases any programmed deceleration times if the limit is reached; to achieve shorter deceleration times, a brake chopper and resistor may be required.

Undervoltage control (power loss ride-through)

If the incoming supply voltage is cut off, the drive will continue to operate by utilizing the kinetic energy of the rotating motor. The drive is fully operational as long as the motor rotates and generates energy to the drive. The drive can continue operation after the break if the main contactor (if present) remained closed.

Note: Units equipped with a main contactor must be equipped with a hold circuit (e.g. UPS) to keep the contactor control circuit closed during a short supply break.



 $U_{\rm DC}$ = Intermediate circuit voltage of the drive, $f_{\rm out}$ = Output frequency of the drive, $T_{\rm M}$ = Motor torque

Loss of supply voltage at nominal load (f_{out} = 40 Hz). The intermediate circuit DC voltage drops to the minimum limit. The controller keeps the voltage steady as long as the input power is switched off. The drive runs the motor in generator mode. The motor speed falls but the drive is operational as long as the motor has enough kinetic energy.

Implementing the undervoltage control (power loss ride-through)

Implement the undervoltage control function as follows:

- Check that the undervoltage control function of the drive is enabled with parameter 30.31 Undervoltage control.
- Parameter 21.01 Start mode must be set to Automatic (in vector mode) or parameter 21.19 Scalar start mode to Automatic (in scalar mode) to make flying start (starting into a rotating motor) possible.

If the installation is equipped with a main contactor, prevent its tripping at the input power break. For example, use a time delay relay (hold) in the contactor control circuit.

WARNING! Make sure that the flying restart of the motor will not cause any danger. If you are in doubt, do not implement the undervoltage control function.

Automatic restart

It is possible to restart the drive automatically after a short (max. 5 seconds) power supply failure by using the Automatic restart function, provided that the drive is allowed to run for 5 seconds without the cooling fans operating.

When enabled, the function takes the following actions upon a supply failure to a successful restart:

- The undervoltage fault is suppressed (but a warning is generated).
- · Modulation and cooling is stopped to conserve any remaining energy.
- DC circuit pre-charging is enabled.

If the DC voltage is restored before the expiration of the period defined by parameter 21.18 Auto restart time and the start signal is still on, normal operation will continue. However, if the DC voltage remains too low at that point, the drive trips on a fault, 3220 DC link undervoltage.

WARNING! Before you activate the function, make sure that no dangerous situations can occur. The function restarts the drive automatically and continues operation after a supply break.

Voltage control and trip limits

The control and trip limits of the intermediate DC voltage regulator are relative to the supply voltage as well as drive/inverter type. The DC voltage (U_{DC}) is approximately 1.41 times the line-to-line supply voltage, and is displayed by parameter 01.11 DC voltage.

The following table shows the values of selected DC voltage levels. The drive DC voltage limits are calculated based on the parameter *95.01 Supply voltage* and *95.02 Adaptive voltage limits*.

Notes:

- parameter 95.03 Estimated AC supply voltage is the estimated voltage during start-up of the drive and is not continuously updated during the time lim eit.
- The absolute voltages vary according to the drive/inverter type and AC supply voltage range.

DC Voltage level		95.01 Supply voltage	
[V]	AC supply voltage range [V] 380415	AC supply voltage range [V] 440480	Automatic/Not selected
Overvoltage fault limit	842	842	842
Overvoltage control limit	779	779	779
Internal brake chopper start limit	779	779	779
Internal brake chopper stop limit	759	759	759
Overvoltage warning limit	745	745	745
Undervoltage warning limit	0.85×1.41×par 95.03 value ¹⁾	0.85×1.41×par 95.03 value ¹⁾	0.85×1.41×par <u>95.03</u> value ¹⁾
	0.85×1.35×380 = 436 ²⁾	0.85×1.35×440 = 463 ²⁾	0.85×1.35×440 = 463 ²⁾
Undervoltage control limit	0.78×1.41×par 95.03 value ¹⁾	0.78×1.41×par 95.03 value ¹⁾	0.78×1.41×par <u>95.03</u> value ¹⁾
	0.78×1.35×380 = 400 ²⁾	0.78×1.35×440 = 463 ²⁾	0.78×1.35×440 = 463 ²⁾
Charging relay closing limit	0.78×1.41×par 95.03 value ¹⁾	0.78×1.41×par 95.03 value ¹⁾	0.78×1.41×par <u>95.03</u> value ¹⁾
	0.78×1.35×380 = 400 ²⁾	0.78×1.35×440 = 463 ²⁾	0.78×1.35×440 = 463 ²⁾
Charging relay opening limit	0.73×1.41×par 95.03 value ¹⁾	0.73×1.41 ×par 95.03 value ¹⁾	0.73×1.41 ×par <u>95.03</u> value ¹⁾
	0.73×1.35×380 = 374 ²⁾	0.73×1.35×440 = 433 ²⁾	0.73×1.35×440 = 433 ²⁾
Undervoltage fault limit	0.73×1.41×par 95.03 value ¹⁾	0.73×1.41×par <u>95.<i>03</i> value ¹⁾</u>	0.73×1.41×par <u>95.03</u> value ¹⁾
	0.73×1.35×380 = 374 ²⁾	0.73×1.35×440 = 433 ²⁾	0.45×1.35×440 = 433 ²⁾
DC voltage at upper bound of supply voltage range (U _{DCmax})	560	648	648
DC voltage at lower bound of supply voltage range (U _{DCmin})	513	594	594

DC Voltage lovel	95.01 Supply voltage				
DC Voltage level [V]	AC supply voltage range [V] 380415	AC supply voltage range [V] 440480	Automatic/Not selected		
Charging activation/ standby limit ³⁾	0.73×1.41×par 95.03 value ¹⁾	0.73×1.41×par 95.03 value ¹⁾	0.73×1.41×par <u>95.<i>03</i></u> value ¹⁾		
	0.73×1.35×380 = 374 ²⁾	0.73×1.35×440 = 433 ²⁾	0.73×1.35×440 = 433 ²⁾		

¹⁾ Parameter Adaptive voltage limits is set to Enable

²⁾ Parameter *Adaptive voltage limits* is set to *Disable*

³⁾ When standby is activated, drive modulation is stopped, the fan is stopped and the pre-charge circuit is activated. If the voltage exceeds this level again, the drive has to complete charging before it will automatically continue operation.

A warning A3A2 DC link undervoltage is generated during any of the below conditions occurs:

- When drive is not modulating and the DC link voltage *01.11 DC voltage* is below 85% of the undervoltage warning limit.
- The drive is modulating, the DC link voltage 01.11 DC voltage is below 73% of the standby limit and the parameter 21.18 Auto restart time > 0. The warning continues to appear if the DC link voltage is continuously less than the standby limit until auto restart time elapses.

Note: Control board must be externally powered with 24 VDC to enable warning in this condition. Else, the control switches off once the DC voltage goes below hardware limit.

A fault 3220 DC link undervoltage is generated during any of the below conditions:

- The DC link voltage 01.11 DC voltage value is less than the undervoltage trip limit and the parameter 21.18 Auto restart time is not enabled.
- The DC link voltage 01.11 DC voltage value is less than the undervoltage trip limit and the parameter 21.18 Auto restart time is enabled. The undervoltage trip occurs only if the warning continues to appear until auto restart time elapses. Notes:
 - Control board must be externally powered with 24 VDC to enable warning in this condition. Else, the control switches off once the DC voltage goes below the hardware limit.
 - DC voltage stabilization parameter is available in service level parameters list. For more information, contact your local ABB representative.

Settings

Parameters 01.11 DC voltage (page 165), 30.30 Overvoltage control (page 259), 30.31 Undervoltage control (page 259), 95.01 Supply voltage (page 355) and 95.02 Adaptive voltage limits (page 355).

Brake chopper

A brake chopper can be used to handle the energy generated by a decelerating motor. When the DC voltage rises high enough, the chopper connects the DC circuit to an external brake resistor. The chopper operation is based on hysteresis.

The internal brake choppers in the drive (in frames R0...R3) start conducting at internal brake chopper start limit 780 V and stop conducting at internal brake chopper stop limit 760 V (AC supply 380...480 V).

For information on external brake choppers, refer to the respective user manual.

Note: Overvoltage control needs to be disabled for the chopper to operate.

Settings

Parameter 01.11 DC voltage (page 165), 30.30 Overvoltage control (page 259) and parameter group 43 Brake chopper (page 314).

Safety and protections

Fixed/Standard protections

Overcurrent

If the output current exceeds the internal overcurrent limit, the IGBTs are shut down immediately to protect the drive.

DC overvoltage

See section Overvoltage control on page 76.

DC undervoltage

See section Undervoltage control (power loss ride-through) on page 76.

Drive temperature

If the temperature rises high enough, the drive first starts to limit the switching frequency and then the current to protect itself. If it is still keeps heating up, for example because of a fan failure, an overtemperature fault is generated.

Short circuit

In case of a short circuit, the IGBTs are shut down immediately to protect the drive.

Emergency stop

The emergency stop signal is connected to the input selected by parameter *21.05 Emergency stop source*. An emergency stop can also be generated through fieldbus (parameter *06.01 Main control word*, bits 0...2).

The mode of the emergency stop is selected by parameter 21.04 *Emergency stop mode*. The following modes are available:

- Off1: Stop along the standard deceleration ramp defined for the particular reference type in use
- Off2: Stop by coasting
- Off3: Stop by the emergency stop ramp defined by parameter 23.23 Emergency stop time.

Notes:

- The installer of the equipment is responsible for installing the emergency stop devices and all additional devices needed for the emergency stop function to fulfill the required emergency stop categories. For more information, contact your local ABB representative.
- After an emergency stop signal is detected, the emergency stop function cannot be canceled even though the signal is canceled.
- If the minimum (or maximum) torque limit is set to 0%, the emergency stop function may not be able to stop the drive.
- During an emergency stop, the speed and torque reference parameters such as reference ramp shapes (23.32 Shape time 1 and 23.33 Shape time 2) are not considered.

Settings

Parameters 21.04 Emergency stop mode (page 212), 21.05 Emergency stop source (page 212), and 23.23 Emergency stop time (page 230).

Motor thermal protection

The control program features two separate motor temperature monitoring functions. The temperature data sources and warning/trip limits can be set up independently for each function.

The motor temperature can be monitored using

- the motor thermal protection model (estimated temperature derived internally inside the drive), or
- sensors installed in the windings. This will result in a more accurate motor model.

Motor thermal protection model

The drive calculates the temperature of the motor on the basis of the following assumptions:

1. When power is applied to the drive for the first time, the motor is assumed to be at ambient temperature (defined by parameter *35.50 Motor ambient temperature*).

After this, when power is applied to the drive, the motor is assumed to be at the estimated temperature.

2. Motor temperature is calculated using the user-adjustable motor thermal time and motor load curve. The load curve should be adjusted in case the ambient temperature exceeds 30%.

Note: The motor thermal model can be used when only one motor is connected to the inverter.

Implementing a motor temperature sensor connection

WARNING! IEC 60664 and IEC 61800-5-1 require double or reinforced insulation between live parts and the surface of accessible parts of electrical equipment which are either non-conductive or conductive but not connected to the protective earth.

You have four implementation alternatives:


- If there is double or reinforced insulation between the sensor and the live parts of the motor, you can connect the sensor directly to the analog/digital input(s) of the drive.
- If there is basic insulation between the sensor and the live parts of the motor, you
 can connect the sensor to the analog/digital input(s) of the drive if all other circuits
 connected to the digital and analog inputs (typically extra-low voltage circuits) are
 protected against contact and insulated with basic insulation from other lowvoltage circuits. The insulation must be rated for the same voltage level as the
 drive main circuit. Note that extra-low voltage circuits (such as 24 V DC) typically
 do not meet these requirements.
- Alternative (for R0...R2 frames only): You can connect the sensor with a basic insulation to the analog/digital input(s) of the drive if you do not connect any other external control circuits to drive digital and analog inputs.

Temperature monitoring using PTC sensors

1...3 PTC sensors can be connected in series to an analog input and an analog output.

The analog output feeds a constant excitation current of 1.6 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage


over the sensor. The temperature measurement function calculates the resistance of the sensor and generates an indication if overtemperature is detected.



Leave the sensor end of the cable shield unconnected.

For wiring of the sensor, refer to the drive hardware manual


The figure below shows typical PTC sensor resistance value as a function of temperature.



In R0...R2 frames, when an analog output is not available or used for other purposes, it is possible to setup a voltage divider connection that uses the internal resistance of a digital input.

1...3 PTC sensors can be connected in series with 10 V reference and digital and analog inputs. The temperature measurement function reads the voltage over the

internal resistance of the digital input from the analog input and calculates the PTC resistance.



Note: RIIO-01 or BIO-01 is required for the analog input. By default, RIIO-01 is provided with the ACS560 drives.

Example settings

The parameters are set as follows for monitoring the temperature with PTC sensors:

Parameter	Value
35.11 Temperature 1 source	PTC analog I/O (20). For R0R2 frames, it can be PTC AI/DI Voltage Divider tree (23) also.
35.14 Temperature 1 Al source	Al1
12.15 Al1 actual value	V
13.12 AO1 source	Temp sensor 1 excitation (20). Note: This is not applicable for R0R2, if PTC AI/DI Voltage Divider tree is used.
35.12 Temperature 1 fault limit	Desired value

WARNING! IEC 60664 requires double or reinforced insulation between live parts and the surface of accessible parts of electrical equipment which are either non-conductive or conductive but not connected to the protective. Obey the electrical planning guidelines for implementing the motor temperature sensor connection. If you ignore them, injury or death, or damage to the equipment can occur

For wiring of the sensor, refer to the drive hardware manual.

Make sure that the DI used is not configured to any other use in the drive control program.

Temperature monitoring using Pt100 sensors

1...3 Pt100 sensors can be connected in series to an analog input and an analog output.

The analog output feeds a constant excitation current of 9.1 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

It is possible to adjust the motor temperature supervision limits and select how the drive reacts when overtemperature is detected.

See section Implementing a motor temperature sensor connection on page 82.

For the wiring of the sensor, see chapter Electrical installation, section Al1 and Al2 as Pt100, Pt1000, Ni1000, KTY83 and KTY84 sensor inputs (X1) in the drive hardware manual.

Temperature monitoring using Pt1000 sensors

1...3 Pt1000 sensors can be connected in series to an analog input and an analog output.

The analog output feeds a constant excitation current of 0.1 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

See section Implementing a motor temperature sensor connection on page 82.

For the wiring of the sensor, see chapter *Electrical installation, Al1 and Al2 as Pt100, Pt1000, Ni1000, KTY83 and KTY84 sensor inputs (X1)* in the *Hardware manual* of the drive.

Temperature monitoring using Ni1000 sensors

One Ni1000 sensor can be connected to an analog input and an analog output on the control unit.

The analog output feeds a constant excitation current of 9.1 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

See section Implementing a motor temperature sensor connection on page 82.

For the wiring of the sensor, see chapter *Electrical installation, Al1 and Al2 as Pt100, Pt1000, Ni1000, KTY83 and KTY84 sensor inputs (X1)* in the *Hardware manual* of the drive.

Temperature monitoring using KTY84 sensors

One KTY84 sensor can be connected to an analog input and an analog output on the control unit.

The analog output feeds a constant excitation current of 2.0 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

The figure and table on page 146 show typical KTY84 sensor resistance values as a function of the motor operating temperature.

See section Implementing a motor temperature sensor connection on page 82.


For the wiring of the sensor, see chapter *Electrical installation, Al1 and Al2 as Pt100, Pt1000, Ni1000, KTY83 and KTY84 sensor inputs (X1)* in the *Hardware manual* of the drive.

Temperature monitoring using KTY83 sensors

One KTY83 sensor can be connected to an analog input and an analog output on the control unit.

The analog output feeds a constant excitation current of 1.0 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

The figure and table below show typical KTY83 sensor resistance values as a function of the motor operating temperature.



It is possible to adjust the motor temperature supervision limits and select how the drive reacts when overtemperature is detected.

See section Implementing a motor temperature sensor connection on page 82.

For the wiring of the sensor, see chapter *Electrical installation, Al1 and Al2 as Pt100, Pt1000, Ni1000, KTY83 and KTY84 sensor inputs (X1)* in the *Hardware manual* of the drive.

Connection of motor temperature sensor to the drive via a relay

PTC alternative A: This table shows the insulation requirement for a customer's external relay, and the insulation requirement for the sensor to fulfill decisive voltage class A (double insulation) of IEC 60800-5-1.

PTC	C relay	Temperature sensor insulation requirement
Type Insulation		
External relay	Basic insulation 6 kV	Basic insulation

PTC alternative B: Decisive voltage class B of IEC 60800-5-1 (basic insulation) is provided with a 6 kV relay. Circuits connected to all motor protection relay inputs and outputs must be protected against direct contact.

Pt100 alternative A: This table shows the insulation requirement for a customer's external relay, and the insulation requirement for the sensor to fulfill decisive voltage class A (double insulation) of IEC 60800-5-1.

Pt10	0 relay	Temperature sensor insulation requirement
Туре	Insulation	between sensor and live parts of motor
External relay	Basic insulation 6 kV	Basic insulation

Pt100 alternative B: Decisive voltage class B of IEC 60800-5-1 (basic insulation) can be achieved when there is basic insulation between the sensor and live parts of the motor. Circuits connected to all motor protection relay inputs and outputs must be protected against direct contact.

Settings and diagnostics

Menu - Primary settings - Motor - Thermal protection estimated, Menu - Primary settings - Motor - Thermal protection measured

Settings

Parameter group 35 Motor thermal protection (page 283).

Motor overload protection

This section describes motor overload protection without using motor thermal protection model, either with estimated or measured temperature. For protection with the motor thermal protection model, see section *Motor thermal protection* on page *81*.

Motor overload protection is required and specified by multiple standards including the US National Electric Code (NEC), UL 508C and the common UL\IEC 61800-5-1 standard in conjunction with IEC 60947-4-1. The standards allow for motor overload protection without external temperature sensors.

The protection feature allows the user to specify the class of operation in the same manner as the overload relays are specified in standards IEC 60947-4-1 and NEMA ICS 2.

Motor overload protection requires that you specify a motor current tripping level. This is defined by a curve using parameters 35.51, 35.52 and 35.53. The tripping level is the motor current at which the overload protection will ultimately trip if the motor current remains at this level continuously.

The motor overload class (class of operation), parameter <u>35.57 Motor overload class</u>, is given as the time required for the overload relay to trip when operating at 7.2 times

the tripping level in the case of IEC 60947-4-1 and 6 times the tripping level in the case of NEMA ICS 2. The standards also specify the time to trip for current levels between the tripping level and the 6 times tripping level. The drive satisfies the IEC standard and NEMA standard trip times.

Using class 20 satisfies the UL 508C requirements.

The motor overload algorithm monitors the squared ratio (motor current / tripping level)2 and accumulates this over time. This is sometimes to as I2t protection. The accumulated value is shown with parameter 35.05.

You can define with parameter 35.56 that when 35.05 reaches 88%, a motor overload warning will be generated, and when it reaches 100%, the drive will trip on the motor overload fault. The rate at which this internal value is increased depends on the actual current, tripping level current and overload class selected.

Parameters 35.51, 35.52 and 35.53 serve a dual purpose. They determine the load curve for temperature estimate as well as specify the overload tripping level.

Settings and diagnostics

Parameters common to motor thermal protection and motor overload protection: 35.51 Motor load curve...35.53 Break point (page 291).

Parameters specific to motor overload protection: 35.05 Motor overload level (page 283), 35.56 Motor overload action...35.57 Motor overload class (page 293).

Events: A783 Motor overload (page 419) and 7122 Motor overload (page 435).

Floating point control (Motor potentiometer)

The Floating point control (parameters are named Motor potentiometer, however) is, in effect, a counter whose value can be adjusted up and down using two digital signals selected by parameters 22.73 *Motor potentiometer up source* and 22.74 *Motor potentiometer down source*. When the Floating point control is enabled by 22.71 *Motor potentiometer function*, the counter assumes the value set by 22.72 *Motor potentiometer initial value*. Depending on the mode selected in 22.71, the counter value is either retained or reset over a power cycle.

The output of he Floating point control counter is shown by 22.80 Motor potentiometer ref act, which can directly be set as the reference source in the main selector parameters, or used as an input by other source selector parameters, both in scalar and vector control.

Note: Parameter 22.70 *Motor potentiometer reference enable* enable should be set appropriately (see the parameter description) to ensure that parameter 22.80 *Motor potentiometer ref act* is increased/decreased by 22.73 *Motor potentiometer up source* or 22.74 *Motor potentiometer down source*.

Programmable protection functions

External events (parameters 31.01...31.10)

Five different event signals from the process can be connected to selectable inputs to generate trips and warnings for the driven equipment. When the signal is lost, an external event (fault, warning, or a mere log entry) is generated.

Motor phase loss detection (parameter 31.19)

The parameter selects how the drive reacts whenever a motor phase loss is detected.

The motor phase loss detection is enabled by default and displays fault *3381 Output phase loss* whenever the drive detects a phase loss. The motor phase loss detection needs to be enabled or disabled based on the motor control mode and the nominal current as follows:

- With the vector control, the motor phase loss detection is always on and there are no operational limits.
- With the scalar control, the motor phase loss detection activates when the motor frequency is above 10% of the motor nominal frequency. This limit cannot be changed.

With motors having nominal current below 1/6 of drive nominal current, the supervision must be disabled as the drive cannot measure the motor current

accurately.

Supply phase loss detection (parameter 31.21)

The parameter selects how the drive reacts whenever a supply phase loss is detected.

Safe torque off detection (parameter 31.22)

The drive monitors the status of the Safe torque off input, and this parameter selects which indications are given when the signals are lost. (The parameter does not affect the operation of the Safe torque off function itself). For more information on the Safe torque off function, see chapter *Planning the electrical installation*, section *Implementing the Safe torque off function* in the *Hardware manual* of the drive.

Swapped supply and motor cabling (parameter 31.23)

The drive can detect if the supply and motor cables have accidentally been swapped (for example, if the supply is connected to the motor connection of the drive). The parameter selects if a fault is generated or not.


Current limit function (parameters 30.09, 30.17, and 30.10)

The drive monitors the maximum current limit, its related parameters and helps the motor not to reach its stall current limit. The maximum current, monitoring time, and how the drive should react to these conditions can be set in the parameters *30.17*, *30.09*, and *30.10* respectively.

By default, when the drive reaches the maximum current limit and exceeds the monitor time, a warning message (A8B6) is displayed.

Stall function (parameters 31.24...31.28)

The drive monitors the stall current limit, its related parameters and helps to prevent stalling of the motor. You can adjust the supervision limits (current, frequency and time) and choose how the drive reacts to a stall condition.



Notes

¹⁾ By default, displays a warning message when the drive reaches maximum current limit (30.17) and exceeds the current limit monitor time (30.09). You can configure the actions as required.

²⁾ The stall condition occurs when the output frequency is below the level set by parameter 31.27 Stall frequency *limit* or the motor speed is below the level set by parameter 31.26 Stall speed limit.

³⁾ If enabled, displays a warning message when the drive reaches stall current limit (*31.25*) and exceeds the stall time (*31.28*). You can configure the actions as required. By default, no action is configured.

Overspeed protection (parameter 31.30)

The user can set overspeed limits by specifying a margin that is added to the currently-used maximum and minimum speed limits.

Local control loss detection (parameter 49.05)

The parameter selects how the drive reacts to a control panel or PC tool communication break.

Al supervision (parameters 12.03...12.05)

The parameters select how the drive reacts when an analog input signal moves out of the minimum and/or maximum limits specified for the input. This can be due to broken I/O wiring or sensor.

Fan control (95.200)

Fan control prevents overheating and dust accumulation in the drive. The user can set the fan to run continuously in maximum speed (Always on [1]) or can set to run the fan in auto mode (Auto [0]). In auto mode, the fan operates according to the temperature of the drive.

Automatic fault resets

The drive can automatically reset itself after over-current, over-voltage, undervoltage and external faults. The user can also specify a fault that is automatically reset.

By default, automatic resets are off and must be specifically activated by the user.

WARNING! Before you activate the function, make sure that no dangerous situations can occur. The function resets the drive automatically and continues operation after a fault.

Settings

Parameters 31.12...31.16 (page 263).

Diagnostics

Signal supervision

Six signals can be selected to be supervised by this function. Whenever a supervised signal exceeds or falls below predefined limits, a bit in *32.01 Supervision status* is activated, and a warning or fault generated.

For example, if user wants to monitor DC voltage and generate a warning/fault message if it exceeds certain limit, he/she can select DC Voltage [7] in the parameter 32.07 Supervision 1 signal, set low/high limit in the parameter 32.09/32.10 and set the action in the parameter 32.06 Supervision 1 action.

The supervised signal is low-pass filtered.

Settings

Parameter group 32 Supervision (page 269).

Energy saving calculators

This feature consists of the following functionalities:

- An energy optimizer that adjusts the motor flux in such a way that the total system
 efficiency is maximized
- A counter that monitors used and saved energy by the motor and displays them in kWh, INR (based on the currency selected in 45.17) or volume of CO₂ emissions, and
- A load analyzer showing the load profile of the drive (see separate section on page 94).

By default energy tariff 1 (45.12) is 5 INR and energy tariff 1 (45.13) is 6 INR. This helps to display the saved money (45.05/45.06/45.07) in INR.

In addition, there are counters that show energy consumption in kWh of the current and previous hour as well as the current and previous day.

Note: The accuracy of the energy savings calculation is directly dependent on the accuracy of the reference motor power given in parameter 45.19 Comparison power.

Settings

- Main menu ≡ → Energy efficiency Implicitly
- Parameter group 45 Energy efficiency (page 317).
- Parameters 01.50 Current hour kWh, 01.51 Previous hour kWh, 01.52 Current day kWh and 01.53 Previous day kWh on page 166.

Load analyzer

Peak value logger

The user can select a signal to be monitored by a peak value logger. The logger records the peak value of the signal along with the time the peak occurred, as well as motor current, DC voltage and motor speed at the time of the peak. The peak value is sampled at 2 ms intervals.

Settings

Parameter group 36 Load analyzer (page 294).

🗖 Diagnostics menu 😲 🎤

The **Diagnostics** menu provides quick information about active faults, warnings, fault history and I/O connection status. It also helps you to find out why the drive is not starting, stopping or running at the desired.

- Active faults **2** 0 : Use this view to see the currently active faults. For information on the fault codes, see list of *Fault messages* on page 427.
- Fault history S: Use this view to see the fault history. For information on the fault codes, see list of *Fault messages* on page 427.
- Active warnings 10 °: Use this view to see currently active warnings. For information on the warning codes, see list of *Warning messages* on page 414.
- I/O status I/O 品: Use this view to see currently active I/O settings.

Settings

Menu <u></u>→ Diagnostics Ų/

Miscellaneous

Backup and restore

You can make backups of the settings manually to the control panel and can restore backup to the drive, or a new drive replacing a faulty one. You can also make backups and restore on the panel with the Drive composer PC tool.

Backup

Manual backup

Make a backup when necessary, for example, after you have started up the drive or when you want to copy the settings to another drive.

Parameter changes from fieldbus interfaces are ignored unless you have forced parameter saving with parameter <u>96.07</u> Parameter save manually.

Automatic backup

The control panel has a dedicated space for one automatic backup. An automatic backup is created two hours after the last parameter change. After completing the backup, the panel waits for 24 hours before checking if there are additional parameter changes. If there are, it creates a new backup overwriting the previous one when two hours have passed after the latest change.

You cannot adjust the delay time or disable the automatic backup function.

Parameter changes from fieldbus interfaces are ignored unless you have forced parameter saving with parameter 96.07 *Parameter save manually*.

Restore

The backups are shown on the panel. Automatic backups are marked with icon \square and manual backups with \square . To restore a backup, select it and press \bigcirc . In the following display you can view backup contents and restore all parameters or select a subset to be restored.

Note: To restore a backup, the drive has to be in Local control.

Settings

- Main menu ≡ → Backup data ■← □
- Parameter 96.07 Parameter save manually (page 359).

User parameter sets

The drive supports four user parameter sets that can be saved to the permanent memory and recalled using drive parameters. It is also possible to use digital inputs to switch between user parameter sets. To change a user parameter set, the drive has to be stopped.

A user parameter set contains all editable values in parameter groups 10...99 except

- forced I/O values such as parameters 10.03 DI force selection and 10.04 DI forced data
- I/O extension module settings (group 15)
- data storage parameters (group 47)
- fieldbus communication settings (groups 50...53 and 58)
- parameter 95.01 Supply voltage.

As the motor settings are included in the user parameter sets, make sure the settings correspond to the motor used in the application before recalling a user set. In an application where different motors are used with the drive, the motor ID run needs to be performed with each motor and the results saved to different user sets. The appropriate set can then be recalled when the motor is switched.

Settings

Parameters 96.10...96.13 (page 360).

Data storage parameters

Twelve (eight 32-bit, four 16-bit) parameters are reserved for data storage. These parameters are unconnected by default and can be used for linking, testing and commissioning purposes. They can be written to and read from using other parameters' source or target selections.

Settings

Parameter group 47 Data storage (page 324).

User lock

For better cyber security, it is highly recommended that you set a master pass code to prevent changing of parameter values and/or the loading of firmware and other files.

WARNING! ABB will not be liable for damages or losses caused by the failure to activate the user lock using a new pass code. See *Cyber security disclaimer* (page 18).

To activate the user lock for the first time, enter the default pass code, 1000000, into 96.02 Pass code. This will make parameters 96.100...96.102 visible. Then enter a new pass code into 96.100 Change user pass code, and confirm the code in 96.101 Confirm user pass code. In 96.102 User lock functionality, define the actions that you want to prevent (we recommend you select all the actions unless otherwise required by the application).

To close the user lock, enter an invalid pass code into *96.02 Pass code*, activate *96.08 Control board boot*, or cycle the power. With the lock closed, parameters *96.100...96.102* are hidden.

To reopen the lock, enter your pass code into 96.02 Pass code. This will again make parameters 96.102...96.102 visible.

Settings

Parameters 96.02 (page 358) and 96.100...96.102 (page 363).

Sine filter support

The control program has a setting that enables the use of ABB sine filters (available separately). With a sine filter connected to the output of the drive, bit 1 of *95.01 Special HW settings* must be switched on. The setting forces the drive to use the scalar motor control mode, and limits the switching and output frequencies to

- · prevent the drive from operating at filter resonance frequencies, and
- protect the filter from overheating.

Contact your local ABB representative before connecting a sine filter from another manufacturer.

Settings

Parameter 95.01 Special HW settings (page 355).

Dead-band function

With the Dead-band function, you can freeze the AI reference for a defined area (that is, dead-band) or ignore a low AI reference caused by possible electromagnetic interference issues.

In voltage mode:

AI dead band value = 10V* AI dead band (12.110) * 0.01

In current mode:

AI dead band value = 20mA* AI dead band (12.110) * 0.01

In addition, 10% of the dead-band value is added as dead-band hysteresis positive and negative. This value is internally set in the firmware and cannot be changed.

AI Hysteresis = AI dead-band value \times 10%

Notes: AI dead-band (12.110) is applicable for both AI1 and AI2.

Example of using dead-band in Al1 (voltage mode)

lf,

12.15 Al1 unit selection = V 12.110 Al dead band = 50 12.18 Al1 max = 0 - 10 V then, Al dead-band value = 10 * 50 * 0.01 = 5 V Al Hysteresis value = 5 * 0.1 = 0.5 V Hysteresis positive value = 5 + 0.5 = 5.5 V Hysteresis negative value = 5 - 0.5 = 4.5 V

When AI1 input voltage increases, up to 5.5 V, the AI1 actual value (12.11) displays zero. After AI1 input voltage reaches 5.5 V, the AI1 actual value displays 5.5 V and continues to display the detected value up to the maximum AI1 value10 V (12.18).

When AI1 input voltage decreases, the AI1 actual value displays the detected value up to 4.5 V. From 4.5 V to zero, the AI1 actual value displays Zero till it reaches 0V.

Example of using dead-band in Al1 (current mode)


If, 12.15 Al1 unit selection = mA 12.110 Al dead band = 50 12.18 Al1 max = 0 - 20 mA then, Al dead-band value = 20 * 50 * 0.01 = 10 mA Al Hysteresis value = 10 * 0.1 = 1.0 mA Hysteresis positive value = 10 + 1.0 = 11.0 mA Hysteresis negative value = 10 - 1.0 = 9.0 mA

When Al1 input voltage increases, up to 11 mA, the Al1 actual value (12.11) displays zero. After Al1 input voltage reaches 11 mA, the Al1 actual value displays 11 mA and continues to display the detected value up to the maximum Al1 value 20 mA (12.18).

When Al1 input voltage decreases, the Al1 actual value displays the detected value up to 9.0 mA. From 9.0 mA to zero, the Al1 actual value displays Zero till it reaches 0V.

See the timing diagram below:

Dead-band function timing diagram



Settings

Parameter 12.110 AI dead band (page 193)

Basic panel home view options

The drive provides 3 basic panel home view screens. The basic panel home view settings allows the user to select the parameters that needs to be displayed in each screen. The basic panel home view 1, 2, and 3 is applied when external control location is EXT 1 (19.11 Ext1/Ext2 selection = EXT 1) and the basic panel home view 4, 5, and 6 is applied when the external control location is EXT 2 (19.11 Ext1/Ext2 selection = EXT 2).

Settings

Parameter 49.19 Basic panel home view 1...49.19 Basic panel home view 1(page 326).

100 Program features

5

Control macros

Contents of this chapter

This chapter describes the intended use, operation and default control connections of the application. Apart from this, it also includes the list of parameter default values for each macro.

The settings and the example referred in this chapter are with respect to the basic control panel. However, you can also perform these actions using the assistant control panel.

Overview

Control macros are set of default parameter values suitable for a certain control configuration. When starting the drive, the user typically selects the best-suited control macro as a starting point and then makes necessary changes to tailor the settings to meet the requirements.

Control macros has the following features:

• Results in a much lower number of user edits compared to the traditional way of programming a drive.

• Allows quick configuration of the drive and enables quick start of the motor. There are two ways of selecting the control macro from the **Main menu** $\equiv \rightarrow$:

 Connection macro I/0 □ → Macro or

• Parameters $p \equiv \rightarrow$ Complete parameter list $\blacksquare \rightarrow$ parameter 96.04 Notes:

- Scalar control is the default control mode for all macros, except for the macros ABB standard and Pharma.
- If Vector motor control mode is selected, make sure that ID run is performed. See *ID run procedure*.

The control macros are categorized as application macros and communication macros.

Application macros

Application macros set the default parameters needed for certain industrial applications.

The available application macros are:

- ABB standard macro
- ABB standard macro (vector)
- 3-wire macro
- Motor potentiometer macro
- PID macro
- Panel PID macro
- Torque control macro
- Pump and Fan Control (PFC) macro
- Soft Pump and Fan Control (SPFC) macro
- Pharma macro
- Plastic extrusion macro
- Jigar macro

ABB standard macro

ABB standard macro 10 200 is the default macro

The macro has the following features:

- · 2-wire I/O configuration with three constant frequency references
- · Applicable for normal control purpose
- One signal is used to start or stop the motor and another signal is used to select the direction
- Uses scalar control by default.

Note: For vector control you can use the ABB standard (vector) macro (page 105).

1 SCR Signal cable shield (screen) 110 kohm 2 Al1 External frequency reference: 010 V ¹) ⁴) ¹⁰ : see 22.11 3 AGND Analog input circuit, common 4 +10V 10 V DC reference voltage	
110 kohm \downarrow \uparrow \downarrow	
AGND Analog input circuit, common	
4 +10V 10 V DC reference voltage	
5 Al2 Not configured ²⁾	
6 AGND Analog input circuit, common	
$\sim 10^{-1}$	
Max. (2) / x AOT see 13.12	
\bigcirc \land	
9 AGND Analog output circuit common	
8) AGND Analog output circuit common 8) X2, X3 Aux. voltage output and programmable digital input	ts
10 +24V Aux. voltage output +24 VDC, max.	. 250 mA ³⁾
11 DGND Aux. voltage output common	
6) 12 DCOM Digital input common for all	
13 DI1 Stop (0) / Start (1) ¹⁰⁾ : see 20.03	
14 Dl2 Forward (0) / reverse (1) ¹⁰ : see 2	0.03
15 DI3 Constant frequency sel 110) ¹⁰⁾ :	
16 DI4 Constant frequency sel 2 ^{4/10} : se	ee 28.23
17 DI5 Ramp 1 (0) / Ramp 2 (1) ^{5) 9)} : see	28.71
9) 18 DI6 Not configured	
X6, X7, X8 Relay outputs	
19 RO1C Ready Run ¹¹⁾ : see 10.2	4
20 RO1A 250 V AC / 30 V DC	
Running ¹¹): see 10.27	
23 RO2A 250 V AC / 30 V DC	
25 RO3C Fault (-1) ¹¹⁾ : see 10.30)
26 RO3A 250 V AC / 30 V DC	
X5 Built-in fieldbus	
29 B+ Internal Modbus RTU (EIA-485), se	
30 A- control through the embedded field	bus
31 DGND interface (EFB)	
(Frame R0R2)	<u> </u>
S100 TERM&BIAS Termination resistor and bias resist	or switch
(Frame R3R8)	
S100 TERM Termination resistor switch	
S200 BIAS Bias resistor switch	
X4 Safety torque off	n
R0R2 R3R8	
R3R8 33 - OUT1 Safety torque off function. Factory of	connection.
34 SGND OUT2 Both circuits must be closed for the	
35 OUT1 SGND start See Safe forgue off function in	
\sim 36 H^{7} N1 N1 hardware manual	
37 + 37 + 37 INZ INZ	
X10 24 V AC/DC (frames R6R8 only)	
40 24 V AC/DC- in 24V AC/DC input, for control unit po	
41 24 V AC/DC+ in when external main power is discor	
X11 Redundant auxiliary voltage output (frames R0R2	
42 +24 V Aux. voltage output +24 V DC, max	a. ∠50 mA ³⁾
43 DGND Aux. voltage output common 44 DCOM Digital input common for all	
44 DCOM Digital input common for all	

Default control connections for the ABB standard macro

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

¹⁾ Current [0(4)...20 mA, R_{in} < 500 ohm] or voltage [0(2)...10 V, R_{in} > 200 kohm] input as selected with parameter 12.15 Al1 unit selection.

²⁾ Current [0(4)...20 mA, R_{in} = 100 ohm] or voltage [0(2)...10 V, R_{in} > 200 kohm] input as selected with parameter 12.25 Al2 unit selection.

³⁾ Total load capacity of the auxiliary voltage output +24V (X2:10) =

6.0 W (250 mA / 24 V) - User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2-RO3).

⁴⁾ The constant speed are set based on the combination of sources as follows:

Source defined by parameter 28.22	Source defined by parameter 28.23	Constant speed active
0	0	Set speed through AI1
1	0	Constant frequency 1
0	1	Constant frequency 2

⁵⁾ The speed reference ramp is set based on the combination of sources as follows:

DI5	Ramp set	Parameters
parameter 28.71		Scalar control (default)
0	Acc/Dec time 1	28.72 Freq acceleration time 1
		28.73 Freq deceleration time 1
1	Acc/Dec time 2	28.74 Freq acceleration time 2
		28.75 Freq acceleration time 2

⁶ Connected with jumpers at the factory.

⁷⁾ Applicable for R0...R2 frames only.

⁸⁾ Use shielded twisted-pair cables for digital signals.

⁹⁾ Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.

¹⁰⁾ Input signal

¹¹⁾ Output signal

For information on cable connection and drive operation, see *Control Connections* in the *hardware manual (3AXD50000044998)*.

ABB standard macro (vector)

The ABB standard macro (vector) is similar to the ABB standard macro. The ABB standard uses scalar motor control mode where as the ABB standard macro (vector) uses vector control as motor control mode.

Similar to ABB standard macro, ABB standard (vector) has the following features:

- 2-wire I/O configuration with three constant frequency references
- Applicable for normal control purpose
- One signal is used to start or stop the motor and another signal is used to select the direction.

To enable the macro, navigate to:

- Main menu $\equiv \rightarrow$ Connection macro $1/0^{\frac{D}{DD}} \rightarrow 1^{\frac{D}{DD}}_{rpm}$ ABB standard (vector) or
- Main menu $\equiv \rightarrow$ Complete parameter list range parameter 96.04 Macro select \rightarrow [17] ABB standard (vector).

Default control connections for the ABB standard (Vector) macro X1 Reference voltage and analog inputs SCR Signal cable shield (screen) External speed reference: 0...10 V^{1) 4) 8)} ċι AI1 1...10 kohm ٦, see 22.11 3 AGND Analog input circuit, common r' 10 V DC reference voltage 4 +10V i. Not configured 2) AI2 . 6 AGND Analog input circuit, common Output frequency. 0...20 mA⁹⁾: AO1 Max. see 13.12 500 ohm Motor current. 0...20 mA⁹⁾: 8 AO2 see 13.22 e¹ 9 AGND Analog output circuit common 7) - X2. X3 Aux. voltage output and programmable digital inputs Aux. voltage output +24 VDC, max. 250 mA³⁾ +24V 10 DGND Aux. voltage output common 11 5) 12 DCOM Digital input common for all 13 DI1 Stop (0) / Start (1): see 20.03 14 DI2 Forward (0) / reverse (1): see 20.03 Constant speed sel 1 4) 8): see .22.22 DI3 15 Constant speed sel 2 4) 8); see 22.23 16 DI4 Ramp 1 (0) / Ramp 2 (1)^{5) 8)}: see 23.11 17 DI5 DI6 Not configured 18 X6, X7, X8 Relay outputs RO1C Ready Run⁹⁾: see 10.24 250 V AC / 30 V DC 20 RO1A 1 2 A RO1B Running⁹⁾: see. 10.27 250 V AC / 30 V DC RO2C RO2A 2 A RO2B 24 Fault(-1)9); see. 10.30 RO3C 26 RO3A 250 V AC / 30 V DC RO3B 2 A X5 Built-in fieldbus 29 B+ Internal Modbus RTU (EIA-485), see Fieldbus 30 Acontrol through the embedded fieldbus DGND interface (EFB) 31 (Frame R0...R2) TERM&BIAS Termination resistor and bias resistor switch S100 (Frame R3...R8) TERM Termination resistor switch S100S200 BIAS Bias resistor switch Safety torque off X4 R0...R2 R3...R8 33 OUT1 R3...R8 Safety torque off function. Factory connection. 34 SGND OUT2 Both circuits must be closed for the drive to 35 OUT1 SGND start. See Safe torque off function in the drive ⁶⁾ IN1 36 IN1 hardware manual. ¹⁰⁾ N2 6 37 IN2 X10 24 V AC/DC (frames R6...R8 only) 40 24 V AC/DC- in 24V AC/DC input, for control unit power supply when external main power is disconnected. 24 V AC/DC+ in 41 Redundant auxiliary voltage output X11 42 +24 V Aux. voltage output +24 V DC, max. 250 mA³⁾ 43 DGND Aux. voltage output common DCOM 44 Digital input common for all

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf ft)

Notes

¹⁾ Current [0(4)...20 mA, R_{in} < 500 ohm] or voltage [0(2)...10 V, R_{in} > 200 kohm] input as selected with parameter 12.15 Al1 unit selection.

²⁾ Current [0(4)...20 mA, R_{in} = 100 ohm] or voltage [0(2)...10 V, R_{in} > 200 kohm] input as selected with parameter 12.25 Al2 unit selection.

 $^{(3)}$ Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2-RO3).

⁴⁾ The constant speed are set based on the combination of sources as follows:

Source defined by par.22.22	Source defined by par.22.23	Constant speed active
0	0	Set speed through AI1
1	0	Constant speed 1

⁵⁾ The speed reference ramp is set based on the combination of sources as follows:

DI5	Ramp set	Parameters
		Vector control (default)
0	1	23.12 Acceleration time 1
		23.13 Deceleration time 1
1	2	23.14 Acceleration time 2
		23.15 Deceleration time 2

⁶⁾ Connected with jumpers at the factory.

⁷⁾ Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.

⁸⁾ Input signal

⁹⁾ Output signal

¹⁰⁾ For R0...R2 frames only

For information on cable connection and drive operation, see *Control Connections* in the *hardware manual (3AXD50000044998)*.


3-wire macro

This macro is used when the drive is controlled using momentary push-buttons. It provides three constant speeds. To enable the macro, select it in the **Primary settings** menu or set parameter 96.04 *Macro select* to 3-wire.

To enable the macro, navigate to:

• Main menu $\equiv \rightarrow$ Connection macro $1/0 \xrightarrow{\square}{\square} \rightarrow \bigcirc \bigcirc$ 3-wire macro or

Main menu $\equiv \rightarrow$ Complete parameter list representation parameter 96.04 *Macro select* \rightarrow [17] 3-wire.



Terminal sizes:

- (frames R0...R8: 0.14...1.5 mm² (all terminals)
- Tightening torgues: 0.5...0.6 N·m (0.4 lbf·ft)

Notes:

- ¹⁾ All is used as a speed reference if vector control is selected.
- ²⁾ In scalar control (default): See Menu Primary settings Start, stop, reference Constant frequencies or parameter group 28 Frequency reference chain. In vector control: See Menu - Primary settings - Start, stop, reference - Constant speeds

or parameter group	22	Speed	reference	selection.
--------------------	----	-------	-----------	------------

DI4	DI5	Operation/Parameter					
		Scalar control (default)	Vector control				
0	0	Set frequency through Al1	Set speed through AI1				
1	0	28.26 Constant frequency 1	22.26 Constant speed 1				
0	1	28.27 Constant frequency 2	22.27 Constant speed 2				
1	1	28.28 Constant frequency 3	22.28 Constant speed 3				

- ³⁾ Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.
- ⁴⁾ Connected with jumpers at the factory.
- ⁵⁾ Only frames R6...R11 have terminals 40 and 41 for external 24 V AC/DC input.
- ⁶⁾ Select voltage or current for inputs AI1 and AI2 and output AO1 with parameters <u>12.15</u>, <u>12.25</u> and 13.15, respectively.
- ⁷⁾ Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA /24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2~RO3). ⁸⁾ Input signal
- ⁹⁾ Output signal

Input signals

- Analog speed/frequency reference (AI1)
- Start, pulse (DI1)
- Stop. pulse (DI2)
- Direction selection (DI3)
- Constant speed/frequency selection (DI4, DI5) ٠

Output signals

- Analog output AO1: Output frequency •
- Analog output AO2: Motor current
- Relay output 1: Ready run •
- Relav output 2: Running
- Relav output 3: Fault (-1)

Motor potentiometer macro

The motor potentiometer macro can be used to adjust the speed of the motor with two-push buttons or with PLCs that change the speed of the motor using two digital signals.

The source for the digital signals, used to increase the values, can be selected by parameters 22.73 *Motor potentiometer up source* and 22.74 *Motor potentiometer down source*.


When enabled by 22.71 *Motor potentiometer function*, the motor potentiometer assumes the value set by 22.72 *Motor potentiometer initial value*. Depending on the mode selected in 22.71, the motor potentiometer value is either retained or reset over a power cycle.

The time to increase the speed from the minimum (22.76 *Motor potentiometer min value*) to the maximum (22.77 *Motor potentiometer max value*) is defined in the parameter 22.78 *Motor potentiometer ramp up*.

The time to decrease the speed from the maximum (22.77 *Motor potentiometer max value*) value to the minimum (22.76 *Motor potentiometer min value*) value is defined in the parameter 22.79 *Motor potentiometer ramp down*.


If the up and down signals are simultaneously on, the motor potentiometer value does not change.

The output of the function is shown by 22.80 *Motor potentiometer ref act*, which can directly be set as the reference source in the main selector parameters, or used as an input by other source selector parameters, both in scalar and vector control.




The following example shows the behavior of the motor potentiometer value.

Parameters 22.73 *Motor potentiometer up source* and 22.74 *Motor potentiometer down source* control speed or frequency from zero to maximum speed or frequency.



The running direction can be changed with parameter 20.04 Ext1 in2 source. See the following example.

Parameters 22.73 *Motor potentiometer up source* and 22.74 *Motor potentiometer down source* control speed or frequency from zero to maximum speed or frequency. The running direction can be changed with parameter 20.04 *Ext1 in2 source*. See the following example.



To enable the macro, navigate to:

- Main menu $\equiv \rightarrow$ Connection macro $1/0^{\Box}_{10} \rightarrow 1^{\odot}_{3+4-}$ Motor potentiometer or
- Main menu ≡ → Complete parameter list e= parameter 96.04 Macro select → [13] Motor potentiometer.

X1 Reference voltage and analog inputs and outputs SCR Signal cable shield (screen) 2 Al1 Not configured 1...10 kohm 3 AGND Analog input circuit, common 4 +10V 10 V DC reference voltage 5 Not configured Al2 6 AGND Analog input circuit, common Max. A01 Output frequency: 0...20 mA⁶): see 13.12 7 500 ohm 8 AO2 Motor current: 0...20 mA⁶⁾: see 13.22 9 AGND Analog output circuit common 3) X2. X3 Aux, voltage ou tput and programmable digital inputs Aux. voltage output +24 VDC, max. 250 mA²⁾ 10 +24V DGND Aux. voltage output common 11 4) Digital input common for all 12 DCOM Stop (0) / Start (1)⁵⁾: see 20.03 13 DI1 14 DI2 Forward (0) / reverse (1)⁵⁾: see 20.03 15 DI3 Reference up ^{1) 5)}: see 22.73 Reference down¹⁾⁵⁾: see 22.74 DI4 16 Constant frequency⁵⁾:see 28.22 17 DI5 Run enable (if 0, drive stops)⁵⁾: see 20.12 18 DI6 X6,X7, X8 Relay outputs RO1C Ready run⁶⁾; see 10.24. RO1A 250 V AC / 30 V DC 21 RO1B 2 A Running⁶⁾: see 10.27. 250 V AC / 30 V DC RO2C RO2A 2 A RO2B Fault (-1)⁶⁾: see 10.30. RO3C 250 V ÁC / 30 V DC RO3A RO3B 2 A X5 Built-in fieldbus 29 Internal Modbus RTU (EIA-485), See Fieldbus B+ 30 Acontrol through the embedded fieldbus interface 31 DGND (EFB). (Frame R0...R2) TERM&BIAS S100 Termination resistor and bias resistor switch (Frame R3...R8) TERM Termination resistor switch S100 S200 BIAS Bias resistor switch Safety torque off X4 R0...R2 R3...R OUT1 33 -R3...R8 Safety torque off function. Factory connection. SGND OUT2 34 Both circuits must be closed for the drive to start. OUT1 4 35 SGND See Safe torgue off function in the drive IN1 36 7) IN1 hardware manual. 4) 4) IN2 37 IN2 24 V AC/DC (frames R6...R8 only) X10 24 V AC/DC- in 24V AC/DC input, for control unit power supply 40 24 V AC/DC+ in when external main power is disconnected. 41 X11 Redundant auxiliary voltage output (frames R0...R2) +24 V Aux. voltage output +24 V DC, max. 250 mA²⁾ 42 43 DGND Aux. voltage output common 44 DCOM Digital input common for all

Default control connections for the ABB potentiometer macro

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf ft)

Notes

¹⁾ If DI3 and DI4 are both active or inactive, the frequency/speed reference is unchanged.

The existing frequency/speed reference is stored during stop and power down.

²⁾ Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2~RO3).

³⁾ Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.

⁴⁾ Connected with jumpers at the factory.

- ⁵⁾ Input signal
- ⁶⁾ Output signal
- ⁷⁾ For R0...R2 frames only

In addition, below input is automatically set as follows:

No.	Name (Input/Setting)	Value
23.11	Ramp set selection	0 = Acc/Dec time 1

For information on cable connection and drive operation, see *Control Connections* in the *Hardware manual (3AXD50000044998)*.

PID macro

The PID macro is suitable for applications where the drive is always controlled by PID and the reference comes from analog input AI1.

To enable the macro, navigate to:

- Main menu $\equiv \rightarrow$ Connection macro $1/0 \xrightarrow{D}{\Box \Box} \rightarrow$ PID or
- Main menu $\equiv \rightarrow$ Complete parameter list parameter 96.04 Macro select \rightarrow [14] PID.

Default control connections for the ABB PID macro					
	X1	Reference volta	ge and analog inputs and outputs		
~	1	SCR	Signal cable shield (screen)		
110 kohm	2	Al1	External PID reference: 010V 7): see 40.16.		
<u>++++</u>	3	AGND	Analog input circuit, common		
	4	+10V	10 V DC reference voltage		
	5	Al2	PID feedback: 420mA ^{1) 7)} : see 40.08		
	6	AGND	Analog input circuit, common		
Max.	7	AO1	Output frequency: 020 mA ⁸⁾ : see 13.12		
500 ohm	8	AO2	Motor current: 020 mA ⁸⁾ : see 13.22		
	9	AGND	Analog output circuit common		
4) -	X2, X3	Aux. voltage out	tput and programmable digital inputs		
	10	+24V	Aux. voltage output +24 VDC, max. 250 mA ⁶⁾		
	= 11	DGND	Aux. voltage output common		
5)	12	DCOM	Digital input common for all		
	13	DI1	Stop (0) / Start (1) PID: see 20.03		
	14	DI2	Internal setpoint 1 ^{3) /)} : see 40.19.		
	15	DI3	Internal setpoint 2 ^{3) /)} : see40.20.		
	16	DI4	Constant frequency 1 ^{2) /)} : see 28.26.		
	17	DI5	Run enable (if 0, drive stops) ⁽¹⁾ : see 20.12		
	18	DI6	Not configured		
	X6,X7, X8	Relay outputs	<u> </u>		
	19	R01C	Ready run ⁸⁾ : see 10.24. 250 V AC / 30 V DC		
14	20	RO1A	250 V AC / 30 V DC		
	21	RO1B	2 A		
	22	RO2C	Running ⁸⁾ : see 10.27.		
X	23	RO2A	250 V ĂC / 30 V DC		
	24	RO2B	L 2A		
	25	RO3C	Fault (-1) ⁸⁾ : see 10.30.		
14	26	RO3A	250 V AC / 30 V DC		
	27	RO3B	LN 2A		
	X5	Built-in fieldbus			
	29	B+	Internal Modbus RTU (EIA-485). See Fieldbus		
	30	A-	control through the embedded fieldbus interface		
	31	DGND	(EFB).		
	(Frame R0	R2)			
	S100	TERM&BIAS	Termination resistor and bias resistor switch		
	(Frame R3	R8)			
	S100	TERM	Termination resistor switch		
	S200	BIAS	Bias resistor switch		
	X4	Safety torque of	f		
		R0R2 R3R			
R3R8	33	- OUT1	Safety torque off function. Factory connection.		
	- 34	SGND OUT2	Both circuits must be closed for the drive to start.		
5)	35	OUT1 SGND	See Safe torgue off function in the drive		
5)	36	⁻⁹⁾ IN1 IN1	hardware manual.		
5)	37	⁵⁾ IN2 IN2			
	X10	24 V AC/DC (fr	ames R6R8 only)		
	40 24 V AC/DC- in 24V AC/DC input, for control unit power supply				
	41 24 V AC/DC+ in when external main power is disconnected.				
	X11		liary voltage output (frames R0R2)		
	42	+24 V	Aux. voltage output +24 V DC, max. 250 mA ⁶⁾		
	43	DGND	Aux. voltage output common		
	44	DCOM	Digital input common for all		

Default control connections for the ABB PID macro

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf ft)

Notes

¹⁾ The signal source is powered externally. See the manufacturer's instructions. To use sensors supplied by the drive aux. voltage output, see chapter *Electrical installation*, section *Connection examples of two-wire and three-wire sensors* in the *Hardware manual* of the drive

²⁾ If Constant frequency is activated it overrides the reference from the PID controller output.

³⁾ The internal setpoint are set based on the combination of sources as follows:

Source defined by par. <i>40.19</i> DI2	Source defined by par. <i>40.20</i> DI3	Internal setpoint active
0	0	Setpoint source: Al1
1	0	Set 1 internal setpoint 1
0	1	Set 1 internal setpoint 2
1	1	Set 1 internal setpoint 3

⁴⁾ Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.

⁵⁾ Connected with jumpers at the factory.

⁶⁾ Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2-RO3).

⁷⁾ Input signal

⁸⁾ Output signal

⁹⁾ For R0...R2 frames only

In addition, below inputs are set automatically as follows:

Parameter No.	Name (Input/Setting)	Value	
20.01	Ext1 commands	1= In1 Start	
23.11	Ramp set selection	0 = Acc/Dec time 1	

For information on cable connection and drive operation, see *Control Connections* in the *Hardware manual (3AXD50000044998)*.

Panel PID macro

The panel PID macro is suitable for applications where the drive is always controlled by a PID controller and the setpoint is defined with the control panel.

To enable the macro, navigate to:

- Main menu $\equiv \rightarrow$ Connection macro $1/0^{\frac{1}{10}} \rightarrow$ Panel PID \bowtie or
- Main menu $\equiv \rightarrow$ Complete parameter list parameter 96.04 Macro select \rightarrow [15] Panel PID.

	X1	Referen	ce volta	ge and analog inputs and outputs
·	1	SC		Signal cable shield (screen)
110 kohm	2	A		Not configured ⁶⁾
	3	AG		Analog input circuit, common
	4	+1		10 V DC reference voltage
	5	A	-	PID feedback, 420mA ^{1) /)} : see 40.08
	6	AG		Analog input circuit, common
Max.	7	AC		Output frequency, 020 mA ⁸⁾ : see 13.12
500 ohm	8	AC		Motor current, 020 mA ⁸): see 13.22
	9	AG		Analog output circuit common
3)	X2, X3			tput and programmable digital inputs
·	10	+24		Aux. voltage output +24 VDC, max. 250 mA ⁵⁾
	11	DG	ND	Aux. voltage output common
4)	12	DC		Digital input common for all
	13	D		Stop (0) / Start (1) PID ⁷ : see 20.03
	14	D		Not configured
	15	D		Not configured
	16	D	-	Constant frequency 1 ^{2) 7)} : see 28.26
	17	D		Run enable (if 0, drive stops) ⁷ : see 20.12
	18	D	-	Not configured
	X6,X7, X8	Relay or		Not conligated
	19	RO		Ready run ⁸⁾ : see 10.24
1	20	RO		250 V AC / 30 V DC
	20	RO		
	21			Running ⁸⁾ : see 10.27
		RO		250 V AC / 30 V DC
	23 24	RO		
		RO		
	25	RO		Fault $(-1)^{8}$: see 10.30
Lűr	26	RO		250 V AC / 30 V DC 2 A
	27	RO		
	X5	Built-in		
	29	В		Internal Modbus RTU (EIA-485). Internal
	30	A		Modbus RTU (EIA-485). See Fieldbus control
	31	DG	ND	through the embedded fieldbus interface (EFB).
	(Frame R0.			Tee
	S100	TERM	&BIAS	Termination resistor and bias resistor switch
	(Frame R3.			Tomain sting an eleter south (
	S100	TEI		Termination resistor switch
	S200	BIA		Bias resistor switch
	X4		orque of	
	20	R0R2		
R3R8	33	-	OUT1	
ГТ	34	SGND	OUT2	Both circuits must be closed for the drive to start
	35		SGND	See Safe torque off function in the drive
4)	36	⁹⁾ IN1	IN1	hardware manual
.)	37	4) IN2	IN2	
	X10			rames R6R8 only)
	40		/DC- in	
	41			when external main power is disconnected.
	X11			iliary voltage output (frames R0R2)
	42	+24		Aux. voltage output +24 V DC, max. 250 mA ⁵⁾
	43	DG		Aux. voltage output common
	44	DC	OM	Digital input common for all

Default control connections for the Panel PID macro

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

¹⁾ The signal source is powered externally. See the manufacturer's instructions. To use sensors supplied by the drive aux. voltage output, see chapter Electrical installation, section *Connection examples* of two-wire and three-wire sensors in the Hardware manual of the drive.

²⁾ If Constant frequency is activated it overrides the reference from the PID controller output.

³⁾ Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.

⁴⁾ Connected with jumpers at the factory.

 $^{5)}$ Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2-RO3).

⁶⁾ PID setpoint is from control panel reference

⁷⁾ Input signal

⁸⁾ Output signal

⁹⁾ For R0...R2 frames only

In addition, below inputs are set automatically as follows:

Parameter No.	Name (Input/Setting)	Value	
20.01	Ext1 commands	1= In1 Start	
23.11	Ramp set selection	0 = Acc/Dec time 1	

For information on cable connection and drive operation, see *Control Connections* in the *Hardware manual (3AXD50000044998)*.

Torque control macro

This macro is used in applications in which torque control of the motor is required. These are typically tension applications, where a particular tension needs to be maintained in the mechanical system.

Torque reference is given through analog input Al2, typically as a current signal in the range of 0...20 mA (corresponding to 0...100% of rated motor torque).

The start/stop signal is connected to digital input DI1. The direction is determined by DI2. Through digital input DI3, it is possible to select speed control (EXT1) instead of torque control (EXT2). As with the PID control macro, speed control can be used for commissioning the system and checking the motor direction.

It is also possible to change the control to local (control panel or PC tool) by pressing the Loc/Rem key. By default, the local reference is speed; if a torque reference is required, the value of parameter 19.16 Local control mode should be changed to Torque.

A constant speed (by default, 300 rpm) can be activated through DI4. DI5 switches between acceleration/deceleration time sets 1 and 2. The acceleration and deceleration times are defined by parameters 23.12...23.15.

Xi Reference voltage and analog inputs 110 kolm Signal cable shield (screen) 2 A11 3 AGND 4 +10V 1 3 4 +10V 5 Al2 1 Torque reference: 0 4 +10V 5 Al2 1 Torque reference: 4 6 AGND Analog input dircuit, common Max. Motor speed used: 020 mA ³ : 8 AO2 9 Aux. voltage output and programmable digital inputs 10 +24V Aux. voltage output and programmable digital inputs 11 DGND 12 DCOM 13 Dif 14 Di2 15 01 15 01 10 +24V 11 DGRU analogi output common for all 12 DCOM 14 Di2 15 Di6 14 Di2 15 Di6 <	Default of the second secon	control c	onnecti	ctions for the Torque control macro					
110 kohm 1 SCR Signal cable shield (screen) 110 kohm 2 Al1 External speed reference: 010 V ^{11,418}); see 22.11 3 AGND Analog input circuit, common 4 +10V 10 V DC reference voltage 5 Al2 Torque reference? 6 AGND Analog input circuit, common 7 AO1 Motor speed used: 020 mA ³); see 13.12 500 ohm 7 AO1 Ack voltage output and programmable digital inputs 10 +24V Aux. voltage output and programmable digital inputs 11 DGND Aux. voltage output common 10 12 DCOM Digital input common for all 11 13 DI1 Stop (0) / Start (1) 10 14 DI2 Forward (0) / Reverse (1) 10 14 DI2 Forward (0) / Start (1) 10 16 DI4 Constant speed 1 (1 = On) 24 17 DI5 Acc/Dc time st (10) / star (21) 10 18 DI6 Run enable (1 = On) 24 20 RO1A 250 V AC / 30									
110 kolm		~ —	- 1						
Max. 500 ohm Max. 500 ohm	110 kohm		- 2	A	N1				
Max. 4 +10V 10 V DC reference 2 ¹⁰ 6 AGND Analog input circuit.common Motor speed used: 020 mA ⁹ : 5 500 ohm 7 AO1 8 AO2 Motor current: 020 mA ⁹ : 9 AGND Analog output and programmable digital inputs 9 AGND Analog output and programmable digital inputs 10 +24V Aux. voltage output and programmable digital inputs 11 DGND Aux. voltage output and programmable digital inputs 11 DGND Aux. voltage output and programmable digital inputs 11 DGND Aux. voltage output on for all 12 DCOM Digital input common 13 D11 Stop (0) / Start (1) 14 D12 Forward (0) / Reverse (1) 15 D13 Speed control (0) / sec 10.24 20 RO1A 250 V AC / 30 V DC 21 RO1B 24 20 22 RO2A 24 20 23 RO2A 250 V AC / 30 V DC 24 RO2A 24 24 <tr< th=""><th>┍└┙┾</th><th></th><td>3</td><td>AG</td><td>GND</td><td></td><td></td></tr<>	┍└┙┾		3	AG	GND				
Max. 500 ohm 5 5 6 6 6 6 6 6 7 7 6 7 7 7 7 7 7 7 7 7		<u> </u>	- 4	+1	10V	10 V DC reference voltage			
Max. 500 chm			5	A	12	Torq	ue reference 2)		
Max. See (3.12) 500 ohm AC1 see (3.22) 9 AGND Analog output circuit common 9 AGND Analog output circuit common 9 AGND Aux. voltage output ad programmable digital input common 9 Aux. voltage output ad programmable digital input common 10 +24V Aux. voltage output ad programmable digital input common 11 DGND Aux. voltage output ad programmable digital input common 14 D12 Forward (0) / Reverse (1) 15 D13 Speed control (0) / Torque control (1) 16 D14 Constant speed 1 (1 = On) 17 D15 Acc/Dec time set (10) / set 2(1) 18 D16 Run enable (1 = On) 24 RO2A 250 V AC / 30 V DC 23 RO2A 250 V AC / 30 V DC 24 RO2B Fault (1) ⁰ ; see (10.27) 25 RO3A 250 V AC / 30 V DC 24 RO2B 2A 25 RO3A 250 V AC / 30 V DC 26 RO3A			6	AG	GND	Anal	og input circuit, common		
500 ohm 8 AC2 Motor current: 020 mA ⁹ : see 13.22 9 AGND Analog output circuit common 5) ¹ 2, X3 Aux. voltage output 24 VDC, max.250 mA ³ ? 11 DGND Aux. voltage output 24 VDC, max.250 mA ³ ? 11 DGND Aux. voltage output 24 VDC, max.250 mA ³ ? 11 DGND Aux. voltage output 24 VDC, max.250 mA ³ ? 11 DGND Aux. voltage output 24 VDC, max.250 mA ³ ? 12 DCOM Digital input common for all 12 DCOM Digital input common for all 13 DI1 Stop (0) / Start (1) 14 DI2 Forward (0) / Reverse (1) 15 DI3 Speed control (0) / set 2(1) 16 DI4 Constant speed 1 (1 = On) X6, X7, X8 Relay outputs Ready run ⁹ : see. 10.24 20 RO1A 26 VAC / 30 V DC 21 RO2A 250 VAC / 30 V DC 22 RO2A 250 VAC / 30 V DC 23 RO2A 20 VAC / 30 V DC 24 RO3C		/ *	7	А	01				
9 AGND Analog output circuit common 5) 42, X3 Aux. voltage output and programmable digital inputs 10 +24 V Aux. voltage output +24 VDC, max. 250 mA ³⁷ 11 DGND Aux. voltage output +24 VDC, max. 250 mA ³⁷ 12 DCOM Digital input common for all 13 D11 Stop (0) / Start (1) 14 D12 Forward (0) / Reverse (1) (2) 16 D14 Constant speed 1 (1 = 0n) 17 D15 Acc/Dec time set 1(0) / set 2(1) 18 D16 Run enable (1 = 0n) X6, X7, X8 Relay outputs 26 VAC / 30 VDC 21 RO1C Ready run ⁹ : sec. 10.24 20 RO1A 250 VAC / 30 VDC 22 RO2C Running ⁹ : sec. 10.30 24 RO2B 2A 25 RO3C Fault (1) ⁹ : sec. 10.30 26 RO3A 250 VAC / 30 VDC 27 RO3B 2A 29 B+ Internal Modbus RTU (EIA-485), see Fieldbus 30 A control through the embedded fieldbus 31 DGND <th>500 ohm └──</th> <th>~ .</th> <td>8</td> <td>A</td> <td>02</td> <td>Mot</td> <td>or current: 020 mA⁹⁾:</td>	500 ohm └──	~ .	8	A	02	Mot	or current: 020 mA ⁹⁾ :		
s) * X2, X3 Aux. voltage output and programmable digital inputs 10 +24V Aux. voltage output +24 VDC, max. 250 mA ³) 11 DGND Aux. voltage output common for all 12 DCOM Digital input common for all 13 DI1 Stop (0) / Start (1) 14 DI2 Forward (0) / Reverse (1) 15 DI3 Speed control (0) / Torque control (1) 16 DI4 Constant speed 1 (1 = On) X6, X7, X8 Relay outputs 19 RO1C Ready run ⁹ ; see. 10.24 20 RO1A 250 VAC/ 30 VDC 21 RO1B 2A 22 RO2C Running ⁹ ; see. 10.27 23 RO2A 250 VAC / 30 VDC 24 RO2B 2A 250 VAC / 30 VDC 26 RO3A 250 VAC / 30 VDC 27 RO3B 2A 26 RO3A 250 VAC / 30 VDC 27 RO3B 2A 28 RO3A 250 VAC / 30 VDC 29 B+ Internat Modbus RTU (EIA-485), see Fieldbus control through the embedded fieldbus 19 TERM&BIAS Termination resistor and bias resistor switch (Frame R3R8) R3R8 R3R8 R3R8 R3R8 R3R8 R3R8 R3R8 R3R8 R3R8 R3R8 R3R8 R3	U	/	- 9	AG	SND				
10 +24V Aux. voltage output 2 VDC, max. 250 mA ^{3/} 11 DGND Aux. voltage output common 12 DCOM Digital input common for all 13 D11 Stop (0) / Start (1) 14 D12 Forward (0) / Reverse (1) 15 D13 Speed control (0) / Torque control (1) 16 D14 Constant speed 1 (1 = On) 17 D15 Acc/Dec time set 1(0) / set 2(1) 18 D16 Run enable (1 = On) X6, X7, X8 Relay outputs Ready run ⁹ ; see. 10.24 20 RO1C Ready run ⁹ ; see. 10.27 21 RO2A 24 RO2A 22 RO2C Running ¹⁰ ; see. 10.27 23 RO2A 250 V AC / 30 V DC 24 RO2B 24 25 RO3C Fault (-19 ¹⁰ ; see. 10.30 26 RO3A 250 V AC / 30 V DC 27 RO3B 24 29 B+ Internal Modbus RTU (EIA-485), see Fieldbus control through the embedded fieldbus interface (EFB)	~	′ ₅₎ ≟ ■	X2. X3	Aux, vol	tage outp				
11 DGND Aux. voltage output common 41 12 DCOM Digital input common for all 13 D11 Stop (0) / Start (1) 14 D12 Forward (0) / Reverse (1) 15 D13 Speed control (0) / Torque control (1) 16 D14 Constant speed 1 (1 = On) 17 D15 Acc/Dec time set 1(0) / set 2(1) 18 D16 Run enable (1 = On) X6, X7, X8 Relay outputs Ready run ⁹ ; see. 10.24 20 RO1A 250 V AC / 30 V DC 21 RO1B ZA 22 RO2A 250 V AC / 30 V DC 23 RO2A 250 V AC / 30 V DC 24 RO2B ZA 25 RO3C Fault (-19): see. 10.30 26 RO3A 250 V AC / 30 V DC 27 RO3B ZA 29 B+ Internal Modbus RTU (EIA-485), see Fieldbus 30 A control through the embedded fieldbus 31 DGND interface (EFB) <		•,							
4) 12 DCOM Digital input common for all 13 Di1 Stop (0) / Start (1) 14 Di2 Forward (0) / Reverse (1) 15 Di3 Speed control (0) / Torque control (1) 16 Di4 Constant speed 1 (1 = On) 17 Di5 Acc/Dec time set (10) / set 2(1) 18 Di6 Run enable (1 = On) X6, X7, X8 Relay outputs 20 RO1C Ready run ⁹ : see. 10.24 20 RO1A 25 V AC / 30 V DC 21 RO1B 2 A 22 RO2C Running ⁹ : see. 10.27 23 RO2A 25 V AC / 30 V DC 24 RO2B 2 A 25 RO3C Fault (-1) ⁹ : see. 10.30 26 RO3A 26 V AC / 30 V DC 27 RO3B 2 A 29 B+ Internal Modbus RTU (EIA-485), see Fieldbus 30 A control through the embedded fieldbus 31 DGND Termination resistor switch 5100 TERM&BIAS Termination resistor switch 520	,					Aux.	voltage output common		
13 Dif Stop (0) / Start (1) 14 Dif Stop (0) / Start (1) 16 Dif Speed control (0) / Forque control (1) 16 Dif Constant speed 1 (1 = On) 17 Dif Acc/Dec time set 1(0) / set 2(1) 18 Dif Ready run ⁹ : see. 10.24 20 RO1A 2A 20 RO1A 2A 20 RO1A 2A 21 RO1B 2A 22 RO2C Running ⁹ : see. 10.27 23 RO2A 250 VAC / 30 VDC 24 RO2B 2A 25 RO3C Fault (-1) ⁹ : see. 10.30 26 RO3A 250 VAC / 30 VDC 29 B+ Internal Modbus RTU (EIA-485), see <i>Fieldbus</i> 30 A- control through the embedded fieldbus 31 DGND interface (EFB) (Frame R3R8) Bias resistor switch 20 BAS Bias resistor switch 33 OUT1 Safety torque off		4)				Diait	al input common for all		
14 Dl2 Forward (0) / Reverse (1) 15 Dl3 Speed control (0) / Torque control (1) 16 Dl4 Constant speed 1 (1 = On) 17 Dl5 Acc/Dec time set 1(0) / set 2(1) 18 Dl6 Run enable (1 = On) X6, X7, X8 Relay outputs 19 RO1C Ready run ⁹): see. 10.24 20 RO1A 250 VAC / 30 VDC 21 RO1B 24 22 RO2C Running ⁹): see. 10.27 23 RO2A 250 VAC / 30 VDC 24 RO2B 2 A 25 RO3C Fault (-1) ⁹): see. 10.30 26 RO3A 250 VAC / 30 VDC 27 RO3B 2 A 30 A control through the embedded fieldbus 31 DGND interface (EFB) (Frame R3R2) Sitoo TERM&BIAS S100 TERM Termination resistor switch S20 Bias resistor switch 34 SGND OUT1 35									
15 DI3 Speed control (0) / Torque control (1) 16 DI4 Constant speed 1 (1 = On) 17 DI5 Acc/Dec time set 1(0) / set 2(1) 18 DI6 Run enable (1 = On) X6, X7, X8 Relay outputs Particular 19 RO1C Ready run ⁹): see. 10.24 20 RO1B 2A 21 RO1B 2A 22 RO2C Running ⁹ : see. 10.27 23 RO2A 250 V AC / 30 V DC 24 RO2B 2A 25 RO3C Fault (-1) ⁹ : see. 10.30 26 RO3A 250 V AC / 30 V DC 27 RO3B 2A 29 B+ Internal Modbus RTU (EIA-485), see Fieldbus 30 A control through the embedded fieldbus 31 DGND interface (EFB) (Frame R0R2) Safety torque off R0R2 S100 TERM Termination resistor switch Safety torque off function, Factory connection. 80 DUT1 Safety torque off function									
16DI4Constant speed 1 (1 = 0n)17DI5Acc/Dec time set 1(0) / set 2(1)18DI6Run enable (1 = 0n)X6, X7, X8Relay outputs19RO1CReady run ⁹): see. 10.2420RO1A250 V AC / 30 V DC21RO1B2 A22RO2CRunning ⁹): see. 10.2723RO2A250 V AC / 30 V DC24RO2B2 A25RO3CFault (-1) ⁹): see. 10.3026RO3A250 V AC / 30 V DC27RO3B2 A28RO2A250 V AC / 30 V DC29B+Internal Modbus RTU (EIA-485), see Fieldbus30A-control through the embedded fieldbus31DGNDTERM&BIAS31DGNDTERM&BIASS100TERM Termination resistor and bias resistor switchS200BIASBias resistor switchS200BIASBias resistor switch33OUT1Safety torque off4)37Jei N24)24 V AC/DC in4)24 V AC/DC (rames R6R8 only)4024 V AC/DC (rin4124 V AC/DC (rin42+24 V43DGND43DGND44ColDC + in45AC/DC input46-20 VIT147Aux. voltage output +24 V DC, max. 250 mA ³⁷									
17 DI5 Acc/Dec time set 1(0) / set 2(1) 18 DI6 Run enable (1 = On) X6, X7, X8 Relay outputs 19 RO1C Ready run ⁹ : see. 10.24 20 RO1A 250 V AC / 30 V DC 21 RO1B 2 A 22 RO2C Running ⁹ : see. 10.27 23 RO2A 250 V AC / 30 V DC 24 RO2B 2 A 25 RO3C Fault (-1) ⁹ : see. 10.30 26 RO3A 250 V AC / 30 V DC 27 RO3B 2 A X5 Built-in fieldbus 2 A 29 B+ Internal Modbus RTU (EIA-485), see <i>Fieldbus</i> 30 A- control through the embedded fieldbus 31 DGND interface (EFB) (Frame R3R8) Safety torque off 83 OUT1 34 SGND 35 -OUT1 36 -OUT1 37 J-i N2 38 OUT1 35									
18 DI6 Run enable (1 = On) X6, X7, X8 Relay outputs 19 RO1C Ready run ⁹): see. 10.24 20 RO1A 250 V AC / 30 V DC 21 RO1B 2A 22 RO2C Running ⁹): see. 10.27 23 RO2A 250 V AC / 30 V DC 24 RO2B 2A 25 RO3A 250 V AC / 30 V DC 26 RO3A 250 V AC / 30 V DC 27 RO3B 2A 29 B+ Internal Modbus RTU (EIA-485), see Fieldbus 30 A control through the embedded fieldbus 31 DGND interface (EFB) (Frame R3R8) Safety torque off S100 TERM Termination resistor switch S200 BIAS Bias resistor switch S200 BIAS Bias resistor switch S1 QUT1 SGND 33 - OUT1 34 SGND OUT2 S100 TERM Termination resistor switch S1 - Safety torque off									
X6, X7, X8 Relay outputs Ready run ⁹ : see. 10.24 19 RO1C 250 V AC / 30 V DC 20 RO1B 2 A 21 RO1B 2 A 23 RO2A 250 V AC / 30 V DC 24 RO2B 2 A 25 RO3C Fault (-1) ⁹ : see. 10.30 26 RO3A 250 V AC / 30 V DC 27 RO3B 2 A 29 B+ Internal Modbus RTU (EIA-485), see Fieldbus 30 A control through the embedded fieldbus 31 DGND interface (EFB) (Frame R3R8) Termination resistor and bias resistor switch S100 TERM&BIAS Termination resistor switch S200 BIAS Bias resistor switch S200 BIAS Bias resistor switch 33 - OUT1 34 SGND OUT2 35 - OUT1 34 SGND OUT2 35 - OUT1 37 <					-				
Image:						Kull	enable (1 – On)		
20 RO1A 250 V AC / 30 V DC 21 RO1B 2A 22 RO2C Running ⁹⁾ : see. 10.27 23 RO2A 250 V AC / 30 V DC 24 RO2B 2A 25 RO3C Fault (-1) ⁹⁾ : see. 10.30 26 RO3A 250 V AC / 30 V DC 27 RO3B 2A 20 Built-in fieldbus 250 V AC / 30 V DC 27 RO3B 2A 30 A- 250 V AC / 30 V DC 31 DGND internal Modbus RTU (EIA-485), see Fieldbus 30 A- control through the embedded fieldbus 31 DGND interface (EFB) (Frame R0R2) S100 TERM Termination resistor switch S100 TERM Termination resistor switch S200 BIAS Bias resistor switch S33 - OUT1 34 SGND Safety torque off function. Factory connection. Both circuits must be closed for the drive to start. See Safe torque off function in the drive to start. See Safe torque off function in the drive to start. See Safe torque off function in the drive to start. See Safe torque off function in the drive to start. See S							\mathbf{B} and $(\mathbf{r}_{1},\mathbf{r}_{2},\mathbf{r}_{3})$, and $(10,24,10$		
21 RO1B 2A 22 RO2C Running ⁹ : see. 10.27 23 RO2A 250 V AC / 30 V DC 24 RO2B 2A 25 RO3C Fault (-1) ⁹ : see. 10.30 26 RO3A 250 V AC / 30 V DC 27 RO3B 2A 29 B+ Internal Modbus RTU (EIA-485), see Fieldbus 30 A- control through the embedded fieldbus 31 DGND interface (EFB) (Frame R3R2) S100 TERM&BIAS S100 TERM Termination resistor and bias resistor switch (Frame R3R8) Bias resistor switch S100 TERM Safety torque off R0R2 33 - OUT1 34 SGND 35 - OUT1 36 - OUT1 37 4) 37 4) 38 - OUT1 Safety torque off function. Factory connection. add choi IN1 IN1 add choi IN1 IN1 37 4) IN2			-						
Note 22 R02C Running ⁹ : see. 10.27 23 R02A 25 VAC / 30 V DC 24 R02B 2A 25 R03C Fault (-1) ⁹ : see. 10.30 26 R03A 250 VAC / 30 V DC 27 R03B 2A 29 B+ Internal Modbus RTU (EIA-485), see Fieldbus 30 A- control through the embedded fieldbus 31 DGND interface (EFB) (Frame R3R8) Termination resistor and bias resistor switch S100 TERM Termination resistor switch S200 BIAS Bias resistor switch S100 TERM Termination resistor switch S200 BIAS Bias resistor switch S100 TERM Safety torque off function. Factory connection. x4 Safety torque off Safety torque off function in the drive to start. See Safe torque off function in the drive to start. See Safe torque off function in the drive to astart. See Safe torque off function in the drive to astart. See Safe torque off function in the drive to astart. See Safe torque off function in the drive to astart. See Safe torque off function in the drive to astart. See Safe torque off function in the drive to astart. See Safe torque off function in the drive to astart. See Safe tor		1				L			
23 RO2A 250 V ÅC / 30 V DC 24 RO2B 2 Å 25 RO3C Fault (-1) ⁹): see. 10.30 26 RO3A 250 V ÅC / 30 V DC 27 RO3B 2 Å 29 B+ Internal Modbus RTU (EIA-485), see Fieldbus 30 A- control through the embedded fieldbus 31 DGND interface (EFB) (Frame R0R2) S100 TERM & Termination resistor and bias resistor switch S200 BIAS Bias resistor switch S100 TERM Termination resistor switch S200 BIAS Bias resistor switch S464 ty torque off R0R2 R3R8 31 -OUT1 Safety torque off function. Factory connection. A0 24 V AC/DC (frames R6R8 only) hardware manual. 40 24 V AC/DC (in 24V AC/DC input, for control unit power suply	ł	┽╬Ĺ▁┠							
24 RO2B 2A 25 RO3C Fault (-1) ⁹): see. 10.30 26 RO3A 250 V AC / 30 V DC 27 RO3B 2A X5 Built-in fieldbus 29 B+ 30 A- control through the embedded fieldbus 30 A- control through the embedded fieldbus 31 DGND 10 TERM&BIAS 100 TERM Termination resistor and bias resistor switch 100 TERM 100 TERM R8. 100 TERM R8. 100 TERM R8. 100 TERM R8. 101 Termination resistor switch 102 Bias resistor switch 101 Safety torque off function. Factory connection. 101 Safety torque off function in the drive to start. See Safe torque off function in the drive to start. See Safe torque off function in the drive hardware manual. 101 24 V AC/DC (frames R6R8 only) 101 24 V AC/DC in 24V AC/DC input, for control unit power supply when external main power is 111 Redundant auxiliary voltage outputt							Running ³⁾ : see. 10.27		
25 R03C Fault (-1) ⁹⁾ : see. 10.30 26 R03A 250 V AC / 30 V DC 27 R03B 2A X5 Built-in fieldbus 30 A- 30 Fault (-1) ⁹⁾ : see. 10.30 30 A- 30 A- 31 DGND interface (EFB) (Frame R0R2) S100 TERM&BIAS S100 TERM Termination resistor and bias resistor switch S200 BIAS Bias resistor switch S4 Safety torque off A4 SGND 33 - 0UT1 Safety torque off function. Factory connection. Both circuits must be closed for the drive to start. See Safe torque off function in the drive hardware manual. 4) 37 40 37 40 10		1							
26 RO3A 250 V ÁC / 30 V DC 27 RO3B 2 A X5 Built-in fieldbus 29 B+ 30 A- control through the embedded fieldbus 31 DGND interface (EFB) (Frame R0R2) S100 TERM&BIAS Termination resistor and bias resistor switch (Frame R3R8) S100 TERM Termination resistor switch S100 TERM S100 TERM S100 TERM S100 TERM S100 TERM S100 TERM S100 Safety torque off function. Factory connection. Safety torque off function. Factory connection. Safety torque off function. Factory connection. Safety torque off function in the	+								
27 RO3B 2 A X5 Built-in fieldbus 29 B+ 30 A- 30 A- control through the embedded fieldbus 31 DGND Interface (EFB) (Frame R0R2) S100 S100 TERM Termination resistor and bias resistor switch S200 Blas S100 TERM Termination resistor switch S200 Blas Safety torque off R3R8 Safety torque off X4 Safety torque off function. Factory connection. Soft corque off function. Factory connection. Both circuits must be closed for the drive to start. See Safe torque off function in the drive to start. See Safe torque off function in the drive hardware manual. X10 AVAC/DC (frames R6R8 only) 40 24 V AC/DC in supply when external main power is X11 <td <="" colspan="2" th=""><th></th><th></th><th></th><th></th><th></th><th></th><th></th></td>	<th></th> <th></th> <th></th> <th></th> <th></th> <th></th> <th></th>								
X5 Built-in fieldbus 29 B+ 30 A- 31 DGND 31 DGND interface (EFB) (Frame R0R2) S100 TERM&BIAS S100 TERM&BIAS (Frame R3R8) S100 TERM S200 BIAS Bias resistor switch S33 - OUT1 S60D OUT2 S61et torque off function. Factory connection. Bold U) IN1 IN1 <th></th> <th>12</th> <th></th> <th></th> <th></th> <th>7</th> <th></th>		12				7			
29 B+ Internal Modbus RTU (EIA-485), see Fieldbus 30 30 A- control through the embedded fieldbus interface (EFB) (Frame R0R2) S100 TERM&BIAS S100 TERM&BIAS Termination resistor and bias resistor switch (Frame R3R8) S100 TERM Termination resistor switch S200 BIAS Bias resistor switch S100 TERM Termination resistor switch S200 BIAS Bias resistor switch S100 TERM Termination resistor switch S200 BIAS Bias resistor switch S100 TERM Termination resistor switch S100 TERM Safety torque off function. Factory connection. Both circuits must be closed for the drive to start. See Safe torque off function in the drive hardware manual. 4) 37 J4) IN2 40 24 V AC/DC (frames R6R8 only) Aux. voltage output 40 24 V AC/DC + in supply when external main power is X11	l	-404					2 A		
30 A- control through the embedded fieldbus interface (EFB) 31 DGND interface (EFB) (Frame R0R2) S100 TERM&BIAS S100 TERM&BIAS Termination resistor and bias resistor switch (Frame R3R8) S100 TERM S100 TERM Termination resistor switch S200 BIAS Bias resistor switch S200 BIAS Bias resistor switch X4 Safety torque off R0R2 R3R8 - OUT1 34 SGND OUT2 35 - OUT1 Sond 36 -to) IN1 IN1 37 J4) IN2 X10 24 V AC/DC (frames R6R8 only) 40 24 V AC/DC - in supply when external main power is X11 Redundant auxiliary voltage output +24 V DC, max. 250 mA ³) 43 DGND Aux. voltage output common									
31 DGND Interface (EFB) (Frame R0R2) S100 TERM&BIAS Termination resistor and bias resistor switch (Frame R3R8) S100 TERM Termination resistor switch S200 BIAS Bias resistor switch S200 BIAS Bias resistor switch X4 Safety torque off R3R8 Given the system 33 OUT1 34 SGND OUT2 35 OUT1 Safety torque off function. Factory connection. Both circuits must be closed for the drive to start. See Safe torque off function in the drive hardware manual. 4) 37 140 IN1 IN1 37 240 IN2 IN2 24V AC/DC input, for control unit power supply when external main power is X11 Redundant auxiliary voltage output 42 +24 V Aux. voltage output 43 DGND Aux. voltage output common				-	-	Inter	nal Modbus RTU (EIA-485), see <i>Fieldbus</i>		
(Frame R0R2) S100 TERM&BIAS Termination resistor and bias resistor switch (Frame R3R8) S100 TERM Termination resistor switch S100 TERM Termination resistor switch S100 TERM Termination resistor switch S100 BIAS Bias resistor switch Safety torque off X4 Safety torque off function. Factory connection. Both circuits must be closed for the drive to start. See Safe torque off function in the drive to start. See Safe torque off function in the drive hardware manual. X10 24 V AC/DC (frames R6R8 only) 40 24 V AC/DC input, for control unit power supply when external main power is X11 Redundant auxiliary voltage output 42 +24 V Aux. voltage output +24 V DC, max. 250 mA ³) 43 DGND Aux. voltage output common			30						
S100 TERM&BIAS Termination resistor and bias resistor switch (Frame R3R8) Termination resistor switch S100 TERM Termination resistor switch S200 BIAS Bias resistor switch S200 BIAS Bias resistor switch S310 TERM Termination resistor switch S200 BIAS Bias resistor switch S4fety torque off R3R8 Bias resistor switch R3R8 S33 OUT1 Safety torque off function. Factory connection. B0th circuits must be closed for the drive to start. See Safe torque off function in the drive to start. See Safe torque off function in the drive hardware manual. 4) 37 1N1 IN1 37 40 IN2 IN2 40 24 V AC/DC (frames R6R8 only) 24 V AC/DC in supply when external main power is X11 Redundant auxiliary voltage output 42 V DC, max. 250 mA ³ 43 DGND Aux. voltage output common			31	DC	GND	inter	face (EFB)		
(Frame R3R8) S100 TERM Termination resistor switch S200 BIAS Bias resistor switch S200 BIAS Bias resistor switch S200 BIAS Bias resistor switch X4 Safety torque off function. Factory connection. SATI SAFETY torque off function. Factory connection. Safety torque off function. Factory connection. SATI SGND OUT2 Safety torque off function. Factory connection. SATI SGND OUT2 SATI Colspan="2">SATI Colspan="2">Colspan="2">Colspan="2">Colspan="2">Colspan="2">Colspan="2">Colspan="2">SATI Colspan="2">Colspan="2" Colspan="2" Colspan="2" Colspan="2" Colspan="2" <th cols<="" th=""><th></th><th>_</th><th>(Frame R0.</th><th></th><th></th><th></th><th></th></th>	<th></th> <th>_</th> <th>(Frame R0.</th> <th></th> <th></th> <th></th> <th></th>		_	(Frame R0.					
S100 TERM Termination resistor switch S200 BIAS Bias resistor switch X4 Safety torque off RoR2 R3R8 R3R8 - OUT1 Safety torque off function. Factory connection. 34 SGND OUT2 Safety torque off function. Factory connection. 4) - - OUT1 SGND OUT2 4) - - - OUT1 SGND Out2 4) - - - OUT1 SGND Out2 Safety torque off function. Factory connection. 4) - - OUT1 SGND OUT2 Safety corque off function. Factory connection. 40 24 V AC/DC (frames R6R8 only) - - - - - 40 24 V AC/DC + in					1&BIAS	Term	nination resistor and bias resistor switch		
S200 BIAS Bias resistor switch X4 Safety torque off R0R2 R3R8 -33 - OUT1 34 SGND OUT2 35 - OUT1 36 - Int 4) - SGND 37 - Int 37 - Int 37 - Int 40 24 V AC/DC (frames R6R8 only) 40 24 V AC/DC - in 24V AC/DC input, for control unit power 41 24 V AC/DC - in supply when external main power is X11 Redundant auxiliary voltage output 42 +24 V Aux. voltage output +24 V DC, max. 250 mA ³) 43 DGND Aux. voltage output common		-	(Frame R3.	R8)					
Safety torque off R3R8 R3R8 R3R8 - OUT1 34 SGND OUT2 35 ¬OUT1 Safety torque off function. Factory connection. 34 SGND OUT2 35 ¬OUT1 SGND 4) 37 J4) IN1 37 J4) IN2 IN2 X10 24 V AC/DC (frames R6R8 only) 40 24 V AC/DC - in 24V AC/DC input, for control unit power 41 24 V AC/DC + in supply when external main power is X11 Redundant auxiliary voltage output 42 +24 V Aux. voltage output +24 V DC, max. 250 mA ³) 43 DGND Aux. voltage output common			S100	TE	RM	Term	nination resistor switch		
R3R8 R0R2 R3R8 R3R8 - 33 - OUT1 34 SGND OUT2 35 - OUT1 Safety torque off function. Factory connection. 4) - 35 - OUT1 37 -40 IN1 40 24 V AC/DC (frames R6R8 only) 40 24 V AC/DC - in 24 V AC/DC - in 24V AC/DC input, for control unit power is X11 Redundant auxiliary voltage output 42 +24 V 43 DGND Aux. voltage output common			S200	B	AS	Bias	resistor switch		
R0R2 R3R8 -33 - OUT1 R3R8 - OUT1 34 SGND OUT2 35 - OUT1 36 - IN1 37 14 IN2 40 24 V AC/DC (frames R6R8 only) 40 24 V AC/DC + in 24V AC/DC + in Supply when external main power is X11 Redundant auxiliary voltage output 42 +24 V 43 DGND		-	¥4	Safety to	orque off				
R3R8 34 SGND OUT2 Safety torque off function. Factory connection. 35 OUT1 SGND Both circuits must be closed for the drive to start. See Safe torque off function in the drive hardware manual. 4) 36 -to) IN1 IN1 start. See Safe torque off function in the drive hardware manual. 4) 37 J4) IN2 IN2 start. See Safe torque off function in the drive hardware manual. 40 24 V AC/DC (frames R6R8 only) 40 24 V AC/DC in upt, for control unit power is upply when external main power is X11 Redundant auxiliary voltage output 42 +24 V Aux. voltage output +24 V DC, max. 250 mA ³⁾ 43 DGND Aux. voltage output common Aux. voltage output common			X 4						
34 SGND OUT2 35 OUT1 SGND 36 -101 N1 40 24 VAC/DC (frames R6R8 only) 40 24 VAC/DC (frames R6R8 only) 40 24 VAC/DC (frames R6R8 only) 41 24 VAC/DC (frames R6R8 only) 42 +24 VAC/DC in supply when external main power is X11 Redundant auxiliary voltage output 42 +24 V 43 DGND Aux. voltage output common			- 33	-	OUT1				
35 OUT1 SGND Start. See Safe torque off function in the drive to start. See Safe torque off function in the drive hardware manual. 4) 37 J4) IN2 IN2 40 24 V AC/DC (frames R6R8 only) 40 24 V AC/DC + in 24V AC/DC input, for control unit power 41 24 V AC/DC + in supply when external main power is X11 Redundant auxiliary voltage output 42 +24 V Aux. voltage output +24 V DC, max. 250 mA ³) 43 DGND Aux. voltage output common		KJKØ		SGND					
A) 36 -10) IN1 IN1 IN1 37 J4) IN2 IN2 hardware manual. 40 24 V AC/DC (frames R6R8 only) 40 24 V AC/DC + in 24V AC/DC input, for control unit power 41 24 V AC/DC + in supply when external main power is X11 Redundant auxiliary voltage output 42 +24 V Aux. voltage output +24 V DC, max. 250 mA ³⁾ 43 DGND Aux. voltage output common									
4) 37 14) IN2 IN2 IN2 IN2 X10 24 V AC/DC (frames R6R8 only) 40 24 V AC/DC- in 24V AC/DC input, for control unit power 41 24 V AC/DC+ in supply when external main power is X11 Redundant auxiliary voltage output 42 +24 V Aux. voltage output +24 V DC, max. 250 mA ³) 43 DGND Aux. voltage output common					-				
X1024 V AC/DC (frames R6R8 only)4024 V AC/DC- in4124 V AC/DC+ in4124 V AC/DC+ in8000000000000000000000000000000000000		4)				haro	ware manual.		
4024 V AC/DC- in24V AC/DC input, for control unit power4124 V AC/DC+ insupply when external main power isX11Redundant auxiliary voltage output42+24 VAux. voltage output +24 V DC, max. 250 mA ³⁾ 43DGNDAux. voltage output common		L				nes F	R6R8 only)		
4124 V AC/DC+ insupply when external main power isX11Redundant auxiliary voltage output42+24 VAux. voltage output +24 V DC, max. 250 mA ³⁾ 43DGNDAux. voltage output common		E E	-						
X11Redundant auxiliary voltage output42+24 VAux. voltage output +24 V DC, max. 250 mA3143DGNDAux. voltage output common		ŀ	-	24 V AC/DC+ in		SUD	bly when external main power is		
42 +24 V Aux. voltage output +24 V DC, max. 250 mA ³⁾ 43 DGND Aux. voltage output common									
43 DGND Aux. voltage output common									
			44	DC		וופוט	ai input common for all		

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

¹⁾ Current [0(4)...20 mA, R_{in} < 500 ohm] or voltage [0(2)...10 V, R_{in} > 200 kohm] input as selected with parameter 12.15 Al1 unit selection.

²⁾ Current [0(4)...20 mA, R_{in} = 100 ohm] or voltage [0(2)...10 V, R_{in} > 200 kohm] input as selected with parameter 12.25 Al2 unit selection.

³⁾ Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2~RO3).

⁴⁾ Connected with jumpers at the factory.

⁵⁾ Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.

⁶⁾ Can be used to set up pressure alarm warning.

⁷⁾ Can be used for cold start prevention with connection to 'temperature reached' output of temperature controller or PLC

⁸⁾ Input signal

⁹⁾ Output signal

¹⁰⁾ For R0...R2 frames only

In addition, some inputs and settings are set automatically as follows:

No.	Name (Input/Setting)	Value
19.11	Ext1/Ext2 selection	5 = D/3
19.14	Ext2 control mode	3 = Torque
20.02	Ext1 start trigger type	1 = Level
20.06	Ext2 commands	2 = In1 Start; In2 Dir
20.07	Ext2 start trigger type	1 = Level
20.08	Ext2 in1 source	2 = DI1
20.09	Ext2 in2 source	2 = DI2
20.12	Run enable 1 source	7 = DI6
22.22	Constant speed sel1	5 = DI4
23.11	Ramp set selection	0 = <i>D</i> /5
26.11	Torque ref1 source	2 = Al2 scaled
31.11	Fault reset selection	0 = Not used

For information on cable connection and drive operation, see *Control Connections* in the *Hardware manual (3AXD50000044998)*

Pump and Fan Control (PFC) macro

The PFC macro is suitable for pump or fan systems consisting of one drive and multiple pumps/fans.

The PFC macro can be used to:


- Control the speed of one of the pumps/fans
- Connect or disconnect the auxiliary pumps in Direct On Line (DOL) connection as and when required.

For example, in a pump application with multiple pumps, the PFC logic controls the pumps as follows:

- 1. The drive varies the motor speed (VSD motor) to control the output of the first pump. This pump is the speed regulated pump.
- 2. When the demand (represented by the process PID reference) exceeds the capacity of the first pump (a user defined speed/frequency limit), the PFC logic automatically starts the auxiliary pump using the drive relay output.
- 3. The PFC logic reduces the speed of the first pump to balance the system output and to get the optimum energy efficiency.
- 4. The PID controller adjusts the speed/frequency of the first pump in such a way that the system output meets the process need.
- 5. If the demand further increases, the PFC logic adds further auxiliary pumps in similar manner.
- 6. When the demand drops, the drive reduces the speed of the first pump and when it reaches below the minimum limit (user defined speed/frequency limit), the PFC logic automatically stops the auxiliary pump. At the same time, the PFC logic increases the speed of the first pump to account for the missing output of the stopped auxiliary pump.

Note: The PFC is supported in external control location EXT2 only. However, you can use EXT1 for manual control of pump 1.

The below timing diagram explains how and when an auxiliary pump is connected with the PFC logic.




Example of a 3-pump constant pressure water supply application:

Pump 1 - connected to VSD motor

Pump 2 - connected to auxiliary motor 1

Pump 3 - connected to auxiliary motor 2

Flow consumption versus pump status						
Consumption	Pump 1 Pump 2 Pump 3					
Low	VSD	Off	Off			
↓ High	VSD	DOL	Off			
, ↓	VSD	VSD DOL DOL				
Low	VSD DOL Off					
	VSD	Off	Off			
VSD	Variable Speed Drive (yellow colour connecting line in the figure). Controlled by drive, tuning the output speed according to PID control.					
DOL	Direct On Line (red colour connecting line in the figure). Pump is running at fixed motor nominal speed.					
Off	Off-line. Pump stops.					



PFC enabled pump control timing diagram

In addition, the PFC logic also supports the following features:

Autochange

Autochange functionality or the automatic rotation can be used to automatically rotate the start order of the PFC system. This function has the following features:

- · Keeps the run time of the pumps/fans equal over time to even their wear .
- Prevent any pump/fan from standing still for too long, which otherwise would clog up the unit.

In some cases it is desirable to rotate the start order only when all units are stopped, for example to minimize the impact on the process.


The Autochange function can be defined in the parameter group 76 PFC configuration.

Note: The Autochange function also triggered by the Timed function. See description on page <u>60</u>.

There are 2 modes of auto change with PFC:

1. Autochange PFC with auxiliary motors

In this mode auto rotation happens with only 2nd and 3rd pump. Two pumps meet the flow consumption for long term running and the 3rd pump is reserved for shifting. Example of PFC autochange with auxiliary pumps in a 3-pump constant pressure water supply application:



Pump 1 - connected to VSD motor

Pump 2 - connected to auxiliary motor 1


Flow consumption versus pump status				
Consumption	Pump 1	Pump 2	Pump 3	
Low	VSD	Off	Off	
Normal	VSD	DOL	Off	
\downarrow	VSD	Off	DOL	
\downarrow	VSD	DOL	Off	
Normal	VSD	Off	DOL	
VSD		Variable Speed Drive (yellow colour connecting line in the figure). Controlled by drive, tuning the output speed according to PID control.		
DOL		Direct On Line (red colour connecting line in the figure). Pump is running at fixed motor nominal speed.		
Off	Off-line. Pump stops.			

2. Autochange PFC with all the motors In this mode, all motors involves in the autochange. VSD motor moves to next

130 Control macros

pump one by one, but the auxiliary motor is always is on-line in DOL mode. Two pumps meet the flow consumption for long term running and the 3rd pump is reserved for shifting. All the motors shifts for autochange routine and special auxiliary circuit is needed for the same. This system is similar to the SPFC.

Example of PFC autochange with all motors in a 3-pump constant pressure water supply application:



- Pump 1 connected to Motor 1
- Pump 2 connected to Motor 2
- Pump 3 connected to Motor 23

Flow consumption versus pump status				
Consumption	Pump 1	Pump 2	Pump 3	
Low	VSD	Off	Off	
Normal	VSD	DOL	Off	
↓	Off	VSD	DOL	
↓	DOL	Off	VSD	
Normal	VSD	DOL	Off	
VSD		Variable Speed Drive (yellow colour connecting line in the figure). Controlled by drive, tuning the output speed according to PID control.		
DOL	Direct On Line (red colour connecting line in the figure). Pump is running at fixed motor nominal speed.			
Off	Off-line. Pump stops.			

Interlock

The Interlock function can be used to notify the PFC logic on when a motor is not available. For example, when a motor is under maintenance or due to manual direct-on-line starting.

When the interlock signal of a motor is in Available status, the motor participates in the PFC starting sequence. If the signal is in Interlocked status, the motor is excluded from the PFC sequence.

The interlock function can be defined in the parameter group 76 PFC configuration.

Parameter Settings

To enable the PFC macro, navigate to:

- Main menu $\equiv \rightarrow$ Connection macro $1/0 \xrightarrow{\mu}{\Box \Box} \rightarrow$ PFC or
- Main menu $\equiv \rightarrow$ Complete parameter list parameter 96.04 Macro select \rightarrow [16] PFC.

The following default values are	used for PFC macro:
----------------------------------	---------------------

No.	Value	No.	Value
10.24	7 = Running	20.08	7 = <i>D</i> /6
10.27	15 = Fault (-1)	20.09	0 = Always off
10.30	46 = <i>PFC</i> 2	20.12	3 = D12
12.17	0	20.19	1 = Selected
12.20	50.0	21.03	0 = Coast
13.12	2 = Output frequency	22.11	1 = Al1 scaled
13.18	50.0	22.18	16 = <i>PID</i>
19.11	1 = <i>D</i> /3	22.22	0 = Always off
19.17	0= <i>No</i>	22.23	0 = Always off
20.01	1 =In1 Start	22.73	0 = Not used
20.03	2 = DI1	22.74	0 = Not used
20.04	0 = Always off	23.11	0 = Acc/Dec time 1
20.05	0 = Always off	28.11	1 = Al1 scaled
20.06	1 = In1 Start	28.15	16 = <i>PID</i>
28.22	0 = Always off	40.19	0 = Not selected
28.23	0 = Always off	40.20	0 = Not selected
28.71	0 = Acc/Dec time 1	40.32	2.50
30.11	-1500 rpm	40.33	3.0
31.01	1 = Inactive (true)	76.21	2 = <i>PFC</i>
31.02	0 = <i>Fault</i>	76.25	2
40.07	2 = On when drive running	76.27	2
40.16	11 = Al1 percent	99.04	0 = Scalar
40.17	0 = Not selected		

X1 Reference voltage and analog inputs and outputs SCR Signal cable shield (screen) 2 PID setpoint, 0...10 V^{1) 5)}: see 40.16 AI1 1...10 kohm 3 AGND Analog input circuit, common н 4 +10V 10 V DC reference voltage 5 PID feedback, 4...20mA^{1) 5)}: see 40.08 Al2 Analog input circuit, common 6 AGND Output frequency: 0...20 mA ⁶⁾: see 13.12 AO1 Max. 500 ohm Motor current, 0...20 mA ⁶⁾: see 13.22 8 AO2 AGND Analog output circuit common X2. X3 Aux. voltage output and programmable digital inputs +24V Aux. voltage output +24 VDC, max. 250 mA⁴⁾ 10 11 DGND Aux. voltage output common 3) 12 DCOM Digital input common for all Stop (0) / Start (1) (EXT 1) 5): see 20.03 13 DI1 Run enable (if 0, drive stops) 5): see 20.12. DI2 14 EXT1 (0) / EXT 2 (1) ⁵⁾: see 19.11 15 DI3 16 DI4 Not configured 17 DI5 Not configured 18 DI6 Not configured X6,X7, X8 **Relay outputs** RO1C Running ⁶⁾: see 10.27 250 V AC / 30 V DC RO1A 21 RO1B 2 A 20 RO2C Fault (-1)⁶⁾: see 10.30 250 V AC / 30 V DC RO2A RO2B 2 A RO3C PFC2 (the 2nd motor = the first auxiliary motor) ⁶⁾: see 10.30 RO3A 250 V AC / 30 V DC RO3B X5 Built-in fieldbus 29 B+ Internal Modbus RTU (EIA-485). See Fieldbus 30 Acontrol through the embedded fieldbus interface DGND (EFB). 31 (Frame R0...R2) S100 TERM&BIAS Termination resistor and bias resistor switch (Frame R3...R8) S100 Termination resistor switch S200 BIAS Bias resistor switch Safety torque off Χ4 R0....R2 R3...R 33 OUT1 R3...R8 Safety torque off function. Factory connection. 34 SGND OUT2 Both circuits must be closed for the drive to start. OUT1 SGND 35 See Safe torque off function in the drive 36 7) IN1 IN1 hardware manual. H<u>3)</u> 3) 37 IN2 IN2 X10 24 V AC/DC (frames R6...R8 only) 24 V AC/DC- in 24V AC/DC input, for control unit power supply 40 41 24 V AC/DC+ in when external main power is disconnected. X11 Redundant auxiliary voltage output (frames R0...R2) 42 +24 V Aux. voltage output +24 V DC, max. 250 mA⁴⁾ 43 DGND Aux. voltage output common 44 DCOM Digital input common for all

Default control connections for the PFC macro

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

¹⁾ The signal source is powered externally. See the manufacturer's instructions. To use sensors supplied by the drive aux. voltage output, see chapter *Electrical installation*, section *Connection examples of two-wire and three-wire sensors* in the Hardware manual of the drive.

²⁾ Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.

³⁾ Connected with jumpers at the factory.

⁴⁾ Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2-RO3).

⁵⁾ Input signal

⁶⁾ Output signal

⁷⁾ For R0...R2 frames only

For information on cable connection and drive operation, see *Control Connections* in the *hardware manual (3AXD50000044998)*.

Soft Pump and Fan Control (SPFC) macro


The Soft Pump and Fan Control (SPFC) logic is a variant of the PFC logic for pump and fan alternation applications where lower pressure peaks are desirable when a new auxiliary motor is to be started. The SPFC logic is an easy way to implement soft starting of direct on line (auxiliary) motors.

In SPFC all the pumps are auxiliary pump and get connected to Direct On Line (DOL) or drive as and when required. In PFC only primary pump is connected to the drive. In SPFC logic the auxiliary pumps are connected as follows:

- 1. As the expected flow rate/demand increases, the speed of auxiliary pump 1 increases accordingly. When the auxiliary pump reaches the start speed (76.30) and exceeds the start delay (76.55), the drive connects the drive controlled motor (auxiliary pump 1) to the supply network in a flying start, that is, while the motor is still coasting.
- 2. The drive then connects to the auxiliary pump 2 and starts controlling the speed.
- 3. The auxiliary pump 1 is connected DOL through a contactor.
- 4. Further auxiliary motors, if connected, are started in a similar manner. The motor stopping routine is the same as for the normal PFC routine.
- 5. In some cases SPFC makes it possible to soften the start-up current while connecting auxiliary motors on-line. Lower pressure peaks on the pipelines and pumps may be achieved as a result.

Note: The SPFC is supported in external control location EXT2 only. EXT1 can be used for the manual control of pump 1.

The below timing diagram explains how and when an auxiliary pump is connected with the SPFC logic.




Example of a 3-pump constant pressure water supply application:

Pump 1 is connected to Motor 1

Pump 2 is connected to Motor 2

Pump 3 is connected to Motor 3

Flow consumption versus pump status				
Consumption	Pump 1	Pump 2	Pump 3	
Low	VSD	Off	Off	
Ļ	DOL	VSD	Off	
High	DOL	DOL	DOL	
Ļ	DOL	Off	VSD	
Low	Off	Off	Off	
Ļ	VSD	Off	DOL	
High	DOL	VSD	DOL	
Ļ	DOL	VSD	Off	
Low	Off	VSD	Off	
\downarrow	VSD	DOL	Off	
High	DOL	DOL	VSD	
VSD	Variable Speed Drive (yellow colour connecting line in the figure). Controlled by drive, tuning the output speed according to PID control.			
DOL	Direct On Line (red colour connecting line in the figure). Pump is running at fixed motor nominal speed.			
Off	Off-line. Pump stops.			



SPFC enabled pump control timing diagram.

(1) 76.30 Start point 1 - Start speed for the auxiliary pump 2.

(2) 76.55 Start delay - Delay time to start auxiliary pump 2. The pump is started only when the speed of the auxiliary pump 1 is higher or same as the start speed (76.30) for the duration mentioned in this parameter.

(3) 76.57 *PFC speed hold on* - Time used to compensate the time needed to accelerate the auxiliary pump 2 to a speed where it produces flow. For duration mentioned in the parameter, the auxiliary pump 1 maintains its speed momentum.

(4) 76.41 Stop point 1 - Stop speed for the auxiliary pump 2.

(5) 76.56 Stop delay - Delay time to turn off the auxiliary pump 2 when the speed of the auxiliary pump 1 is lower or same as the stop speed (76.41) for the duration mentioned in this parameter.


(6) 76.58 *PFC speed hold off* - Time is used to compensate the time needed to accelerate the auxiliary pump 1 to a speed where it produces flow.

Autochange

SPFC system supports autochange naturally as the drive starts all the pump. Autochange functionality in SPFC is similar to autochange function in PFC except that autochange with auxiliary motor is not applicable for SPFC. See section *Autochange* on *128*.

In autochange, two pumps meet the flow consumption for long term running and the 3rd pump is reserved for shifting.

Example of a 3-pump constant pressure water supply application:



- Pump 1 connected to Motor 1
- Pump 2 connected to Motor 2
- Pump 3 connected to Motor 3

Flow consumption versus pump status				
Consumption	Pump 1	Pump 2	Pump 3	
Low	VSD	Off	Off	
Normal	DOL	VSD	Off	
	Off	DOL	VSD	
\downarrow	VSD	DOL	Off	
Normal	DOL	VSD	Off	
VSD	Variable Speed Drive (yellow colour connecting line in the figure). Controlled by drive, tuning the output speed according to PID control.			
DOL	Direct On Line (red colour connecting line in the figure). Pump is running at fixed motor nominal speed.			
Off	Off-line. Pump stops.			

Parameter Settings


To enable the SPFC macro, navigate to :

- Main menu $\equiv \rightarrow$ Connection macro $1/0^{-1}_{\Box\Box} \rightarrow$ SPFC or
- Main menu $\equiv \rightarrow$ Complete parameter list parameter 96.04 Macro select \rightarrow [18] SPFC.

The following default values are used for the SPFC macro:

No.	Value	No.	Value
10.24	7 = Running	22.73	0 = Not used
10.27	45 = PFC1	22.74	0 = Not used
10.30	46 = <i>PFC2</i>	23.11	6 = <i>DI</i> 5
12.17	0	28.11	1 = Al1 scaled
12.20	50.0	28.15	16 = <i>PID</i>
13.12	2 = Output frequency	28.22	0 = Always off
13.18	50.0	28.23	0 = Always off
19.11	5 = <i>DI3</i>	28.71	0 = Acc/Dec time 1
19.17	0 = <i>No</i>	30.11	-1500 rpm
20.01	1 = In1 Start	31.01	1 = Inactive (true)
20.03	2 = DI1	31.02	0 = <i>Fault</i>
20.04	0 = Always off	40.07	2 = On when drive running
20.05	0 = Always off	40.16	11 = Al1 percent
20.06	1 = In1 Start	40.17	0 = Not selected
20.08	7 = <i>DI</i> 6	40.19	0 = Not selected
20.09	0 = Always off	40.20	0 = Not selected
20.12	3 = <i>DI</i> 2	40.32	2.50
20.19	1 = Selected	40.33	3.0
21.03	0 = Coast	76.21	2 = SPFC
22.11	16 = <i>PID</i>	76.25	2
22.18	16 = <i>PID</i>	76.27	2
22.22	0 = Always off	99.04	0 = Scalar
22.23	0 = Always off		

SPFC circuit diagram



Default control connections for the SPFC macro					
		X1	Reference volta	age and analog inputs and outputs	
	·	1	SCR	Signal cable shield (screen)	
110 kohm 🖵 🗲	1 fr	2	Al1	PID setpoint, 010 V ^{1) 5)} : see 40.16	
		3	AGND	Analog input circuit, common	
	<u>, </u>	4	+10V	10 V DC reference voltage	
•	- i -	5	AI2	PID feedback, 420mA ^{1) 5)} : see 40.08	
		6	AGND	Analog input circuit, common	
Max. r 🗷 🔶		7	AO1	Output frequency: 020 mA ⁶): see 13.12	
500 ohm	÷ †	8	AO2	Motor current, 020 mA ⁶): see 13.22	
	- <u> </u>	9	AGND	Analog output circuit common	
4	2)	X2, X3		Itput and programmable digital inputs	
r.		10	+24V	Aux. voltage output +24 V DC, max. 250 mA ⁴	
_		11	DGND	Aux. voltage output (24 v DO, max. 250 mA)	
	3)	11			
			DCOM	Digital input common for all Stop (0) / Start (1) (EXT 1) ⁵⁾ : see 20.03	
		13	DI1	Run enable ⁵⁾ : see 20.12 (if 0, drive stops).	
		14	DI2	Run enable $\stackrel{\text{orightarrow}}{:}$ see 20.12 (if 0, drive stops).	
		15	DI3	EXT1 (0) / EXT 2 (1) ⁵⁾ see 19.11	
		16	DI4	Not configured	
		17	DI5	Not configured	
		18	DI6	Stop (0) / Start (1) (EXT 2): see 20.04	
		X6,X7, X8	Relay outputs		
		19	RO1C	Running ⁶⁾ : see 10.24	
	14	20	RO1A	– , 250 V ÅC / 30 V DC	
	$+\!\!+\!\!\Box$ -	21	RO1B	⊔_ 2A	
		22	RO2C	PFC1 (1st auxiliary pump) ⁶⁾ : see 10.27	
	14	23	RO2A	250 V AC / 30 V DC	
	$++\Box$ -	24	RO2B	2A	
		25	RO3C	PFC2 (2nd auxiliary pump) ⁶⁾ : see 10.30	
	1	26	RO3A	250 V AC / 30 V DC	
	$+\Box$	27	RO3B	2A	
		X5	Built-in fieldbus	S	
		29	B+	Internal Modbus RTU (EIA-485). See Fieldbus	
		30	A-	control through the embedded fieldbus interface	
		31	DGND	(EFB).	
		(Frame R0.	R2)		
		S100	TERM&BIAS	Termination resistor and bias resistor switch	
		(Frame R3.	R8)		
		S100	TERM	Termination resistor switch	
		S200	BIAS	Bias resistor switch	
			Safety torque of	ff	
		X4	R0R2 R3R		
		33	- OUT1		
	R3R8	34	SGND OUT2	Safety torque off function. Factory connection.	
		35	OUT1 SGND	Both circuits must be closed for the drive to start.	
		36	⁷⁾ IN1 IN1	See Sale lorque on function in the drive	
	3)	37	³⁾ IN2 IN2		
		X10		frames R6R8 only)	
		40	24 V AC/DC- in	24V AC/DC input, for control unit power supply	
		40	24 V AC/DC+ in		
				iliary voltage output (frames R0R2)	
		42	+24 V	Aux. voltage output +24 V DC, max. 250 mA ⁴	
		42	DGND	Aux. voltage output +24 v DC, max. 250 mA v	
		43	DCOM	Digital input common for all	
		44	DOOM		

Dof 4: . -. 0000

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

¹⁾ The signal source is powered externally. See the manufacturer's instructions. To use sensors supplied by the drive aux. voltage output, see chapter *Electrical installation*, section *Connection examples of two-wire and three-wire sensors* in the Hardware manual of the drive.

²⁾ Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.

³⁾ Connected with jumpers at the factory.

⁴⁾ Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2-RO3).

⁵⁾ Input signal

⁶⁾ Input signal

7) For R0...R2 frames only


For information on cable connection and drive operation, see *Control Connections* in the *hardware manual (3AXD50000044998)*.

Pharma macro

The various machines used in the pharmaceutical industry, e.g. Agitators, mixers, centrifuges, etc. are driven by motors which are controlled by drives. You can use the Pharma macro to automatically configure the basic drive parameters required to control these machines. The following settings are configured automatically with this macro:


- · Start, stop, and multiple constant speed selections
- · Ramp time
- Motor control
- Relay output
- Analog output

The below figure explains how a drive is connected to a motor in a reactor.



To enable the Pharma macro, navigate to :

- Main menu ≡ → Connection macro 1/0 → Pharma ▲ → or
- Main menu ≡ → Complete parameter list range parameter 96.04 Macro select → [19] Pharma Application.



Default control connections for the Pharma macro

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

¹⁾ Current [0(4)...20 mA, R_{in} < 500 ohm] or voltage [0(2)...10 V, R_{in} > 200 kohm] input as selected with parameter 12.15 Al1 unit selection.

²⁾ Current [0(4)...20 mA, R_{in} = 100 ohm] or voltage [0(2)...10 V, R_{in} > 200 kohm] input as selected with parameter 12.25 Al2 unit selection.

³⁾ Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2-RO3).

⁴⁾ The constant speed is set based on the following combination of sources:

Source defined by No.22.22	Source defined by No.22.23	Source defined by par.22.24	Constant speed active	Value
0	0	0	Set speed through AI1	-
1	0	0	Constant speed 1	600
0	1	0	Constant speed 2	900
0	0	1	Constant speed 4	1480

⁵⁾ Connected with jumpers at the factory.

⁶⁾ Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.

⁷⁾ Input signal

⁸⁾ Output signal

⁹⁾ For R0...R2 frames only

In addition, some inputs and settings are set automatically as follows:


No.	Name (Input/Setting)	Value	
20.01	Ext1 commands	4 = In1P Start; In2 Stop	
21.03	Stop mode	1 = Ramp	
23.11	Ramp set selection	0 = Acc/Dec time 1	
23.12	Acceleration time 1	300 s	
23.13	Deceleration time 1	300 s	
99.04	Motor control mode	1 = Vector	

For information on cable connection and drive operation, see *Control Connections* in the *Hardware manual (3AXD50000044998)*.

Plastic extrusion macro

Plastic extrusion in a plastic industry is a process of converting plastic materials from solid to liquid states and reconstituting them as finished components.

The below diagram shows the different process involved in a plastic extrusion.



Basic plastic extrusion block diagram

The plastic granules (in solid state) are fed as input which then goes through various process in the extruder machine to get the desired plastic product as output. The extruder operates with five to six motors and drives, depending on the type of extruder machine.

The Plastic extrusion macro is suitable for the drives used in plastic extrusion industry.

To enable the macro, navigate to:

- Main menu ≡ → Connection macro 1/0 → Plastic extrusion
 or
- Main menu $\equiv \rightarrow$ Complete parameter list parameter 96.04 Macro select \rightarrow [20] Plastic Extrusion.

Default control connections for the ABB Plastic extrusion macro						
		X1				analog inputs
	~	- 1	S	CR		al cable shield (screen)
110 kohm	· · ·	- 2	A	AI1	see	ernal speed reference: 010 V ^{1) 4) 8)} : 22.11
┌───		3	AC	GND	Anal	og input circuit, common
	-	- 4	+′	10V	10 V	DC reference voltage
~	1.1	5		12		configured
		6		SND		og input circuit, common
	~ ~				Mot	or speed used: 020 mA ⁹⁾ :
Max.	/ 	7	A	01	see	13.12
500 ohm └─↓		8	A	02		or current: 020 mA ⁹⁾ : 13.22
0		- 9	AC	GND		og output circuit common
1	$5) = \frac{9}{5}$					d programmable digital inputs
	o)	- 10		24V		voltage output +24 VDC, max. 250 mA ³⁾
				GND	Aux.	voltage output +24 VDC, max. 250 mA /
Г	4)	11				voltage output common
	(4)	. 12		COM	Digit	al input common for all
		13		011		in1 source ⁸⁾ : see 20.03
		14		012	Not	configured
		15		013	Exte	ernal event 1 source ^{6) 8)} : see 31.01
		16		014	Not	configured
		. 17	0	015	Not	configured
		18	C	016	Not	configured
		X6, X7, X8	Relay or	utputs		
		19		D1C		Zero speed ⁹⁾ : see. 10.24
		20		D1A		250 V AC / 30 V DC
	12-1	20		D1B	∟∕∟	2 A
		22		D2C		Running ⁹⁾ : see. <i>10.27</i>
		23				250 V AC / 30 V DC
	1/2			D2A		250 V AC / 50 V DC
-		24		D2B		
		- 25		D3C		Fault ⁹⁾ : see. 10.30
	1/2	26		D3A	\Box	250 V AC / 30 V DC
L	-	- 27		D3B		2 A
		X5	Built-in			
		29		3+	Inter	nal Modbus RTU (EIA-485), see <i>Fieldbus</i>
		30	-	A-		rol through the embedded fieldbus
		31	DC	GND	inter	face (EFB)
		(Frame R0.	R2)			
		S100	TERM	1&BIAS	Term	nination resistor and bias resistor switch
		(Frame R3.				,
		S100		RM	Term	nination resistor switch
		S200	В	IAS	Bias	resistor switch
				orque off		
		X4		R3R8		
		- 33	-	OUT1		
	R3R8	- <u>33</u> 34	SGND	OUT2		ty torque off function. Factory connection.
		35	OUT1	SGND		circuits must be closed for the drive to
					start	. See Safe torque off function in the drive
	4)	- 36	-10) IN1	IN1	hard	<i>lware</i> manual.
		4) IN2	IN2	<u> </u>		
	X10					R6R8 only)
		40	24 V AC/DC- in			AC/DC input, for control unit power
		41	24 V AC/DC+ in			bly when external main power is
		X11			ry vo	oltage output
		42		24 V		voltage output +24 V DC, max. 250 mA ³⁾
		43	DC	GND		voltage output common
		44	DC	COM	Digit	al input common for all
					U	

www.ediana.fondha.ADD.Dlaadia . .

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

¹⁾ Current [0(4)...20 mA, R_{in} < 500 ohm] or voltage [0(2)...10 V, R_{in} > 200 kohm] input as selected with parameter 12.15 Al1 unit selection.

²⁾ Current [0(4)...20 mA, R_{in} = 100 ohm] or voltage [0(2)...10 V, R_{in} > 200 kohm] input as selected with parameter 12.25 Al2 unit selection.

 $^{(3)}$ Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2~RO3).

⁴⁾ Connected with jumpers at the factory.

⁵⁾ Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.

⁶⁾ Can be used to set up pressure alarm warning.

⁷⁾ Can be used for cold start prevention with connection to 'temperature reached' output of temperature controller or PLC

⁸⁾ Input signal

⁹⁾ Output signal

¹⁰⁾ For R0...R2 frames only

For information on cable connection and drive operation, see *Control Connections* in the *hardware manual (3AXD50000044998)*.

Additional Notes

• Some inputs and settings are set automatically as follows:

No.	Name (Input/Setting)	Value
20.01	Ext1 commands	In1 Start
21.03	Stop mode	Ramp

• As per the default settings, when the Al1 reference is at any value, the drive can be started. If you want to enable the drive to start the motor only when the Al reference is below minimum value, set the parameter as follows:


No.	Name (Input/Setting)	Value
32.07	Supervision 1 signal	Al1
32.09	Supervision 1 low	1.00V
32.05	Supervision 1 function	Low
20.19	Enable start command	Supervision 1

When the extruder is jammed and the motor is stopped, you can use these settings to prevent the motor to start with existing AI reference. This helps to prevent damage of the screw in the extruder.

Jigar macro

The Jigar machine is a machine used in the textile industry. The ABB Jigar macro is suitable for the Jigar machine and automatically configures the drive parameters required for Jigar machine applications.

Jigar machine has two main rollers controlled by two separate drive. If one act as winder and the other act as unwinder and vice versa.



Jigar machine sequence

The Jigar machine has two operation sequences:

- 1. The fabric rolls on the first roller and passes it to the coloring section. In the coloring section, the fabric winds to the second roller.
- 2. Once the second roller fills, the process reverses and the second roller starts unwinding and the first roller winds the fabric.

	Machine sequ	ence 1	Machine sequence 2		
	Drive 1 (Winder)	Drive 2 (Unwinder)	Drive 2 (Winder)	Drive 1 (Unwinder)	
Unwinding	Speed / Forward direction		Speed / Forward direction		
Winding		<i>Torque</i> mode - Reverse direction		<i>Torque</i> mode - Reverse direction	

To enable the macro, navigate to:

• Main menu $\equiv \rightarrow$ Connection macro $1/0^{\Box}_{\Box\Box} \rightarrow$ Jigar or

Main menu $\equiv \rightarrow$ Complete parameter list representation parameter 96.04 Macro select \rightarrow [30] Jigar.

X1 Reference voltage and analog inputs SCR Signal cable shield (screen) External speed reference: 0...10 V^{1) 4) 8)}: D AI1 1...10 kohm ιĩ see 22.11 3 AGND Analog input circuit, common r' 10 V DC reference voltage 4 +10V . Torque reference ^{2) 4) 8)} see 22.12 5 AI2 6 AGND Analog input circuit, common Motor speed used: 0...20 mA⁹⁾: AO1 Max. see 13.12 500 ohm Motor current: 0...20 mA⁹⁾: 8 AO2 see13.22 ŗ, 9 AGND Analog output circuit common X2. X3 Aux. voltage output and programmable digital inputs 5) +24V Aux. voltage output +24 VDC, max. 250 mA³⁾ 10 DGND Aux. voltage output common 11 4) 12 DCOM Digital input common for all 13 DI1 Stop (0) / Start (1) (EXT 1) 8) 11): see 20.03 Stop (0) / Start (1) (EXT 2) 8) 12): see 20.03 14 DI2 Ext1 (0) / EXT 2 (1) 5) 13) : see 19.11 15 DI3 16 DI4 Not configured 17 DI5 Not configured DI6 Not configured 18 X6, X7, X8 Relay outputs R01C Zero speed⁹⁾: see. 10.24 250 V AC / 30 V DC 20 RO1A 1 RO1B 2 A 21 Running⁹⁾: see. 10.27 RO2C RO2A 250 V AC / 30 V DC 2 A RO2B Fault⁹⁾: see. 10.30 RO3C 26 RO3A 250 V AC / 30 V DC RO3B 2 A Χ5 Built-in fieldbus 29 B+ Internal Modbus RTU (EIA-485), see Fieldbus 30 Acontrol through the embedded fieldbus DGND interface (EFB) 31 (Frame R0...R2) TERM&BIAS Termination resistor and bias resistor switch S100 (Frame R3...R8) Termination resistor switch TERM S100 S200 BIAS Bias resistor switch Safety torque off X4 R0...R2 R3...R8 33 OUT1 R3 R8 Safety torque off function. Factory connection. 34 SGND OUT2 Both circuits must be closed for the drive to 35 OUT1 SGND start. See Safe torque off function in the drive 36 IN1 10) IN1 hardware manual. 4١ 37 4) IN2 IN2 X10 24 V AC/DC (frames R6...R8 only) 40 24 V AC/DC- in 24V AC/DC input, for control unit power supply when external main power is 24 V AC/DC+ in 41 X11 Redundant auxiliary voltage output 42 +24 V Aux. voltage output +24 V DC, max. 250 mA³⁾ 43 DGND Aux. voltage output common 44 DCOM Digital input common for all

Default control connections for the ABB Jigar macro

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf ft)

Notes

¹⁾ Current [0(4)...20 mA, R_{in} < 500 ohm] or voltage [0(2)...10 V, R_{in} > 200 kohm] input as selected with parameter 12.15 Al1 unit selection.

²⁾ Current [0(4)...20 mA, R_{in} = 100 ohm] or voltage [0(2)...10 V, R_{in} > 200 kohm] input as selected with parameter 12.25 Al2 unit selection.

³⁾ Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2~RO3).

⁴⁾ Connected with jumpers at the factory.

⁵⁾ Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.

⁶⁾ Can be used to set up pressure alarm warning.

⁷⁾ Can be used for cold start prevention with connection to 'temperature reached' output of temperature controller or PLC

⁸⁾ Input signal

⁹⁾ Output signal

¹⁰⁾ For R0...R2 frames only

¹¹⁾ The start in forward direction is connected to digital input DI1 and the start/stop in reverse direction is connected to digital input DI2.

¹²⁾ The start is connected to digital input DI1 and the torque reversal is connected to digital input DI2.

¹³⁾ EXT1 is configured for speed control and EXT2 is configured for torque control in both drive 1 and drive 2.

For information on cable connection and drive operation, see *Control Connections* in the *hardware manual (3AXD50000044998)*.

Additional Notes

No.	Name (Input/Setting)	Value
12.20	AI1 scaled at AI1 max	1500.000
12.30	Al2 scaled at Al2 max	100.000
19.11	Ext1/Ext2 selection	DI3
19.14	Ext2 control mode	Torque
20.01	Ext1 commands	In1 Start fwd; In2 Start rev
20.06	Ext2 commands	In1 Start
20.08	Ext2 in1 source	DI1
22.22	Constant speed sel1	Always off
22.23	Constant speed sel2	Always off
23.11	Ramp set selection	Acc/Dec time 1
26.11	Torque ref1 source	AI2 scaled
26.20	Torque reversal	DI2
99.04	Motor control mode	Vector

Some inputs and settings are set automatically as follows:

Parameter default values for different application macros

The default values listed in the *Parameters* table on page *161* are applicable for ABB standard macro (factory macro). The default values may differ for other macros. The different default values for each application macros are listed in the below table.

			96.04 Ma	cro select	
Parameter		ABB standard (1)	ABB standard (vector) (17)	Torque control (26)	3-wire (11)
10.24	RO1 source	2 = Ready run	2 = Ready run	2 = Ready run	2 = Ready run
10.27	RO2 source	7 = Running	7 = Running	7 = Running	7 = Running
10.30	RO3 source	15 = <i>Fault (-1)</i>	15 = Fault (-1)	15 = <i>Fault (-1)</i>	15 = <i>Fault (-1)</i>
12.20	AI1 scaled at AI1 max	50.000	1500.000	1500.000	50.000
12.30	AI2 scaled at AI2	50.000	1500.000	100.000	50.000
13.12	AO1 source	2 = Output frequency	1 = Motor speed used	1 = Motor speed used	2 = Output frequency
13.18	AO1 source max	50.0	1500.0	1500.0	50.0
19.11	Ext1/Ext2 selection	0 = <i>EXT1</i>	0 = <i>EXT1</i>	5 = D /3	0 = <i>EXT1</i>
19.14	Ext2 control mode	2 = Speed	2 = Speed	3 = Torque	2 = Speed
20.01	Ext1 commands	2 = In1 Start; In2 Dir	2 = In1 Start; In2 Dir	2 = In1 Start; In2 Dir	2 = In1P Start; In2 Stop; In3 Dir
20.03	Ext1 in1 source	2 = DI1	2 = D I1	2 = DI1	2 = DI1
20.04	Ext1 in2 source	3 = D I2	3 = <i>DI</i> 2	3 = D I2	3 = D /2
20.05	Ext1 in3 source	0 = Always off	0 = Always off	0 = Always off	0 = Always off
20.06	Ext2 commands	0 = Not selected	0 = Not selected	1 = In1 Start	1 = In1 Start
20.08	Ext2 in1 source	0 = Always off	0 = Always off	2 = D I1	2 = D /1
20.09	Ext2 in2 source	0 = Always off	0 = Always off	3 = D I2	3 = D /2
20.12	Run enable 1 source	1 = Selected	1 = Selected	7 = <i>D</i> 16	4 = DI3
21.03	Stop mode	1 = Coast	1 = Coast	1 = Coast	1 = Coast
22.11	Ext1 speed ref1	1 = Al1 scaled	1 = Al1 scaled	1 = Al1 scaled	1 = AI1 scaled
22.18	Ext2 speed ref1	0 = Zero	0 = Zero	0 = Zero	0 = <i>Zero</i>
22.21	Constant speed function	0b0001	0b0001	06000	
22.22	Constant speed	4 = DI3	4 = D/3	5 = D I4	5 = D I4
22.23	Constant speed sel2	5 = DI 4	5 = D I4	5 = D I4	6 = D /5
22.24	Constant speed sel3	0 = Always off	0 = Always off	0 = Always off	0 = Always off

Parameter		96.04 Macro select					
		ABB standard (1)	ABB standard (vector) (17)	Torque control (26)	<mark>3-wire</mark> (11)		
22.27	Constant speed 2	600	600	600	600		
22.29	Constant speed 4	1200	1200	1200	1200		
22.71	Motor potentiometer	0 = Disabled	0 = Disabled	0 = Disabled	0 = Disabled		
22.73	Motor potentiometer up	0 = Not used	0 = Not used	0 = Not used	0 = Not used		
22.74	Motor potentiometer	0 = Not used	0 = Not used	0 = Not used	0 = Not used		
23.11	Ramp set selection	6 = <i>DI5</i>	6 = <i>DI5</i>	6 = <i>DI5</i>	0 = Acc/Dec time		
23.12	Acceleration time	20.000s	20.000s	20.000s	20.000s		
23.13	Deceleration time	20.000s	20.000s	20.000s	20.000s		
28.11	Ext1 frequency ref1	1 = Al1 scaled	1 = Al1 scaled	1 = Al1 scaled	1 = Al1 scaled		
28.15	Ext1 frequency ref2	0 = Zero	0 = Zero	0 = Zero	0 = <i>Zero</i>		
28.22	Constant frequency sel1	4 = D /3	4 = <i>D</i> /3	4 = <i>DI</i> 3	5 = D I4		
28.23	Constant frequency sel2	5 = D I4	5 = D I4	5 = D I4	6 = DI 5		
28.71	Freq ramp set selection	6 = <i>DI5</i>	6 = <i>DI5</i>	6 = <i>DI5</i>	0 = Acc/Dec time		
30.10	Current limit actions	0 = No action	0 = No action	0 = No action	0 = No action		
30.11	Minimum speed	-1500.00	-1500.00	-1500.00	-1500.00		
31.11	Fault reset selection	0 = Not used	0 = Not used	0 = Not used	0 = Not used		
40.07	Process PID operation mode	0 = Off	0 = Off	0 = Off	0 = Off		
40.16	Set 1 setpoint 1 source	11 = Al1 percent	11 = Al1 percent	1 = Al1 percent	1 = Al1 percent		
40.17	Set 1 setpoint 2 source	0 = Not selected	0 = Not selected	0 = Not selected	0 = Not selected		
40.19	Set 1 internal setpoint sel1	0 = Not selected	0 = Not selected	0 = Not selected	0 = Not selected		
40.20	Set 1 internal setpoint sel2	0 = Not selected	0 = Not selected	0 = Not selected	0 = Not selected		
40.32	Set 1 gain	1.00	1.00	1.00	1.00		
40.33	Set 1 integration time	60.0	60.0	60.0	60.0		
76.21	PFC configuration	0 = Off	0 = O ff	0 = Off	0 = Off		
76.25	Number of motors	1	1	1	1		
76.27	Max number of motors allowed	1	1	1	1		
99.04	Motor control mode	1 = Scalar	0 = Vector	0 = Vector	1 = Scalar		

P			96.04	Macro select	
	Parameter	Motor potenti- ometer (13)	Pharma Application (19)	<i>PID</i> (14)	Panel PID (15)
10.24	RO1 source	11 = Ready run	2 = Ready run	2 = Ready run	2 = Ready run
10.27	RO2 source	7 = Running	7 = Running	7 = Running	7 = Running
10.30	RO3 source	15 = <i>Fault (-1)</i>	14 = <i>Fault</i>	15 = <i>Fault (-</i> 1)	15 = <i>Fault (-1)</i>
12.20	Al1 scaled at Al1 max	50.000	1500.000	50.000	50.000
12.30	AI2 scaled at AI2 min	50.000	50.000	50.000	50.000
13.12	AO1 source	2 = Output frequency	1 = Motor speed used	2 = Output frequency	2 = Output frequency
13.18	AO1 source max	50.0	1500.0	50.0	50.0
19.11	Ext1/Ext2 selection	0 = <i>EXT</i> 1	0 = <i>EXT1</i>	0 = <i>EXT1</i>	0 = <i>EXT1</i>
19.14	Ext2 control mode	2 = Speed	2 = Speed	2 = Speed	2 = Speed
19.17	Local control mode	0 = <i>No</i>	0 = <i>No</i>	0 = <i>No</i>	0 = <i>No</i>
20.01	Ext1 commands	2 = In1 Start; In2 Dir	4 = In1P Start; In2 Stop	1 = In1 Start	1 = In1 Start
20.03	Ext1 in1 source	2 = DI1	2 = DI1	2 = D I1	2 = DI1
20.04	Ext1 in2 source	3 = D /2	3 = DI2	0 = Always off	0 = Always off
20.05	Ext1 in3 source	0 = Always off	0 = Always off	0 = Always off	0 = Always off
20.06	Ext2 commands	0 = Not selected	0 = Not selected	0 = Not selected	0 = Not selected
20.08	Ext2 in1 source	0 = Always off	0 = Always off		0 = Always off
20.09	Ext2 in2 source	0 = Always off	0 = Always off	0 = Always off	0 = Always off
20.12	Run enable 1 source	7 = <i>DI</i> 6	1 = Selected	6 = D /5	6 = <i>DI5</i>
21.03	Stop mode	1 =Coast	1 = Ramp	0 = Coast	0 = Coast
22.11	Ext1 speed ref1	15 = Motor potentiometer	1 = Al1 scaled	16 = <i>PID</i>	16 = <i>PID</i>
22.18	Ext2 speed ref1	0 = Zero	0 = Zero	0 = <i>Zero</i>	0 = <i>Zero</i>
22.21	Constant speed function	0b000	0b0001	0b0000	0b0000
22.22	Constant speed sel1	6 = <i>DI5</i>	4 = <i>DI</i> 3	5 = D /4	5 = D I4
22.23	Constant speed sel2	0 = Always off	5 = D <i>I</i> 4	0 = Always off	0 = Always off
22.24	Constant speed sel3	0 = Always off	5 = <i>DI</i> 5	0 = Always off	0 = Always off
22.26	Constant speed 1	300	600	300	300
22.27	Constant speed 2	600	900	600	600

	Demonstern	96.04 Macro select				
	Parameter	Motor potenti- ometer (13)	Pharma Application (19)	PID (14)	Panel PID (15)	
22.29	Constant speed 4	1200	1480	1200	1200	
22.71	Motor potentiometer function	1 = Enabled (init at stop /power-	0 = Disabled	0 = Disabled	0 = Disabled	
22.73	Motor potentiometer up source	4 = <i>D</i> /3	0 = Not used	0 = Not used	0 = Not used	
22.74	Motor potentiometer down source	5 = D I4	0 = Not used	0 = Not used	0 = Not used	
23.11	Ramp set selection	0 = Acc/Dec time 1	0 = Acc/Dec time 1	0 = Acc/Dec time 1	0 = <i>Acc/Dec time</i> 1	
23.12	Acceleration time 1	20.000s	300s	20.000s	20.000s	
23.13	Deceleration time 1	20.000s	300s	20.000s	20.000s	
28.11	Ext1 frequency ref1	15 = Motor potentiometer	1 = AI1 scaled	16 = <i>PID</i>	16 = <i>PID</i>	
28.15	Ext1 frequency ref2	0 = Zero	0 = Zero	0 = Zero	0 = Zero	
28.22	Constant frequency sel1	6 = D <i>I</i> 5	4 = DI3	5 = D I4	5 = D I4	
28.23	Constant frequency sel2	0 = Always off	5 = DI4	0 = Always off	0 = Always off	
28.71		0 = Acc/Dec time 1	6 = <i>DI5</i>	0 = Acc/Dec time 1	0 = Acc/Dec time	
30.10	Current limit actions	0 = No action	0 = No action	0 = No action	0 = No action	
30.11	Minimum speed	-1500.00	-1500.00	-1500.00	-1500.00	
31.11	Fault reset selection	0 = Not used	0 = Not used	0 = Not used	0 = Not used	
40.07	Process PID operation mode	0 = Off	0 = O ff	2 = On when drive running	2 = On when drive running	
40.16	Set 1 setpoint 1 source	11 = Al1 percent	11 = Al1 percent	11 = AI1 percent	13 = Control panel (ref saved)	
40.17	Set 1 setpoint 2 source	0 = Not selected	0 = Not selected	2 = Internal setpoint	0 = Not selected	
40.19	Set 1 internal setpoint sel1	0 = Not selected	0 = Not selected	3 = D/2	0 = Not selected	
40.20	Set 1 internal setpoint sel2	0 = Not selected	0 = Not selected	4 = D/3	0 = Not selected	
40.32		1.00	1.00	1.00	1.00	
40.33	Set 1 integration time	60.0	60.0	60.0	60.0	
76.21		0 = Off	0 = Off	0 = Off	0 = Off	
76.25	Number of motors	1	1	1	1	
76.27	Max number of motors allowed	1	1	1	1	
99.04		1 = Scalar	0 = Vector	1 = Scalar	1 = Scalar	

Parameter					
		PFC (16)	SPFC (18)	Plastic Extrusion (20)	<i>Jigar</i> (30)
10.24	RO1 source	7 = Running	7 = Running	11 = Zero speed	11 = Ready run
10.27	RO2 source	15 = Fault (-1)	43 = <i>PFC1</i>	7 = Running	7 = Running
10.30	RO3 source	46 = <i>PFC2</i>	46 = <i>PFC2</i>	14 = <i>Fault</i>	14 = Fault (-1)
12.20	AI1 scaled at AI1 max	50.000	50.000	1500.000	1500.000
12.30	AI2 scaled at AI2 max	50.000	50.000	50.000	100.000
13.12	AO1 source	2 = Output frequency	2 = Output frequency	1 = Motor speed used	1 = Output frequency
13.18	AO1 source max	50.0	50.0	1500.0	50.0
19 .11	Ext1/Ext2 selection	1 = <i>DI</i> 3	5 = D /3	0 = <i>EXT1</i>	0 = <i>DI</i> 3
19.14	Ext2 control mode	2 = Speed	2 = Speed	2 = Speed	2 = Torque
19.17	Local control mode	0 = <i>No</i>	0 = <i>No</i>	1 = Yes	1 = <i>No</i>
20.01	Ext1 commands	1 = In1 Start	1 = In1 Start	1 = In1 Start	1 = In1 Start fwd; In2 Start rev
20.03	Ext1 in1 source	2 = D I1	2 = DI1	2 = D I1	2 = DI1
20.04	Ext1 in2 source	0 = Always off	0 = Always off	3 = D I2	3 = D I2
20.05	Ext1 in3 source	0 = Always off	0 = Always off	0 = Always off	0 = Always off
20.06	Ext2 commands	1 = In1 Start	1 = In1 Start	0 = Always off	0 = In1 Start
20.08	Ext2 in1 source	7 = DI6	7 = DI6	0 = Always off	0 = <i>D</i> /1
20.09	Ext2 in2 source	0 = Always off	0 = Always off	0 = Always off	0 = Always off
20.12	Run enable 1 source	3 = D 12	3 = D I2	1 = Selected	1 = Selected
21.03	Stop mode	0 = Coast	0 = Coast	1 = Ramp	1 = Coast
22.11	Ext1 speed ref1	1 = AI1 scaled	1 = Al1 scaled	1 = AI1 scaled	1 = AI1 scaled
22.18	Ext2 speed ref1	16 = <i>PID</i>	0 = Zero	0 = Zero	0 = Zero
22.21	Constant speed function	0b0001	0b0001	0b0001	0b0001
22.22	Constant speed sel1	0 = Always off	4 = DI3	4 = <i>DI3</i>	4 = Always off
22.23	Constant speed sel2	0 = Always off	5 = DI 4	5 = DI 4	5 = Always off
22.24	Constant speed sel3	0 = Always off	0 = Always off	0 = Always off	0 = Always off
22.2 <mark>6</mark>	Constant speed 1	300.00	300.00	300.00	300.00
22.27	Constant speed 2	600.00	600.00	600.00	600.00

Parameter					
		PFC (16)	SPFC (18)	Plastic Extrusion (20)	<i>Jigar</i> (30)
22.2 <mark>9</mark>	Constant speed 4	1200.00	1200.00	1200.00	1200.00
22.71	Motor potentiometer function	0 = Disabled	0 = Disabled	0 = Disabled	0 = Disabled
22.73	Motor potentiometer up source	0 = Not used	0 = Not used	0 = Not used	0 = Not used
22.74	Motor potentiometer down source	0 = Not used	0 = Not used	0 = Not used	0 = Not used
23.11	Ramp set selection	0 = Acc/Dec time 1	6 = <i>DI5</i>	6 = <i>DI5</i>	6 = Acc/Dec time 1
23.12	Acceleration time 1	20.000s	20.000s	20.000s	20.000s
23.13	Deceleration time 1	20.000s	20.000s	20.000s	20.000s
26.11	Torque ref1 source	0 = Zero	0 = Zero	0 = <i>Zero</i>	2 = AI2 scaled
28.11	Ext1 frequency ref1	1 = AI1 scaled	1 = AI1 scaled	1 = Al1 scaled	1 = Al1 scaled
28.15	Ext1 frequency ref2	16 = <i>PID</i>	16 = <i>PID</i>	0 = Zero	0 = Zero
28.22	Constant frequency sel1	0 = Always off	0 = Always off	4 = D/3	4 = <i>D</i> /3
28.23	Constant frequency	0 = Always off	0 = Always off	5 = D I4	5 = D I4
28.71	Freq ramp set selection	0 = Acc/Dec time 1	0 = Acc/Dec time	6 = D <i>I</i> 5	6 = D /5
30.10	Current limit actions	0 = No action	0 = No action	1 = Warning	1 = No action
30.11	Minimum speed	-1500.00	-1500.00	0.00	0.00
31.11	Fault reset selection	0 = Not used	0 = Not used	0 = Not used	0 = Not used
40.07	Process PID operation mode	2 = On when drive running	2 = On when drive running	0 = Off	0 = Off
40.16	Set 1 setpoint 1 source	11 = AI1 percent	11 = AI1 percent	11 = AI1 percent	11 = AI1 percent
40.17	Set 1 setpoint 2 source	0 = Not selected	0 = Not selected	0 = Not selected	0 = Not selected
40.19	Set 1 internal setpoint sel1	0 = Not selected	0 = Not selected	0 = Not selected	0 = Not selected
40.20		0 = Not selected	0 = Not selected	0 = Not selected	0 = Not selected
40.32	Set 1 gain	2.50	2.50	1.00	1.00
40.33	Set 1 integration	3.0	3.0	60.0 s	60.0 s
76.21	PFC configuration	2 = PFC	2 = SPFC	0 = <i>Off</i>	0 = <i>Off</i>
76.25	Number of motors	2	2	1	1
76.27	Max number of motors allowed	2	2	1	1
99.04	Motor control mode	1 = Scalar	1 = Scalar	0 = Vector	0 = Vector

6

Parameters

What this chapter contains

The chapter describes the parameters, including actual signals of the control program.

Terms and abbreviations

Term	Definition
Actual signal	Type of <i>parameter</i> that is the result of a measurement or calculation by the drive, or contains status information. Most actual signals are read-only, but some (especially counter-type actual signals) can be reset.
Def	(In the following table, shown on the same row as the parameter name) The default value of a <i>parameter</i> when used in the Factory macro. For information on other macro-specific parameter values, see chapter <i>Control macros</i> (page 101).
FbEq16	 (In the following table, shown on the same row as the parameter range, or for each selection) 16-bit fieldbus equivalent: The scaling between the value shown on the panel and the integer used in communication when a 16-bit value is selected for transmission to an external system. A dash (-) indicates that the parameter is not accessible in 16-bit format. The corresponding 32-bit scalings are listed in chapter <i>Additional parameter data</i> (page 377).
Other	The value is taken from another parameter. Choosing "Other" displays a parameter list in which the user can specify the source parameter.
Other [bit]	The value is taken from a specific bit in another parameter. Choosing "Other" displays a parameter list in which the user can specify the source parameter and bit.
Parameter	Either a user-adjustable operating instruction for the drive, or an <i>actual</i> signal.
p.u.	Per unit
[parameter number]	Value of the parameter

Summary of parameter groups

Group	Contents	Page
01 Actual values	Basic signals for monitoring the drive.	164
03 Input references	Values of references received from various sources.	167
04 Warnings and faults	Information on warnings and faults that occurred last.	168
05 Diagnostics	Various run-time-type counters and measurements related to drive maintenance.	169
06 Control and status words	Drive control and status words.	172
07 System info	Drive hardware and firmware information.	177
10 Standard DI, RO	Configuration of digital inputs and relay outputs.	178
11 Standard DIO, FI, FO	Configuration of the frequency input.	186
12 Standard Al	Configuration of standard analog inputs.	187
13 Standard AO	Configuration of standard analog outputs.	192
15 I/O Extension module	Configuration of the I/O extension module. See also section <i>Programmable I/O extensions</i> (page 42). Note: The contents of the parameter group vary according to the selected I/O extension module type.	198
19 Operation mode	Selection of local and external control location sources and operating modes.	203
20 Start/stop/direction	Start/stop/direction and run/start/jog enable signal source selection; positive/negative reference enable signal source selection.	
21 Start/stop mode	Start and stop modes; emergency stop mode and signal source selection; DC magnetization settings.	
22 Speed reference selection	Speed reference selection; motor potentiometer settings.	223
23 Speed reference ramp	Speed reference ramp settings (programming of the acceleration and deceleration rates for the drive).	232
25 Speed control	Speed controller settings.	236
26 Torque reference chain	Settings for the torque reference chain.	243
28 Frequency reference chain	Settings for the frequency reference chain.	247
30 Limits	Drive operation limits.	258
31 Fault functions	Configuration of external events; selection of behavior of the drive upon fault situations.	265
32 Supervision	Configuration of signal supervision functions 16.	273
34 Timed functions	Configuration of the timed functions.	280
35 Motor thermal protection	Motor thermal protection settings such as temperature measurement configuration, load curve definition and motor fan control configuration.	287
36 Load analyzer	Peak value and amplitude logger settings.	298
37 User load curve	Settings for user load curve.	299
40 Process PID set 1	Parameter values for process PID control.	302
41 Process PID set 2	A second set of parameter values for process PID control.	316
43 Brake chopper	Settings for the internal brake chopper.	318
44 Mechanical brake control	Configuration of mechanical brake control.	320
45 Energy efficiency	Settings for the energy saving calculators.	321

Group	Contents	Page
46 Monitoring/scaling settings	Speed supervision settings; actual signal filtering; general scaling settings.	325
47 Data storage	Data storage parameters that can be written to and read from using other parameters' source and target settings.	328
49 Panel port communication	Communication settings for the control panel port on the drive.	329
50 Fieldbus adapter (FBA)	Fieldbus communication configuration.	332
51 FBA A settings	Fieldbus adapter A configuration.	336
52 FBA A data in	Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter A.	337
53 FBA A data out	Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter A.	338
58 Embedded fieldbus	Configuration of the embedded fieldbus (EFB) interface.	338
70 Override	Enabling/disabling of override function, override activation signal and override speed/frequency.	
71 External PID1	Configuration of external PID.	348
76 PFC configuration	PFC (Pump and fan control) and Autochange configuration parameters. See also section Pump and Fan Control (PFC) macro on page 125.	
77 PFC maintenance and monitoring	PFC (Pump and fan control) and Autochange configuration parameters. See also section Pump and Fan Control (PFC) macro on page 125.	
95 HW configuration	Various hardware-related settings.	359
96 System	Language selection; access levels; macro selection; parameter save and restore; control unit reboot; user parameter sets; unit selection.	
97 Motor control	Switching frequency; slip gain; voltage reserve; flux braking; anti- cogging (signal injection); IR compensation.	368
98 User motor parameters	Motor values supplied by the user that are used in the motor model.	
99 Motor data	Motor configuration settings.	373

Parameter listing

No.	Name/Value	Description	Def/FbEq16
01 Act	tual values	Basic signals for monitoring the drive. All parameters in this group are read-only unless otherwise noted. Note: Values of these actual signals are filtered with the filter time defined in group 46 <i>Monitoring/scaling settings</i> . The selection lists for parameters in other groups mean the raw value of the actual signal instead. For example, if a selection is "Output frequency" it does not point to the value of parameter 01.06 Output frequency but to the raw value.	
01.01	Motor speed used	Estimated motor speed. A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed.	-
	-30000.00 30000.00 rpm	Estimated motor speed.	See par. 46.01
01.02	Motor speed estimated	Estimated motor speed in rpm. A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed.	-
	-30000.00 30000.00 rpm	Estimated motor speed.	See par. 46.01
01.03	Motor speed %	Motor speed in percent of the synchronous motor speed.	-
	-1000.00 1000.00%	Motor speed.	10 = 1%
01.06	Output frequency	Estimated drive output frequency in Hz. A filter time constant for this signal can be defined by parameter 46.12 Filter time output frequency.	-
	-500.00500.00 Hz	Estimated output frequency.	See par. 46.02
01.07	Motor current	Measured (absolute) motor current in A.	-
	0.0030000.00 A	Motor current.	1 = 1 A
01.08	Motor current % of motor nom	Motor current (drive output current) in percent of the nominal motor current.	-
	0.01000.0%	Motor current.	1 = 1%
01.09	Motor current % of drive nom	Motor current (drive output current) in percent of the nominal drive current.	-
	0.01000.0%	Motor current.	1 = 1%
01.10	Motor torque	Motor torque in percent of the nominal motor torque. See also parameter <i>01.30 Nominal torque scale</i> . A filter time constant for this signal can be defined by parameter <i>46.13 Filter time motor torque</i> .	-
	-1600.01600.0%	Motor torque.	See par. 46.03
01.11	DC voltage	Measured DC link voltage.	-
	0.002000.00 V	DC link voltage.	10 = 1 V
01.13	Output voltage	Calculated motor voltage in V AC.	-
	02000 V	Motor voltage.	1 = 1 V

No.	Name/Value	Description	Def/FbEq16
01.14	Output power	Drive output power. A filter time constant for this signal can be defined by parameter <i>46.14 Filter time power</i> .	-
	-32768.00 32767.00 kW	Output power.	See par. 46.04
01.15	Output power % of motor nom	Output power in percent of the nominal motor power.	-
	-300.00 300.00%	Output power.	1 = 1%
01.17	Motor shaft power	Estimated mechanical power at motor shaft. The unit is selected by parameter 96.16 Unit selection.	-
	-32768.00… 32767.00 hp or kW	Motor shaft power.	See par. 46.04
01.18	Inverter GWh counter	Amount of energy that has passed through the drive (in either direction) in full gigawatt-hours. The minimum value is zero.	-
	065535 GWh	Energy in GWh.	1 = 1 GWh
01.19	Inverter MWh counter	Amount of energy that has passed through the drive (in either direction) in full megawatt-hours. Whenever the counter rolls over, 01.18 Inverter GWh counter is incremented. The minimum value is zero.	-
	01000 MWh	Energy in MWh.	1 = 1 MWh
01.20	Inverter kWh counter	Amount of energy that has passed through the drive (in either direction) in full kilowatt-hours. Whenever the counter rolls over, 01.19 Inverter MWh counter is incremented. The minimum value is zero.	-
	01000 kWh	Energy in kWh.	10 = 1 kWh
01.24	Flux actual %	Used flux reference in percent of nominal flux of motor.	-
	0200%	Flux reference.	1 = 1%
01.30	Nominal torque scale	Torque that corresponds to 100% of nominal motor torque. The unit is selected by parameter <i>96.16 Unit selection</i> . Note: This value is copied from parameter <i>99.12 Motor</i> <i>nominal torque</i> if entered. Otherwise the value is calculated from other motor data.	-
	0.000…4000000 N∙m or lb∙ft	Nominal torque.	1 = 100 unit
01.31	Ambient temperature	Ambient temperature of the drive. Note: This parameter is applicable only for frames R6 or larger.	-
	°C or °F	Temperature	1 = 1 °
01.50	Current hour kWh	Current hour energy consumption. This is the energy of the last 60 minutes (not necessarily continuous) the drive has been running, not the energy of a calendar hour. The value is set to the value before the power cycle when the drive is again up and running.	-
	0.00 1000000.00 kWh	Energy.	1 = 1 kWh

No.	Name/Value	Description	Def/FbEq16
01.51	Previous hour kWh	Previous hour energy consumption. The value 01.50 Current hour kWh is stored here when its values has been cumulated for 60 minutes. The value is set to the value before the power cycle when the drive is again up and running.	-
	0.00 1000000.00 kWh	Energy.	1 = 1 kWh
01.52	Current day kWh	Current day energy consumption. This is the energy of the last 24 hours (not necessarily continuous) the drive has been running, not the energy of a calendar day. The value is set to the value before the power cycle when the drive is again up and running.	-
	0.00 1000000.00 kWh	Energy.	1 = 1 kWh
01.53	Previous day kWh	Previous day energy consumption. The value 01.52 Current day kWh is stored here when its value has been cumulated for 24 hours. The value is set to the value before the power cycle when the drive is again up and running.	-
	0.00 1000000.00 kWh	Energy.	1 = 1 kWh
01.54	Cumulative inverter energy	Amount of energy that has passed through the drive (in either direction) in full kilowatt-hours. The minimum value is zero.	-
	-200000000.0 200000000.0 kWh	Energy in kWh.	10 = 1 kWh
01.55	Inverter GWh counter (resettable)	Amount of energy that has passed through the drive (in either direction) in full gigawatt-hours. The minimum value is zero. You can reset the value by setting it to zero. Resetting any of parameters 01.5501.58 resets all of them.	-
	065535 GWh	Energy in GWh.	1 = 1 GWh
01.56	Inverter MWh counter (resettable)	Amount of energy that has passed through the drive (in either direction) in full megawatt-hours. Whenever the counter rolls over, 01.55 Inverter GWh counter (resettable) is incremented. The minimum value is zero. You can reset the value by setting it to zero. Resetting any of parameters 01.5501.58 resets all of them.	-
	01000 MWh	Energy in MWh.	1 = 1 MWh
01.57	Inverter MWh counter (resettable)	Amount of energy that has passed through the drive (in either direction) in full kilowatt-hours. Whenever the counter rolls over, 01.56 Inverter MWh counter (resettable) is incremented. The minimum value is zero. You can reset the value by setting it to zero. Resetting any of parameters 01.5501.58 resets all of them.	-
	01000 kWh	Energy in kWh.	10 = 1 kWH
01.58	Inverter kWh counter (resettable)	Amount of energy that has passed through the drive (in either direction) in full kilowatt-hours. The minimum value is zero. You can reset the value by setting it to zero. Resetting any of parameters 01.5501.58 resets all of them.	-
	-200000000.0 200000000.0 kWh	Energy in kWh.	10 = 1 kWH
01.61	Abs motor speed used	Absolute value of parameter 01.01 Motor speed used.	-
	0.00 30000.00 rpm	Estimated motor speed.	See par. 46.01

No.	Name/Value	Description	Def/FbEq16
01.62	Abs motor speed %	Absolute value of parameter 01.03 Motor speed %.	-
	0.00 1000.00%	Estimated motor speed.	10 = 1%
01.63	Abs output frequency	Absolute value of parameter 01.06 Output frequency.	-
	0.00500.00 Hz	Estimated output frequency.	See par. 46.02
01.64	Abs motor torque	Absolute value of parameter 01.10 Motor torque.	-
	0.01600.0%	Motor torque.	See par. 46.03
01.65	Abs output power	Absolute value of parameter 01.14 Output power.	-
	0.00 32767.00 kW	Output power.	1 = 1 kW
01.66	Abs output power % motor nom	Absolute value of parameter 01.15 Output power % of motor nom.	-
	0.00 300.00%	Output power.	1 = 1%
01.68	Abs motor shaft power	Absolute value of parameter 01.17 Motor shaft power.	-
	0.00 32767.00 hp or kW	Motor shaft power.	1 = 1 kW or hp
03 Inp	ut references	Values of references received from various sources. All parameters in this group are read-only unless otherwise noted.	
03.01	Panel reference	Reference 1 given from the control panel or PC tool.	-
	-100000.00 100000.00	Control panel or PC tool reference.	1 = 10
03.02	Panel reference remote	Reference 2 given from the control panel or PC tool.	-
	-100000.00 100000.00	Control panel or PC tool reference.	1 = 10
03.05	FB A reference 1	Reference 1 received through fieldbus adapter A. See also chapter <i>Fieldbus control through a fieldbus adapter</i> (page 471).	-
	-100000.00 100000.00	Reference 1 from fieldbus adapter A.	1 = 10
03.06	FB A reference 2	Reference 2 received through fieldbus adapter A.	-
	-100000.00 100000.00	Reference 2 from fieldbus adapter A.	1 = 10
03.09	EFB reference 1	Scaled reference 1 received through the embedded fieldbus interface.	1 = 10
	-30000.00 30000.00	Scaled reference 1 received through the embedded fieldbus interface.	1 = 10
03.10	EFB reference 2	Scaled reference 2 received through the embedded fieldbus interface.	1 = 10
	-30000.00 30000.00	Scaled reference 2 received through the embedded fieldbus interface.	1 = 10

No.	Name/Va	alue	Descriptio	n	Def/FbEq16	
04 Wai	rnings ai	nd faults	For explan chapter Fa	o on warnings and faults that occurred last. ations of individual warning and fault codes, see <i>ult tracing</i> . ters in this group are read-only unless otherwise		
04.01	Tripping	fault	Code of the trip).	e 1st active fault (the fault that caused the current	0x0000	
	0x0000	.0xffff	1st active f	ault.	1 = 1	
04.02	Active fa	ult 2	Code of the	e 2nd active fault.	0x0000	
	0x0000	.0xffff	2nd active	fault.	1 = 1	
04.03	Active fa	ult 3	Code of the	e 3rd active fault.	0x0000	
	0x0000	.0xffff	3rd active	ault.	1 = 1	
04.06	Active wa	arning 1	Code of the	e 1st active warning.	0x0000	
	0x0000	.0xffff	1st active v	varning.	1 = 1	
04.07	Active wa	arning 2	Code of the	e 2nd active warning.	0x0000	
	0x0000	.0xffff	2nd active	warning.	1 = 1	
04.08	Active wa	arning 3	Code of the 3rd active warning.		0x0000	
	0x0000	.0xffff	3rd active warning.		1 = 1	
04.11	Latest fa	ult	Code of the	0x0000		
	0x0000	.0xffff	1st stored	fault.	1 = 1	
04.12	2nd lates	st fault	Code of the 2nd stored (non-active) fault.		0x0000	
	0x0000	.0xffff	2nd stored fault.		1 = 1	
04.13	3rd lates	t fault	Code of the 3rd stored (non-active) fault.		0x0000	
	0x0000	.0xffff	3rd stored fault.		1 = 1	
04.16	Latest wa	arning	Code of the 1st stored (non-active) warning.		0x0000	
	0x0000	.0xffff	1st stored warning.		1 = 1	
04.17	2nd lates	st warning	Code of the 2nd stored (non-active) warning.		0x0000	
	0x0000	.0xffff	2nd stored warning.		1 = 1	
04.18	3rd lates	t warning	Code of the	e 3rd stored (non-active) warning.	0x0000	
	0x0000	.0xffff	3rd stored	warning.	1 = 1	
04.40	si b		status of th by parame	Shows the user-defined event word. This word collects the status of the events (warnings, faults or pure events) selected by parameters 04.4104.71. This parameter is read-only.		
	Bit	Name		Description		
	0	User bit 0		1 = Event selected by parameter 04.41 is active		
	1	User bit 1		1 = Event selected by parameter 04.43 is active		
	15	User bit 15	1 = Event selected by parameter 04.71 is active			
	0000hl	FFFFh	User-define	ser-defined event word.		

No. Name/Value 04.41 Event word 1 bit 0 code		e Description				
		Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 0 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing (page 411).	0x2310h			
	0000hFFFFh	Code of event.	1 = 1			
04.43	Event word 1 bit 1 code	Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 1 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing (page 411).	0x3210h			
	0000hFFFFh	Code of event.	1 = 1			
04.45, 04,47, 04,49, 						
04.71	Event word 1 bit 15 code	Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 15 of 04.40 Event word 1. The event codes are listed in chapter Fault tracing (page 411).	0x2330h			
	0000hFFFFh	Code of event.	1 = 1			
05 Diag	nostics	Various run-time-type counters and measurements related to drive maintenance. All parameters in this group are read-only unless otherwise noted.				
05.01	On-time counter	On-time counter. The counter runs when the drive is powered.	0			
	065535 d	On-time counter.	1 = 1 d			
05.02	Run-time counter	Motor run-time counter. The counter runs when the inverter modulates.	0			
	065535 d	Motor run-time counter.	1 = 1 d			
05.03	Hours run	Corresponding parameter to <i>05.02 Run-time counter</i> in hours, that is, 24 * <i>05.02</i> value + fractional part of a day.	-			
	0.0 429496729.5 h	Hours.	1 = 1 h			
05.04	Fan on-time counter	Running time of the drive cooling fan. Can be reset from the control panel by keeping Reset down for over 3 seconds.	0			
	065535 d	Cooling fan run-time counter.	1 = 1 d			
05.10	Control board temperature	Measured temperature of the control board.	0			
	-100 300 °C	Control board temperature in degrees Celsius or Fahrenheit.	1 = unit			
05.11	Inverter temperature	Estimated drive temperature in percent of fault limit. The fault limit varies according to the type of the drive. 0.0% = 0 °C (32 °F) 100.0% = Fault limit	0			
	-40.0160.0%	Drive temperature in percent.	1 = 1%			

No.	Name/\	/alue	Descrip	tion		Def/FbEq16
05.20	Diagnostic word 1			Diagnostic word 1. For possible causes and remedies, see 0b0000 chapter <i>Fault tracing</i> .		
	Bit Name Value					
	0	Any warnin	g or fault	Yes = Drive	e has generated a warning or tripped on	a fault.
	1	Any warnin	g	y Yes = Drive has generated a warning.		
	2	Any fault		Yes = Drive has tripped on a fault.		
	3	Reserved		I		
	4	Overcurren	ıt flt	Yes = Drive	e has tripped on fault 2310 Overcurrent.	
	5	Reserved				
	6	DC overvol	tage	Yes = Drive	e has tripped on fault 3210 DC link over	/oltage.
	7	DC underv	oltage		e has tripped on fault 3220 DC link unde	
	8	Reserved				
	9	Device ove	rtemp flt	Yes = Drive	e has tripped on fault 4310 Excess temp	erature.
	1015	Reserved				
	0b0000	0b1111	Diagnos	tic word 1.		1 = 1
05.21	Diagnostic word 2			Diagnostic word 2. For possible causes and remedies, see chapter <i>Fault tracing</i> .		060000
	Bit	Name			Value	
	09	Reserved				
	10				Yes = Drive has tripped on fault 4981 E temperature 1 or 4982 External temperature	
	1115	1115 Reserved				
	0b0000	0b1111	Diagnos	tic word 2.		1 = 1
05.22	Diagnostic word 3		Diagnostic word 3. For possible causes and remedies, see chapter <i>Fault tracing</i> .		060000	
	Bit	Name		Value		
	08	Reserved.				
	9	kWh pulse	ŀ	1 = kWh pulse	is active.	
	10	Reserved.				
	10		and.	1 = Drive fan i	s rotating above idle speed.	
		Fan comma	5 1			
	1215	Reserved	····· 1]
	1215			tic word 3.		1 = 1
05.80	1215 0b0000	Reserved	Diagnos	s the paramete curred. This is	er 24.02 Used speed feedback at which applicable in both scalar and speed	1 = 1
05.80	1215 0b0000	Reserved 0b1111 peed at fault 00	Diagnos Displays fault occ control r	s the paramete curred. This is		
05.80	1215 0b0000 <i>Motor</i> s -30000. 30000.0	Reserved 0b1111 peed at fault 00	Diagnos Displays fault occ control r Motor sp	s the paramete curred. This is node. peed at fault.		- See par.
	1215 0b0000 Motor s -30000. 30000.0 Output f fault	Reserved 0b1111 peed at fault 00 00 rpm	Diagnos Displays fault occ control r Motor sp Displays	s the paramete curred. This is node. peed at fault.	applicable in both scalar and speed equency (<i>01.06</i>) at which fault occurred.	- See par.
	-30000. -30	Reserved 0b1111 peed at fault 00 00 rpm frequency at	Diagnos Displays fault occ control r Motor sp Displays Output f	s the paramete surred. This is node. peed at fault. s the output fre requency at fa	applicable in both scalar and speed equency (<i>01.06</i>) at which fault occurred.	- See par. 46.01 - See par.

Parameters 171

No.	Name/Value	Description	Def/FbEq16
05.83	Motor current at fault	Displays the motor current (01.07) at which fault occurred.	-
05.84	Motor torque at fault	Displays the motor torque (01.10) at which fault occurred.	-
	-1600.01600.0%	Motor torque at fault.	See par. 46.03
05.85	Main status word at fault	Displays the main status word (<i>06.11</i>) at which fault occurred. For the bit list, see parameter <i>06.11 Main status word</i> .	0x0000
		Bit Name	
		0 Ready to switch ON	
		1 Ready run	
		2 Ready ref	
		3 Tripped	
		4 Not in use	
		5 Not in use	
		6 Not in use	
		7 Warning	
		8 Modulating	
		9 Remote	
		10 Net OK	
		11 User bit 0	
		12 User bit 1	
		13 User bit 2	
		14 Charging	
		15 User bit 3	
	0x00000xffff	Main status word at fault.	1 = 1
05.86	DI delayed status at fault	Displays the DI delayed status (10.02) at which fault occurred. For the bit list, see parameter 10.02 DI delayed status.	0b0000
	0b00000b1111	DI delayed status at fault.	1 = 1
05.87	Inverter temperature at fault	Displays the inverter temperature (05.11) at which fault occurred.	-
	-40160°C	Inverter temperature at fault.	1 = 1°C
05.88	Reference used at fault	Displays the reference used (28.01/23.01) at which fault occurred. The type of the reference depends on the selected operation mode (19.01).	-
	-500.00500.00 Hz/	Reference used at fault.	See par. 46.02/
	-1600.01600.0%/		See par. <u>46.03</u> / See par.
	30000.00 30000.00 rpm		46.01

No.	Name/V	/alue	Descript	tion			Def/FbEq16
05.99	BIO-01 status Bit 0	DIP switch	switches Notes: • This feinform contac • This p new B • Both D DO1.	S1 and eature is ation of t ABB s aramet tIO-01 r DIP swit The for ates fau Deso 0 = 0	s not available with the stan n the availability on new BIC sales team. er is applicable for frames F nodule is attached. tches cannot be connected bidden bit combination S1= ult 7087 I/O module configure cription DFF = DO1 on port S1,	dard BIO-01. For)-01 module, (0R2 when the simultaneously to) and S2 = 1	-
	1	S2		0 = 0	DN = AO1 on port S1 DFF = DI3 on port S2 DN = DO1 on port S2		
	25	Reserved					
	0000h	.FFFh	States of	the BI	O-01 DIP switches S1 and S	52	1 = 1
06 Col words		d status	Drive control and status words.				
			program) For the b word and respectiv). iit descr I state c rely.	, the fieldbus interfaces and riptions see page 478. The r diagram are presented on pa is read-only.	elated status	
			Ī	Bit	Name		
			(0	Off1 control		
			-	1	Off2 control		
			_	2	Off3 control		
				3	Run		
				4	Ramp out zero		
				5	Ramp hold	_	
			Ľ	6 7	Ramp in zero	_	
			Ľ	/ 8	Reset Inching 1	_	
				9	Inching 2	_	
				10	Remote cmd	_	
				11	Ext ctrl loc	_	
				12	User bit 0		
			-	12 13	User bit 0 User bit 1	_	
			•			_	
				13	User bit 1	-	
				13 14	User bit 1 User bit 2		

No.	Name/Value	Descriptio	n			Def/FbEq16
06.11	Main status word	For the bit of	descrip tate dia y.	of the drive. tions see page <i>480</i> . The rela agram are presented on page read-only.	ated control es 478 and 481	0x0000
		Bit	t	Name	1	
		0		Ready to switch ON		
		1		Ready run		
		2		Ready ref		
		3		Tripped		
		4		Off 2 inactive		
		5		Off 3 inactive		
		6		Switch-on inhibited		
		7		Warning		
		8		At setpoint		
		9		Remote		
		10)	Above limit		
		11		User bit 0		
		12	2	User bit 1		
		13	3	User bit 2		
		14	ł	User bit 3]	
		15	5	Reserved		
	0x00000xffff	Main status	s word.			1 = 1

о.	Name/\	/alue	Descript	ion	Def/FbEq16			
6.16	Drive si	tatus word 1		Drive status word 1. 0b0000 This parameter is read-only.				
	Bit	Name	De	escription				
	0	Enabled		= Both run enable (see par. 20.12) and start enable (a e present.	20.19) signals			
	1	Inhibited		Start inhibited. To start the drive, the inhibiting signal 5.18) must be removed and the start signal cycled.	al (see par.			
	2	DC charge	d 1:	= DC circuit has been charged.				
	3	Ready to st	tart 1	= Drive is ready to receive a start command.				
	4	Following reference	1	= Drive is ready to follow given reference.				
	5	Started	1	= Drive has been started.				
	6	Modulating	1	= Drive is modulating (output stage is being controlle	d).			
	7	Limiting	1	= Any operating limit (speed, torque, etc.) is active.				
	8	Local contr	ol 1	= Drive is in local control.				
	9	Network co	ntrol 1	= Drive is in <i>network control</i> (see page 16).				
	10	Ext1 active	1	= Control location EXT1 active.				
	11	Ext2 active		= Control location EXT2 active.				
	12	Reserved		-				
	13	Start request 1 =		Start requested. 0 = When Enable to rotate signal (see par. 22) is 0 (rotating of the motor is disabled).				
	14	Running 1 =		= Drive is controlling speed or frequency, in PID sleep agnetization.	o or pre-			
	15	Reserved						
	0b0000	0b1111	Drive sta	tus word 1.	1 = 1			
6.17	Drive s			tus word 2. ameter is read-only.	060000			
	Bit	Name		Description				
	0	Identificatio	n run done	1 = Motor identification (ID) run has been performed.				
	1	Magnetized		1 = The motor has been magnetized.				
	2	Torque con		1 = Torque control mode active.				
	3	Speed cont		1 = Speed control mode active.				
	4	Reserved						
	5	Safe refere	nce active	1 = A "safe" reference is applied by functions such as parameters 49.05 and 50.02 .				
	6	Last speed	active	 1 = A "last speed" reference is applied by functions such as parameters 49.05 and 50.02. 				
	78	Reserved						
	9	Jogging ac	tive	1 = Jogging enable signal is on.				
	10	Above limit		1 = Actual speed, frequency or torque equals or ex (defined by parameters 46.3146.33). Valid in bot rotation.				
	1112	Reserved						
	13	Start delay	active	1 = Start delay (par. 21.22) active.				
			active	1 = Start delay (par. 27.22) active.				


No.	Name/	me/Value Description		on	Def/FbEq16	
06.18	Start inhibit status word		inhibiting s The condit the start co inhibiting c See also p	it status word. This word specifies the source of the signal that is preventing the drive from starting. tions marked with an asterisk (*) only require that ommand is cycled. In all other instances, the sondition must be removed first. warameter 06.16 Drive status word 1, bit 1. neter is read-only.	060000	
	Bit	Name		Description		
	0	Not ready r	un	1 = DC voltage is missing or drive has not been pa correctly. Check the parameters in groups 95 and 9		
	1	Ctrl location	n changed	* 1 = Control location has changed.		
	2	SSW inhibi	t	1 = Control program is keeping itself in inhibited sta	ate.	
	3	Fault reset		* 1 = A fault has been reset.		
	4	Lost start e	nable	1 = Start enable signal missing.		
	5	Lost run en	able	1 = Run enable signal missing.		
	6	Reserved		•		
	7	STO		1 = Safe torque off function active.		
	8	Current calibration ended		* 1 = Current calibration routine has finished.		
	9	ID run ended		* 1 = Motor identification run has finished.		
	10	Reserved				
	11	Em Off1		1 = Emergency stop signal (mode off1).		
	12	Em Off2		1 = Emergency stop signal (mode off2).		
	13	Em Off3		1 = Emergency stop signal (mode off3).		
	14	Auto reset inhibit		1 = The autoreset function is inhibiting operation.		
	15	Jogging act	ive	1 = The jogging enable signal is inhibiting operation.		
	0b00000b1111		Start inhibit status word.		1 = 1	
06.19	Speed control status word			ntrol status word. neter is read-only.	060000	
	Bit	Name		Description		
	0	Zero speed		1 = Drive has been running below zero speed limit (par. 21.0 for a time defined by parameter 21.07 Zero speed delay.		
	1	Forward		1 = Drive is running in forward direction above zero speed limi (par. <i>21.06</i>).		
	2	Reverse		1 = Drive is running in reverse direction above zero speed lin (par. 21.06).		
	36	Reserved				
	7	Any consta request	nt speed	1 = A constant speed or frequency has been sele 06.20.	cted; see par	
	815	Reserved				
	01.000	00b1111	0	trol status word.	1 = 1	


No.	Name/V	alue	Descrip	otion	Def/FbEq16
06.20	Constant speed status word		constar parame <u>Constar</u>	Constant speed/frequency status word. Indicates which constant speed or frequency is active (if any). See also parameter 06.19 Speed control status word, bit 7, and section <i>Constant speeds/frequencies</i> (page 44). This parameter is read-only.	
	Bit Name			Description	
	0	Constant			
	1	Constant speed 2		1 = Constant speed or frequency 2 selected	
	2	2 Constant :		1 = Constant speed or frequency 3 selected	
	3	Constant s		1 = Constant speed or frequency 4 selected	
	4	Constant s		1 = Constant speed or frequency 5 selected	
	5	Constant s		1 = Constant speed or frequency 6 selected	
	6	Constant s	speed 7	1 = Constant speed or frequency 7 selected	
	715	Reserved			
	0b0000.	0b1111	Consta	nt speed/frequency status word.	1 = 1
06.21	Drive status word 3			atus word 3. rameter is read-only.	0b0000
	Bit Name				
	0	NameDeDC hold active1 =		1 = DC hold is active.	
	1	Post-magnetizing 1 = F active		1 = Post-magnetizing is active.	
	2	Motor pre-heating 1 = N active		1 = Motor pre-heating is active.	
	315	315 Reserved			
	0b00000b1111		Drive st	atus word 1.	1 = 1
06.29	MSW bit 10 selection		Selects (User b	Above limit	
	False		0	0	
	True		1	1	
	Above limit		Bit 10 of 06.17 Drive status word 2 (see page 174).		2
	Other [bit]		Source	-	
06.30	MSW bit 11 selection		Selects (User b	Ext ctrl loc	
	False		0	0	
	True		1	1	
	Ext ctrl loc		Bit 11 o	2	
	Other [bit]		Source	-	
06.31	MSW bit	12	Selects (User b	Ext run enable	
	False		0	0	
	True		1		1
	True Ext run enable		Status	of the external run enable signal (see parameter 20.12 able 1 source)	2
	Other [bit]				

No.	Name/	Value	Description		Def/FbEq16		
06.32	MSW b selectio			ary source whose 06.11 Main statu	status is transmitted as bit 13 is word.	False	
	False		0			0	
	True		1			1	
	Other [ˈbit]	Source select	ion (see <i>Terms a</i>	nd abbreviations on page 161)	-	
06.33	MSW bit 14 selection			ary source whose 06.11 Main statu	status is transmitted as bit 14 is word.	False	
	False		0			0	
	True		1			1	
	Other [ˈbit]	Source select	ion (see <i>Terms a</i>	nd abbreviations on page 161)	-	
07 Sys	stem in	fo		e and firmware ir s in this group are			
07.03	Drive r	ating id	Type of the dr	ive. (Rating ID in	brackets.)	Not selected	
07.04	Firmwa	are name	Firmware iden	tification.		-	
07.05	Firmwa	are version	Version numb	er of the firmware	Э.	0.00.0.0	
	0.00.0. 255.25	0255.255. 5	-	1=1			
07.06	Loadin name	g package	Name of the fi	-			
07.07	Loadin version	g package	Version numb	0.00.0.0			
	0.00.0. 255.25	0255.255. 5	-			1=1	
07.11	Cpu us	age	Microprocesso	0			
	0100)%	Microprocessor load.			1 = 1	
07.35	07.35 Drive configuration				e automatically detects and or C-series option.	0x0000	
	Bit	Name		Bit	Name		
	0	Reserved		8	BIO-01		
	1	Base unit		9	RIIO-01		
	2	Reserved		10	FSCA-01		
	3	FENA-21		11	FEIP-21		
	4	FECA-01		12	FMBT-21		
	5	FPBA-01		13			
	6	FCAN-01		14	FPNO-21		
	7	Reserved		15	FEPL-02		
	0x0000)0xffff	Drive configur	ation.		1 = 1	

No.	Name/V	alue	Description			Def/FbEq16
07.36				Plug 'n' play configuration. Drive automatically detects and enables any installed fieldbus or C-series option.		
	Bit Name			Bit	Name	
	0	FLON-01		4	CMOD-02	
	1	FDNA-01		5	CPTC-02	
	2	FCNA-01		6	CHDI-01	
	3	CMOD-01		715	Reserved	
	0x0000.	.0xffff	Drive configu	ation 2.		1 = 1
10 Sta	ndard D	I, RO	Configuration	of digital inputs and relay ou	tputs.	
10.01	DI status	3	activation/dea any are speci Bits 05 refle Example: 00 DI3, DI4 and	Displays the electrical status of digital inputs DI1DI6. The activation/deactivation delays of the inputs (if any are specified) are ignored. Bits 05 reflect the status of DI1DI6. Example: 000000000010011b = DI5, DI2 and DI1 are on, DI3, DI4 and DI6 are off. This parameter is read-only.		
	Bit	Name		Description		
	0	DI1		1 = Digital input 1 is ON.		
	1	DI2		1 = Digital input 2 is ON.		
	2	DI3		1 = Digital input 3 is ON.		
	3	DI4		1 = Digital input 4 is ON.		
	4	DI5		1 = Digital input 5 is ON.		
	5	DI6		1 = Digital input 6 is ON.		
	615	Reserved				
	0b0000.	0b1111	Status for dig	Status for digital inputs.		
10.02	the delayed s Example: 00 DI3, DI4 and This word is delay. When remain the sa for the new v			status of digital inputs DI1DI6. Bits 05 reflect status of DI1DI6. 0000000010011b = DI5, DI2 and DI1 are on, DI6 are off. updated only after a 2 ms activation/deactivation the value of a digital input changes, it must ame in two consecutive samples, that is for 2 ms, alue to be accepted. ter is read-only.		06000
	Bit	Name		Description		
	0	DI1		1 = Digital input 1 is ON.		
	1	DI2		1 = Digital input 2 is ON.		
	2	DI3		1 = Digital input 3 is ON.		
	3	DI4		1 = Digital input 4 is ON.		
	4	DI5		1 = Digital input 5 is ON.		
	5	DI6		1 = Digital input 6 is ON.		
	615	Reserved				
	0b00000b1111		Delayed status for digital inputs.		1 = 1	

No.	Name/Value	Description	Def/FbEq16					
10.03	DI force selection	The electrical statuses of the digital inputs can be overridden for e.g. testing purposes. A bit in parameter 10.04 DI forced data is provided for each digital input, and its value is applied whenever the corresponding bit in this parameter is 1. Note: Boot and power cycle reset the force selections (parameters 10.03 and 10.04).	060000					
	Bit Value							
		e DI1 to value of bit 0 of parameter 10.04 DI forced data. (0 = No						
		e DI2 to value of bit 1 of parameter 10.04 DI forced data. (0 = No						
		e DI3 to value of bit 2 of parameter 10.04 DI forced data. (0 = No	,					
		e DI4 to value of bit 3 of parameter 10.04 DI forced data. (0 = No	,					
		e DI5 to value of bit 4 of parameter 10.04 DI forced data. (0 = No	,					
		e DI6 to value of bit 5 of parameter 10.04 DI forced data. (0 = No	rmal mode)					
	615 Reserved	3						
	0b00000b1111	Override selection for digital inputs.	1 = 1					
10.04	DI forced data	Allows the data value of a forced digital input to be changed from 0 to 1. It is only possible to force an input that has been selected in parameter 10.03 <i>DI force selection</i> . Bit 0 is the forced value for DI1; bit 5 is the forced value for the DI6.	06000					
	Bit Value	·						
	0 Force th	value of this bit to D1, if so defined in parameter 10.03 DI force selection.						
	1 Force th	Force the value of this bit to D3, if so defined in parameter 10.03 DI force selection.						
	2 Force th	Force the value of this bit to D3, if so defined in parameter 10.03 DI force selection.						
	3 Force the value of this bit to D4, if so defined in parameter 10.03 DI force selection							
	4 Force th	e value of this bit to D5, if so defined in parameter 10.03 DI force	e selection.					
	5 Force th	e value of this bit to D6, if so defined in parameter 10.03 DI force	e selection.					
	615 Reserved	1						
	0b00000b1111	Forced values of digital inputs.	1 = 1					
10.05	DI1 ON delay	Defines the activation delay for digital input DI1.	0.0 s					
	*DI status		1					
	**Delayed DI status _		1					
	-	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	──> Time					
	$t_{On} = 10.05 DI1 ON de$ $t_{Off} = 10.06 DI1 OFF d$ *Electrical status of dig **Indicated by 10.02 D	<i>elay</i> jital input. Indicated by <i>10.01 DI status.</i>						
	0.0 3000.0 s	Activation delay for DI1.	10 = 1 s					
		Defines the deactivation delay for digital input DI1. See	0.0 s					
10.06	DI1 OFF delay	parameter 10.05 DI1 ON delay.	0.00					





No.	Name/Va	alue	Description	Def/FbEq16				
10.15	DI6 ON d	delay	Defines the activation delay for digital input DI6.	0.0 s				
	**Delaye	*DI status ed DI status 	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	1 0 1 0 $Time$				
	t _{Off} = <u>10.1</u> *Electrical		ay					
	0.0 30	000.0 s	Activation delay for DI6.	10 = 1 s				
10.16	DI6 OFF	delay	Defines the deactivation delay for digital input DI6. See parameter 10.15 DI6 ON delay.	0.0 s				
	0.0 30	000.0 s	Deactivation delay for DI6.	10 = 1 s				
10.21	RO statu	IS	Status of relay outputs RO3RO1.	0b0000				
	Bit	Value						
	0	1 = RO1 is	energized.					
	1	1 = RO2 is	1 = RO2 is energized.					
	2	1 = RO3 is	1 = RO3 is energized.					
	315	Reserved						
	050000	061111	Status of relay outputs	1 - 1				
	0b0000	-	Status of relay outputs.	1 = 1				
10.22	RO force	e selection	The signals connected to the relay outputs can be overridden for e.g. testing purposes. A bit in parameter 10.23 RO forced data is provided for each relay output, and its value is applied whenever the corresponding bit in this parameter is 1. Note: Boot and power cycle reset the force selections (parameters 10.22 and 10.23).	060000				
	Bit	Value						
	0	1 = Force F	1 = Force RO1 to value of bit 0 of parameter 10.23 RO forced data. (0 = No					
	1	1 = Force F	RO2 to value of bit 1 of parameter 10.23 RO forced data. (0 = No	ormal mode)				
	2	1 = Force F	RO3 to value of bit 2 of parameter 10.23 RO forced data. (0 = No	ormal mode)				
	315	Reserved						
	060000	061111	Quarries colorian for relay sub-	4 - 4				
	0b0000		Override selection for relay outputs.	1 = 1				

No.	Name/V	/alue	Description	Def/FbEq16
10.23	RO forc	ed data	Contains the values of relay outputs that are used instead of the connected signals if selected in parameter <i>10.22 RO force selection</i> . Bit 0 is the forced value for RO1.	0b0000
	Bit	Value		
	0	Force the v	value of this bit to RO1, if so defined in parameter 10.22 RO force	e selection.
	1		value of this bit to RO2, if so defined in parameter 10.22 RO force	
	2		value of this bit to RO3, if so defined in parameter 10.22 RO force	e selection.
	315	Reserved		
	0b0000.	0b1111	Forced RO values.	1 = 1
10.24	RO1 so	urce	Selects a drive signal to be connected to relay output RO1.	Ready run
	Not ene	rgized	Output is not energized.	0
	Energiz	ed	Output is energized.	1
	Ready r	un	Bit 1 of 06.11 Main status word (see page 173).	2
	Enabled	1	Bit 0 of 06.16 Drive status word 1 (see page 174).	4
	Started		Bit 5 of 06.16 Drive status word 1 (see page 174).	5
	Magneti	zed	Bit 1 of 06.17 Drive status word 2 (see page 174).	6
	Running		Bit 6 of 06.16 Drive status word 1 (see page 174).	7
	Ready ref		Bit 2 of 06.11 Main status word (see page 173).	8
	At setpoint		Bit 8 of 06.11 Main status word (see page 173).	9
	Reverse	9	Bit 2 of 06.19 Speed control status word (see page 175).	10
	Zero sp	eed	Bit 0 of 06.19 Speed control status word (see page 175).	11
	Above li	mit	Bit 10 of 06.17 Drive status word 2 (see page 174).	12
	Warning]	Bit 7 of 06.11 Main status word (see page 173).	13
	Fault		Bit 3 of 06.11 Main status word (see page 173).	14
	Fault (-1)	Inverted bit 3 of 06.11 Main status word (see page 173).	15
	Fault/Warning		Bit 3 of 06.11 Main status word OR bit 7 of 06.11 Main status word (see page 173).	16
	Overcurrent		Fault 2310 Overcurrent has occurred.	17
	Overvol	tage	Fault 3210 DC link overvoltage has occurred.	18
	Drive temp		Fault 2381 IGBT overload or 4110 Control board temperature or 4210 IGBT overtemperature or 4290 Cooling or 42F1 IGBT temperature or 4310 Excess temperature or 4380 Excess temperature difference has occurred.	19
	Undervo	oltage	Fault 3220 DC link undervoltage has occurred.	20
	Motor te	emp	Fault 4981 External temperature 1 or 4982 External temperature 2 has occurred.	21
	Brake c	ommand	Bit 0 of 44.01 Brake control status (see page 320).	22
	Ext2 act	tive	Bit 11 of 06.16 Drive status word 1 (see page 174).	23
	Remote	control	Bit 9 of 06.11 Main status word (see page 173).	24
	Timed fu	unction 1	Bit 0 of 34.01 Timed functions status (see page 280).	27
	Timed fu	unction 2	Bit 1 of 34.01 Timed functions status (see page 280).	28
	Timed fu	unction 3	Bit 2 of 34.01 Timed functions status (see page 280).	29
	Reserve	ed		3032

No.	Name/Value	Description	Def/FbEq16		
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 273).	33		
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 273).	34		
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 273).	35		
	Start delay	Bit 13 of 06.17 Drive status word 2 (see page 174).	39		
	RO/DIO control word bit0	Bit 0 of 10.99 RO/DIO control word (see page 185).	40		
	RO/DIO control word bit1	Bit 1 of 10.99 RO/DIO control word (see page 185).	41		
	RO/DIO control word bit2	Bit 2 of 10.99 RO/DIO control word (see page 185).	42		
	PFC1	Bit 0 of 76.01 PFC status (see page 352).	45		
	PFC2	Bit 1 of 76.01 PFC status (see page 352).	46		
	PFC3	Bit 2 of 76.01 PFC status (see page 352).	47		
	PFC4	Bit 3 of 76.01 PFC status (see page 352).	48		
	Event word 1	Event word 1 = 1 if any bit of 04.40 Event word 1 (see page 168) is 1, that is, if any warning, fault or pure event that has been defined with parameters 04.4304.71 is on.	53		
	User load curve	Bit 3 (Outside load limit) of 37.01 ULC output status word (see page 299).	61		
	RO/DIO control word	Maps to corresponding bit in parameter 10.99 RO/DIO control word. For example, Bit 0 of 10.99 RO/DIO control word controls RO1, Bit 1 of 10.99 RO/DIO control word controls RO2, and so on.	62		
	Other [bit]	Source selection (see Terms and abbreviations on page 161).	-		
10.25	RO1 ON delay	Defines the activation delay for relay output RO1.	0.0 s		
	Status of selected source		1 0		
	RO status 		$ \begin{array}{c} 1 \\ \hline 0 \\ \hline \end{array} \\ \hline Time \end{array} $		
		$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	Time		
	^t On ^t Off ^t On ^t Off t _{On} = 10.25 RO1 ON delay t _{Off} = 10.26 RO1 OFF delay				
	0.0 3000.0 s	Activation delay for RO1.	10 = 1 s		
10.26	RO1 OFF delay	Defines the deactivation delay for relay output RO1. See parameter <i>10.25 RO1 ON delay</i> .	0.0 s		
	0.0 3000.0 s	Deactivation delay for RO1.	10 = 1 s		
10.27	RO2 source	Selects a drive signal to be connected to relay output RO2. For the available selections, see parameter <i>10.24 RO1</i> <i>source</i> .	Running		

No.	Name/Va	lue	Description	Def/FbEq16
10.28	RO2 ON	delay	Defines the activation delay for relay output RO2.	0.0 s
	t _{on} = 10.24	of selected source	$c_{\rm ext}$	1 0 0 $Time$
	0.0 30		Activation delay for RO2.	10 = 1 s
10.29	RO2 OFI	⁼ delay	Defines the deactivation delay for relay output RO2. See parameter 10.28 RO2 ON delay.	0.0 s
	0.0 30	00.0 s	Deactivation delay for RO2.	10 = 1 s
10.30	RO3 sou	rce	Selects a drive signal to be connected to relay output RO3. For the available selections, see parameter <i>10.24 RO1</i> <i>source</i> .	Fault (-1)
10.31	RO3 ON	delay	Defines the activation delay for relay output RO3.	0.0 s
		of selected source RO status 11 RO3 ON del	$t_{c, 2}$ $t_{c, 3}$	$ \begin{array}{c} 1 \\ 0 \\ 1 \\ \hline 0 \\ \hline Time \end{array} $
	-	1 RO3 ON del 2 RO3 OFF de		
10.32	0.0 30 RO3 OFI		Activation delay for RO3. Defines the deactivation delay for relay output RO3. See	10 = 1 s 0.0 s
10.32	NUS UFI	uciay	parameter 10.31 RO3 ON delay.	0.0 5
	0.0 30	00.0 s	Deactivation delay for RO3.	10 = 1 s
10.99	word t c a s t		Storage parameter for controlling the relay outputs e.g. through the embedded fieldbus interface. To control the relay outputs (RO) of the drive, send a control word with the bit assignments shown below as Modbus I/O data. Set the target selection parameter of that particular data (<i>58.10158.114</i>) to <i>RO/DIO control word</i> . In the source selection parameter of the desired output, select the appropriate bit of this word.	060000
	Bit	Name	Description	
	0	RO1	Source bits for relay outputs RO1RO3. See parameter	rs 10.24,
	1	RO2	10.27 and 10.30.	
	2	RO3		
	2 315	Reserved		

No.	Name/Value	Description	Def/FbEq16
	0b00000b1111	RO/DIO control word.	1 = 1
10.101	RO1 toggle counter	Displays the number of times relay output RO1 has changed states.	0
	04294967000	State change count.	1 = 1
10.102	RO2 toggle counter	Displays the number of times relay output RO2 has changed states.	0
	04294967000	State change count.	1 = 1
10.103	RO3 toggle counter	Displays the number of times relay output RO3 has changed states.	0
	04294967000	State change count.	1 = 1

11 Standard D	10, FI, FO	Configuration of the frequency input.	
11.21 DI5 con	figuration	Selects how digital input 5 is used.	Digital input
Digital i	nput	DI5 is used as a digital input.	0
Frequer	ncy input	DI5 is used as a frequency input.	1
11.38 Freq in value	1 actual	Displays the value of frequency input 1 (via DI6DI5 when it is used as a frequency input) before scaling. See parameter <i>11.42 Freq in 1 min.</i> This parameter is read-only.	0
0 160	000 Hz	Unscaled value of frequency input 1.	1 = 1 Hz
11.39 Freq in value	1 scaled	Displays the value of frequency input 1 (via DI5 or DI6 when it is used as a frequency input) after scaling. See parameter <i>11.42 Freq in 1 min.</i> This parameter is read-only.	0
-32768. 32767.0		Scaled value of frequency input 1 (DI5 or DI6).	1 = 1
11.42 Freq in		Defines the minimum for the frequency actually arriving at frequency input 1 (DI5 or DI6 when it is used as a frequency input). The incoming frequency signal (11.38 Freq in 1 actual value) is scaled into an internal signal (11.39 Freq in 1 scaled value) by parameters 11.4211.45 as follows: 11.39 11.45 11.44 11.44 11.44 11.44 11.44 11.44 11.43 11.43 11.43 11.43 11.43	0 Hz
0 160	000 Hz	Minimum frequency of frequency input 1 (DI5 or DI6).	1 = 1 Hz

No.	Name/Value	Description	Def/FbEq16
11.43	Freq in 1 max	Defines the maximum for the frequency actually arriving at frequency input 1 (DI5 or DI6 when it is used as a frequency input). See parameter <i>11.42 Freq in 1 min</i> .	16000 Hz
	0 16000 Hz	Maximum frequency for frequency input 1 (DI5 or DI6).	1 = 1 Hz
11.44	Freq in 1 at scaled min	Defines the value that is required to correspond internally to the minimum input frequency defined by parameter 11.42 <i>Freq in 1 min.</i> See diagram at parameter 11.42 <i>Freq in 1 min.</i>	0.000
	-32768.000 32767.000	Value corresponding to minimum of frequency input 1.	1 = 1
11.45	Freq in 1 at scaled max	Defines the value that is required to correspond internally to the maximum input frequency defined by parameter <i>11.43 Freq in 1 max.</i> See diagram at parameter <i>11.42 Freq in 1 min.</i>	50.000
	-32768.000 32767.000	Value corresponding to maximum of frequency input 1.	1 = 1

12 Standard Al		Configuration of standard analog inputs.		
12.02	AI force	e selection	The true readings of the analog inputs can be overridden for e.g. testing purposes. A forced value parameter is provided for each analog input, and its value is applied whenever the corresponding bit in this parameter is 1. Note: AI filter times (parameters 12.16 AI1 filter time and 12.26 AI2 filter time) have no effect on forced AI values (parameters 12.13 AI1 forced value and 12.23 AI2 forced value). Note: Boot and power cycle reset the force selections (parameters 12.02 and 12.03).	060000
	Bit	Value		
	0	1 = Force A	AI1 to value of parameter 12.13 AI1 forced value.	
	1	1 = Force A	I2 to value of parameter 12.23 AI2 forced value.	
	215	Reserved		
		•		
	0b000	.0b1111	Forced values selector for analog inputs Al1 and Al2.	1 = 1
12.03	2.03 AI supervision function		Selects how the drive reacts when an analog input signal moves out of the minimum and/or maximum limits specified	No action

12.03 AI supervision function	Selects how the drive reacts when an analog input signal moves out of the minimum and/or maximum limits specified for the input. The supervision applies a margin of 0.5 V or 1.0 mA to the limits. For example, if the maximum limit for the input is 7.000 V, the maximum limit supervision activates at 7.500 V. The inputs and the limits to be observed are selected by parameter <i>12.04 Al supervision selection</i> .	No action
No action	No action taken.	0
Fault	Drive trips on 80A0 AI supervision.	1
Warning	Drive generates an A8A0 AI supervision warning.	2
Last speed	Drive generates a warning (<i>A8A0 Al supervision</i>) and freezes the speed (or frequency) to the level the drive was operating at. The speed/frequency is determined on the basis of actual speed using 850 ms low-pass filtering. WARNING! Make sure that it is safe to continue operation in case of a communication break.	3

No.	Name/	Value	Desc	ription	Def/FbEq16	
	Speed	ref safe	spee safe	generates a warning (<i>A8A0 AI supervision</i>) and sets the d to the speed defined by parameter 22.41 Speed ref (or 28.41 Frequency ref safe when frequency reference ng used). WARNING! Make sure that it is safe to continue operation in case of a communication break.	4	
12.04	Al supervision selection		parar Note be ei	ifies the analog input limits to be supervised. See meter <i>12.03 AI supervision function</i> . : The control location based AI supervision function can ther activated or deactivated with parameter <i>12.05 AI</i> rvision force.	0Ь0000	
	Bit	Name		Description		
	0	AI1 < MIN		1 = Minimum limit supervision of Al1 active.		
	1	AI1 > MAX		1 = Maximum limit supervision of AI1 active.		
	2	AI2 < MIN		1 = Minimum limit supervision of Al2 active.		
	3	AI2 > MAX		1 = Maximum limit supervision of AI2 active.		
	415	Reserved				
	01-000	0-4444	A		4 - 4	
12.05		0b1111 ervision force		ation of analog input supervision. ates/deactivates analog input supervision for each	1 = 1 0b0000	
			you c (12.0 super For e 19.11 12.04 12.05	h a control location does not utilize AI for referencing, an use this parameter to deactivate the AI supervision 4). This hides the warning or fault generated by AI rvision function (<i>12.03</i>), for the selected control location. xample, if <i>1 Ext1/Ext2 selection</i> = EXT1 <i>4 AI supervision selection</i> = Bit 0 or Bit 1 is 1 <i>5 AI supervision force</i> = Bit 0 is 0 AI1 supervision is masked in EXT1.		
	Bit	Name		Description		
	0	AI1 Ext1		1 = AI1 supervision is active when EXT1 is used.		
	1	AI1 Ext2		1 = AI1 supervision is active when EXT2 is used.		
	2	Al1 Local		1 = AI1 supervision is active when local control is used.		
	3			Reserved		
	4	Al2 Ext1		1 = Al2 supervision is active when EXT1 is used.		
	•			1 = Al2 supervision is active when EXT2 is used.		
	5	Al2 Ext2				
	5 6	Al2 Local		1 = AI2 supervision is active when local control is used.		
	5			1 = AI2 supervision is active when local control is used.		
	5 6 715	Al2 Local	Activ	1 = Al2 supervision is active when local control is used. ation/deactivation of analog input supervision.	1 = 1	
12.11	5 6 715 0b000.	Al2 Local Reserved	Displ on wi settin	ation/deactivation of analog input supervision. ays the value of analog input AI1 in mA or V (depending nether the input is set to current or voltage by a hardware	1 = 1 0	

No.	Name/Value	Description	Def/FbEq16
12.12	Al1 scaled value	Displays the value of analog input Al1 after scaling. See parameters 12.19 Al1 scaled at Al1 min and 12.20 Al1 scaled at Al1 max. This parameter is read-only.	0
	20700.000	· · · · · · · · · · · · · · · · · · ·	1 - 1
	-32768.000 32767.000	Scaled value of analog input Al1.	1 = 1
12.13	Al1 forced value	Forced value that can be used instead of the true reading of the input. See parameter <i>12.02 Al force selection</i> .	0
	0.00011.000 V	Forced value of analog input AI1.	1000 = 1 unit
12.15	Al1 unit selection	Selects the unit for readings and settings related to analog input A11. Note: In firmware ASCL2 and ASCL4), this setting must match the corresponding hardware setting on the drive control unit. See chapter <i>Electrical installation</i> , section <i>Switches</i> in the <i>Hardware manual</i> of the drive and the default control connections for the macro in use in chapter <i>Control macros</i> (page 101). Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.	V
	V	Volts.	2
	mA	Milliamperes.	10
12.16	AI1 filter time	Defines the filter time constant for analog input AI1.	0.100 s
		With the signal is also filtered due to the signal interface hardware (approximately 0.25 ms time constant). This cannot be changed by any parameter.	
	0.00030.000 s	Filter time constant.	1000 = 1
12.17	Al1 min	Defines the minimum site value for analog input Al1. Set the value actually sent to the drive when the analog signal from plant is wound to its minimum setting. See also parameter <i>12.19 Al1 scaled at Al1 min</i> .	0.000
	0.00011.000 V	Minimum value of AI1.	1000 = 1


No.	Name/Value	Description	Def/FbEq16
12.18	Al1 max	Defines the maximum site value for analog input AI1. Set the value actually sent to the drive when the analog signal from plant is wound to its maximum setting. See also parameter <i>12.19 Al1 scaled at Al1 min</i> .	10.000
	0.00011.000 V	Maximum value of Al1.	1000 = 1
12.19	Al1 scaled at Al1 min	Defines the real internal value that corresponds to the minimum analog input Al1 value defined by parameter 12.17 Al1 min. (Changing the polarity settings of 12.19 and 12.20 can effectively invert the analog input.) Al _{scaled} (12.12) 12.20 12.17 12.18 12.18	0.000
	-32768.000 32767.000	Real value corresponding to minimum AI1 value.	1 = 1
12.20	Al1 scaled at Al1 max	Defines the real internal value that corresponds to the maximum analog input Al1 value defined by parameter 12.18 Al1 max. See the drawing at parameter 12.19 Al1 scaled at Al1 min.	50.000
	-32768.000 32767.000	Real value corresponding to maximum Al1 value.	1 = 1
12.21	Al2 actual value	Displays the value of analog input AI2 in mA or V (depending on whether the input is set to current or voltage by a hardware setting). This parameter is read-only.	-
	0.00022.000 mA	Value of analog input Al2.	1000 = 1 unit
12.22	AI2 scaled value	Displays the value of analog input Al2 after scaling. See parameters 12.29 Al2 scaled at Al2 min and 12.101 Al1 percent value. This parameter is read-only.	0.000
	-32768.000 32767.000	Scaled value of analog input Al2.	1 = 1
12.23	AI2 forced value	Forced value that can be used instead of the true reading of the input. See parameter <i>12.02 AI force selection</i> .	0.000
	0.00022.000 mA	Forced value of analog input Al2.	1000 = 1 unit

No.	Name/Value	Description	Def/FbEq16
12.25	AI2 unit selection	Selects the unit for readings and settings related to analog input Al2. Note: In firmware ASCL2 and ASCL4), this setting must match the corresponding hardware setting on the drive control unit. See chapter <i>Electrical installation</i> , section <i>Switches</i> in the <i>Hardware manual</i> of the drive and the default control connections for the macro in use in chapter <i>Control macros</i> (page 101). Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.	mA
	V	Volts.	2
	mA	Milliamperes.	10
12.26	AI2 filter time	Defines the filter time constant for analog input Al2. See parameter 12.16 Al1 filter time.	0.100 s
	0.00030.000 s	Filter time constant.	1000 = 1 s
12.27	AI2 min	Defines the minimum site value for analog input Al2. Set the value actually sent to the drive when the analog signal from plant is wound to its minimum setting.	4.000 mA
	0.00022.000	Minimum value of Al2.	1000 = 1 unit
12.28	AI2 max	Defines the maximum site value for analog input Al2. Set the value actually sent to the drive when the analog signal from plant is wound to its maximum setting.	20.000 mA
	0.00022.000 mA	Maximum value of Al2.	1000 = 1 unit
12.29	AI2 scaled at AI2 min	Defines the real value that corresponds to the minimum analog input Al2 value defined by parameter 12.27 Al2 min. (Changing the polarity settings of 12.29 and 12.101 can effectively invert the analog input.) Al _{scaled} (12.22) 12.101 12.27 12.28 12.28	0.000
	-32768.000 32767.000	Real value corresponding to minimum Al2 value.	1 = 1
12.30	AI2 scaled at AI2 max	Defines the real value that corresponds to the minimum analog input Al2 value defined by parameter 12.28 Al2 max. See the drawing at parameter of 12.29 Al2 scaled at Al2 min.	50.000
	-32768.000 32767.000	Real value corresponding to maximum Al2 value.	1 = 1


No.	Name/Va	alue	Description	Def/FbEq16
12.101	Al1 perc	ent value	Value of analog input Al1 in percent of Al1 scaling (12.18 Al1 max - 12.17 Al1 min).	0
	0.0010	0.00%	Al1 value	100 = 1%
12.102	12.102 Al2 percent value		Value of analog input Al2 in percent of Al2 scaling (12.28 Al2 max - 12.27 Al2 min).	0
	0.0010	0.00%	Al2 value	100 = 1%
12.110	Al dead	band	Defines AI dead band value in percentage where 100% = 10V in voltage mode and 100% = 20mA in current mode. This is applicable for both AI1 and AI2. Note: 10% of the AI dead-band value is internally added to the firmware as AI dead-band hysteresis (positive and negative). This value cannot be changed. For more information on dead-band function and its calculation, see section <i>Dead-band function</i> on page 97.	0.40%
	0.0010	0.00%	Deadband for AI signals.	100 = 1%
13 Sta	ndard A	0	Configuration of standard analog outputs.	
13.02 AO force sele		e selection	The source signals of the analog outputs can be overridden for e.g. testing purposes. A forced value parameter is provided for each analog output, and its value is applied whenever the corresponding bit in this parameter is 1. Note: Boot and power cycle reset the force selections (parameters 13.02 and 13.11).	060000
			u ,	I
	Bit	Value	u	<u> </u>
	Bit 0		AO1 to value of parameter <i>13.13 AO1 forced value</i> . (0 = Normal	mode)
		1 = Force A	Г" , ,	,
	0	1 = Force A	AO1 to value of parameter <i>13.13 AO1 forced value</i> . (0 = Normal	,
	0	1 = Force A 1 = Force A Reserved	AO1 to value of parameter <i>13.13 AO1 forced value</i> . (0 = Normal	,
13.11	0 1 215 0b0000.	1 = Force A 1 = Force A Reserved	AO1 to value of parameter <i>13.13 AO1 forced value</i> . (0 = Normal AO2 to value of parameter <i>13.23 AO2 forced value</i> . (0 = Normal	mode)
13.11	0 1 215 0b0000. <i>AO1 acti</i>	1 = Force A 1 = Force A Reserved 0b1111	AO1 to value of parameter 13.13 AO1 forced value. (0 = Normal AO2 to value of parameter 13.23 AO2 forced value. (0 = Normal Forced values selector for analog outputs AO1 and AO2. Displays the value of AO1 in mA	mode)
	0 1 215 0b0000. <i>AO1 acti</i>	1 = Force A 1 = Force A Reserved 0b1111 ual value 22.000 mA	AO1 to value of parameter 13.13 AO1 forced value. (0 = Normal AO2 to value of parameter 13.23 AO2 forced value. (0 = Normal Forced values selector for analog outputs AO1 and AO2. Displays the value of AO1 in mA This parameter is read-only.	mode) 1 = 1 -
	0 1 215 0b0000. <i>AO1 actu</i> 0.0002	1 = Force A 1 = Force A Reserved 0b1111 ual value 22.000 mA	AO1 to value of parameter 13.13 AO1 forced value. (0 = Normal AO2 to value of parameter 13.23 AO2 forced value. (0 = Normal Forced values selector for analog outputs AO1 and AO2. Displays the value of AO1 in mA This parameter is read-only. Value of AO1.	mode) 1 = 1 - 1 = 1 mA Output
	0 0 1 215 0b0000. AO1 actu 0.0002 AO1 sou Zero	1 = Force A 1 = Force A Reserved 0b1111 ual value 22.000 mA	AO1 to value of parameter 13.13 AO1 forced value. (0 = Normal AO2 to value of parameter 13.23 AO2 forced value. (0 = Normal Forced values selector for analog outputs AO1 and AO2. Displays the value of AO1 in mA This parameter is read-only. Value of AO1. Selects a signal to be connected to analog output AO1.	node) 1 = 1 - 1 = 1 mA Output frequency
	0 1 215 0b0000. AO1 actr 0.0002 AO1 sources Zero Motor sp	1 = Force A 1 = Force A Reserved 0b1111 ual value 22.000 mA irce	AO1 to value of parameter 13.13 AO1 forced value. (0 = Normal AO2 to value of parameter 13.23 AO2 forced value. (0 = Normal Forced values selector for analog outputs AO1 and AO2. Displays the value of AO1 in mA This parameter is read-only. Value of AO1. Selects a signal to be connected to analog output AO1. None.	mode) 1 = 1 - 1 = 1 mA Output frequency 0
	0 1 215 0b0000. AO1 actr 0.0002 AO1 sources Zero Motor sp	1 = Force A 1 = Force A Reserved 0b1111 ual value 22.000 mA Irce peed used requency	AO1 to value of parameter <i>13.13 AO1 forced value</i> . (0 = Normal AO2 to value of parameter <i>13.23 AO2 forced value</i> . (0 = Normal Forced values selector for analog outputs AO1 and AO2. Displays the value of AO1 in mA This parameter is read-only. Value of AO1. Selects a signal to be connected to analog output AO1. None. <i>01.01 Motor speed used</i> (page <i>164</i>).	mode) 1 = 1 - 1 = 1 mA <i>Output</i> <i>frequency</i> 0 1
	0 1 215 0b0000. AO1 actu AO1 sou Zero Motor sp Output fr Motor cu	1 = Force A 1 = Force A Reserved 0b1111 ual value 22.000 mA Irce Deed used requency Irrent wrent % of	AO1 to value of parameter 13.13 AO1 forced value. (0 = Normal AO2 to value of parameter 13.23 AO2 forced value. (0 = Normal Forced values selector for analog outputs AO1 and AO2. Displays the value of AO1 in mA This parameter is read-only. Value of AO1. Selects a signal to be connected to analog output AO1. None. 01.01 Motor speed used (page 164). 01.06 Output frequency (page 164).	mode) 1 = 1 - 1 = 1 mA Output frequency 0 1 3
	0 1 215 0b0000. AO1 actr 0.0002 AO1 sou Zero Motor sp Output fr Motor cu Motor cu	1 = Force A 1 = Force A Reserved 0b1111 ual value 22.000 mA trce weed used requency trrent trrent % of minal	AO1 to value of parameter 13.13 AO1 forced value. (0 = Normal AO2 to value of parameter 13.23 AO2 forced value. (0 = Normal Forced values selector for analog outputs AO1 and AO2. Displays the value of AO1 in mA This parameter is read-only. Value of AO1. Selects a signal to be connected to analog output AO1. None. 01.01 Motor speed used (page 164). 01.06 Output frequency (page 164). 01.07 Motor current (page 164).	mode) 1 = 1 - 1 = 1 mA Output frequency 0 1 3 4
	0 1 215 0b0000. AO1 actu AO1 sou Zero Motor sp Output fr Motor cu Motor cu motor nc	1 = Force A 1 = Force A Reserved 0b1111 ual value 22.000 mA urce weed used requency urrent urrent % of ominal rque	AO1 to value of parameter 13.13 AO1 forced value. (0 = Normal AO2 to value of parameter 13.23 AO2 forced value. (0 = Normal Forced values selector for analog outputs AO1 and AO2. Displays the value of AO1 in mA This parameter is read-only. Value of AO1. Selects a signal to be connected to analog output AO1. None. 01.01 Motor speed used (page 164). 01.06 Output frequency (page 164). 01.07 Motor current (page 164). 01.08 Motor current % of motor nom (page 164).	mode) 1 = 1 - 1 = 1 mA Output frequency 0 1 3 4 5
	0 0 1 215 0b0000. AO1 actu 0.0002 AO1 sou Zero Motor sp Output fr Motor cu motor nc Motor to	1 = Force A 1 = Force A Reserved 0b1111 ual value 22.000 mA urce eeed used requency urrent % of ominal rque ge	AO1 to value of parameter 13.13 AO1 forced value. (0 = Normal AO2 to value of parameter 13.23 AO2 forced value. (0 = Normal AO2 to value of parameter 13.23 AO2 forced value. (0 = Normal Forced values selector for analog outputs AO1 and AO2. Displays the value of AO1 in mA This parameter is read-only. Value of AO1. Selects a signal to be connected to analog output AO1. None. 01.01 Motor speed used (page 164). 01.07 Motor current (page 164). 01.08 Motor current % of motor nom (page 164). 01.10 Motor torque (page 164).	mode) 1 = 1 - 1 = 1 mA Output frequency 0 1 3 4 5 6
13.11	0 0 1 215 0b0000. AO1 actu 0.0002 AO1 sou Zero Motor sp Output fr Motor cu motor nc Motor to DC volta	1 = Force A 1 = Force A Reserved 0b1111 ual value 22.000 mA urce veed used requency urrent urrent % of minal rque ge ower	AO1 to value of parameter 13.13 AO1 forced value. (0 = Normal AO2 to value of parameter 13.23 AO2 forced value. (0 = Normal AO2 to value of parameter 13.23 AO2 forced value. (0 = Normal Forced values selector for analog outputs AO1 and AO2. Displays the value of AO1 in mA This parameter is read-only. Value of AO1. Selects a signal to be connected to analog output AO1. None. 01.01 Motor speed used (page 164). 01.06 Output frequency (page 164). 01.07 Motor current (page 164). 01.10 Motor torque (page 164). 01.11 DC voltage (page 164).	mode) 1 = 1 - 1 = 1 mA Output frequency 0 1 3 4 5 6 7

No.	Name/Value	Description	Def/FbEq16
	Temp sensor 1 excitation	The output is used to feed an excitation current to the temperature sensor 1, see parameter 35.11 Temperature 1 source. See also section <i>Motor thermal protection</i> (page 81).	20
	Temp sensor 2 excitation	The output is used to feed an excitation current to the temperature sensor 2, see parameter 35.21 Temperature 2 source. See also section <i>Motor thermal protection</i> (page 81).	21
	Abs motor speed used	01.61 Abs motor speed used (page 168).	26
	Abs motor speed %	01.62 Abs motor speed % (page 167).	27
	Abs output frequency	01.63 Abs output frequency (page 167).	28
	Abs motor torque	01.64 Abs motor torque (page 167).	30
	Abs output power	01.65 Abs output power (page 167).	31
	Abs motor shaft power	01.68 Abs motor shaft power (page 167).	32
	AO1 data storage	13.91 AO1 data storage (page 198).	37
	AO2 data storage	13.92 AO2 data storage (page 198).	38
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
13.13	AO1 forced value	Forced value that can be used instead of the selected output signal. See parameter <i>13.02 AO force selection</i> .	0.000 mA
	0.00022.000 mA / 0.00011.000 V	Forced value for AO1.	1 = 1 unit
13.15	AO1 unit selection	Selects the unit for readings and settings related to analog input AO1. Note: In firmware ASCL2 and ASCL4), this setting must match the corresponding hardware setting on the drive control unit. See chapter <i>Electrical installation</i> , section <i>Switches</i> in the <i>Hardware manual</i> of the drive and the default control connections for the macro in use in chapter <i>Control macros</i> (page 101). Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.	mA
	V	Volts.	2
	mA	Milliamperes.	10

No.	Name/Value	Description	Def/FbEq16
13.16	AO1 filter time	Defines the filtering time constant for analog output AO1. W filtered signal 100 63 T Filtered signal t $O = I \times (1 - e^{-t/T})$ I = filter input (step) O = filter output t = time T = filter time constant	0.100 s
	0.000 30.000 s	Filter time constant.	1000 = 1 s



No.	Nam	e/Value	Description			Def/FbEq16	
				me the source for the AO is char ninimum and maximum values ov			
	13.12 AO1 so 13.22 AO2 so			13.17 AO1 source min, 13.27 AO2 source min	13.18 AO1 source 13.28 AO2 source		
	0	Zero		N/A (Output is constant zero.)			
	1	Motor speed u	ised	0	46.01 Speed sca	aling	
	3	Output freque	ncy	0	46.02 Frequency	/ scaling	
	4	Motor current		0	Max. value of 30 <i>current</i>	.17 Maximum	
	5	Motor current nominal	% of motor	0%	100%		
	6	Motor torque		0	46.03 Torque sc	aling	
	7	DC voltage		Min. value of 01.11 DC voltage	Max. value of 01 voltage	.11 DC	
	8	Output power		0	46.04 Power sca	aling	
	14	Freq ref used		0	46.02 Frequency	/ scaling	
	16	Process PID c	out	Min. value of 40.01 Process PID output actual	Max. value of 40 PID output actua		
	20	Temp sensor	1 excitation	N/A (Analog output is not scale	ed; it is determine	ned by the	
	21	Temp sensor 2	2 excitation	sensor's triggering voltage.)			
	26	Abs motor spe	ed used	0	46.01 Speed sca	aling	
	27	Abs motor spe	ed %	0	46.01 Speed sca	aling	
	28	Abs output fre	quency	0	46.02 Frequency	/ scaling	
	30	Abs motor tore	que	0	46.03 Torque sc	aling	
	31	Abs output po	wer	0	46.04 Power sca	aling	
	32	Abs motor sha		0	46.04 Power sca	ling	
	37	AO1 data stor	age	13.91 AO1 data storage (page - 198).			
	38	AO2 data stor	age	13.92 AO2 data storage (page 198).	-		
		Other		Min. value of the selected	Max. value of the		
	-3276	68.032767.0	Real signal v value.	value corresponding to minimum	AO1 output	1 = 1	
13.18	AO1	source max	parameter 1 maximum re	eal maximum value of the signa 3.12 AO1 source) that correspon quired AO1 output value (defined ut at AO1 src max). See parame	ds to the by parameter	50.0	
	-3276	68.032767.0	Real signal v value.	alue corresponding to maximum	AO1 output	1 = 1	
3.19	AO1 min	out at AO1 src		ines the minimum output value for analog output AO1. e also drawing at parameter <i>13.17 AO1 source min</i> .		0.000 mA	
)22.000 mA /)11.000 V	Minimum AC	1 output value.		1000 = 1 m	
3.20	AO1 max	out at AO1 src		naximum output value for analog wing at parameter <i>13.17 AO1</i> so		20.000 mA	
)22.000 mA /)11.000 V	Maximum AC	D1 output value.		1000 = 1 m	




No.	Name/Value	Description	Def/FbEq16
13.28	AO2 source max	Defines the real maximum value of the signal (selected by parameter 13.22 AO2 source) that corresponds to the maximum required AO2 output value (defined by parameter 13.30 AO2 out at AO2 src max). See parameter 13.27 AO2 source min. See parameter 13.17 AO1 source min about the AO automatic scaling.	3.2
	-32768.032767.0	Real signal value corresponding to maximum AO2 output value.	1 = 1
13.29	AO2 out at AO2 src min	Defines the minimum output value for analog output AO2. See also drawing at parameter <i>13.27 AO2 source min</i> .	4.000 mA
	0.000 22.000 mA	Minimum AO2 output value.	1000 = 1 mA
13.30	AO2 out at AO2 src max	Defines the maximum output value for analog output AO2. See also drawing at parameter <i>13.27 AO2 source min</i> .	20.000 mA
	0.000 22.000 mA	Maximum AO2 output value.	1000 = 1 mA
13.91	AO1 data storage	Storage parameter for controlling analog output AO1 e.g. through the embedded fieldbus interface. In parameter 13.12 AO1 source, select AO1 data storage. Then set this parameter as the target of the incoming value data. With the embedded fieldbus interface, simply set the target selection parameter of that particular data (58.10158.114) to AO1 data storage.	0.00
	-327.68327.67	Storage parameter for AO1.	100 = 1
13.92	AO2 data storage	Storage parameter for controlling analog output AO2 e.g. through the embedded fieldbus interface. In parameter 13.22 AO2 source, select AO2 data storage. Then set this parameter as the target of the incoming value data. With the embedded fieldbus interface, simply set the target selection parameter of that particular data (58.10158.114) to AO2 data storage.	0.00
	-327.68327.67	Storage parameter for AO2.	100 = 1
15 I/O modu	Extension le	Configuration of the I/O extension module installed in slot 2. See also section <i>Programmable I/O extensions</i> (page 42). Note: The contents of the parameter group vary according to the selected I/O extension module type.	
15.01	Extension module type	Activates (and specifies the type of) an I/O extension module, If the extension module has been installed and the drive is powered (keeping all bits in 07.35 Drive configuration and 07.36 Drive configuration 2 as 0), the drive automatically sets the value to the type it has detected in 15.02 Detected extension module. Warning A7AB Extension I/O configuration failure is generated if 15.01 Extension module type is not None and not matching 15.02 Detected extension module. In that case you will have to set the value of this parameter manually.	None
	None	None.	0
	BREL	External relay option BREL-01. Note: Applicable for frames R0R2 only.	5
15.02	Detected extension module	I/O extension module detected on the drive.	None
	None	Inactive.	0
		External relay option BREL-01.	5

No.	Name/	Value	Description		Def/FbEq16		
15.04	RO/DC) status	digital output Bits 01 ind the status of Example: 10	status of the relay outputs RO4 and RO75 and t DO1 on the extension module. licates the status of RO4RO75; bit 5 indicates DO1. 20101b = RO4 is on, RO5 is off. and DO1 is on. ter is read-only.	-		
	Bit	Name		Description			
	0	RO4		1 = Relay output 4 is ON.			
	1	RO5		1 = Relay output 5 is ON			
	2	RO6		1 = Relay output 6 is ON			
	3	RO7		1 = Relay output 7 is ON			
	4	Reserv	ed	·			
	5	DO1		1 = Digital output 1 is ON.			
	615	15 Reserved					
	0000h.	FFFFh	Status of rela	ay/digital outputs.	1 = 1		
15.05			overridden, f parameter 1 relay or digit correspondir Note: Boot a	al statuses of the relay/digital outputs can be for example, for testing purposes. A bit in 5.06 RO/DO forced data is provided for each al output, and its value is applied whenever the ng bit in this parameter is 1. and power cycle reset the force selections 15.05 and 15.06).	0000h		
	Bit	Name	Value				
	0	RO4	1 = Force RO4 to	o value of bit 0 of parameter 15.06 RO/DO forced	data.		
	1	RO5	1 = Force RO5 to	o value of bit 1 of parameter 15.06 RO/DO forced	data.		
	2	RO6	1 = Force RO6 to	o value of bit 2 of parameter 15.06 RO/DO forced	data.		
	3	R07	1 = Force RO7 to	o value of bit 3 of parameter 15.06 RO/DO forced	data.		
	4	Reserv	Reserved				
	5	DO1	1 = Force DO1 to	o value of bit 5 of parameter 15.06 RO/DO forced	data.		
	615	Reserv	ed				
		FFFFh		ection for relay/digital outputs.	1 = 1		

No.	Name/	Value	Description	Def/FbEq16
15.06	RO/DC	D forced data	Allows the data value of a forced relay or digital output to be changed from 0 to 13. It is only possible to force an output that has been selected in parameter 15.05 RO/DO force selection. Bits 013 are the forced values for RO4RO57; bit 5 is the forced value for DO1.	0000h
	Bit	Name	Description	
	0	RO4	Force the value of this bit to RO4, if so defined in parameter RO/DO force selection.	15.05
	1	RO5	Force the value of this bit to RO5, if so defined in parameter RO/DO force selection.	15.05
	2	RO6	Force the value of this bit to RO6, if so defined in parameter RO/DO force selection.	15.05
	3	RO7	Force the value of this bit to RO7, if so defined in parameter 15.05 RO/DO force selection.	
	4	Reserved	•	
	5	DO1	Force the value of this bit to DO1 if so defined in parameter 1 force selection.	5.05 RO/DO
	615	Reserved	•	
	0000h	FFFFh	Forced values of relay/digital outputs.	1 = 1
15.07	RO4 source		Selects a drive signal to be connected to relay output RO4.	Not energized
	Not energized		Output is not energized.	0
	Energized		Output is energized.	1
	Ready run		Bit 1 of 06.11 Main status word (see page 173).	2
	Reserv	/ed		3
	Enable	ed	Bit 0 of 06.16 Drive status word 1 (see page 174).	4
	Started	ł	Bit 5 of 06.16 Drive status word 1 (see page 174).	5
	Magne	etized	Bit 1 of 06.17 Drive status word 2 (see page 174).	6
	Runnir	ng	Bit 6 of 06.16 Drive status word 1 (see page 174).	7
	Ready	ref	Bit 2 of 06.11 Main status word (see page 173).	8
	At setpoint		Bit 8 of 06.11 Main status word (see page 173).	9
	Revers	se	Bit 2 of 06.19 Speed control status word (see page 175).	10
	Zero s	peed	Bit 0 of 06.19 Speed control status word (see page 175).	11
	Above	limit	Bit 10 of 06.17 Drive status word 2 (see page 174).	12
	Warnir	ng	Bit 7 of 06.11 Main status word (see page 173).	13
	Fault		Bit 3 of 06.11 Main status word (see page 173).	14
	Fault (-1)	Inverted bit 3 of 06.11 Main status word (see page 173).	15
	Fault/V	Varning	Bit 3 of 06.11 Main status word OR bit 7 of 06.11 Main status word (see page 173).	16
	Overcu	urrent	Fault 2310 Overcurrent has occurred.	17
	Overvo	oltage	Fault 3210 DC link overvoltage has occurred.	18

No.	Name/Value	Description	Def/FbEq16
	Drive temp	Fault 2381 IGBT overload or 4110 Control board temperature or 4210 IGBT overtemperature or 4290 Cooling or 42F1 IGBT temperature or 4310 Excess temperature or 4380 Excess temperature difference has occurred.	19
	Undervoltage	Fault 3220 DC link undervoltage has occurred.	20
	Motor temp	Fault 4981 External temperature 1 or 4982 External temperature 2 has occurred.	21
	Brake command	Bit 0 of 44.01 Brake control status (see page 320).	22
	Ext2 active	Bit 11 of 06.16 Drive status word 1 (see page 174).	23
	Remote control	Bit 9 of 06.11 Main status word (see page 173).	24
	Reserved		2526
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 280).	27
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 280).	28
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 280).	29
	Reserved		3032
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 273).	33
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 273).	34
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 273).	35
	Reserved		3638
	Start delay	Bit 13 of 06.17 Drive status word 2 (see page 174).	39
	RO/DIO control word bit0	Bit 0 of 10.99 RO/DIO control word (see page 185).	40
	RO/DIO control word bit1	Bit 1 of 10.99 RO/DIO control word (see page 185).	41
	RO/DIO control word bit2	Bit 2 of 10.99 RO/DIO control word (see page 185).	42
	Reserved		4344
	PFC1	Bit 0 of 76.01 PFC status (see page 352).	45
	PFC2	Bit 1 of 76.01 PFC status (see page 352).	46
	PFC3	Bit 2 of 76.01 PFC status (see page 352).	47
	PFC4	Bit 3 of 76.01 PFC status (see page 352).	48
	PFC5	Bit 4 of 76.01 PFC status (see page 352).	49
	PFC6	Bit 5 of 76.01 PFC status (see page 352).	50
	Reserved		5152
	Event word 1	Event word 1 = 1 if any bit of 04.40 Event word 1 (see page 168) is 1, that is, if any warning, fault or pure event that has been defined with parameters 04.4104.71 is on.	53
	User load curve	Bit 3 (Outside load limit) of 37.01 ULC output status word (see page 396).	61
	RO/DIO control word	For 15.07 RO4 source: Bit 3 (RO4) of 10.99 RO/DIO control word (see page 185). For 15.10 RO5 source: Bit 4 (RO5) of 10.99 RO/DIO control word (see page 185).	62
	Other [bit]	Source selection (see Terms and abbreviations on page 161).	-



No.	Name/Value	Description	Def/FbEq16
15.14	RO6 ON delay	Defines the activation delay for relay output RO6.	0.0 s
	Status of selected source	ton torr ton torr	1 0 1 0 Time
	$t_{\rm Off} = 15.12 \text{ RO5 OFF de}$ 0.0 3000.0 s	Activation delay for RO6.	10 = 1 s
15.15	RO6 OFF delay	Defines the deactivation delay for relay output RO6. See parameter <i>15.11 RO5 ON delay</i> .	0.0 s
	0.0 3000.0 s	Deactivation delay for RO6.	10 = 1 s
15.16	RO7 source	Selects a drive signal to be connected to relay output RO7. For the available selections, see parameter 15.07 RO4 source.	Not energized
15.17	RO7 ON delay	Defines the activation delay for relay output RO7.	0.0 s
	Status of selected source 	ton toff ton toff	1 0 1 0 <i>Time</i>
	t _{On} = 15.11 RO5 ON de t _{Off} = 15.12 RO5 OFF de	lay	
	0.0 3000.0 s	Activation delay for RO7.	10 = 1 s
15.18	RO7 OFF delay	Defines the deactivation delay for relay output RO7. See parameter <i>15.11 RO5 ON delay</i> .	0.0 s
	0.0 3000.0 s	Deactivation delay for RO7.	10 = 1 s
19 Op	eration mode	Selection of local and external control location sources and operating modes. See also section <i>Operating modes of the drive</i> (page 37).	
19.01	Actual operation mode	Displays the operating mode currently used. See parameters <i>19.1119.14</i> . This parameter is read-only.	Scalar (Hz)
	Zero	None.	1
	Speed	Speed control (in vector motor control mode).	2
	Torque	Torque control (in vector motor control mode).	3

No.	Name/Value	Description	Def/FbEq16
	Min	The torque selector is comparing the output of the speed controller (25.01 Torque reference speed control) and torque reference (26.74 Torque ref ramp out) and the smaller of the two is used (in vector motor control mode).	4
	Max	The torque selector is comparing the output of the speed controller (25.01 Torque reference speed control) and torque reference (26.74 Torque ref ramp out) and the greater of the two is used (in vector motor control mode).	5
	Add	The speed controller output is added to the torque reference (in vector motor control mode).	6
	Reserved		79
	Scalar (Hz)	Frequency control in scalar motor control mode (in scalar motor control mode).	10
	Forced magn.	Motor is in magnetizing mode.	20
19.11	Ext1/Ext2 selection	Selects the source for external control location EXT1/EXT2 selection. 0 = EXT1 1 = EXT2	EXT1
	EXT1	EXT1 (permanently selected).	0
	EXT2	EXT2 (permanently selected).	1
	FBAA MCW bit 11	Control word bit 11 received through fieldbus interface A.	2
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 280).	19
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 280).	20
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 280).	21
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 273).	25
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 273).	26
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 273).	27
	EFB MCW bit 11	Control word bit 11 received through the embedded fieldbus interface.	32
	FBA A connection loss	Detected communication loss of fieldbus interface A changes control mode to EXT2.	33
	EFB connection loss	Detected communication loss of embedded fieldbus interface changes control mode to EXT2.	35
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
19.12	Ext1 control mode	Selects the operating mode for external control location EXT1 in vector motor control mode.	Speed
	Zero	None.	1

No.	Name/Value	Description	Def/FbEq16
	Speed	Speed control. The torque reference used is 25.01 Torque reference speed control (output of the speed reference chain).	2
	Torque	Torque control. The torque reference used is 26.74 Torque ref ramp out (output of the torque reference chain).	3
	Minimum	Combination of selections Speed and Torque: the torque selector compares the speed controller output (25.01 Torque reference speed control) and the torque reference (26.74 Torque ref ramp out) and selects the smaller of the two. If speed error becomes negative, the drive follows the speed controller output until speed error becomes positive again. This prevents the drive from accelerating uncontrollably if the load is lost in torque control.	4
	Maximum	Combination of selections Speed and Torque: the torque selector compares the speed controller output (25.01 Torque reference speed control) and the torque reference (26.74 Torque ref ramp out) and selects the greater of the two. If speed error becomes positive, the drive follows the speed controller output until speed error becomes negative again. This prevents the drive from accelerating uncontrollably if the load is lost in torque control.	5
19.14	Ext2 control mode	Selects the operating mode for external control location EXT2 in vector motor control mode. For the selections, see parameter 19.12 Ext1 control mode.	Speed
19.16	Local control mode	Selects the operating mode for local control in vector motor control mode.	Speed
	Speed	Speed control. The torque reference used is 25.01 Torque reference speed control (output of the speed reference chain).	0
	Torque	Torque control. The torque reference used is 26.74 Torque ref ramp out (output of the torque reference chain).	1
19.17	Local control disable	Enables/disables local control (startHand and stopOff buttons on the control panel, and the local controls on the PC tool). MARNINGI Before disabling local control, ensure that the control panel is not needed for stopping the drive.	No
	No	Local control enabled.	0
	Yes	Local control disabled.	1
20 Sta	nt/stop/direction	Start/stop/direction and run/start/jog enable signal source	

20 Start/stop/direction	Start/stop/direction and run/start/jog enable signal source selection; positive/negative reference enable signal source selection. For information on control locations, see section <i>Local control</i> vs. external control (page 33).	
20.01 Ext1 commands	Selects the source of start, stop and direction commands for external control location 1 (EXT1). See also parameters 20.0220.05. See parameter 20.21 for the determination of the actual direction.	In1 Start; In2 Dir
Not selected	No start or stop command sources selected.	0

No.	Name/Value	Description					Def/FbEq16
	In1 Start	The source of the start in parameter 20.03 Ext1 in source bits are interpret	11 sc	urce. The state			1
		State of source 1 (20	. <mark>03</mark>)	Command			
		0 -> 1 (20.02 = Edge 1 (20.02 = Level))	Start			
		0		Stop			
	In1 Start; In2 Dir	The source selected by signal; the source selected by determines the direction bits are interpreted as for bits are selected by the selected by the selected by bits are selected by the selected by bits are selected	ted b n. Th	by 20.04 Ext1 in. e state transitior	2 so	urce	2
		State of source 1 (20.03)	S	tate of source : (20.04)	2	Command	
		0		Any		Stop	
		0 -> 1 (20.02 = Edge)		0		Start forward	
		1 (20.02 = Level)		1		Start reverse	
		the reverse start signal. bits are interpreted as for State of source 1 (20.03)	ollow	s: tate of source : (20.04)		Command	
		0		0		Stop	
		0 -> 1 (20.02 = Edge) 1 (20.02 = Level)		0		Start forward	
		0		> 1 (20.02 = Edg (20.02 = Level)		Start reverse	
		1		1		Stop	
	In1P Start; In2 Stop	The sources of the start parameters 20.03 Ext1 The state transitions of follows:	in1 s	ource and 20.04	1 Ext	1 in2 source.	4
		State of source 1 (20.03)	Sta	ate of source 2 (20.04)		Command	
		0 -> 1		1		Start	
		Any		0		Stop	
		 Notes: Parameter 20.02 Ext1 start trigger type has no effect with this setting. When source 2 is 0, the Start and Stop keys on the control panel are disabled. 					

No.	Name/Value	Description				Def/FbEq16	
	In1P Start; In2 Stop; In3 Dir	2 Stop; The sources of the start and stop commands are selected by parameters 20.03 Ext1 in1 source and 20.04 Ext1 in2 source. The source selected by 20.05 Ext1 in3 source determines the direction. The state transitions of the source bits are interpreted as follows:					
		State of source 1 (20.03)	State of source 2 (20.04)	State of source 3 (20.05)	Command		
		0 -> 1	1	0	Start forward		
		0 -> 1	1	1	Start reverse		
		Any	0	Any	Stop		
		 Notes: Parameter 2 this setting. When source panel are dis 	e 2 is 0, the Sta		s no effect with s on the control		
	In1P Start fwd; In2P Start rev; In3 Stop	parameters 20. 20.05 Ext1 in3 source determine	The sources of the start and stop commands are selected by parameters 20.03 Ext1 in1 source, 20.04 Ext1 in2 source and 20.05 Ext1 in3 source. The source selected by 20.05 Ext1 in3 source determines the stop. The state transitions of the source bits are interpreted as follows:				
		State of source 1 (20.03)	State of source 2 (20.04)	State of source 3 (20.05)	Command		
		0 -> 1	Any	1	Start forward		
		Any	0 -> 1	1	Start reverse		
		Any Note: Parameter with this setting	Any er 20.02 Ext1 s	0 tart trigger type	Stop has no effect		
	Control panel	The start and s panel (or PC co				11	
	Fieldbus A	The start and st A. Note: Set also			fieldbus adapter • <i>Level</i> .	12	
	Embedded fieldbus	The start and s fieldbus interfac Note: Set also	ce.			14	
20.02	Ext1 start trigger type	EXT1 is edge-to Note: This para signal is selected	Defines whether the start signal for external control location EXT1 is edge-triggered or level-triggered. Note: This parameter is not effective if a pulse-type start signal is selected. See the descriptions of the selections of parameter 20.01 Ext1 commands.				
	Edge	The start signal	l is edge-trigger	ed.		0	
	Level	The start signal	l is level-trigger	ed.		1	
20.03	Ext1 in1 source	Selects source	DI1				
	Always off	0 (always off).				0	
	Always on	1 (always on).				1	
	DI1	Digital input DI	1 (10.02 DI dela	ayed status, bit	0).	2	
	DI2	Digital input DI	2 (10.02 DI dela	aved status. bit	1).	3	

No.	Name/Value	Description	Description				
	DI3	Digital input DI3 (10.02	<i>DI delayed status</i> , bit 2	?).	4		
	DI4	Digital input DI4 (10.02	<i>DI delayed status</i> , bit 3	s).	5		
	DI5	Digital input DI5 (10.02	Digital input DI5 (10.02 DI delayed status, bit 4).				
	DI6	Digital input DI6 (10.02	Digital input DI6 (10.02 DI delayed status, bit 5).				
	Timed function 1	Bit 0 of 34.01 Timed fun	ctions status (see page	e 280).	18		
	Timed function 2	Bit 1 of 34.01 Timed fun	ctions status (see page	e 280).	19		
	Timed function 3	Bit 2 of 34.01 Timed fun	ctions status (see page	e 280).	20		
	Supervision 1	Bit 0 of 32.01 Supervision	on status (see page 27	<mark>3</mark>).	24		
	Supervision 2	Bit 1 of 32.01 Supervision	on status (see page 27	3).	25		
	Supervision 3	Bit 2 of 32.01 Supervision	on status (see page 27	3).	26		
	Other [bit]	Source selection (see 7	erms and abbreviations	on page 161).	-		
20.04	Ext1 in2 source		Selects source 2 for parameter 20.01 Ext1 commands. For the available selections, see parameter 20.03 Ext1 in1				
20.05	Ext1 in3 source	Selects source 3 for par For the available selecti source.	Always off				
20.06	Ext2 commands	Selects the source of sta external control location See also parameters 20 the determination of the	Not selected				
	Not selected	No start or stop comma	nd sources selected.		0		
	In1 Start	State of source 1 (20.07 = Edge 1 (20.07 = Edge 1 (20.07 = Edge 1 (20.07 = Edge 1 (20.07 = Level)	1				
In1 Start; In2 Dir The source selected by 20.08 Ext2 in1 source is the start signal; the source selected by 20.09 Ext2 in2 source determines the direction. The state transitions of the source bits are interpreted as follows:					2		
		State of source 1 (20.08)	State of source 2 (20.09)	Command			
		0	Any	Stop Start forward			
		0 -> 1 (20.07 = Edge) 1 (20.07 = Level)	0	Start forward Start reverse			
		(20.07 - Level)	I	Start reverse			

No.	Name/Value	Description				Def/FbEq16
	In1 Start fwd; In2 Start rev	The source select start signal; the s the reverse start bits are interprete	ource selecte signal. The st	d by 20.09 Ext2 ate transitions o	2 in2 source is	3
		State of source (20.08)	Command			
		0		0	Stop	
		0 -> 1 (20.07 = L 1 (20.07 = Let		0	Start forward	
		0		l (20.07 = Edge 20.07 = Level)) Start reverse	
		1		1	Stop	
	In1P Start; In2 Stop The sources of the start and stop commands are selected by parameters 20.08 Ext2 in1 source and 20.09 Ext2 in2 source. The state transitions of the source bits are interpreted as follows:					4
		State of source (20.08)	e 1 State	e of source 2 (20.09)	Command	
		0 -> 1		1	Start	
		Any		0	Stop	
		 Notes: Parameter 20.07 Ext2 start trigger type has no effect with this setting. When source 2 is 0, the Start and Stop keys on the control panel are disabled. 				
	In1P Start; In2 Stop; In3 Dir	The sources of th parameters 20.08 The source selec direction. The sta interpreted as foll	B Ext2 in1 sou ted by 20.10 I te transitions	rce and 20.09 E Ext2 in3 source	<i>xt2 in2 source</i> . determines the	5
		State of source 1 (20.08)	State of source 2 (20.09)	State of source 3 (20.10)	Command	
		0 -> 1	1	0	Start forward	
		0 -> 1	1	1	Start reverse	
		Any	0	Any	Stop	
		 Notes: Parameter 20. this setting. When source 2 panel are disa 	2 is 0, the Sta			

No.	No. Name/Value Description						
	In1P Start fwd; In2P Start rev; In3 Stop	parameters 20.	08 Ext2 in1 sou source. The sou nes the direction	rce, 20.09 Ext2 irce selected by n. The state tra	are selected by 2 in2 source and y 20.10 Ext2 in3 insitions of the	6	
		State of source 1 (20.08)	source 1 source 2 source 3 Command				
		0 -> 1	Any	1	Start forward		
		Any	0 -> 1	1	Start reverse		
		Any	Any	0	Stop		
		Note: Parameter with this setting		tart trigger type	has no effect		
	Control panel	The start and s panel (or PC co				11	
	Fieldbus A	The start and st A. Note: Set also			fieldbus adapter • <i>Level</i> .	12	
	Embedded fieldbus	The start and s fieldbus interfac Note: Set also	ce.		the embedded	14	
20.07	Ext2 start trigger type	EXT2 is edge-to Note: This para signal is selected	Defines whether the start signal for external control location EXT2 is edge-triggered or level-triggered. Note: This parameter is not effective if a pulse-type start signal is selected. See the descriptions of the selections of parameter 20.06 Ext2 commands.				
	Edge	The start signal	is edge-trigger	ed.		0	
	Level	The start signal	is level-trigger	ed.		1	
20.08	Ext2 in1 source	Selects source For the availabl				Always off	
20.09	Ext2 in2 source	Selects source For the availab				Always off	
20.10	Ext2 in3 source		Selects source 3 for parameter 20.06 Ext2 commands. For the available selections, see parameter 20.03 Ext1 in1				
20.11	Run enable stop mode	signal switches The source of t	Selects the way the motor is stopped when the run enable signal switches off. The source of the run enable signal is selected by parameter 20.12 Run enable 1 source.				
	Coast	The motor coas	sts to a stop.	nical brake is u	tors of the drive. sed, ensure it is	0	
	Ramp	Stops along the group 23 Speed				1	
	Torque limit	Stops according 30.20).	g to torque limit	s (parameters	30.19 and	2	

No.	Name/Value	Description	Def/FbEq16
20.12	Run enable 1 source	Selects the source of the external run enable signal. If the run enable signal is switched off, the drive will not start. If already running, the drive will stop according to the setting of parameter 20.11 Run enable stop mode. 1 = Run enable signal on. See also parameter 20.19 Enable start command.	Selected
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0)	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1)	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2)	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3)	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4)	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5)	7
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 280)	18
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 280)	19
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 280)	20
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 273)	24
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 273)	25
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 273)	26
	FBAAMCW bit 3	Control word bit 3 received through fieldbus interface A	30
	EFB MCW bit 3	Control word bit 3 received through the embedded fieldbus interface	32
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161)	-
20.19	Enable start command	Selects the source for the start enable signal. 1 = Start enable. With the signal switched off, any drive start command is inhibited. (Switching the signal off while the drive is running will not stop the drive.) See also parameter 20.12 Run enable 1 source.	Selected
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0)	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1)	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2)	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3)	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4)	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5)	7
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 280)	18
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 280)	19
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 280)	20
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 273)	24
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 273)	25
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 273)	26

No.	Name/Value	Description	Description				
	Other [bit]	Source select	ion (see <mark>Te</mark>	erms and abbreviations o	on page <mark>161</mark>)	-	
20.21	Direction	rather than the In the table the parameter 20, configured in 2	Reference direction lock. Defines the direction of the drive rather than the sign of the reference, except in some cases. In the table the actual drive rotation is shown as a function of parameter 20.21 Direction and Direction command (from DI configured in 20.01 Ext1 commands or 20.06 Ext2 commands and its related parameters).				
	Par. 20.21 Direction	DI = Forward		DI = Reverse	DI not defi	ned	
	Forward	Motor rotates in fo direction	orward	Motor rotates in forward direction	Same as to	orward DI	
	Reverse	Motor rotates in re direction	everse	Motor rotates in reverse direction	Same as re	everse DI	
	Request			-			
	Reference from motor potentiometer reference /other	Motor rotates in fo direction	orward	Motor rotates in reverse direction	Same as fo	orward DI	
	Reference from AI/FB/EFB/ Control Panel Ref Saved & Copied/Safe Speed / Last Speed	Motor rotates in d reference	lirection of	Motor rotates always in reverse direction (-1 * ABS [Reference])	Same as fo	orward DI	
	Reference from Constant Speed / PID / Jog ref	Motor rotates in d reference [DI have no effect		Motor rotates in direction of reference DI have no e [DI have no effect]		effect	
	Request	Refer the table	e above fo	r rotation direction of mo	tor.	0	
	Forward	reference. (Ne	egative refe	gardless of the sign of th erence values are replac s are used as is.)		1	
	Reverse	reference. (Ne	egative refe	gardless of the sign of th erence values are replac s are multiplied by -1.)		2	
20.22	Enable to rotate	affect any othe back to 1 start This paramete some external the equipmen When this par	Positive reference values are multiplied by -1.) Setting this parameter to 0 stops motor rotating but does not affect any other conditions for rotating. Setting the parameter back to 1 starts motor rotating again. This parameter can be used for example with a signal from some external equipment to prevent the motor rotating before the equipment is ready. When this parameter is 0 (rotating of the motor is disabled), bit 13 of parameter 06.16 Drive status word 1 is set to 0.			Selected	
	Not selected	0 (always off)				0	
	Selected	1 (always on)					
	DI1	Digital input D					
	DI2	Digital input D					
	DI3	Digital input D	013 (<u>10.02 I</u>	DI delayed status, bit 2)		4	
	DI4	Digital input D	Digital input DI4 (10.02 DI delayed status, bit 3)			5	
	DI5	Digital input D	015 (<u>10.02 L</u>	DI delayed status, bit 4)		6	

No.	Name/Value	Description	Def/FbEq16
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5)	7
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 280)	18
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 280)	19
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 280).	20
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 273)	24
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 273)	25
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 273)	26
	Other [bit]	Source selection (see Terms and abbreviations on page 161)	-
20.25	Jogging enable	Selects the source for a jog enable signal. (The sources for jogging activation signals are selected by parameters 20.26 Jogging 1 start source and 20.27 Jogging 2 start source.) 1 = Jogging is enabled. 0 = Jogging is enabled. Note: Jogging can be enabled only when no start command from an external control location is active. On the other hand, if jogging is already enabled, the drive cannot be started from an external control location (apart from inching commands through fieldbus). See section Rush control (page 72).	Not selected
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0)	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1)	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2)	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3)	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4)	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5)	7
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 280)	18
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 280)	19
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 280)	20
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 273)	24
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 273)	25
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 273)	26
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161)	-
20.26	Jogging 1 start source	 If enabled by parameter 20.25 Jogging enable, selects the source for the activation of jogging function 1. (Jogging function 1 can also be activated through fieldbus regardless of parameter 20.25.) 1 = Jogging 1 active Notes: If both jogging 1 and 2 are activated, the one that was activated first has priority. This parameter cannot be changed while the drive is running. 	Not selected
	Not selected	0	0
	Selected	1	1

No.	Name/Va	alue	Description	Def/FbEq16	
	DI1		Digital input DI1 (10.02 DI delayed status, bit 0)	2	
	DI2		Digital input DI2 (10.02 DI delayed status, bit 1)	3	
	DI3		Digital input DI3 (10.02 DI delayed status, bit 2)	4	
	DI4		Digital input DI4 (10.02 DI delayed status, bit 3)	5	
	DI5		Digital input DI5 (10.02 DI delayed status, bit 4)	6	
	DI6		Digital input DI6 (10.02 DI delayed status, bit 5)	7	
	Timed fu	nction 1	Bit 0 of 34.01 Timed functions status (see page 280)	18	
	Timed fu	nction 2	Bit 1 of 34.01 Timed functions status (see page 280)	19	
	Timed fu	nction 3	Bit 2 of 34.01 Timed functions status (see page 280)	20	
	Supervis	ion 1	Bit 0 of 32.01 Supervision status (see page 273)	24	
	Supervis	ion 2	Bit 1 of 32.01 Supervision status (see page 273)	25	
	Supervis	ion 3	Bit 2 of 32.01 Supervision status (see page 273)	26	
	Other [bi	it]	Source selection (see Terms and abbreviations on page 16	1) -	
20.27	Jogging source	2 start	If enabled by parameter 20.25 Jogging enable, selects the source for the activation of jogging function 2. (Jogging function 2 can also be activated through fieldbus regardless of parameter 20.25.) 1 = Jogging 2 active. For the selections, see parameter 20.26 Jogging 1 start source. Notes: • If both jogging 1 and 2 are activated, the one that was activated first has priority. • This parameter cannot be changed while the drive is running.	Not selected	
20.28	Remote action	to local	Select the action to take when the drive switches between remote and local control modes.	Keep running	
	Keep rur	nning	The drive will continue to run when the user presses the Loc/Rem button on the control panel or the Drive Composer PC tool.	0	
	Stop		The drive will stop when the user presses the Loc/Rem butto on the control panel or the Drive Composer PC tool.	n 1	
20.30 Enable signal warning function			Selects 20.22 Enable to rotate and 20.12 Run enable 1 00 source warnings to be suppressed. This parameter can be used to prevent these warnings from being added to the event log. Whenever a bit of this parameter is set to 1, the corresponding warning is suppressed.		
	Bit	Name	Value]	
	0	Enable to re			
	1	Run enable			
	215	Reserved			
			Mand for dischier angele ein der de	4 - 4	
	0000hl	-rffn	Word for disabling enable signal warnings.	1 = 1	

No. Name/Value	Description	Def/FbEq16
21 Start/stop mode	Start and stop modes; emergency stop mode and signal source selection; DC magnetization settings.	
21.01 Start mode	 Selects the motor start function for the vector motor control mode, ie. when 99.04 Motor control mode is set to Vector. Notes: The start function for the scalar motor control mode is selected by parameter 21.19 Scalar start mode. Starting into a rotating motor is not possible when DC magnetizing is selected (<i>Fast</i> or <i>Const time</i>). This parameter cannot be changed while the drive is running. See also section <i>DC magnetization</i> (page 69). 	Automatic
Fast	The drive pre-magnetizes the motor before start. The pre- magnetizing time is determined automatically, being typically 200 ms to 2 s depending on motor size. This mode should be selected if a high break-away torque is required.	0
Const time	The drive pre-magnetizes the motor before start. The pre- magnetizing time is defined by parameter 21.02 Magnetization time. This mode should be selected if constant pre-magnetizing time is required (e.g. if the motor start must be synchronized with the release of a mechanical brake). This setting also guarantees the highest possible break-away torque when the pre-magnetizing time is set long enough. WARNING! The drive will start after the set magnetizing time has passed even if motor magnetization is not completed. In applications where a full break-away torque is essential, ensure that the constant magnetizing time is long enough to allow generation of full magnetization and torque.	1
Automatic	Automatic start guarantees optimal motor start in most cases. It includes the flying start function (starting into a rotating motor) and the automatic restart function. The drive motor control program identifies the flux as well as the mechanical state of the motor and starts the motor instantly under all conditions. Note: If parameter <i>99.04 Motor control mode</i> is set to <i>Scalar</i> , no flying start or automatic restart is possible unless parameter <i>21.19 Scalar start mode</i> is set to <i>Automatic</i> .	2

No.	Name/Value	Description	Def/FbEq16	
21.02	Magnetization time	 Defines the pre-magnetization parameter 21.01 Start mode motor control mode), or parameter 21.19 Scalar star scalar motor control mode). After the start command, the d premagnetizes the motor for th magnetizing, set this parameter higher than, the rotor time con rule-of-thumb value given in the 	500	
		Motor rated power	Constant magnetizing time	
		< 1 kW	≥ 50 to 100 ms	
		1 to 10 kW	≥ 100 to 200 ms	
		10 to 200 kW	<u>></u> 200 to 1000 ms	
		200 to 1000 kW	<u>></u> 1000 to 2000 ms	
		Note: This parameter cannot b running.	be changed while the drive is	
	010000 ms	Constant DC magnetizing time	2.	1 = 1
21.03	Stop mode	Selects the way the motor is si is received. Additional braking is possible to parameter <i>97.05 Flux braking</i>)		Coast
	Coast	Stops by switching off the outp The motor coasts to a stop. WARNING! If a mechal safe to stop the drive b	0	
	Ramp	Stops along the active deceler group 23 Speed reference ram Frequency reference chain on	1	
	Torque limit	Stops according to torque limit 30.20). This mode is only poss mode.	2	
21.04	Emergency stop mode	Selects the way the motor is si stop command is received. The source of the emergency si parameter 21.05 Emergency si	stop signal is selected by	Ramp stop (Off1)
	Ramp stop (Off1)		erence type (see section <i>Rush</i> drive has stopped, it can be mergency stop signal and	0

No.	Name/Value	Description	Def/FbEq16
	Coast stop (Off2)	 With the drive running: 1 = Normal operation. 0 = Stop by coasting. The drive can be restarted by restoring the start interlock signal and switching the start signal from 0 to 1. With the drive stopped: 1 = Starting allowed. 0 = Starting not allowed. 	1
	Eme ramp stop (Off3)	 With the drive running: 1 = Normal operation 0 = Stop by ramping along emergency stop ramp defined by parameter 23.23 <i>Emergency stop time</i>. After the drive has stopped, it can be restarted by removing the emergency stop signal and switching the start signal from 0 to 1. With the drive stopped: 1 = Starting allowed 0 = Starting not allowed 	2
21.05	Emergency stop source	Selects the source of the emergency stop signal. The stop mode is selected by parameter 21.04 Emergency stop mode. 0 = Emergency stop active 1 = Normal operation Note: This parameter cannot be changed while the drive is running.	Inactive (true)
	Active (false)	0.	0
	Inactive (true)	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
21.06	Zero speed limit	Defines the zero speed limit. The motor is stopped along a speed ramp (when ramped stop is selected or emergency stop time is used) until the defined zero speed limit is reached. After the zero speed delay, the motor coasts to a stop.	30.00 rpm
	0.0030000.00 rpm	Zero speed limit.	See par. 46.01


No.	Name/Value	Description	Def/FbEq16
21.07	Zero speed delay	Defines the delay for the zero speed delay function. The function is useful in applications where a smooth and quick restarting is essential. During the delay, the drive knows the rotor position accurately. Without zero speed delay:	0 ms
		The drive receives a stop command and decelerates along a ramp. When actual motor speed falls below the value of parameter 21.06 Zero speed limit, inverter modulation is stopped and the motor coasts to a standstill.	
		Speed	
		Speed controller switched off: Motor coasts to a stop.	
		21.06 Zero speed limit	
		Time	
		<u>With zero speed delay</u> : The drive receives a stop command and decelerates along a ramp. When actual motor speed falls below the value of parameter <i>21.06 Zero speed limit</i> , the zero speed delay function activates. During the delay the function keeps the speed controller live: the inverter modulates, motor is magnetized and the drive is ready for a quick restart. Zero speed delay can be used e.g. with the jogging function.	
		Speed	
		Speed controller remains active. Motor is decelerated to true zero speed.	
		Contract of the second limit of the second limit defined limit the second	
	030000 ms	Zero speed delay.	1 = 1

No.	Name/Va	alue	Description	Def/FbEq16
21.08	DC current control		Activates/deactivates the DC hold and post-magnetization functions. See section <i>DC magnetization</i> (page 69). Note: DC magnetization causes the motor to heat up. In applications where long DC magnetization times are required, externally ventilated motors should be used. If the DC magnetization period is long, DC magnetization cannot prevent the motor shaft from rotating if a constant load is applied to the motor.	06000
	Bit	Value		
	0		DC hold. See section <i>DC hold</i> (page 69).	
	1	1 = Enable Note: Post-	DC hold function has no effect if the start signal is switched off. post-magnetization. See section <i>Settings</i> (page 70). -magnetization is only available when ramping is the selected sta 21.03 <i>Stop mode</i>).	op mode (see
	215	Reserved		
				1
	0b000		DC magnetization selection.	1 = 1
21.09	DC hold	speed	Defines the DC hold speed in speed control mode. See parameter 21.08 DC current control, and section DC hold (page 69).	5.00 rp
	0.0010	00.00 rpm	DC hold speed.	See par. 46.01
21.10	DC curre reference		Defines the DC hold current in percent of the motor nominal current. See parameter 21.08 DC current control, and section DC magnetization (page 69). After 100 s post-magnetization time, the maximum magnetization current is limited to the magnetization current corresponding to the actual flux reference.	30.0
	0.0100	0.0%	DC hold current.	1 = 1
21.11	Post mag time	gnetization	Defines the length of time for which post-magnetization is active after stopping the motor. The magnetization current is defined by parameter <i>21.10 DC current reference</i> . See parameter <i>21.08 DC current control</i> .	0
	03000	s	Post-magnetization time.	1 = 1
21.14	Pre-heating input source		 Selects the source for controlling pre-heating for the motor. The status of the pre-heating is shown as bit 2 of 06.21 Drive status word 3. Notes: The heating function requires that STO is not triggered. The heating function requires that the drive is not faulted. 	Off
	Off		0. Pre-heating is always deactivated.	0
	On		1. Pre-heating is always activated when the drive is stopped.	1
	DI1		Digital input DI1 (10.02 DI delayed status, bit 0)	2
	DI2		Digital input DI2 (10.02 DI delayed status, bit 1)	3
	DI3		Digital input DI3 (10.02 DI delayed status, bit 2)	4
	DI4		Digital input DI4 (10.02 DI delayed status, bit 3)	5
	DI5		Digital input DI5 (10.02 DI delayed status, bit 4)	6
	DI6		Digital input DI6 (10.02 DI delayed status, bit 5)	7

No.	Name/Value	Description	Def/FbEq16
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 273)	8
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 273)	9
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 273)	10
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 280)	11
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 280)	12
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 280)	13
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161)	-
21.15	Pre-heating time delay	Time delay before pre-heating starts after the drive is stopped.	60 s
	103000 s	Pre-heating time delay.	1 = 1 s
21.16	Pre-heating current	Defines the DC current used to heat the motor. The value is in percent of the nominal motor current.	0.0
	0.030.0%	Pre-heating current.	1 = 1
21.18	Auto restart time	The motor can be automatically started after a short supply power failure using the automatic restart function. See section <i>Automatic restart</i> (page 77). When this parameter is set to 0.0 seconds, automatic restarting is disabled. Otherwise, the parameter defines the maximum duration of the power failure after which restarting is attempted. Note that this time also includes the DC precharging delay. WARNING! Before you activate the function, make sure that no dangerous situations can occur. The function restarts the drive automatically and continues operation after a supply break.	10.0
	0.0 s	Automatic restarting disabled.	0
	0.110.0 s	Maximum power failure duration.	1 = 1
21.19	Scalar start mode	 Selects the motor start function for the scalar motor control mode, ie. when 99.04 Motor control mode is set to Scalar. Notes: The start function for the vector motor control mode is selected by parameter 21.01 Start mode. This parameter cannot be changed while the drive is running. See also section <i>DC magnetization</i> (page 69). 	Normal
	Normal	Immediate start from zero speed.	0
	Const time	The drive pre-magnetizes the motor before start. The pre- magnetizing time is defined by parameter 21.02 <i>Magnetization time</i> . This mode should be selected if constant pre-magnetizing time is required (e.g. if the motor start must be synchronized with the release of a mechanical brake). This setting also guarantees the highest possible break-away torque when the pre-magnetizing time is set long enough. Note: This mode cannot be used to start into a rotating motor. WARNING : The drive will start after the set pre- magnetizing time has passed even if motor magnetization is not completed. In applications where a full break-away torque is essential, ensure that the constant magnetizing time is long enough to allow generation of full magnetization and torque.	1

No.	Name/Value	Description	Def/FbEq16
	Automatic	The drive automatically selects the correct output frequency to start a rotating motor. This is useful for flying starts: if the motor is already rotating, the drive will start smoothly at the current frequency. Note: Cannot be used in multimotor systems.	2
	Torque boost	The drive pre-magnetizes the motor before the start. The pre- magnetizing time is defined by parameter 21.02 Magnetization time. Torque boost is applied at start. Torque boost is stopped when output frequency exceeds 20 Hz or when it is equal to the reference value. See parameter 21.26 Torque boost current. This mode should selected if a high break-away torque is required. Note: This mode cannot be used to start into a rotating motor. MARNING! The drive will start after the set pre- magnetization is not completed. In applications where a full break-away torque is essential, ensure that the constant magnetizing time is long enough to allow generation of full magnetization and torque.	3
	Automatic+boost	Automatic start with torque boost. Automatic start is performed first and the motor is magnetized. If the speed is found to be zero, torque boost is applied.	4
	Flying start	The drive automatically selects the correct output frequency to start a rotating motor. If the motor is already rotating, drive will start smoothly at the current frequency. The mode will start the motor with vector control and switch to scalar control on the fly when the motor speed has been found. Compared to the Automatic start mode, Flying start detects the motor speed faster. Flying start requires more accurate information about motor model. Therefore standstill ID run is done automatically when the drive is started for the first time after selecting Flying start. Motor plate values should be accurate. Wrong plate values may decrease the starting performance. Note During flying start, the drive will at first run in vector control mode. This is why, when using flying start, the drive nominal current setting must be in the allowed range for vector control mode, see parameter 99.06 Motor nominal <i>current</i> .	5
	Flying start+boost	Flying start with torque boost. Flying start is performed first and the motor is magnetized. If the speed is found to be zero, torque boost is applied.	6
21.21	DC hold frequency	Defines the DC hold frequency, which is used instead of parameter 21.09 DC hold speed when the motor is in scalar frequency mode. See parameter 21.08 DC current control, and section DC hold (page 69).	5.00
	0.001000.00 Hz	DC hold frequency.	1 = 1
21.22	Start delay	Defines the start delay. After the conditions for start have been fulfilled, the drive waits until the delay has elapsed and then starts the motor. During the delay, warning <i>AFE9 Start</i> <i>delay</i> is shown. Start delay can be used with all start modes.	0.00
	0.0060.00 s	Start delay	1 = 1

No.	Name/Value	Description	Def/FbEq16
21.26	Torque boost current	Maximum current supplied during torque boost.	100.0
	15.0300.0%	Value in percent of the nominal motor current.	1 = 1
21.27	Torque boost time	Defines the minimum and maximum torque boost time. If torque boost time is less than 40% of frequency acceleration time (see parameters 28.72 and 28.74), then torque boost time is set at 40% of frequency acceleration time.	20.0 s
	0.060.0 s	Nominal motor time.	1 = 1%
21.30	Speed compensated stop mode	 Selects the method used to stop the drive. See also section. Speed compensated stop (page 75). Speed compensated stop is active only if the operation mode is not torque, and parameter 21.03 Stop mode is Ramp, or parameter 20.11 Run enable stop mode is Ramp (in case Run enable is missing). 	Off
	Off	Stop according parameter 21.03 Stop mode, no speed compensated stop.	0
	Speed comp FWD	If the direction of rotation is forward, speed compensation is used for constant distance braking. Speed difference (between used speed and maximum speed) is compensated by running the drive with current speed before the motor is stopped along a ramp. If the direction of rotation is reverse, the drive is stopped along a ramp.	1
	Speed comp REV	If the direction of rotation is reverse, speed compensation is used for constant distance braking. Speed difference (between used speed and maximum speed) is compensated by running the drive with current speed before the motor is stopped along a ramp. If the direction of rotation is forward, the drive is stopped along a ramp.	2
	Speed comp bipolar	Regardless of the direction of rotation, speed compensation is used for constant distance braking. Speed difference (between used speed and maximum speed) is compensated by running the drive with current speed before the motor is stopped along a ramp.	3
21.31	Speed comp stop delay	This delay adds distance to the total distance traveled during a stop from maximum speed. It is used to adjust the distance to match requirements so that the distance traveled is not solely determined by the deceleration rate.	0.00
	0.001000.00 s	Speed delay.	1 = 1
21.32	Speed comp stop threshold	This parameter sets a speed threshold below which the Speed compensated stop feature is disabled. In this speed region, the speed compensated stop is not attempted and the drive stops as it would, using the ramp option.	10%
	0100%	Speed threshold as a percent of the motor nominal speed.	1 = 1%
21.34	Force auto restart	Forces automatic restart. The parameter is applicable only if parameter 95.04 <i>Supply voltage</i> is set to <i>External 24V</i> .	Disable
	Disable	Force auto restart disabled. Parameter 21.18 Auto restart time is in effect if its value is more than 0.0 s.	0



No.	Name/Value	Description	Def/FbEq16
	Al1 scaled	12.12 Al1 scaled value (see page 189).	1
	Al2 scaled	12.22 AI2 scaled value (see page 190).	2
	FB A ref1	03.05 FB A reference 1 (see page 167).	4
	FB A ref2	03.06 FB A reference 2 (see page 167).	5
	EFB ref1	03.09 EFB reference 1 (see page 167).	8
	EFB ref2	03.10 EFB reference 2 (see page 167).	9
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15
	PID	40.01 Process PID output actual (output of the process PID controller).	16
	Frequency input	11.38 Freq in 1 actual value (when DI5 or DI6 is used as a frequency input).	17
	Control panel (ref saved)	Panel reference (03.01 Panel reference, see page 167) saved by the control system for the location where the control returns is used as the reference. Reference	18
	Control panel (ref copied)	Panel reference (03.01 Panel reference, see page 167) for the previous control location is used as the reference when the control location changes if the references for the two locations are of the same type (eg frequency/speed/torque/PID); otherwise, the actual signal is used as the new reference. Reference Keference	19
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
22.12	Ext1 speed ref2	Selects Ext1 speed reference source 2. For the selections, and a diagram of reference source selection, see parameter 22.11 Ext1 speed ref1.	Zero
22.13	Ext1 speed function	Selects a mathematical function between the reference sources selected by parameters 22.11 Ext1 speed ref1 and 22.12 Ext1 speed ref2. See diagram at 22.11 Ext1 speed ref1.	Ref1
	Ref1	Signal selected by 22.11 Ext1 speed ref1 is used as speed reference 1 as such (no function applied).	0
	Add (ref1 + ref2)	The sum of the reference sources is used as speed reference 1.	1
	Sub (ref1 - ref2)	The subtraction ([22.11 Ext1 speed ref1] - [22.12 Ext1 speed ref2]) of the reference sources is used as speed reference 1.	2
	Mul (ref1 × ref2)	The multiplication of the reference sources is used as speed reference 1.	3

No.	Name/Value	Description	Def/FbEq16	
	Min (ref1, ref2)	The smaller of the reference sources is used as speed reference 1.	4	
	Max (ref1, ref2)	The greater of the reference sources is used as speed reference 1.	5	
22.18	Ext2 speed ref1	Selects Ext2 speed reference source 1. Two signal sources can be defined by this parameter and 22.19 Ext2 speed ref2. A mathematical function (22.20 Ext2 speed function) applied to the two signals creates an Ext2 reference. See diagram at 28.11 Ext1 frequency ref1.	Zero	
	Zero	None.	0	
	Al1 scaled	12.12 Al1 scaled value (see page 189).	1	
	Al2 scaled	12.22 Al2 scaled value (see page 190).	2	
	FB A ref1	03.05 FB A reference 1 (see page 167).	4	
	FB A ref2	03.06 FB A reference 2 (see page 167).	5	
	EFB ref1	03.09 EFB reference 1 (see page 167).	8	
	EFB ref2	03.10 EFB reference 2 (see page 167).	9	
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15	
	PID	40.01 Process PID output actual (output of the process PID controller).	16	
	Frequency input	11.38 Freq in 1 actual value (when DI5 or DI6 is used as a frequency input).	17	
	Control panel (ref saved)	Panel reference (03.01 Panel reference, see page 167) saved by the control system for the location where the control returns is used as the reference. Reference Ketrence Ext1 reference Ketrence Active reference Inactive reference	18	
	Control panel (ref copied)	Ext1 -> Ext2 Panel reference (03.01 Panel reference, see page 167) for the previous control location is used as the reference when the control location changes if the references for the two locations are of the same type (eg frequency/speed/torque/PID); otherwise, the actual signal is used as the new reference. Reference $\star \star \star \star \star \star \star \star \star \star $	19	
	Other	Source selection (see Terms and abbreviations on page 161).	-	
22.19	Ext2 speed ref2	Selects Ext2 speed reference source 2. For the selections, and a diagram of reference source selection, see parameter 22.18 Ext2 speed ref1.	Zero	

No.	Name/	Name/Value Description			Def/FbEq16	
22.20	sou 22.		sou	ects a mathematical function between the reference rces selected by parameters 22.18 Ext2 speed ref1 and 19 Ext2 speed ref2. See diagram at 22.18 Ext2 speed	Ref1	
	Ref1			nal selected by <i>Ext2 speed ref1</i> is used as speed prence 1 as such (no function applied).	0	
	Add (re	ef1 + ref2)	The 1.	sum of the reference sources is used as speed reference	1	
	Sub (re	ef1 - ref2)		subtraction ([22.11 Ext1 speed ref1] - [22.12 Ext1 speed]) of the reference sources is used as speed reference 1.	2	
	Mul (re	f1 × ref2)		e multiplication of the reference sources is used as speed rence 1.	3	
	Min (re	f1, ref2)		e smaller of the reference sources is used as speed erence 1.	4	
	Max (ref1, ref2)			greater of the reference sources is used as speed prence 1.	5	
22.21	function the		the	ermines how constant speeds are selected, and whether rotation direction signal is considered or not when lying a constant speed.	0b0001	
	Bit	Name		Information		
	0	Constant sp mode Direction		 1 = Packed: 7 constant speeds are selectable using the th defined by parameters 22.22, 22.23 and 22.24. 0 = Separate: Constant speeds 1, 2 and 3 are separately at the sources defined by parameters 22.22, 22.23 and 22.24. In case of conflict, the constant speed with the smaller nur priority. 1 = Start dir: To determine running direction for a constant 	activated by respectively. nber takes	
		enable		sign of the constant speed setting (parameters 22.2622. multiplied by the direction signal (forward: +1, reverse: -1). effectively allows the drive to have 14 (7 forward, 7 reverse speeds if all values in 22.2622.32 are positive. WARNING: If the direction signal is reverse and th constant speed is negative, the drive will run in the direction.	32) is . This e) constant e active	
				0 = Accord Par: The running direction for the constant spe determined by the sign of the constant speed setting (para 22.2622.32).		
		-			-	
	215	Reserved				

No.	Name/\	/alue	Des	cription			Def/FbEq16
22.22	2 Constant speed sel1 When bit 0 of parameter 22.21 Constant speed function is 0 (Separate), selects a source that activates constant speed 1. When bit 0 of parameter 22.21 Constant speed function is 1 (Packed), this parameter and parameters 22.23 Constant speed sel2 and 22.24 Constant speed sel3 select three sources whose states activate constant speeds as follows:				DI3		
		Source defi by par. 22		Source defined by par. 22.23	Source defined by par. 22.24	Constant speed ac	tive
		0		0	0	None	
		1		0	0	Constant speed	
		0		1	0	Constant speed	
		1		1	0	Constant speed	
		0		0	1	Constant speed	
		0		1	1	Constant speed	
		1		1	1	Constant speed	
	Always	off	0 (a	ways off).			0
	Always	on	1 (a	ways on).			1
	DI1		Digi	tal input DI1 (<mark>10</mark> .0	2 DI delayed statu	s, bit 0).	2
	DI2		Digi	tal input DI2 (<mark>10.0</mark>	2 DI delayed statu	s, bit 1).	3
	DI3		Digi	tal input DI3 (<mark>10.0</mark>	2 DI delayed statu	<mark>s</mark> , bit 2).	4
	DI4		Digi	tal input DI4 (<mark>10.0</mark>	2 DI delayed statu	<mark>s</mark> , bit 3).	5
	DI5		Digi	tal input DI5 (<mark>10</mark> .0	2 DI delayed statu	s, bit 4).	6
	DI6		Digi	tal input DI6 (<mark>10</mark> .0	2 DI delayed statu	<mark>s</mark> , bit 5).	7
	Timed f	unction 1	Bit C) of 34.01 Timed f	unctions status (se	e page <mark>280</mark>).	18
	Timed f	unction 2	Bit 1	of 34.01 Timed f	unctions status (se	e page <mark>280</mark>).	19
	Timed f	unction 3	Bit 2	of 34.01 Timed f	unctions status (se	e page <mark>280</mark>).	20
	Supervi	ision 1	Bit C	of 32.01 Supervi	sion status (see pa	ige 273).	24
	Supervi	ision 2	Bit 1	of 32.01 Supervi	sion status (see pa	ige 273).	25
	Supervi	ision 3	Bit 2	of 32.01 Supervi	sion status (see pa	ige 273).	26
	Other [l	bit]	Sou	rce selection (see	Terms and abbrev	<i>iations</i> on page 161).	-
22.23	Constant speed sel2		(Sep Whe (Pac spec sour at pa	parate), selects a sen bit 0 of parametecked), this parametecked), this parametecked sel1 and 22.24 reces that are used parameter 22.22 Co	source that activate ter 22.21 Constant ter and parameter Constant speed so to activate consta constant speed sel1	e/3 select three nt speeds. See table	D14
22.24	Constai sel3	nt speed	(Sep Whe (Pac spec sour at pa	barate), selects a s on bit 0 of paramet cked), this paramet ed sel1 and 22.23 ces that are used arameter 22.22 Co	source that activate ter 22.21 Constant ter and parameter Constant speed so to activate consta constant speed self	e/2 select three nt speeds. See table	Always off

No.	Name/Value	Description	Def/FbEq16
22.26	Constant speed 1	Defines constant speed 1 (the speed the motor will turn when constant speed 1 is selected).	300.00
	-30000.00 30000.00 rpm	Constant speed 1.	See par. 46.01
22.27	Constant speed 2	Defines constant speed 2.	600.00
	-30000.00 30000.00 rpm	Constant speed 2.	See par. 46.01
22.28	Constant speed 3	Defines constant speed 3.	900.00
	-30000.00 30000.00 rpm	Constant speed 3.	See par. 46.01
22.29	Constant speed 4	Defines constant speed 4.	1200.00
	-30000.00 30000.00 rpm	Constant speed 4.	See par. 46.01
22.30	Constant speed 5	Defines constant speed 5.	1500.00
	-30000.00 30000.00 rpm	Constant speed 5.	See par. 46.01
22.31	Constant speed 6	Defines constant speed 6.	2400.00
	-30000.00 30000.00 rpm	Constant speed 6.	See par. 46.01
22.32	Constant speed 7	Defines constant speed 7.	3000.00
	-30000.00 30000.00 rpm	Constant speed 7.	See par. 46.01
22.41	Speed ref safe	 Defines a safe speed reference value that is used with supervision functions such as 12.03 AI supervision function 49.05 Communication loss action 50.02 FBA A comm loss func. 	0.00
	-30000.00 30000.00 rpm	Safe speed reference.	See par. 46.01
22.42	Jogging 1 ref	Defines the speed reference for jogging function 1. For more information on jogging, see page 72.	0.00
	-30000.00 30000.00 rpm	Speed reference for jogging function 1.	See par. 46.01
22.43	Jogging 2 ref	Defines the speed reference for jogging function 2. For more information on jogging, see page 72.	0.00
	-30000.00 30000.00 rpm	Speed reference for jogging function 2.	See par. 46.01

No.	Name/Value		e Description		
22.51	Critical speed function		dete rota	ables/disables the critical speeds function. Also ermines whether the specified ranges are effective in both ting directions or not. e also section <i>Critical speeds/frequencies</i> (page 44).	060000
	Bit Name Information				
	0	Enable		1 = Enable: Critical speeds enabled.	
		<u>.</u>		0 = Disable: Critical speeds disabled.	
	1	Sign mode		1 = Signed: The signs of parameters 22.5222.57 are tak account.	
	0.15			0 = Absolute: Parameters 22.5222.57 are handled as abs Each range is effective in both directions of rotation.	solute values.
	215	Reserved			
	0b000	.0b1111	Criti	ical speeds configuration word.	1 = 1
22.52	Critical	speed 1 low	Not	ines the low limit for critical speed range 1. a: This value must be less than or equal to the value of 53 <i>Critical speed 1 high</i> .	0.00
	-30000. 30000.0		Low	limit for critical speed 1.	See par. 46.01
22.53	Critical : high	speed 1	Not	Defines the high limit for critical speed range 1. Note: This value must be greater than or equal to the value of 22.52 <i>Critical speed 1 low.</i>	
	-30000.00 30000.00 rpm		Higl	h limit for critical speed 1.	See par. 46.01
22.54			Defines the low limit for critical speed range 2. Note: This value must be less than or equal to the value of 22.55 <i>Critical speed 2 high</i> .		0.00
	-30000.00 30000.00 rpm		Low	limit for critical speed 2.	See par. 46.01
22.55 Critical speed 2 high		speed 2	Not	ines the high limit for critical speed range 2. e: This value must be greater than or equal to the value of <i>54 Critical speed 2 low.</i>	0.00
		-30000.00 Hig 30000.00 rpm		h limit for critical speed 2.	See par. 46.01
22.56			Defines the low limit for critical speed range 3. Note: This value must be less than or equal to the value of 22.57 Critical speed 3 high.		0.00
	-30000. 30000.0		Low limit for critical speed 3.		See par. 46.01
22.57	Critical : high	speed 3	Not	Defines the high limit for critical speed range 3. Note: This value must be greater than or equal to the value of 22.56 <i>Critical speed 3 low.</i>	
	-30000. 30000.0		High limit for critical speed 3.		See par. 46.01
22.70	Motor potentio referenc	ometer ce enable	sou	Determines when parameters 22.73 Motor potentiometer up source and 22.74 Motor potentiometer up source may change parameter 22.80 Motor potentiometer ref act.	
	Not sele	ected		or potentiometer Up/Down sources (22.73 and 22.74) are abled.	0

No.	Name/Value	Description	Def/FbEq16
	Selected	Motor potentiometer Up/Down sources (22.73 and 22.74) are enabled.	1
	While running	Motor potentiometer reference enable follows bit 4 (Following reference) of parameter <i>06.16 Drive status word 1</i> .	2
22.71	Motor	Activates and selects the mode of the motor potentiometer.	Disabled
	potentiometer function	See section Speed compensated stop (page 75).	
	Disabled	Motor potentiometer is disabled and its value set to 0.	0
	Enabled (init at stop /power-up)	When enabled, the motor potentiometer first adopts the value defined by parameter 22.72 <i>Motor potentiometer initial value</i> . The value can then be adjusted from the up and down sources defined by parameters 22.73 <i>Motor potentiometer up source</i> and 22.74 <i>Motor potentiometer down source</i> . A stop or a power cycle will reset the motor potentiometer to the initial value (22.72).	1
	Enabled (resume always)	As <i>Enabled (init at stop /power-up)</i> , but the motor potentiometer value is retained over a stop or power cycle.	2
	Enabled (init to actual)	Whenever another reference source is selected, the value of the motor potentiometer follows that reference. After the source of reference returns to the motor potentiometer, its value can again be changed by the up and down sources (defined by 22.73 and 22.74).	3
	Enabled (resume/init to Actual)	As <i>Enabled (init to actual)</i> , but the motor potentiometer ref act value is retained over power cycle.	4
22.72	Motor potentiometer initial value	Defines an initial value (starting point) for the motor potentiometer. See the selections of parameter 22.71 Motor potentiometer function.	0.00
	-32768.00 32767.00	Initial value for motor potentiometer.	1 = 1
22.73	Motor potentiometer up source	Selects the source of motor potentiometer up signal. 0 = No change 1 = Increase motor potentiometer value. (If both the up and down sources are on, the potentiometer value will not change.) Note: Motor potentiometer function up/down source control speed or frequency from zero to maximum speed or frequency. The running direction can be changed with parameter 20.04 Ext1 in2 source. See the figure in section <i>Motor potentiometer macro</i> on page 111.	Not used
	Not used	Not used	0
	Not used	Not used	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 280).	18
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 280).	19

No.	Name/Value	Description	Def/FbEq16
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 280).	20
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 273).	24
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 273).	25
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 273).	26
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
22.74	Motor potentiometer down source	Selects the source of motor potentiometer down signal. 0 = No change 1 = Decrease motor potentiometer value. (If both the up and down sources are on, the potentiometer value will not change.) Note: Motor potentiometer function up/down source control speed or frequency from zero to maximum speed or frequency. The running direction can be changed with parameter 20.04 Ext1 in2 source. See the figure in section Motor potentiometer macro on page 111. For the selections, see parameter 22.73 Motor potentiometer up source.	Not used
22.76	Motor potentiometer min value	Defines the minimum value of the motor potentiometer. Note: If vector control mode is used, value of this parameter must be changed.	-50.00
	-32768.00 32767.00	Motor potentiometer minimum.	1 = 1
22.77	Motor potentiometer max value	Defines the maximum value of the motor potentiometer. Note: If vector control mode is used, value of this parameter must be changed.	50.00
	-32768.00 32767.00	Motor potentiometer maximum.	1 = 1
22.78	Motor potentiometer ramp up	Defines the time required for the motor potentiometer to change from minimum (22.76) to maximum (22.77).	40.0 s
	0.03600.0 s	Motor potentiometer change time.	10=1
22.79	Motor potentiometer ramp down	Defines the time required for the motor potentiometer to change from maximum (22.77) to minimum (22.76).	40.0 s
	0.03600.0 s	Motor potentiometer change time.	10=1
22.80	Motor potentiometer ref act	The output of the motor potentiometer function. (The motor potentiometer is configured using parameters <i>22.7122.74.</i>) This parameter is read-only.	0.00
	-32768.00 32767.00	Value of motor potentiometer.	1 = 1
22.86	Speed reference act 6	Displays the value of the speed reference (EXT1 or EXT2) that has been selected by 19.11 Ext1/Ext2 selection. See diagram at 22.11 Ext1 speed ref1 or the control chain diagram on page 490. This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference after additive 2.	See par. 46.01


No.	Name/Value	Description	Def/FbEq16
22.87	Speed reference act 7	Displays the value of speed reference before application of critical speeds. See the control chain diagram on page 493. The value is received from 22.86 Speed reference act 6 unless overridden by • any constant speed • a jogging reference • network control reference • control panel reference • safe speed reference. This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference before application of critical speeds.	See par. 46.01
23 Sp ramp	eed reference	Speed reference ramp settings (programming of the acceleration and deceleration rates for the drive). See the control chain diagram on page <i>496</i> .	
23.01	Speed ref ramp input	Displays the used speed reference (in rpm) before it enters the ramping and shaping functions. See the control chain diagram on page <i>496</i> . This parameter is read-only.	0.00
	-30000.00 30000.00 rpm	Speed reference before ramping and shaping.	See par. 46.01
23.02	Speed ref ramp output	Displays the ramped and shaped speed reference in rpm. See the control chain diagram on page 496. This parameter is read-only.	0.00
	-30000.00 30000.00 rpm	Speed reference after ramping and shaping.	See par. 46.01
23.11	Ramp set selection	Selects the source that switches between the two sets of acceleration/deceleration ramp times defined by parameters 23.1223.15. 0 = Acceleration time 1 and deceleration time 1 are active 1 = Acceleration time 2 and deceleration time 2 are active	DI5
	Acc/Dec time 1	0	0
	Acc/Dec time 2	1	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0)	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1)	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3)	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4)	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5)	7
	FBAA	For Transparent16 and Transparent32 profiles only. DCU control word bit 10 received through the fieldbus adapter.	18
	EFB DCU CW bit 10	Only for the DCU profile. DCU control word bit 10 received through the embedded fieldbus interface.	20
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-

No.	Name/Value	Description	Def/FbEq16
23.12	Acceleration time 1	Defines acceleration time 1 as the time required for the speed to change from zero to the speed defined by parameter 46.01 Speed scaling (not to parameter 30.12 Maximum speed). If the speed reference increases faster than the set acceleration rate, the motor speed will follow the acceleration rate. If the speed reference increases slower than the set acceleration rate, the motor speed will follow the reference. If the acceleration time is set too short, the drive will automatically prolong the acceleration in order not to exceed the drive torque limits.	20.000
	0.0001800.000 s	Acceleration time 1.	10 = 1
23.13	Deceleration time 1	Defines deceleration time 1 as the time required for the speed to change from the speed defined by parameter 46.01 Speed scaling (not from parameter 30.12 Maximum speed) to zero. If the speed reference decreases slower than the set deceleration rate, the motor speed will follow the reference. If the reference changes faster than the set deceleration rate, the motor speed will follow the deceleration rate. If the deceleration rate is set too short, the drive will automatically prolong the deceleration in order not to exceed drive torque limits (or not to exceed a safe DC link voltage). If there is any doubt about the deceleration is on (parameter 30.30 Overvoltage control is on (parameter 30.30 Overvoltage control). Note: If a short deceleration time is needed for a high inertia application, the drive should be equipped with braking equipment such as a brake chopper and brake resistor.	20.000
	0.0001800.000 s	Deceleration time 1.	10 = 1
23.14	Acceleration time 2	Defines acceleration time 2. See parameter 23.12 Acceleration time 1.	60.000
	0.0001800.000 s	Acceleration time 2.	10 = 1
23.15	Deceleration time 2	Defines deceleration time 2. See parameter 23.13 Deceleration time 1.	60.000
	0.0001800.000 s	Deceleration time 2.	10 = 1
23.20	Acc time jogging	Defines the acceleration time for the jogging function ie. the time required for the speed to change from zero to the speed value defined by parameter <i>46.01 Speed scaling</i> . See section <i>Jogging</i> (page 72).	60.000
	0.0001800.000 s	Acceleration time for jogging.	10 = 1
23.21	Dec time jogging	Defines the deceleration time for the jogging function ie. the time required for the speed to change from the speed value	60.000
		defined by parameter <i>46.01 Speed scaling</i> to zero. See section <i>Jogging</i> (page 72).	

No.	Name/Value	Description	Def/FbEq16
23.23	Emergency stop time	 Defines the time inside which the drive is stopped if an emergency stop Off3 is activated (ie. the time required for the speed to change from the speed value defined by parameter 46.01 Speed scaling or 46.02 Frequency scaling to zero). Emergency stop mode and activation source are selected by parameters 21.04 Emergency stop mode and 21.05 Emergency stop source respectively. Emergency stop can also be activated through fieldbus. Note: Emergency stop Off1 uses the standard deceleration ramp as defined by parameters 23.1123.1523.1223.13. The same parameter value is also used in frequency control mode (ramp parameters 28.7128.7528.7228.73). 	3.000
	0.0001800.000 s	Emergency stop Off3 deceleration time.	10 = 1
23.28	Variable slope	Activates the variable slope function, which controls the slope of the speed ramp during a speed reference change. This allows for a constantly variable ramp rate to be generated, instead of just the standard two ramps normally available. If the update interval of the signal from an external control system and the variable slope rate (23.29 Variable slope rate) are equal, speed reference (23.02 Speed ref ramp output) is a straight line. Speed reference Speed reference 23.02 Speed ref ramp output Time t = update interval of signal from an external control system A = speed reference change during t This function is only active in remote external control.	Off
	Off	Variable slope disabled.	0
	On	Variable slope enabled (not available in local control).	1
23.29	Variable slope rate	Defines the rate of the speed reference change when variable slope is enabled by parameter 23.28 Variable slope. For the best result, enter the reference update interval into this parameter.	50
	230000 ms	Variable slope rate.	1 = 1

No.	Name/Value	Description	Def/FbEq16
23.32	Shape time 1	Defines the shape of the acceleration and deceleration ramps used with the set 1. 0.000 s: Linear ramp. Suitable for steady acceleration or deceleration and for slow ramps. 0.0011000.000 s: S-curve ramp. S-curve ramps are ideal for lifting applications. The S-curve consists of symmetrical curves at both ends of the ramp and a linear part in between. Acceleration: Speed Linear ramp: 23.32 = 0 s Linear ramp: 23.32 = 0 s S-curve ramp: 23.32 > 0 s S-curve ramp: 23.32 > 0 s Time	0.000
		Deceleration:	
		Speed S-curve ramp: 23.32 > 0 s Linear ramp: 23.32 = 0 s Linear ramp: 23.32 = 0 s Time	
	0.0001800.000 s	Ramp shape at start and end of acceleration and deceleration.	10 = 1
23.33	Shape time 2	Defines the shape of the acceleration and deceleration ramps used with the set 2. See parameter 23.32 Shape time 1.	0.000
	0.0001800.000 s	Ramp shape at start and end of acceleration and deceleration.	10 = 1


No.	Name/Value	Description	Def/FbEq16
	eed reference tioning	Speed error calculation; speed error window control configuration; speed error step. See the control chain diagram on page <i>496</i> .	
24.01	Used speed reference	Displays the ramped and corrected speed reference (before speed error calculation). See the control chain diagram on page <i>496</i> . This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed reference used for speed error calculation.	See par. 46.01
24.02	Used speed feedback	Displays the speed feedback used for speed error calculation. See the control chain diagram on page 496. This parameter is read-only.	-
	-30000.00 30000.00 rpm	Speed feedback used for speed error calculation.	See par. 46.01
24.03	Speed error filtered	Displays the filtered speed error. See the control chain diagram on page 496. This parameter is read-only.	-
	-30000.0 30000.0 rpm	Filtered speed error.	See par. 46.01
24.12	Speed error filter time	Defines the time constant of the speed error low-pass filter. If the used speed reference changes rapidly, the possible interferences in the speed measurement can be filtered with the speed error filter. Reducing the ripple with this filter may cause speed controller tuning problems. A long filter time constant and fast acceleration time contradict one another. A very long filter time results in unstable control.	0 ms
	010000 ms	Speed error filtering time constant. 0 = filtering disabled.	1 = 1 ms
25 Sp	eed control	Speed controller settings. See the control chain diagrams on pages 497 and 498.	
25.01	Torque reference speed control	Displays the speed controller output that is transferred to the torque controller. See the control chain diagram on page 497. This parameter is read-only.	0.0
	-1600.01600.0%	Limited speed controller output torque.	See par. 46.03



No.	Name/Value	Description	Def/FbEq16
25.03	Speed integration time	Defines the integration time of the speed controller. The integration time defines the rate at which the controller output changes when the error value is constant and the proportional gain of the speed controller is 1. The shorter the integration time, the faster the continuous error value is corrected. This time constant must be set to the same order of magnitude as the time constant (time to respond) of the actual mechanical system being controlled, otherwise instability will result. Setting the integration time to zero disables the I-part of the controller. This is useful to do when tuning the proportional gain; adjust the proportional gain first, then return the integration time. Anti-windup (the integrator just integrates up to 100%) stops the integrator if the controller output is limited. The figure below shows the speed controller output after an error step when the error remains constant.	2.50
	$K_{p} \times e \begin{cases} \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\$	Controller output Gain = $K_p = 1$ $T_1 = Integration time > T_D = Derivation time = 0$	
	K _p × e	T_{l}	
	0.001000.00 s	Integration time for speed controller.	10 = 1

No.	Name/Value	Description	Def/FbEq16
No. 25.04	Speed derivation time $K_{p} \times T_{D} \times \frac{\Delta e}{T_{s}} \begin{cases} - \frac{1}{K_{p}} \\ K_{p} $	Defines the derivation time of the speed controller. Derivative action boosts the controller output if the error value changes. The longer the derivation time, the more the speed controller output is boosted during the change. If the derivation time is set to zero, the controller works as a PI controller, otherwise as a PID controller. The derivation makes the control more responsive for disturbances. For simple applications, derivative time is not normally required and should be left at zero. The speed error derivative must be filtered with a low pass filter to eliminate disturbances. The figure below shows the speed controller output after an error step when the error remains constant. $\frac{\sqrt[9]{}}{K_{1}} = \frac{1}{T_{1}} = 1$ = Integration time > 0	0.000
	Ts	= Derivation time > 0 = Sample time period = 250 μs = Error value change between two samples	
	0.00010.000 s	Derivation time for speed controller.	1000 = 1
25.05	Derivation filter time	Defines the derivation filter time constant. See parameter 25.04 Speed derivation time.	8
	010000 ms	Derivation filter time constant.	1 = 1

No.	Name/Value	Description	Def/FbEq16
25.06	Acc comp derivation time	Description Description Defines the derivation time for acceleration(/deceleration) compensation. In order to compensate for a high inertia load during acceleration, a derivative of the reference is added to the output of the speed controller. The principle of a derivative action is described under parameter 25.04 Speed derivation time. Note: As a general rule, set this parameter to the value between 50 and 100% of the sum of the mechanical time constants of the motor and the driven machine. The figure below shows the speed responses when a high inertia load is accelerated along a ramp. No acceleration compensation: No acceleration compensation: Accual speed Accual speed Accual speed	0.00
		Speed reference 	
	0.001000.00 s	Acceleration compensation derivation time.	10 = 1
25.07	Acc comp filter time	Defines the acceleration (or deceleration) compensation filter time constant. See parameters 25.04 Speed derivation time and 25.06 Acc comp derivation time.	8.0
	0.01000.0 ms	Acceleration/deceleration compensation filter time.	1 = 1
25.30	Flux adaptation enable	Visible only when user lock is open with pass code 584. See parameter 96.02 Pass code.) Enables/disables speed controller adaptation based on motor flux reference (01.24 Flux actual %). The proportional gain of the speed controller is multiplied by a coefficient of 01 between 0100% flux reference respectively.	Enable



No.	Name/Value	Description	Def/FbEq16
25.37	Mechanical time constant	Mechanical time constant of the drive and the machinery as determined by the speed controller autotune function. The value can be adjusted manually.	0.00
	0.001000.00 s	Mechanical time constant.	100 = 1 s
25.38	Autotune torque step	Defines an added torque value used by the autotune function. This value is scaled to motor nominal torque. Note that the torque used by the autotune function can also be limited by the torque limits (in parameter group <i>30 Limits</i>) and nominal motor torque.	10.00
	0.00100.00%	Autotune torque step.	100 = 1%
25.39	Autotune speed step	Defines a speed value added to the initial speed for the autotune routine. The initial speed (speed used when autotune is activated) plus the value of this parameter is the calculated maximum speed used by the autotune routine. The maximum speed can also be limited by the speed limits (in parameter group <i>30 Limits</i>) and nominal motor speed. The value is scaled to motor nominal speed. Note: The motor will exceed the calculated maximum speed slightly at the end of each acceleration stage.	10.00
	0.00100.00%	Autotune speed step.	100 = 1%
25.40	Autotune repeat times	Determines how many acceleration/deceleration cycles are performed during the autotune routine. Increasing the value will improve the accuracy of the autotune function, and allow the use of smaller torque or speed step values.	5
	110		1 = 1
25.53	Torque prop reference	Displays the output of the proportional (P) part of the speed controller. See the control chain diagram on page <i>497</i> . This parameter is read-only.	0.0
	-30000.0 30000.0%	P-part output of speed controller.	See par. 46.03
25.54	Torque integral reference	Displays the output of the integral (I) part of the speed controller. See the control chain diagram on page <i>497</i> . This parameter is read-only.	0.0
	-30000.0 30000.0%	I-part output of speed controller.	See par. 46.03
25.55	Torque deriv reference	Displays the output of the derivative (D) part of the speed controller. See the control chain diagram on page <i>497</i> . This parameter is read-only.	0.0
	-30000.0 30000.0%	D-part output of speed controller.	See par. 46.03
25.56	Torque acc compensation	Displays the output of the acceleration compensation function. See the control chain diagram on page 497. This parameter is read-only.	0.0
	-30000.0 30000.0%	Output of acceleration compensation function.	See par. 46.03

No.	Name/Value	Description	Def/FbEq16
26 Tor chain	que reference	Settings for the torque reference chain. See the control chain diagrams on pages <i>498</i> and <i>499</i> .	
26.01	Torque reference to TC	Displays the final torque reference given to the torque controller in percent. This reference is then acted upon by various final limiters, like power, torque, load etc. See the control chain diagrams on pages 498 and 499. This parameter is read-only.	0.0
	-1600.01600.0%	Torque reference for torque control.	See par. 46.03
26.02	Torque reference used	Displays the final torque reference (in percent of motor nominal torque) given to the torque controller, and comes after frequency, voltage and torque limitation. See the control chain diagram on page <i>500</i> . This parameter is read-only.	0.0
	-1600.01600.0%	Torque reference for torque control.	See par. 46.03
26.08	Minimum torque ref	Defines the minimum torque reference. Allows for local limiting of the torque reference before it is passed on to the torque ramp controller. For absolute torque limiting, refer to parameter <i>30.19 Minimum torque 1</i> .	-300.0%
	-1000.00.0%	Minimum torque reference.	See par. 46.03
26.09	Maximum torque ref	Defines the maximum torque reference. Allows for local limiting of the torque reference before it is passed on to the torque ramp controller. For absolute torque limiting, refer to parameter <i>30.20 Maximum torque 1</i> .	300.0%
	0.01000.0%	Maximum torque reference.	See par. 46.03
26.11	Torque ref1 source	Selects torque reference source 1. Two signal sources can be defined by this parameter and 26.12 Torque ref2 source. A digital source selected by 26.14 Torque ref1/2 selection can be used to switch between the two sources, or a mathematical function (26.13 Torque ref1 function) applied to the two signals to create the reference.	Zero
	0 AI FB Other		26.72
	Zero	None.	0

No.	Name/Value	Description	Def/FbEq16
	Al1 scaled	12.12 Al1 scaled value (see page 189).	1
	Al2 scaled	12.22 Al2 scaled value (see page 190).	2
	Reserved		3
	FB A ref1	03.05 FB A reference 1 (see page 167).	4
	FB A ref2	03.06 FB A reference 2 (see page 167).	5
	Reserved		67
	EFB ref1	03.09 EFB reference 1 (see page 167).	8
	EFB ref2	03.10 EFB reference 2 (see page 167).	9
	Reserved		1014
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15
	PID	40.01 Process PID output actual (output of the process PID controller).	16
	Frequency input	11.38 Freq in 1 actual value (when DI5 is used as a frequency input).	17
	Control panel (ref saved)	Panel reference (03.01 Panel reference, see page 167) saved by the control system for the location where the control returns is used as the reference. Reference	18
		EXT2 reference Active reference Inactive reference EXT1 -> EXT2	
	Control panel (ref copied)	Panel reference (03.01 Panel reference, see page 167) for the previous control location is used as the reference when the control location changes if the references for the two locations are of the same type (e.g. frequency/speed/torque/PID); otherwise, the actual signal is used as the new reference.	19
		Reference EXT1 reference EXT2 reference Active reference Inactive reference	
	Other	Source selection (see Terms and abbreviations on page 161).	-
26.12	Torque ref2 source	Selects torque reference source 2. For the selections, and a diagram of reference source selection, see parameter 26.11 Torque ref1 source.	Zero
26.13	Torque ref1 function	Selects a mathematical function between the reference sources selected by parameters 26.11 Torque ref1 source and 26.12 Torque ref2 source. See diagram at 26.11 Torque ref1 source.	Ref1
	Ref1	Signal selected by 26.11 Torque ref1 source is used as torque reference 1 as such (no function applied).	0
	Add (ref1 + ref2)	The sum of the reference sources is used as torque reference 1.	1

No.	Name/Value	Description	Def/FbEq16	
	Sub (ref1 - ref2)	The subtraction ([26.11 Torque ref1 source] - [26.12 Torque ref2 source]) of the reference sources is used as torque reference 1.	2	
	Mul (ref1 × ref2)	The multiplication of the reference sources is used as torque reference 1.	3	
	Min (ref1, ref2)	The smaller of the reference sources is used as torque reference 1.	4	
	Max (ref1, ref2)	The greater of the reference sources is used as torque reference 1.	5	
26.14	Torque ref1/2 selection	Configures the selection between torque references 1 and 2. See diagram at 26.11 Torque ref1 source. 0 = Torque reference 1 1 = Torque reference 2	Torque reference 1	
	Torque reference 1	0	0	
	Torque reference 2	1	1	
	Follow Ext1/Ext2 selection	Torque reference 1 is used when external control location EXT1 is active. Torque reference 2 is used when external control location EXT2 is active. See also parameter 19.11 Ext1/Ext2 selection.	2	
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0)	3	
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1)	4	
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2)	5	
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3)	6	
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4)	7	
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5)	8	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161)	-	
26.17	Torque ref filter time	Defines a low-pass filter time constant for the torque reference.	0.000 s	
	0.00030.000 s	Filter time constant for torque reference.	1000 = 1 s	
26.18	Torque ramp up time	Defines the torque reference ramp-up time, ie. the time for the reference to increase from zero to nominal motor torque.	0.000 s	
	0.00060.000 s	Torque reference ramp-up time.	100 = 1 s	
26.19	Torque ramp down time	Defines the torque reference ramp-down time, ie. the time for the reference to decrease from nominal motor torque to zero.	0.000 s	
	0.00060.000 s	Torque reference ramp-down time.	100 = 1 s	
26.20	Torque reversal Selects the source of torque reversal function.		Always off	
	Always off	Torque reversal function is disabled.	0	
	Always on	Torque reversal function is enabled.	1	
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2	
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3	
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4	
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5	
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6	
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7	
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 280).	8	
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 280).	9	

No.	Name/Value	Description	Def/FbEq16	
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 280).	10	
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 273).	11	
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 273).	12	
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 273).	13	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-	
26.70	Torque reference act 1	Displays the value of torque reference source 1 (selected by parameter 26.11 Torque ref1 source). See the control chain diagram on page 498. This parameter is read-only.	0.0	
	-1600.01600.0%	Value of torque reference source 1.	See par. 46.03	
26.71	Torque reference act 2	Displays the value of torque reference source 2 (selected by parameter 26.12 Torque ref2 source). See the control chain diagram on page 498. This parameter is read-only.	0.0	
	-1600.01600.0%	Value of torque reference source 2.	See par. 46.03	
26.72	Torque reference act 3	Displays the torque reference after the function applied by parameter 26.13 Torque ref1 function (if any), and after selection (26.14 Torque ref1/2 selection). See the control chain diagram on page 498. This parameter is read-only.	0.0	
	-1600.01600.0%	Torque reference after selection.	See par. 46.03	
26.73	<i>Torque reference act 4</i>	Displays the torque reference after application of reference additive 1. See the control chain diagram on page <i>498</i> . This parameter is read-only.	0.0	
	-1600.01600.0%	Torque reference after application of reference additive 1.	See par. 46.03	
26.74	Torque ref ramp out	Displays the torque reference after limiting and ramping. See the control chain diagram on page <i>498</i> . This parameter is read-only.	0.0	
	-1600.01600.0%	Torque reference after limiting and ramping.	See par. 46.03	
26.75	<i>Torque reference act 5</i>	Displays the torque reference after control mode selection. See the control chain diagram on page 499. This parameter is read-only.	0.0	
	-1600.01600.0%	Torque reference after control mode selection.	See par. 46.03	
26.76	<i>Torque reference act 6</i>	Displays the torque reference after the trim addition to the parameter 26.75 Torque reference act 5.	0.0	
	-1600.01600.0%	Torque reference after control mode selection.	See par. 46.03	
26.81	Rush control gain	Rush controller gain term. See section <i>Rush control</i> (page 72).	5.0	
	0.010000.0	Rush controller gain (0.0 = disabled).	1 = 1	
26.82	Rush control integration time	Rush controller integration time term.	2.0s	
	0.010.0 s	Rush controller integration time (0.0 = disabled).	1 = 1s	

No.	Name/Value	Description	Def/FbEq16
28 Frequency reference chain		Settings for the frequency reference chain. See the control chain diagrams on pages 490 and 491.	
28.01	Frequency ref ramp input	Displays the used frequency reference before ramping. See the control chain diagram on page <i>490</i> . This parameter is read-only.	0.00
	-500.00500.00 Hz	Frequency reference before ramping.	See par. 46.02
28.02	Frequency ref ramp output	Displays the final frequency reference (after selection, limitation and ramping). See the control chain diagram on page 490. This parameter is read-only.	0.00
	-500.00500.00 Hz	Final frequency reference.	See par. 46.02

No.	Name/Value	Name/Value Description					
28.11	Ext1 frequency ref1	Selects Ext1 frequency reference source 1. Two signal sources can be defined by this parameter and 28.12 Ext1 frequency ref2. A mathematical function (28.13 Ext1 frequency function) applied to the two signals creates an Ext1 reference (A in the figure below). A digital source selected by 19.11 Ext1/Ext2 selection can be used to switch between Ext1 reference and the corresponding Ext2 reference defined by parameters 28.15 Ext2 frequency ref1, 28.16 Ext2 frequency ref2 and 28.17 Ext2 frequency function (B in the figure below).	Al1 scaled				
	0 AI FB <i>Other</i> AI FB <i>Other</i>	28.11 28.13 ADD SUB MUL Ext1 19.11 0					
	0 AI FB <i>Other</i> AI FB <i>Other</i>	$\Pi $ \square	9.92				
	Zero	None	0				
	Al1 scaled	12.12 Al1 scaled value (see page 189)	1				
	Al2 scaled	Scaled 12.22 AI2 scaled value (see page 190) A ref1 03.05 FB A reference 1 (see page 167)					
	FB A ref1						
	FB A ref2						
	EFB ref1	03.09 EFB reference 1 (see page 167)	8				
	EFB ref2	03.10 EFB reference 2 (see page 167)	9				
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer)	15				
_	PID	40.01 Process PID output actual (output of the process PID controller)	16				

No.	Name/Value Description					
	Frequency input	11.38 Freq in 1 actual value (when DI5 or DI6 is used as a frequency input).	17			
	Control panel (ref saved)	Panel reference (03.01 Panel reference, see page 167) saved by the control system for the location where the control returns is used as the reference. Reference	18			
	Control panel (ref copied)	Panel reference (03.01 Panel reference, see page 167) for the previous control location is used as the reference when the control location changes if the references for the two locations are of the same type (eg frequency/speed/torque/PID); otherwise, the actual signal is used as the new reference. <i>Reference</i> \leftarrow Ext1 reference \leftarrow Ext2 reference \leftarrow Active reference \leftarrow Inactive reference	19			
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-			
28.12	Ext1 frequency ref2	Selects Ext1 frequency reference source 2. For the selections, and a diagram of reference source selection, see parameter 28.11 Ext1 frequency ref1.	Zero			
28.13	Ext1 frequency function	Selects a mathematical function between the reference sources selected by parameters 28.11 Ext1 frequency ref1 and 28.12 Ext1 frequency ref2. See diagram at 28.11 Ext1 frequency ref1.	Ref1			
	Ref1	Signal selected by 28.11 Ext1 frequency ref1 is used as frequency reference 1 as such (no function applied).	0			
	Add (ref1 + ref2)	The sum of the reference sources is used as frequency reference 1.	1			
	Sub (ref1 - ref2)	The subtraction ([28.11 Ext1 frequency ref1] - [28.12 Ext1 frequency ref2]) of the reference sources is used as frequency reference 1.	2			
	Mul (ref1 × ref2)	The multiplication of the reference sources is used as frequency reference 1.	3			
	Min (ref1, ref2)	The smaller of the reference sources is used as frequency reference 1.	4			
	Max (ref1, ref2)	The greater of the reference sources is used as frequency reference 1.	5			
28.15	Ext2 frequency ref1	Selects Ext2 frequency reference source 1. Two signal sources can be defined by this parameter and 28.16 Ext2 frequency ref2. A mathematical function (28.17 Ext2 frequency function) applied to the two signals creates an Ext2 reference. See diagram at 28.11 Ext1 frequency ref1.	Zero			
	Zero	None.	0			
	AI1 scaled	12.12 Al1 scaled value (see page 189).	1			

No.	Name/Value	Description	Def/FbEq16
	Al2 scaled	12.22 Al2 scaled value (see page 190).	2
	FB A ref1	03.05 FB A reference 1 (see page 167).	4
	FB A ref2	03.06 FB A reference 2 (see page 167).	5
	EFB ref1	03.09 EFB reference 1 (see page 167).	8
	EFB ref2	03.10 EFB reference 2 (see page 167).	9
	Reserved		1014
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15
	PID	40.01 Process PID output actual (output of the process PID controller).	16
	Frequency input	<i>11.38 Freq in 1 actual value</i> (when DI5 or DI6 is used as a frequency input).	17
	Control panel (ref saved)	Panel reference (03.01 Panel reference, see page 167) saved by the control system for the location where the control returns is used as the reference. Reference	18
	Control panel (ref copied)	Panel reference (03.01 Panel reference, see page 167) for the previous control location is used as the reference when the control location changes if the references for the two locations are of the same type (eg frequency/speed/torque/PID); otherwise, the actual signal is used as the new reference. Reference Ext1 reference Ext2 reference Active reference Active reference Active reference Active reference	19
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
28.16	Ext2 frequency ref2	Selects Ext2 frequency reference source 2. For the selections, and a diagram of reference source selection, see parameter 28.15 Ext2 frequency ref1.	Zero
28.17	8.17 Ext2 frequency function Selects a mathematical function between the reference sources selected by parameters 28.15 Ext2 frequency ref1 and 28.16 Ext2 frequency ref2. See diagram at 28.15 Ext2 frequency ref1.		Ref1
	Ref1	Signal selected by 28.15 Ext2 frequency ref1 is used as frequency reference 1 as such (no function applied).	0
	Add (ref1 + ref2)	The sum of the reference sources is used as frequency reference 1.	1
	Sub (ref1 - ref2)	The subtraction ([28.15 Ext2 frequency ref1] - [28.16 Ext2 frequency ref2]) of the reference sources is used as frequency reference 1.	2

No.	Name/Value E		escription Def/FbE	
			The multiplication of the reference sources is used as frequency reference 1.	3
	Min (re	ef1, ref2)	The smaller of the reference sources is used as frequency reference 1.	4
	Max (r	ef1, ref2)	The greater of the reference sources is used as frequency reference 1.	5
28.21	function who		Determines how constant frequencies are selected, and whether the rotation direction signal is considered or not when applying a constant frequency.	0b0001
	Bit	Name	Information	
	0 Const freq mode		1 = Packed: 7 constant frequencies are selectable using sources defined by parameters 28.22, 28.23 and 28.24.	the three
			0 = Separate: Constant frequencies 1, 2 and 3 are separa by the sources defined by parameters 28.22, 28.23 and 2 respectively. In case of conflict, the constant frequency w number takes priority.	28.24
	1	Direction enable	1 = Start dir: To determine running direction for a constant sign of the constant speed setting (parameters 22.262; multiplied by the direction signal (forward: +1, reverse: -1 effectively allows the drive to have 14 (7 forward, 7 reverses speeds if all values in 22.2622.32 are positive. Marking: If the direction signal is reverse and the direction. WARNING: If the direction signal is reverse and the direction. 0 = Accord Days. The supplied direction for the constant speed is negative.	2.32) is). This se) constant he active e forward
			0 = Accord Par: The running direction for the constant spidetermined by the sign of the constant speed setting (par 22.2622.32).	
	2	Frequency	step Frequency step: 1 = Freq step enable; 0 = Freq step disa	ıble
	315	Reserved	·	
	06000	0b1111	Constant frequency configuration word.	1 = 1

No.	Name/\	/alue	Description			Def/FbEq16
28.22	Constai sel1	nt frequency	When bit 0 of parame 0 (Separate), selects frequency 1. When bit 0 of parame 1 (Packed), this paran frequency sel2 and 2 three sources whose follows:	a source that active ter 28.21 Constant meter and paramete 8.24 Constant frequ	ates constant frequency function is ers 28.23 Constant uency sel3 select	DI3
		Source defi	ned Source defined	Source defined	Constant frequer	псу
		by par. 28		by par. 28.24	active	
		0	0	0	None	4
		1	0	0	Constant frequence Constant frequence	5
		1	1	0	Constant frequence	
		0	0	1	Constant frequence	
		1	0	1	Constant frequence	
		0	1	1	Constant frequence	y 6
		1	1	1	Constant frequence	y 7
	Always	off	0.			0
	Always on		1.			1
	DI1		Digital input DI1 (10.0	02 DI delayed statu	s, bit 0).	2
	DI2		Digital input DI2 (10.0	2 DI delayed statu	s, bit 1).	3
	DI3		Digital input DI3 (10.02 DI delayed status, bit 2).		4	
	DI4		Digital input DI4 (10.0	02 DI delayed status	s, bit 3).	5
	DI5		Digital input DI5 (10.0	02 DI delayed status	s, bit 4).	6
	DI6		Digital input DI6 (10.0	02 DI delayed statu	s, bit 5).	7
	Timed f	unction 1	Bit 0 of 34.01 Timed	<i>functions status</i> (se	e page <u>280</u>).	18
	Timed f	unction 2	Bit 1 of 34.01 Timed	functions status (se	e page 280).	19
	Timed f	unction 3	Bit 2 of 34.01 Timed	functions status (se	e page <u>280</u>).	20
	Supervi	sion 1	Bit 0 of 32.01 Superv	ision status (see pa	ge 273).	24
	Supervi	sion 2	Bit 1 of 32.01 Superv	ision status (see pa	ge 273).	25
	Supervi	sion 3	Bit 2 of 32.01 Superv	<i>ision status</i> (see pa	ge 273).	26
	Other [t	bit]	Source selection (see	Terms and abbrev	iations on page 161).	-
28.23	Constal sel2	nt frequency	When bit 0 of parame 0 (Separate), selects frequency 2. When bit 0 of parame 1 (Packed), this parau frequency sel1 and 2 three sources that are See table at paramet For the selections, see sel1.	a source that activa ter 28.21 Constant meter and paramete 8.24 Constant freque e used to activate c er 28.22 Constant fr	ates constant frequency function is ers 28.22 Constant iency sel3 select onstant frequencies. requency sel1.	DI4

No.	Name/Value	Description	Def/FbEq16
28.24	Constant frequency sel3	When bit 0 of parameter 28.21 Constant frequency function is 0 (Separate), selects a source that activates constant frequency 3. When bit 0 of parameter 28.21 Constant frequency function is 1 (Packed), this parameter and parameters 28.22 Constant frequency sel1 and 28.23 Constant frequency sel2 select three sources that are used to activate constant frequencies. See table at parameter 28.22 Constant frequency sel1. For the selections, see parameter 28.22 Constant frequency sel1.	Always off
28.26	Constant frequency 1	Defines constant frequency 1 (the frequency the motor will turn when constant frequency 1 is selected).	5.00 Hz
	-500.00…500.00 Hz	Constant frequency 1.	See par. 46.02
28.27	Constant frequency 2	Defines constant frequency 2.	10.00 Hz
	-500.00500.00 Hz	Constant frequency 2.	See par. 46.02
28.28	Constant frequency 3	Defines constant frequency 3.	15.00 Hz
	-500.00500.00 Hz	Constant frequency 3.	See par. 46.02
28.29	Constant frequency 4	Defines constant frequency 4.	20.00 Hz
	-500.00500.00 Hz	Constant frequency 4.	See par. 46.02
28.30	Constant frequency 5	Defines constant frequency 5.	25.00 Hz
	-500.00500.00 Hz	Constant frequency 5.	See par. 46.02
28.31	Constant frequency 6	Defines constant frequency 6.	40.00 Hz
	-500.00500.00 Hz	Constant frequency 6.	See par. 46.02
28.32	Constant frequency 7	Defines constant frequency 7.	50.00 Hz
	-500.00500.00 Hz	Constant frequency 7.	See par. 46.02
28.41	Frequency ref safe	Defines a safe frequency reference value that is used with supervision functions such as • 12.03 AI supervision function • 49.05 Communication loss action • 50.02 FBA A comm loss func.	0.00 Hz
	-500.00500.00 Hz	Safe frequency reference.	See par. 46.02
28.42	Jogging 1 frequency ref	Defines the frequency reference for jogging function 1 in scalar control mode.	0.00 Hz
	-500.00500.00 Hz	Jogging 1 frequency reference.	See par. 46.02
28.43	Jogging 2 frequency ref	Defines the frequency reference for jogging function 2 in scalar control mode.	0.00 Hz

No. Name/Value		Des	scription	Def/FbEq16	
	-500.00500.00 Hz		Jog	ging 2 frequency reference.	See par. 46.02
28.51	Critical frequency function		dete rota	ables/disables the critical frequencies function. Also ermines whether the specified ranges are effective in both ating directions or not. e also section <i>Critical speeds/frequencies</i> (page 44).	060000
	Bit	Name		Information	
	0	Crit freq		1 = Enable: Critical frequencies enabled.	
				0 = Disable: Critical frequencies disabled.	
	1	Sign mode		1 = According to par: The signs of parameters 28.5228.4 into account.	
				0 = Absolute: Parameters 28.5228.57 are handled as abs Each range is effective in both directions of rotation.	solute values.
	25	Reserved			
	0b000)0b1111	Crit	ical frequencies configuration word.	1 = 1
28.52	Critical Iow	frequency 1	Not	ines the low limit for critical frequency 1. te: This value must be less than or equal to the value of 53 Critical frequency 1 high.	0.00 Hz
	-500.00 Hz	0500.00	Lov	v limit for critical frequency 1.	See par. 46.02
28.53	Critical frequency 1 high		Not	ines the high limit for critical frequency 1. te: This value must be greater than or equal to the value of 52 Critical frequency 1 low.	0.00 Hz
	-500.00500.00 Hz		Hig	h limit for critical frequency 1.	See par. 46.02
28.54	Critical frequency 2 low		Not	ines the low limit for critical frequency 2. te: This value must be less than or equal to the value of 55 Critical frequency 2 high.	0.00 Hz
	-500.00500.00 Hz		Lov	v limit for critical frequency 2.	See par. 46.02
28.55	Critical high	frequency 2	Not	ines the high limit for critical frequency 2. te: This value must be greater than or equal to the value of 54 Critical frequency 2 low.	0.00 Hz
	-500.00 Hz	0500.00	Hig	h limit for critical frequency 2.	See par. 46.02
28.56	6 Critical frequency 3 low		Not	ines the low limit for critical frequency 3. te: This value must be less than or equal to the value of <i>57 Critical frequency 3 high</i> .	0.00 Hz
	-500.00 Hz	0500.00	Lov	v limit for critical frequency 3.	See par. 46.02
28.57	Critical high	frequency 3	Not	ines the high limit for critical frequency 3. te: This value must be greater than or equal to the value of 56 Critical frequency 3 low.	0.00 Hz
	-500.00 Hz	0500.00	Hig	h limit for critical frequency 3.	See par. 46.02

No.	Name/Value	Description	Def/FbEq16
28.71	Freq ramp set selection	Selects a source that switches between the two sets of acceleration/deceleration times defined by parameters 28.7228.75. 0 = Acceleration time 1 and deceleration time 1 are in force 1 = Acceleration time 2 and deceleration time 2 are in force	DI5
	Acc/Dec time 1		0
	Acc/Dec time 2	1	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0)	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 0)	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 1)	4
	DI4	Digital input Did (10.02 DI delayed status, bit 2)	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 6)	6
	DIG	Digital input DIS (10.02 DI delayed status, bit 4)	7
	FBAA	Only for the Transparent16 or Transparent32 profile.	18
	FDAA	Transparent16 or Transparent32 control word bit received through the fieldbus A interface.	10
	EFB DCU CW bit 10	Only for the DCU profile. DCU control word bit 10 received through the embedded fieldbus interface.	20
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
28.72	Freq acceleration time 1	Defines acceleration time 1 as the time required for the frequency to change from zero to the frequency defined by parameter 46.02 Frequency scaling. After this frequency has been reached, the acceleration continues with the same rate to the value defined by parameter 30.14 Maximum frequency. If the reference increases faster than the set acceleration rate, the motor will follow the acceleration rate. If the reference increases slower than the set acceleration rate, the motor frequency will follow the reference. If the acceleration time is set to short, the drive will automatically prolong the acceleration in order not to exceed the drive torque limits.	20.000 s
	0.0001800.000 s	Acceleration time 1.	10 = 1 s
28.73	Freq deceleration time 1	Defines deceleration time 1 as the time required for the frequency to change from the frequency defined by parameter 46.02 Frequency scaling (not from parameter 30.14 Maximum frequency) to zero. If there is any doubt about the deceleration time being too short, ensure that DC overvoltage control (30.30 Overvoltage control) is on. Note: If a short deceleration time is needed for a high inertia application, the drive should be equipped with braking equipment such as a brake chopper and brake resistor.	20.000 s
	0.0001800.000 s	Deceleration time 1.	10 = 1 s
28.74	Freq acceleration time 2	Defines acceleration time 2. See parameter 28.72 Freq acceleration time 1.	60.000 s
	0.0001800.000 s	Acceleration time 2.	10 = 1 s
28.75	Freq deceleration time 2	Defines deceleration time 2. See parameter 28.73 Freq deceleration time 1.	60.000 s
	0.0001800.000 s	Deceleration time 2.	10 = 1 s

No.	Name/Value	Description	Def/FbEq16
28.76	Freq ramp in zero source	Selects a source that forces the frequency reference to zero. 0 = Force frequency reference to zero 1 = Normal operation	Inactive
	Active	0	0
	Inactive	1	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0)	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1)	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2)	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3)	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4)	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5)	7
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161)	-

No.	Name/Value	Description	Def/FbEq16
28.82	Shape time 1	Defines the shape of the acceleration and deceleration ramps used with the set 1. 0.000 s: Linear ramp. Suitable for steady acceleration or deceleration and for slow ramps. 0.0011000.000 s: S-curve ramp. S-curve ramps are ideal for lifting applications. The S-curve consists of symmetrical curves at both ends of the ramp and a linear part in between. Acceleration: Speed Linear ramp: 28.82 = 0 s S-curve ramp: 28.82 > 0 s S-curve ramp: 28.82 > 0 s Time	0.000 s
I		Deceleration:	
		Speed S-curve ramp: 28.82 > 0 s Linear ramp: 28.82 = 0 s Linear ramp: 28.82 = 0 s Time	
	0.0001800.000 s	Ramp shape at start and end of acceleration and deceleration.	10 = 1 s
28.83	Shape time 2	Defines the shape of the acceleration and deceleration ramps used with the set 2. See parameter <i>28.82 Shape time 1</i> .	0.000 s
	0.0001800.000 s	Ramp shape at start and end of acceleration and deceleration.	10 = 1 s

No.	Name/	Value	Desc	ription	Def/FbEq16	
28.92	Frequency ref act 3		parar selec diagr	ays the frequency reference after the function applied by meter 28.13 Ext1 frequency function (if any), and after tion (19.11 Ext1/Ext2 selection). See the control chain am on page 490. parameter is read-only.	0.00	
	-500.00 Hz)500.00	Frequ	uency reference after selection.	See par. 46.02	
28.96	Freque	ncy ref act 7	frequ chain	ays the frequency reference after application of constant encies, control panel reference, etc. See the control diagram on page 490. parameter is read-only.	0.00	
	-500.00 Hz)500.00	Frequ	uency reference 7.	See par. 46.02	
28.97	Frequency ref unlimited		frequ chain	ays the frequency reference after application of critical encies, but before ramping and limiting. See the control diagram on page 490. parameter is read-only.	0.00	
	-500.00 Hz	0500.00	Frequ	uency reference before ramping and limiting.	See par. 46.02	
30 Lin	nits		Drive	operation limits.		
30.01	Limit word 1			ays limit word 1. parameter is read-only.f	0b0000	
	Bit	Name		Description		
	0	Torq lim		1 = Drive torque is limited by the motor control (undervol current control, load angle control or pull-out control), or limits defined by parameters.		
	12	Reserved				
	3	Torq ref ma	х	1 = Torque reference ramp input is being limited by 26.0 torque ref, 30.20 Maximum torque 1, 30.26 Power motor 30.27 Power generating limit. See the diagram on page	otoring limit, or	
	4	Torq ref mir	1	1 = Torque reference ramp input is being limited by 26.08 Minimut torque ref, 30.19 Minimum torque 1, 30.26 Power motoring limit, 30.27 Power generating limit. See the diagram on page 500.		
	5	Tlim max s	beed	1 = Torque reference is being limited by the rush control because of maximum speed limit (<i>30.12 Maximum speed</i>)		
	6	Tlim min sp	eed	1 = Torque reference is being limited by the rush control because of minimum speed limit (<i>30.11 Minimum speed</i>)		
	7	Max speed	ref lim	1 = Speed reference is being limited by 30.12 Maximum	speed	
	8	Min speed	ref lim	1 = Speed reference is being limited by 30.11 Minimum	speed	
	9	Max freq re	f lim	1 = Frequency reference is being limited by 30.14 Maxim	um frequency	
	10	Min freg ref	lim	1 = Frequency reference is being limited by 30.13 Minim	um frequency	
	10	1 1				

No.	No. Name/Value		Desc	ription	Def/FbEq16		
30.02	Torque li	mit status		ays the torque controller limitation status word. parameter is read-only.	0b0000		
	Bit	Name		Description			
	0	Undervoltag	ge	*1 = Intermediate DC circuit undervoltage			
	1	Overvoltage Minimum torque Maximum torque		*1 = Intermediate DC circuit overvoltage			
	2			*1 = Torque is being limited by 30.19 Minimum torque 1, motoring limit, or 30.27 Power generating limit			
	3			*1 = Torque is being limited by 30.20 Maximum torque 1, motoring limit, or 30.27 Power generating limit	30.26 Power		
	4	Internal cur	rent	1 = An inverter current limit (identified by bits 811) is a	ctive		
	5	Load angle		Not applicable			
	6	Motor pullo	ut	(With asynchronous motors only) Motor pull-out limit is active, ie. the motor cannot produce any more torque			
	7	Reserved					
	8	Thermal		1 = Input current is being limited by the main circuit therr	nal limit		
	9	Max curren	t	*1 = Maximum output current (I _{MAX}) is being limited			
	10	User currer	nt	*1 = Output current is being limited by 30.17 Maximum c			
	11	Thermal IG	BT	*1 = Output current is being limited by a calculated them value			
	12	IGBT overtemperature IGBT overload		 *1 = Output current is being limited because of estimated IGBT temperature *1 = Output current is being limited because of IGBT junction to case temperature 			
	13						
				and one out of bits 911 can be on simultaneously. The ceeded first.	bit typically		
	0b0000.	0b1111	Torqu	ie limitation status word.	1 = 1		
30.09	Current limit monitor time 0120s Current limit actions No action			Defines the drive current limit monitor time after which action is taken as specified in the parameter 30.10 .			
			Current limit monitor time.		100=1		
30.10			curre	Selects how the drive reacts when the drive reaches the current limit (<i>30.17 Maximum current</i>) and exceeds the monitor time set by parameter <i>30.09 Current limit monitor time</i> .			
			None (current limit action disabled).		0		
	Warning		The drive generates an A8B6 Current limit warning.		1		
			The drive trips on fault 8009 Current limit. 2		2		
30.11				es the minimum allowed speed. WARNING! This value must not be higher than 30.12 Maximum speed. WARNING! In speed control mode only. In frequency control mode, use frequency limits (30.13 and 30.14).	-1500.00 rpm		
	-30000.0 30000.00		Minin	num allowed speed.	See par. 46.01		

No.	Name/Value	Description	Def/FbEq16
30.12	Maximum speed	Defines the maximum allowed speed. Note: This parameter does not affect the speed acceleration and deceleration ramp times. See parameter 46.01 Speed scaling. Marching. Marching. WARNING! This value must not be lower than 30.11 Minimum speed. WARNING! In speed control mode only. In frequency control mode, use frequency limits (30.13 and 30.14).	1500.00 rpm
	-30000.00 30000.00 rpm	Maximum speed.	See par. 46.01
30.13	Minimum frequency	Defines the minimum allowed frequency. WARNING! This value must not be higher than 30.14 Maximum frequency. WARNING! in frequency control mode only.	-50.00 Hz
	-500.00500.00 Hz	Minimum frequency.	See par. 46.02
30.14	Maximum frequency	Defines the maximum allowed frequency. Note: This parameter does not affect the frequency acceleration and deceleration ramp times. See parameter 46.02 Frequency scaling. Marking! Marking! Minimum frequency. WARNING! Marking! Mar	50.00 Hz
	-500.00500.00 Hz	Maximum frequency.	See par. 46.02
30.17	Maximum current	Defines the maximum allowed drive current. The system sets the default value to 90% of the rated current. If required, you can increase the parameter value by 10%. Note: The maximum current range and default value depends on the drive type.	2.92 A
	0.003.24 A	Maximum drive current.	1 = 1 A

No.	Name/Value	Description	Def/FbEq16
30.18	Torq lim sel	Selects a source that switches between two different predefined minimum torque limit sets. 0 = minimum torque limit defined by 30.19 and maximum torque limit defined by 30.20 are active 1 = minimum torque limit selected by 30.21 and maximum torque limit defined by 30.22 are active The user can define two sets of torque limits, and switch between the sets using a binary source such as a digital input. The first set of limits is defined by parameters 30.19 and 30.20. The second set has selector parameters for both the minimum (30.21) and maximum (30.22) limits that allows the use of a selectable analog source (such as an analog input).	Torque limit set 1
		0 Al1 Al2 PID 30.23 Other 30.19 User-defined minimum torque limit 30.22	
		0 Al1 PID 30.24 Other 30.20	
		Note: In addition to the user-defined limits, torque may be limited for other reasons (such as power limitation). See block diagram <i>Torque limitation</i> on page <i>500</i> .	
	Torque limit set 1	0 (minimum torque limit defined by 30.19 and maximum torque limit defined by 30.20 are active).	0
	Torque limit set 2	1 (minimum torque limit selected by <i>30.21</i> and maximum torque limit defined by <i>30.22</i> are active).	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	Reserved		810
	EFB	Only for the DCU profile. DCU control word bit 15 received through the embedded fieldbus interface.	11
	Other [bit]	Source selection (see Terms and abbreviations on page 161).	-

No.	Name/Value	Description	Def/FbEq16
30.19	Minimum torque 1	Defines a minimum torque limit for the drive (in percent of nominal motor torque).	-300.0%
	-1600.00.0%	Minimum torque limit 1.	See par. 46.03
30.20	Maximum torque 1	Defines a maximum torque limit for the drive (in percent of nominal motor torque).	300.0%
	0.01600.0%	Maximum torque 1.	See par. 46.03
30.21	Min torque 2 source	 Defines the source of the minimum torque limit for the drive (in percent of nominal motor torque) when the source selected by parameter 30.18 Torq lim sel is 1, or 30.18 is set to Torque limit set 2. See diagram at 30.18 Torq lim sel. Note: Any positive values received from the selected source are inverted. 	Minimum torque 2
	Zero	None.	0
	Al1 scaled	12.12 Al1 scaled value (see page 189).	1
	Al2 scaled	12.22 AI2 scaled value (see page 190).	2
	Reserved		314
	PID	40.01 Process PID output actual (output of the process PID controller).	15
	Minimum torque 2	30.23 Minimum torque 2.	16
	Other	Source selection (see Terms and abbreviations on page 161).	-
30.22	Max torque 2 source	 Defines the source of the maximum torque limit for the drive (in percent of nominal motor torque) when the source selected by parameter 30.18 Torq lim sel is 1, or 30.18 is set to Torque limit set 2. See diagram at 30.18 Torq lim sel. Note: Any negative values received from the selected source are inverted. 	Maximum torque 2
	Zero	None.	0
	Al1 scaled	12.12 Al1 scaled value (see page 189).	1
	Al2 scaled	12.22 Al2 scaled value (see page 190).	2
	Reserved		314
	PID	40.01 Process PID output actual (output of the process PID controller).	15
	Maximum torque 2	30.24 Maximum torque 2.	16
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
30.23	Minimum torque 2	 Defines the minimum torque limit for the drive (in percent of nominal motor torque) when the source selected by 30.18 Torq lim sel is 1, or 30.18 is set to Torque limit set 2 and 30.21 Min torque 2 source is set to Minimum torque 2. See diagram at 30.18 Torq lim sel. 	-300.0%
	-1600.00.0%	Minimum torque limit 2.	See par. 46.03

No.	Name/Value	Description	Def/FbEq16
30.24	Maximum torque 2	Defines the maximum torque limit for the drive (in percent of nominal motor torque) when The limit is effective when • the source selected by <i>30.18 Torq lim sel</i> is 1, or • <i>30.18</i> is set to <i>Torque limit set 2</i> and	300.0%
		• 30.22 Max torque 2 source is set to Maximum torque 2. See diagram at 30.18 Torq lim sel.	
	0.01600.0%	Maximum torque limit 2.	See par. 46.03
30.26	Power motoring limit	Defines the maximum allowed power fed by the inverter to the motor in percent of nominal motor power.	300.00%
	0.00600.00%	Maximum motoring power.	1 = 1%
30.27	Power generating limit	Defines the maximum allowed power fed by the motor to the inverter in percent of nominal motor power. Note: If your application, like a pump or a fan, requires that the motor must rotate in one direction only, use speed/ frequency limit (30.11 <i>Minimum speed/30.13 Minimum frequency</i>), or direction limit (20.21 Direction) to achieve this. Do not set parameter 30.19 <i>Minimum torque</i> 1 or 30.27 <i>Power generating limit</i> to 0%, as the drive is then not able to stop correctly.	-300.00%
	-600.000.00%	Maximum generating power.	1 = 1%
30.30	Overvoltage control	Enables the overvoltage control of the intermediate DC link. Fast braking of a high inertia load causes the voltage to rise to the overvoltage control limit. To prevent the DC voltage from exceeding the limit, the overvoltage controller automatically decreases the braking torque. Note: If the drive is equipped with a brake chopper and resistor, or a regenerative supply unit, the controller must be disabled.	Enable
	Disable	Overvoltage control disabled.	0
	Enable	Overvoltage control enabled.	1
30.31	Undervoltage control	Enables the undervoltage control of the intermediate DC link. If the DC voltage drops due to input power cut off, the undervoltage controller will automatically decrease the motor torque in order to keep the voltage above the lower limit. By decreasing the motor torque, the inertia of the load will cause regeneration back to the drive, keeping the DC link charged and preventing an undervoltage trip until the motor coasts to a stop. This will act as a power-loss ride-through functionality in systems with high inertia, such as a centrifuge or a fan.	Enable
	Disable	Undervoltage control disabled.	0
	Enable	Undervoltage control enabled.	1
30.35	Thermal current limitation	Enables/disables temperature-based output current limitation. The limitation should only be disabled if required by the application.	Enable
	Disable	Thermal current limitation disabled.	0
	Enable	Thermal current limitation enabled.	1

No.	Name/Value	Description	Def/FbEq16
30.36	Speed limit selection	Selects a source that switches between two different predefined adjustable speed limit sets. 0 = minimum speed limit defined by 30.11 and maximum speed limit defined by 30.12 are active 1 = minimum speed limit selected by 30.37 and maximum speed limit defined by 30.38 are active. The user can define two sets of speed limits, and switch between the sets using a binary source such as a digital input. The user can define two sets of speed limits, and switch between the sets using a binary source such as a digital input. The first set of limits is defined by parameters 30.11 Minimum speed and 30.12 Maximum speed. The second set has selector parameters for both the minimum (30.37) and maximum (30.38) limits that allows the use of a selectable analog source (such as an analog input).	Not selected
		0 Al1 Al2 Minimum speed Other 30.37 1 0 User-defined minimum speed limit	
		30.38 Al1 Al2 Maximum speed Other 30.12 User-defined maximum speed limit	
	Not selected	Adjustable speed limits are disabled. (Minimum speed limit defined by <i>30.11 Minimum speed</i> and maximum speed limit defined by <i>30.12 Maximum speed</i> are active).	0
	Selected	Adjustable speed limits are enabled. (Minimum speed limit defined by 30.37 Min speed source source and maximum speed limit defined by 30.38 Max speed source are active).	1
	Ext1 active	Adjustable speed limits are enabled if EXT1 is active.	2
	Ext2 active	Adjustable speed limits are enabled if EXT2 is active.	3
	Torque control	Adjustable speed limits are enabled if Torque control mode (vector motor control) is active.	4
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	5
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	6
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	7
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	8
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	9

No.	Name/Value	Description		
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	10	
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-	
30.37	Min speed source	Defines the source of a minimum speed limit for the drive when the source is selected by 30.36 Speed limit selection. WARNING! In vector motor control mode only. In scalar motor control mode, use frequency limits 30.13 and 30.14.	Minimum speed	
	Zero	None.	0	
	Al1 scaled	12.12 Al1 scaled value.	1	
	Al2 scaled	12.22 AI2 scaled value.	2	
	Minimum speed	30.11 Minimum speed.	11	
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-	
30.38	Max speed source		Minimum speed	
	Zero	None.	0	
	Al1 scaled	12.12 Al1 scaled value.	1	
	Al2 scaled	12.22 AI2 scaled value.	2	
	Maximum speed	30.12 Maximum speed.	12	
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-	
31 Fau	It functions	Configuration of external events; selection of behavior of the drive upon fault situations.		
31.01	External event 1 source	Defines the source of external event 1. See also parameter <i>31.02 External event 1 type</i> . 0 = Trigger event 1 = Normal operation	Inactive (true)	
	Active (false)	0.	0	
	Inactive (true)	1.	1	
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3	
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4	
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5	
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6	
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7	
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-	
31.02	External event 1 type	Selects the type of external event 1.	Fault	
	Fault	The external event generates a fault.	0	
	Warning	The external event generates a warning.	1	
31.03	External event 2 source	Defines the source of external event 2. See also parameter 31.04 External event 2 type. For the selections, see parameter 31.01 External event 1 source.	Inactive (true)	
31.04	External event 2 type	Selects the type of external event 2.	Fault	
	Fault	The external event generates a fault.	0	

No.	Name/Value	Description	Def/FbEq16
	Warning	The external event generates a warning.	1
31.05	5 External event 3 source Defines the source of external event 3. See also parameter 31.06 External event 3 type. For the selections, see parameter 31.01 External event 1 source.		Inactive (true)
31.06	External event 3 type	Selects the type of external event 3.	Fault
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
31.07	External event 4 source	Defines the source of external event 4. See also parameter 31.08 External event 4 type. For the selections, see parameter 31.01 External event 1 source.	Inactive (true)
31.08	External event 4 type	Selects the type of external event 4.	Fault
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
31.09	External event 5 source	Defines the source of external event 5. See also parameter 31.10 External event 5 type. For the selections, see parameter 31.01 External event 1 source.	Inactive (true)
31.10	External event 5 type	Selects the type of external event 5.	Fault
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
31.11	Fault reset selection	 Selects the source of an external fault reset signal. The signal resets the drive after a fault trip if the cause of the fault no longer exists. 0 → 1 = Reset Notes: When the start stop signal is through DIs (parameter 20.01 or 20.06) or from local control mode and the user wants a fault reset through the fieldbus, selecton FBAA and EFB MCW bit 7 can be used. Whenever the remote control mode is in fieldbus (Start stop command and reference is through fieldbus), the fault can be reset from the fieldbus regardless of the selection of the parameter. 	Not used
	Not used	Not used.	0
	Not used	Not used.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 280).	18
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 280).	19

No.	Name/V	alue	Description	Def/FbEq16		
	Timed fu	unction 3	Bit 2 of 34.01 Timed functions status (see page 280).	20		
	Supervis	sion 1	Bit 0 of 32.01 Supervision status (see page 273).	24		
	Supervision 2		Bit 1 of 32.01 Supervision status (see page 273).	25		
	Supervis	sion 3	Bit 2 of 32.01 Supervision status (see page 273).	26		
	FBAAN	1CW bit 7	Control word bit 7 received through fieldbus interface A.	30		
	EFB MC	-	Control word bit 7 received through the embedded	32		
			fieldbus interface.	52		
	Other [b	it]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-		
31.12 Autoreset se		et selection	Selects faults that are automatically reset. The parameter is a 16-bit word with each bit corresponding to a fault type. Whenever a bit is set to 1, the corresponding fault is automatically reset. MARNING! Before you activate the function, make sure that no dangerous situations can occur. The function restarts the drive automatically and continues operation after a fault. The bits of this binary number correspond to the following faults:	0x0000		
	Bit	Fault				
	0	Overcurren	t			
	1	Overvoltage	9			
	2	Undervoltad				
	3	Al supervis	on fault			
	4	Reserved				
	5	OverFRequ	•			
	6	EarthFault				
	7	Shortcicrcu				
	89	Reserved				
	10	Selectable	ole fault (see parameter 31.13 Selectable fault)			
	11		It 1 (from source selected by parameter 31.01 External event 1	-		
	12		It 2 (from source selected by parameter 31.03 External event 2	,		
	13		ult 3 (from source selected by parameter 31.05 External event 3	,		
	14		ult 4 (from source selected by parameter 31.07 External event 4	,		
	15	External fau	ult 5 (from source selected by parameter 31.09 External event 5	source)		
	0x0000.	0xffff	Automatic reset configuration word.	1 = 1		
31.13	Selectal	ble fault	Defines the fault that can be automatically reset using parameter <i>31.12 Autoreset selection</i> , bit 10. Faults are listed in chapter <i>Fault tracing</i> (page <i>427</i>).	0x0000		
	0x00000xffff		Fault code.	10 = 1		
31.14	Number	of trials	Defines the maximum number of automatic resets that the drive is allowed to attempt within the time defined by parameter <i>31.15 Total trials time</i> . If the fault persists, subsequent reset attempts will be made at intervals defined by <i>31.16 Delay time</i> . The faults to be automatically reset are defined by <i>31.12</i> Autoreset selection.	0		
	05		Number of automatic resets.	10 = 1		

No.	Name/Value	Description	Def/FbEq16
31.15	Total trials time	Defines a time window for automatic fault resets. The maximum number of attempts made during any period of this length is defined by 31.14 Number of trials. Note: If the fault condition remains and cannot be reset, each reset attempt will generate an event and start a new time window. In practice, if the specified number of resets (31.14) at specified intervals (31.16) take longer than the value of 31.15, the drive will continue to attempt resetting the fault until the cause is eventually removed.	30.0 s
	1.0600.0 s	Time for automatic resets.	10 = 1 s
31.16	Delay time	Defines the time that the drive will wait after a fault before attempting an automatic reset. See parameter 31.12 <i>Autoreset selection</i> .	0.0 s
	0.0120.0 s	Autoreset delay.	10 = 1 s
31.19	Motor phase loss	Selects how the drive reacts when a motor phase loss is detected.	Fault
	No action	No action taken.	0
	Fault	The drive trips on fault 3381 Output phase loss.	1
31.21	Supply phase loss	Selects how the drive reacts when a supply phase loss is detected.	Fault
	No action	No action taken.The output current is limited to 50% when supply phase loss is detected. No fault or warning is given.	0
	Fault	Drive trips on fault 3130 Input phase loss.	1
31.20	Earth fault	Selects how the drive reacts when an earth (ground) fault or current unbalance is detected in the motor or the motor cable.	Fault
	No action	No action taken.	0
	Warning	The drive generates an A2B3 Earth leakage warning.	1
	Fault	The drive trips on fault.2330 Earth leakage. If the earth fault is detected while brake chopper is enabled, the drive trips on fault 7191 BC short circuit instead of 2330 Earth leakage.	2

No.	Name/Value	Descri	iption			Def/FbEq16
31.22	STO indication run/stop	torque indicat stoppe The tal genera Notes: • This func- the s rem both • The as if	off (ST ions al: d when bles at ated wite s paran ction its setting oval of n STO : loss o t is inte ore info	n indications are given w O) signals are switched so depend on whether the n this occurs. each selection below she the the particular setting. Inter does not affect the refer does not affect the set of this parameter: a runrione or both STO signal signals are restored and f only one STO signal allow rpreted as a malfunction rmation on the STO, see ction in the Hardware m	off or lost. The ne drive is running or now the indications operation of the STO ill operate regardless of ning drive will stop upon s, and will not start until all faults reset. ways generates a fault e chapter <i>The Safe</i>	Fault/Fault
	Fault/Fault	loique	on run		andar of the drive.	0
		Inp	uts			-
		IN1	IN2	Indication (runn	ing or stopped)	
		0	0		afe torque off	
		0	1	FA81 Safe	fe torque off and torque off 1	
		1	0	FA82 Safe	fe torque off and torque off 2	
		1	1	(Normal o	operation)	
	Fault/Warning	Inn		India	ation	1
		IN1	uts IN2	Running	Stopped	
		0	0	Fault 5091 Safe torque	Warning A5A0 Safe torque off	
		0	1	Faults 5091 Safe torque off and FA81 Safe torque off 1	Warning <i>A5A0 Safe</i> torque off and fault <i>FA81 Safe torque off 1</i>	
		1	0	Faults 5091 Safe torque off and FA82 Safe torque off 2	Warning A5A0 Safe torque off and fault FA82 Safe torque off 2	
		1	1	(Normal o	operation)	
	Fault/Event					2
			uts		ation	
		IN1	IN2	Running	Stopped	
		0	0	Fault 5091 Safe torque off	Event B5A0 Safe torque off	
		0	1	Faults 5091 Safe torque off and FA81 Safe torque off 1	Event <i>B5A0 Safe</i> torque off and fault <i>FA81 Safe torque off 1</i>	
		1	0	Faults 5091 Safe torque off and FA82 Safe torque off 2	Event <i>B5A0 Safe</i> torque off and fault <i>FA82 Safe torque off 2</i>	
		1	1	(Normal o	operation)	
				•		

No.	Name/Value	Descri	iption		Def/FbEq16
	Warning/Warning				3
		Inputs		Indication (running or stopped)	
		IN1	IN2	,	
		0	0	Warning A5A0 Safe torque off	
		0	1	Warning A5A0 Safe torque off and fault FA81 Safe torque off 1	
		1	0	Warning A5A0 Safe torque off and fault FA82 Safe torque off 2	
		1	1	(Normal operation)	
	Event/Event				4
		Inp IN1	uts IN2	Indication (running or stopped)	
		0	0	Event B5A0 STO event	
		0	1	Event <i>B5A0 STO event</i> and fault <i>FA81</i> Safe torque off 1	
		1	0	Event B5A0 STO event and fault FA82	
			-	Safe torque off 2	
		1	1	(Normal operation)	
	No indication/No				5
	indication	Inp	outs	Indication (running or stopped)	
		IN1	IN2	Indication (running of stopped)	
		0	0	None	
		0	1	Fault FA81 Safe torque off 1	
		1	0	Fault FA82 Safe torque off 2	
		1	1	(Normal operation)	
31.23	Wiring or earth fault	motor	cable c	he drive reacts to incorrect input power and onnection (ie. input power cable is connected to onnection).	Fault
	No action	No act	ion tak	en.	0
	Fault	The dr	ive trip	s on fault 3181 Wiring or earth fault.	1
31.24	Stall function	A stall • The <i>limit</i> • the 31.2 leve • the	condition drive e t), and output 27 Stall el set by condition	he drive reacts to a stall condition. on is defined as follows: exceeds the stall current limit (<i>31.25 Stall current</i> frequency is below the level set by parameter <i>frequency limit</i> or the motor speed is below the y parameter <i>31.26 Stall speed limit</i> , and ons above have been true longer than the time ameter <i>31.28 Stall time</i> .	No action
	No action	None (stall su	pervision disabled).	0
	Warning			nerates an A780 Motor stall (Programmable 24 Stall function) warning.	1
	Fault	The dr	ive trip	s on fault 7121 Motor stall.	2
31.25	Stall current limit			imit in percent of the nominal current of the arameter 31.24 Stall function.	200.0%
	0.01600.0%	Stall ci	urrent li	imit.	-

No.	Name/Value	Description	Def/FbEq16
31.26	Stall speed limit	Stall speed limit in rpm. See parameter 31.24 Stall function.	150.00 rpm
	0.0010000.00 rpm	Stall speed limit.	See par. 46.01
31.27	Stall frequency limit	Stall frequency limit. See parameter <i>31.24 Stall function</i> . Note: Setting the limit below 10 Hz is not recommended.	15.00 Hz
	0.001000.00 Hz	Stall frequency limit.	See par. 46.02
31.28	Stall time	Stall time. See parameter 31.24 Stall function.	20 s
	03600 s	Stall time.	-
31.30	Overspeed trip margin	Defines, together with 30.11 Minimum speed and 30.12 Maximum speed, the maximum allowed speed of the motor (overspeed protection). If the speed (24.02 Used speed feedback) feedback exceeds the speed limit defined by parameter 30.11 or 30.12 by more than the value of this parameter, the drive trips on the 7310 Overspeed fault. WARNING! This function only supervises the speed in vector motor control mode. The function is not effective in scalar motor control mode. Example: If the maximum speed is 1420 rpm and speed trip margin is 300 rpm, the drive trips at 1720 rpm. Speed feedback (24.02)	500.00 rpm
	0.0010000.00 rpm	Overspeed trip margin.	See par. <u>46.01</u>

No.	Name/Value	Description	Def/FbEq16
31.31 Frequency trip margin		Defines, together with 30.13 Minimum frequency and 30.14 Maximum frequency, the maximum allowed frequency of the motor. If the speed (28.01 Frequency ref ramp input) exceeds the frequency limit defined by parameter 30.13 or 30.14 by more than the value of this parameter, the drive trips on the 73F0 Overfrequency fault. WARNING! This function only supervises the speed in scalar motor control mode. The function is not effective in vector motor control mode. Example: If the maximum speed is 40 Hz and speed trip margin is 10 Hz, the drive trips at 50 Hz. Frequency (25.02)	15.00 Hz
	0.0010000.00 Hz	Overfrequency trip margin.	See par. 46.02
31.36	Aux fan fault function	Selects how the drive reacts when an auxiliary fan problem is detected. Certain drive types (especially those protected to IP55) have an auxiliary fan built into the front cover as standard. If it is necessary to operate the drive without the front cover (for example, during commissioning), you can set the parameter to value No action within two minutes from power-up to temporarily suppress the fault or warning. Return the value to Fault or Warning afterwards. This parameter is applicable only for frames R3 or larger. On frame sizes R3R5, the auxiliary fan is attached to connector X10 and on frame sizes R6 and larger to connector X16.	Warning
	Fault	The drive trips on fault 5081 Auxiliary fan broken. The fault is suppressed for two minutes after power-up.	0
	Warning	The drive generates a warning <i>A582 Auxiliary fan missing</i> . The warning is suppressed for two minutes after power-up.	1
	No action	No action taken	2

No.	Name/V	alue	Description		Def/FbEq16
31.40	31.40 Disable warning messages		a 16-bit word w	rnings to be suppressed. This parameter is vith each bit corresponding to a warning. t is set to 1, the corresponding warning is	0000h
	Bit	Name		Description	
	0	Reserved		•	
	1	DC link und	lervoltage	1 = Warning A3A2 DC link undervoltage is s	uppressed.
	24	Reserved	0		
	5	Emergency	stop (off2)	1 = Warning AFE1 Emergency stop (off2) is	suppressed.
	6	Emergency	stop (off1or off3		
	715	Reserved			
	0000h	FFFFh	Word for disab	ling warnings.	1 = 1
32 Sup	pervision	1	Six values can is generated w	of signal supervision functions 16. be chosen to be monitored; a warning or fault thenever predefined limits are exceeded. on <i>Signal supervision</i> (page <i>93</i>).	
32.01 Supervision status		sion status	Signal supervision status word. Indicates whether the values monitored by the signal supervision functions are within or outside their respective limits. Note: This word is independent of the drive actions defined by parameters 32.06, 32.16, 32.26, 32.36, 32.46 and 32.56.		06000
	Bit	Name		Description	
	0	Supervisior	1 active	1 = Signal selected by 32.07 is outside its limits	6.
	1	Supervision	1 2 active	1 = Signal selected by 32.17 is outside its limits.	
	2	Supervisior	1 3 active	1 = Signal selected by 32.27 is outside its limits	s.
	3	Supervision	1 4 active	1 = Signal selected by 32.37 is outside its limits	6.
	4	Supervisior	1 5 active	1 = Signal selected by 32.47 is outside its limits	5.
	5	Supervisior	16 active	1 = Signal selected by 32.27 is outside its limits	5.
	615	Reserved			
	0b0000.	0b1111	Signal supervi	sion status word.	1 = 1
32.05	32.05 Supervision 1 function		how the monitor to its low and h	de of signal supervision function 1. Determines ored signal (see parameter 32.07) is compared high limits (32.09 and 32.10 respectively). The ken when the condition is fulfilled is selected by	Disabled
	Disabled		Signal supervi	sion 1 not in use.	0
	Low		limit - 0.5 * hys	whenever signal is below 'Supervision low' steresis. Action is deactivated whenever signal rvision low' limit + 0.5 * hysteresis.	1
	High		limit + 0.5 * hy	whenever signal is above 'Supervision High' steresis. Action is deactivated whenever signal rvision High' limit - 0.5 * hysteresis.	2

No.	Name/Value	Description	Def/FbEq16
	Abs low	Action is taken whenever absolute value of signal is below absolute value of 'Supervision Low' limit - 0.5 * hysteresis. Action is deactivated whenever absolute value of signal is above absolute value of 'Supervision Low' limit + 0.5 * hysteresis.	3
	Abs high	Action is taken whenever absolute value of signal is above absolute value of 'Supervision High' limit + 0.5 * hysteresis. Action is deactivated whenever absolute value of signal is below absolute value of 'Supervision High' limit - 0.5 * hysteresis.	4
	Both	Action is taken whenever signal is above 'Supervision High' limit + 0.5 * hysteresis or below 'Supervision Low' limit - 0.5*hysteresis. Action is deactivated whenever signal is in between 'Supervision High' limit - 0.5 * hysteresis and 'Supervision Low' limit + 0.5*hysteresis.	5
	Abs both	Action is taken whenever absolute value of signal is above absolute value of 'Supervision High' limit + 0.5 * hysteresis or below absolute value of 'Supervision Low' limit - 0.5*hysteresis. Action is deactivated whenever absolute value of signal is in between absolute value of 'Supervision High' limit - 0.5 * hysteresis and absolute value of 'Supervision Low' limit + 0.5*hysteresis.	6
	Hysteresis	Action is taken whenever signal is above 'Supervision High' limit + 0.5 * hysteresis. Action is deactivated whenever signal is below 'Supervision Low' limit - 0.5 * hysteresis. The status is unchanged when signal value is in between 'Supervision High' limit + 0.5 * hysteresis and 'Supervision Low' limit - 0.5 * hysteresis.	7
	Low falling	Action taken whenever the signal falls from a value higher than 'Supervision low' limit + 0.5 * hysteresis to a value which is lower than 'Supervision low' limit - 0.5 * hysteresis. Action is deactivated when the signal rises to higher than 'Supervision low' limit + 0.5*hysteresis.	8
	High rising	Action taken whenever the signal rises from a value lower than 'Supervision high' limit - 0.5 * hysteresis to a value which is higher than 'Supervision high' limit + 0.5 * hysteresis. Action is deactivated when the signal falls to lower than 'Supervision high' limit - 0.5*hysteresis.	9
32.06	Supervision 1 action	Selects whether the drive generates a fault, warning or neither when the value monitored by signal supervision 1 exceeds its limits. Note: This parameter does not affect the status indicated by 32.01 Supervision status.	No action
	No action	No warning or fault generated.	0
	Warning	Warning A8B0 Signal supervision 1 is generated.	1
	Fault	Drive trips on fault 80B0 Signal supervision 1.	2
	Fault if running	If running, the drive trips on fault 80B0 Signal supervision 1.	3
32.07	Supervision 1 signal	Selects the signal to be monitored by signal supervision function 1.	Frequency
	Zero	None.	0
	Speed	01.01 Motor speed used (page 164).	1
	Frequency	01.06 Output frequency (page 164).	3
	Current	01.07 Motor current (page 164).	4

No.	Name/Value	Description	Def/FbEq16
	Torque	01.10 Motor torque (page 164).	6
	DC voltage	01.11 DC voltage (page 164).	7
	Output power	01.14 Output power (page 165).	8
	Al1	12.11 Al1 actual value (page 188).	9
	Al2	12.21 AI2 actual value (page 190).	10
	Inverter temperature	05.11 Inverter temperature (page 169).	23
	Process PID output	40.01 Process PID output actual (page 302).	24
	Process PID feedback	40.02 Process PID feedback actual (page 302).	25
	Process PID setpoint	40.03 Process PID setpoint actual (page 302).	26
	Process PID deviation	40.04 Process PID deviation actual (page 302).	27
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
32.08	Supervision 1 filter time	Defines a filter time constant for the signal monitored by signal supervision 1.	0.000 s
	0.000 30.000 s	Signal filter time.	1000 = 1 s
32.09	Supervision 1 low	Defines the lower limit for signal supervision 1.	0.00
	-21474836.00 21474836.00	Low limit.	-
32.10	Supervision 1 high	Defines the high limit for signal supervision 1.	0.00
	-21474836.00 21474836.00	High limit.	-
32.11	Supervision 1 hysteresis	Defines the hysteresis for the signal monitored by signal supervision 1.	0.00
	0.00100000.00	Hysteresis.	-
32.15	Supervision 2 function	Selects the mode of signal supervision function 2. Determines how the monitored signal (see parameter 32.17) is compared to its low and high limits (32.19 and 32.20 respectively). The action to be taken when the condition is fulfilled is selected by 32.16.	Disabled
	Disabled	Signal supervision 2 not in use.	0
	Low	Action is taken whenever the signal falls below its low limit.	1
	High	Action is taken whenever the signal rises above its high limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) high limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6

No.	Name/Value	Description	Def/FbEq16
	Hysteresis	Action is taken whenever the signal rises above the value defined by the high limit + 0.5 hysteresis. The action is deactivated when the signal falls below the value defined by the low limit - 0.5 hysteresis.	7
32.16	Supervision 2 action	Selects whether the drive generates a fault, warning or neither when the value monitored by signal supervision 2 exceeds its limits. Note: This parameter does not affect the status indicated by 32.01 Supervision status.	No action
	No action	No warning or fault generated.	0
	Warning	Warning A8B1 Signal supervision 2 is generated.	1
	Fault	Drive trips on fault 80B1 Signal supervision 2.	2
	Fault if running	If running, the drive trips on fault 80B0 Signal supervision 1.	3
32.17	Supervision 2 signal	Selects the signal to be monitored by signal supervision function 2. For the available selections, see parameter 32.07 <i>Supervision 1 signal</i> .	Current
32.18	Supervision 2 filter time	Defines a filter time constant for the signal monitored by signal supervision 2.	0.000 s
	0.000 30.000 s	Signal filter time.	1000 = 1 s
32.19	Supervision 2 low	Defines the low limit for signal supervision 2.	0.00
	-21474836.00 21474836.00	Low limit.	-
32.20	Supervision 2 high	Defines the high limit for signal supervision 2.	0.00
	-21474836.00 21474836.00	High limit.	-
32.21	Supervision 2 hysteresis	Defines the hysteresis for the signal monitored by signal supervision 2.	0.00
	0.00100000.00	Hysteresis.	-
32.25	Supervision 3 function	Selects the mode of signal supervision function 3. Determines how the monitored signal (see parameter 32.27) is compared to its low and high limits (32.29 and 32.30 respectively). The action to be taken when the condition is fulfilled is selected by 32.26.	Disabled
	Disabled	Signal supervision 3 not in use.	0
	Low	Action is taken whenever the signal falls below its low limit.	1
	High	Action is taken whenever the signal rises above its high limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) high limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
	Hysteresis	Action is taken whenever the signal falls below its (hysteresis) low limit or rises above its (hysteresis) high limit.	7

No.	Name/Value	Description	Def/FbEq16
32.26	Supervision 3 action	Selects whether the drive generates a fault, warning or neither when the value monitored by signal supervision 3 exceeds its limits. Note: This parameter does not affect the status indicated by 32.01 Supervision status.	
	No action	No warning or fault generated.	0
	Warning	Warning A8B2 Signal supervision 3 is generated.	1
	Fault	Drive trips on fault 80B2 Signal supervision 3.	2
	Fault if running	If running, the drive trips on fault 80B0 Signal supervision 1.	3
32.27	Supervision 3 signal	Selects the signal to be monitored by signal supervision function 3. For the available selections, see parameter 32.07 <i>Supervision 1 signal.</i>	Torque
32.28	Supervision 3 filter time	Defines a filter time constant for the signal monitored by signal supervision 3.	0.000 s
	0.000 30.000 s	Signal filter time.	1000 = 1 s
	Supervision 3 low Defines the low limit for signal supervision 3.		0.00
	-21474836.00 21474836.00	Low limit.	-
32.30	Supervision 3 high	Defines the high limit for signal supervision 3.	0.00
	-21474836.00 21474836.00	High limit.	-
32.31	Supervision 3 hysteresis	Defines the hysteresis for the signal monitored by signal supervision 3.	0.00
	0.00100000.00	Hysteresis.	-
32.35	Supervision 4 function	Selects the mode of signal supervision function 4. Determines how the monitored signal (see parameter 32.37) is compared to its low and high limits (32.39 and 32.30 respectively). The action to be taken when the condition is fulfilled is selected by 32.36.	Disabled
	Disabled	Signal supervision 4 not in use.	0
	Low	Action is taken whenever the signal falls below its low limit.	1
	High	Action is taken whenever the signal rises above its high limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) high limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
	Hysteresis	Action is taken whenever the signal falls below its (hysteresis) low limit or rises above its (hysteresis) high limit.	7

No.	Name/Value	Description	Def/FbEq16	
32.36	Supervision 4 action	Selects whether the drive generates a fault, warning or neither when the value monitored by signal supervision 4 exceeds its limits. Note: This parameter does not affect the status indicated by <i>32.01 Supervision status</i> .	No action	
	No action	No warning or fault generated.	0	
	Warning	Warning A8B3 Signal supervision 4 is generated.	1	
	Fault	Drive trips on fault 80B3 Signal supervision 4.	2	
	Fault if running	Drive trips on fault 80B0 Signal supervision 1 if the motor is running.	3	
32.37	Supervision 4 signal	Selects the signal to be monitored by signal supervision function 4. For the available selections, see parameter 32.07 Supervision 1 signal.	Zero	
32.38	Supervision 4 filter time	Defines a filter time constant for the signal monitored by signal supervision 4.	0.000 s	
	0.000 30.000 s	Signal filter time.	1000 = 1 s	
32.39	Supervision 4 low	Defines the low limit for signal supervision 4.	0.00	
	-21474836.00 21474836.00	Low limit.	-	
32.40	Supervision 4 high	high Defines the high limit for signal supervision 4.		
	-21474836.00 21474836.00	High limit.	-	
32.41	Supervision 4 hysteresis	Defines the hysteresis for the signal monitored by signal supervision 4.	0.00	
	0.00100000.00	Hysteresis.	-	
32.45	Supervision 5 function	Selects the mode of signal supervision function 5. Determines how the monitored signal (see parameter 32.47) is compared to its low and high limits (32.49 and 32.40 respectively). The action to be taken when the condition is fulfilled is selected by 32.46.	Disabled	
	Disabled	Signal supervision 5 not in use.	0	
	Low	Action is taken whenever the signal falls below its low limit.	1	
	High	Action is taken whenever the signal rises above its high limit.	2	
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit.	3	
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) high limit.	4	
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5	
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6	
	Hysteresis	Action is taken whenever the signal falls below its (hysteresis) low limit or rises above its (hysteresis) high limit.	7	

No.	Name/Value	Description	Def/FbEq16
32.46	Supervision 5 action	Selects whether the drive generates a fault, warning or neither when the value monitored by signal supervision 5 exceeds its limits. Note: This parameter does not affect the status indicated by <i>32.01 Supervision status</i> .	No action
	No action	No warning or fault generated.	0
	Warning	Warning A8B4 Signal supervision 5 is generated.	1
	Fault	Drive trips on fault 80B4 Signal supervision 5.	2
	Fault if running	Drive trips on fault <i>80B0 Signal supervision 1</i> if the motor is running.	3
32.47	Supervision 5 signal	Selects the signal to be monitored by signal supervision function 5. For the available selections, see parameter 32.07 <i>Supervision 1 signal</i> .	Zero
32.48	Supervision 5 filter time	Defines a filter time constant for the signal monitored by signal supervision 5.	0.000 s
	0.000 30.000 s	Signal filter time.	1000 = 1 s
32.49	Supervision 5 low	Defines the low limit for signal supervision 5.	0.00
	-21474836.00 21474836.00	Low limit.	-
32.50	Supervision 5 high	Defines the high limit for signal supervision 5.	0.00
	-21474836.00 21474836.00	High limit.	-
32.51	Supervision 5 hysteresis	Defines the hysteresis for the signal monitored by signal supervision 5.	0.00
	0.00100000.00	Hysteresis.	-
32.55	Supervision 6 function	Selects the mode of signal supervision function 6. Determines how the monitored signal (see parameter 32.57) is compared to its low and high limits (32.59 and 32.50 respectively). The action to be taken when the condition is fulfilled is selected by 32.56.	Disabled
	Disabled	Signal supervision 6 not in use.	0
	Low	Action is taken whenever the signal falls below its low limit.	1
	High	Action is taken whenever the signal rises above its high limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) high limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
	Hysteresis	Action is taken whenever the signal falls below its (hysteresis) low limit or rises above its (hysteresis) high limit.	7

No.	Name/Value	Description	Def/FbEq16
32.56	Supervision 6 action	Selects whether the drive generates a fault, warning or neither when the value monitored by signal supervision 6 exceeds its limits. Note: This parameter does not affect the status indicated by 32.01 Supervision status.	No action
	No action	No warning or fault generated.	0
	Warning	Warning A8B5 Signal supervision 6 is generated.	1
	Fault	Drive trips on fault 80B5 Signal supervision 6.	2
	Fault if running	Drive trips on fault <i>80B0 Signal supervision 1</i> if the motor is running.	3
32.57	Supervision 6 signal	Selects the signal to be monitored by signal supervision function 6. For the available selections, see parameter 32.07 <i>Supervision 1 signal.</i>	Zero
32.58	Supervision 6 filter time	Defines a filter time constant for the signal monitored by signal supervision 6.	0.000 s
	0.000 30.000 s	Signal filter time.	1000 = 1 s
32.59	Supervision 6 low	Defines the low limit for signal supervision 6.	0.00
	-21474836.00 21474836.00	Low limit.	-
32.60	Supervision 6 high	Defines the high limit for signal supervision 6.	0.00
	-21474836.00 21474836.00	High limit.	-
32.61	Supervision 6 hysteresis	Defines the hysteresis for the signal monitored by signal supervision 6.	0.00
	0.00100000.00	Hysteresis.	-
24 Tin	ned functions	Configuration of the timed functions	

34 Tin	34 Timed functions		Ŭ	of the timed functions. on <i>Motor control</i> (page 64).	
34.01	Timed functions status			combined timers. The status of a combined gical OR of all timers connected to it. rr is read-only.	060000
	Bit Name			Description	
	0	Timed func	tion 1	1 = Active.	
	1	Timed func	tion 2	1 = Active.	
	2	Timed func	tion 3	1 = Active.	
	315 Reserved			•	
	0b00000b1111		Status of comb	bined timers 13.	1 = 1

No.	Name/Value		Description		Def/FbEq16
34.02	Timer s	tatus	Status of time This paramete	rs 112. er is read-only.	0b0000
	Bit	Name		Description	
	0	Timer 1		1 = Active.	
	1	Timer 2		1 = Active.	
	2	Timer 3		1 = Active.	
	3	Timer 4		1 = Active.	
	4	Timer 5		1 = Active.	
	5	Timer 6		1 = Active.	
	6	Timer 7		1 = Active.	
	7	Timer 8		1 = Active.	
	8	Timer 9		1 = Active.	
	9	Timer 10		1 = Active.	
	10	Timer 11		1 = Active.	
	11	Timer 12		1 = Active.	
	1215	Reserved			
	J				
34.04	060000	0b1111	Timer status.		1 = 1
	Season/exception			sons 13, exception weekday and exception	0b0000
04.04	day status		holiday. Only o be a workday	and a holiday at the same time. er is read-only.	00000
	Bit	Name		Description	1
	0	Season 1		1 = Active.	
	0	Season 1 Season 2		1 = Active. 1 = Active.	
	0 1 2	Season 1 Season 2 Season 3		1 = Active. 1 = Active. 1 = Active.	
	0 1 2 3	Season 1 Season 2 Season 3 Season 4		1 = Active. 1 = Active.	·
	0 1 2 3 49	Season 1 Season 2 Season 3 Season 4 Reserved		1 = Active. 1 = Active. 1 = Active. 1 = Active.	
	0 1 2 3 49 10	Season 1 Season 2 Season 3 Season 4 Reserved Exception		1 = Active. 1 = Active. 1 = Active. 1 = Active. 1 = Active. 1 = Active.	
	0 1 2 3 49 10 11	Season 1 Season 2 Season 3 Season 4 Reserved Exception		1 = Active. 1 = Active. 1 = Active. 1 = Active.	
	0 1 2 3 49 10	Season 1 Season 2 Season 3 Season 4 Reserved Exception		1 = Active. 1 = Active. 1 = Active. 1 = Active. 1 = Active. 1 = Active.	
	0 1 2 3 49 10 11 1215	Season 1 Season 2 Season 3 Season 4 Reserved Exception	holiday	1 = Active. 1 = Active. 1 = Active. 1 = Active. 1 = Active. 1 = Active.	1 = 1
34.10	0 1 2 3 49 10 11 1215 0b0000 1111	Season 1 Season 2 Season 3 Season 4 Reserved Exception Reserved	Status of the s	1 = Active.	1 = 1 Disabled
34.10	0 1 2 3 49 10 11 1215 0b0000 1111 <i>Timed f</i>	Season 1 Season 2 Season 3 Season 4 Reserved Exception Reserved 0b11110b	Status of the s Selects the so 0 = Disabled.	1 = Active. seasons and exception weekday and holiday.	
34.10	0 1 2 3 49 10 11 1215 0b0000 1111 <i>Timed f</i> enable	Season 1 Season 2 Season 3 Season 4 Reserved Exception 1 Reserved 0b11110b 0b11110b 0b11110b	Status of the s Selects the so 0 = Disabled. 1 = Enabled.	1 = Active. seasons and exception weekday and holiday.	Disabled
34.10	0 1 2 3 49 10 11 1215 0b0000 1111 <i>Timed f</i> enable Disable	Season 1 Season 2 Season 3 Season 4 Reserved Exception 1 Reserved 0b11110b 0b11110b 0b11110b	Status of the s Selects the so 0 = Disabled. 1 = Enabled. 0. 1.	1 = Active. seasons and exception weekday and holiday.	Disabled 0
34.10	0 1 2 3 49 10 11 1215 0b0000 1111 <i>Timed f</i> <i>enable</i> Disable Enabled	Season 1 Season 2 Season 3 Season 4 Reserved Exception 1 Reserved 0b11110b 0b11110b 0b11110b	Status of the s Selects the so 0 = Disabled. 1 = Enabled. 0. 1. Digital input D	1 = Active. seasons and exception weekday and holiday. surce for the timed functions enable signal.	Disabled 0 1
34.10	0 1 2 3 49 10 11 1215 0b0000 1111 <i>Timed f</i> enable Disable Enablec DI1	Season 1 Season 2 Season 3 Season 4 Reserved Exception 1 Reserved 0b11110b 0b11110b 0b11110b	Status of the s Selects the so 0 = Disabled. 1 = Enabled. 0. 1. Digital input D Digital input D	1 = Active. seasons and exception weekday and holiday. burce for the timed functions enable signal. 11 (10.02 Dl delayed status, bit 0).	Disabled 0 1 2
34.10	0 1 2 3 49 10 11 1215 0b0000 111 1215 0b0000 1111 Timed f enable Enable DI1 DI2	Season 1 Season 2 Season 3 Season 4 Reserved Exception 1 Reserved 0b11110b 0b11110b 0b11110b	Status of the s Selects the so 0 = Disabled. 1 = Enabled. 0. 1. Digital input D Digital input D Digital input D	1 = Active. 1 = Active.	Disabled 0 1 2 3
34.10	0 1 2 3 49 10 11 1215 0b0000 1111 Timed f enable Enable Disable Enable DI1 DI2 DI3	Season 1 Season 2 Season 3 Season 4 Reserved Exception 1 Reserved 0b11110b 0b11110b 0b11110b	Status of the s Selects the so 0 = Disabled. 1 = Enabled. 0. 1. Digital input D Digital input D Digital input D Digital input D	1 = Active. seasons and exception weekday and holiday. outcols for the timed functions enable signal. 11 (10.02 DI delayed status, bit 0). 12 (10.02 DI delayed status, bit 1). 13 (10.02 DI delayed status, bit 2).	Disabled 0 1 2 3 4

No.	Name/Value		Description		Def/FbEq16	
	Other [b	it]	Source selection (see Terms and abbreviations on page 161).		-	
34.11	Timer 1 configur	ation	Defines when timer 1 is active.		0b0111	
	Bit	Name	De	escription		
	0	Monday	1 =	1 = Monday is an active start day.		
	1	Tuesday	1 =	1 = Tuesday is an active start day.		
	2	Wednesday	· 1 =	- Wednesday is an active start day.		
	3	Thursday	1 =	- Thursday is an active start day.		
	4	Friday Saturday Sunday Season 1		= Friday is an active start day.		
	5			- Saturday is an active start day.		
	6			- Sunday is an active start day.		
	7			- Timer is active in season 1.		
	8	Season 2		Timer is active in season 2.		
	9	Season 3		Timer is active in season 3.		
	10	Season 4		- Timer is active in season 4.		
	11	Exceptions		 0 = Exceptions days are disabled. 1 = Exception days are enabled. Bits 12 and 13 are taken into account. 0 = Timer is inactive on exception days configured as "Holiday". 1 = Timer is active on exception days configured as 		
	12 Holidays		"He			
				"Holiday".		
	13	Workdays		0 = Timer is inactive on exception days configured as "Workday".		
				 Timer is active on exception days configure /orkday". 	d as	
	1415	Reserved				
	0b0000.	0b1111	Configuration of ti	imer 1.	1 = 1	
34.12	Timer 1	start time	Defines the daily schanged in secon	start time of timer 1. The time can be d steps	00:00:00	
			The timer can be started at an other time than the start time. E.g. if the timer's duration is more than one day and the active session starts during the time, the timer is started at 00:00 and stopped when there is no duration left.			
	00:00:0023:59:59		Daily start time of the timer.		1 = 1	
34.13	Timer 1	duration	Defines the duration of timer 1. The duration can be changed in minute steps.		00 00:00	
			The duration can extend over the change of the day but if an exception day becomes active, the period is interrupted at midnight. In the same way the period started on an exception day stays active only until the end of the day, even if the duration is longer. The timer will continue after a break if there is duration left.			
	00:00	007 00:00	Timer duration.		1 = 1	
34.14	Timer 2 configur	ation	See 34.11 Timer	1 configuration.	0b0111	
34.15	Timer 2	start time	See 34.12 Timer	1 start time.	00:00:00	
		duration	See 34.13 Timer	1 duration	00 00:00	

No.	Name/Value	ne/Value Description		
34.17	Timer 3 configuration	See 34.11 Timer 1 configuration.	0b0111	
34.18	Timer 3 start time	See 34.12 Timer 1 start time.	00:00:00	
34.19	Timer 3 duration	See 34.13 Timer 1 duration.	00 00:00	
34.20	Timer 4 configuration	See 34.11 Timer 1 configuration.	0b0111	
34.21	Timer 4 start time	See 34.12 Timer 1 start time.	00:00:00	
34.22	Timer 4 duration	See 34.13 Timer 1 duration.	00 00:00	
34.23	Timer 5 configuration	See 34.11 Timer 1 configuration.	0b0111	
34.24	Timer 5 start time	See 34.12 Timer 1 start time.	00:00:00	
34.25	Timer 5 duration	See 34.13 Timer 1 duration.	00 00:00	
34.26	Timer 6 configuration	See 34.11 Timer 1 configuration.	0b0111	
34.27	Timer 6 start time	See 34.12 Timer 1 start time.	00:00:00	
34.28	Timer 6 duration	See 34.13 Timer 1 duration.	00 00:00	
34.29	Timer 7 configuration	See 34.11 Timer 1 configuration.	0b0111	
34.30	Timer 7 start time	See 34.12 Timer 1 start time.	00:00:00	
34.31	Timer 7 duration	See 34.13 Timer 1 duration.	00 00:00	
34.32	Timer 8 configuration	See 34.11 Timer 1 configuration.	0b0111	
34.33	Timer 8 start time	See 34.12 Timer 1 start time.	00:00:00	
34.34	Timer 8 duration	See 34.13 Timer 1 duration.	00 00:00	
34.35	Timer 9 configuration	See 34.11 Timer 1 configuration.	0b0111	
34.36	Timer 9 start time	See 34.12 Timer 1 start time.	00:00:00	
34.37	Timer 9 duration	See 34.13 Timer 1 duration.	00 00:00	
34.38	Timer 10 configuration	See 34.11 Timer 1 configuration.	0b0111	
34.39	Timer 10 start time	See 34.12 Timer 1 start time.	00:00:00	
34.40	Timer 10 duration	See 34.13 Timer 1 duration.	00:00	
34.41	Timer 11 configuration	See 34.11 Timer 1 configuration.	0b0111	
34.42	Timer 11 start time	See 34.12 Timer 1 start time.	00:00:00	
34.43	Timer 11 duration	See 34.13 Timer 1 duration.	00 00:00	
34.44	Timer 12 configuration	See 34.11 Timer 1 configuration.	0b0111	
34.45	Timer 12 start time	See 34.12 Timer 1 start time.	00:00:00	
34.46	Timer 12 duration	See 34.13 Timer 1 duration.	00 00:00	

No.	Name/\	/alue	Description		Def/FbEq16
34.60	.60 Season 1 start date		is the number of The season cha at a time. Timer are not inside the The season sta order to use all the season is m- in increasing or	rt date of season 1 in format dd.mm, where dd of the day and mm is the number of the month. anges at midnight. One season can be active rs are started on exception days even if they he active season. Int dates (14) must be given in increasing seasons. The default value is interpreted that ot configured. If the season start dates are not rder and the value is something else than the season configuration warning is given.	1.1
	-		Season start da	ate.	
34.61	Season	2 start date		rt date of season 2. <i>son 1 start date</i> .	1.1
34.62	Season	3 start date		rt date of season 3. <i>son 1 start date</i> .	1.1
34.63	Season	4 start date		rt date of season 4. <i>son 1 start date</i> .	1.1
34.70	Number of active exceptions		Defines how many of the exceptions are active by specifying the last active one. All preceding exceptions are active. Exceptions 13 are periods (duration can be defined) and exceptions 416 are days (duration is always 24 hours). Example: If the value is 4, exceptions 14 are active, and exceptions 516 are not active.		3
	016		Number of active exception periods or days.		-
34.71	Excepti	on types	Exceptions 1	es of exceptions 116 as workday or holiday. 3 are periods (duration can be defined) and 16 are days (duration is always 24 hours).	0b0000
	Bit	Name		Description	
	0	Exception 1		0 = Workday. 1 = Holiday	
	1	Exception 2		0 = Workday. 1 = Holiday	
	2	Exception 3		0 = Workday. 1 = Holiday	
	3	Exception 4		0 = Workday. 1 = Holiday	
	4	Exception 5	5	0 = Workday, 1 = Holiday	
	5	Exception 6		0 = Workday. 1 = Holiday	
	6			0 = Workday. 1 = Holiday	
	7	Exception 8	3	0 = Workday. 1 = Holiday	
	8	Exception 9	9	0 = Workday. 1 = Holiday	
	9	Exception 1	10	0 = Workday. 1 = Holiday	
	10	Exception 1	11 (0 = Workday. 1 = Holiday	
	11	Exception 1	12	0 = Workday. 1 = Holiday	
	12	Exception 1	13 (0 = Workday. 1 = Holiday	
	40	E (* 4			

1	=	1	

0b0000...0b1111 Types of except

Exception 14

Exception 15

Exception 16

13

14

15

Types of exception period or days.

0 = Workday. 1 = Holiday

0 = Workday. 1 = Holiday

0 = Workday. 1 = Holiday

No.	Name/Value	Description	Def/FbEq16
34.72	Exception 1 start	Defines the start date of the exception period in format dd.mm, where dd is the number of the day and mm is the number of the month. The timer started on an exception day is always stopped at 23:59:59 even if it has duration left. The same date can be configured to be holiday and workday. The date is active if any of exception days are active.	1.1
	-	Start date of exception period 1.	
34.73	Exception 1 length	Defines the length of the exception period in days. Exception period is handled the same as a number of consecutive exception days.	0 d
	060 d	Length of exception period 1.	1 = 1
34.74	Exception 2 start	See 34.72 Exception 1 start.	1.1
34.75	Exception 2 length	See 34.73 Exception 1 length.	0 d
34.76	Exception 3 start	See 34.72 Exception 1 start.	1.1
34.77	Exception 3 length	See 34.73 Exception 1 length.	0 d
34.78	Exception day 4	Defines the date of exception day 4.	1.1
	-	Start date of exception day 4. The timer started on an exception day is always stopped at 23:59:59 even if it has duration left.	
34.79	Exception day 5	See 34.79 Exception day 4.	1.1
34.80	Exception day 6	See 34.79 Exception day 4.	1.1
34.81	Exception day 7	See 34.79 Exception day 4	1.1
34.82	Exception day 8	See 34.79 Exception day 4.	1.1
34.83	Exception day 9	See 34.79 Exception day 4.	1.1
34.84	Exception day 10	See 34.79 Exception day 4.	1.1
34.85	Exception day 11	See 34.79 Exception day 4.	1.1
34.86	Exception day 12	See 34.79 Exception day 4.	1.1
34.87	Exception day 13	See 34.79 Exception day 4.	1.1
34.88	Exception day 14	See 34.79 Exception day 4.	1.1
34.89	Exception day 15	See 34.79 Exception day 4.	1.1
34.90	Exception day 16	See 34.79 Exception day 4.	1.1

No.	Name/\	/alue	Description		Def/FbEq16
34.100	Timed function 1		0 = Not connecte		060000
	Bit	Name		Description	
	0	Timer 1		0 = Inactive. 1 = Active.	
	1	Timer 2		0 = Inactive. 1 = Active.	
	2	Timer 3		0 = Inactive. 1 = Active.	
	3	Timer 4		0 = Inactive. 1 = Active.	
	4	Timer 5		0 = Inactive. 1 = Active.	
	5	Timer 6		0 = Inactive. 1 = Active.	
	6	Timer 7		0 = Inactive. 1 = Active.	
	7	Timer 8		0 = Inactive. 1 = Active.	
	8	Timer 9		0 = Inactive. 1 = Active.	
	9	Timer 10		0 = Inactive. 1 = Active.	
	10	Timer 11		0 = Inactive. 1 = Active.	
	11	Timer 12		0 = Inactive. 1 = Active.	
	1215	Reserved			
	0b0000	0b1111	Timers connected to combined timer 1.		1 = 1
4.101	Timed f	unction 2	Defines which timers are connected to combined timer 2. 0b0000 See 34.01 Timed functions status.		0b0000
4.102	Timed f	unction 3	Defines which timers are connected to combined timer 3. 0b0000 See 34.01 Timed functions status.		0b0000
4.110	Boost ti	me function		h combined timers (that is, timers that are the combined timers) are activated with the action.	060000
	Bit	Name		Description	
	0	Timed fund	tion 1	0 = Inactive. 1 = Active.	
	1	Timed fund	tion 2	0 = Inactive. 1 = Active.	
	2	Timed fund	tion 3	0 = Inactive. 1 = Active.	
	315	Reserved		-	
	0b0000	0b1111	Combined tin	ners including the extra timer.	1 = 1
4.111	Boost ti activatio	me on source	Selects the so 0 = Disabled. 1 = Enabled.	ource of extra time activation signal.	Off
	Off		0.		0
	On		1.		1
	DI1		Digital input [DI1 (10.02 DI delayed status, bit 0).	2
	DI2		Digital input [DI2 (10.02 DI delayed status, bit 1).	3
	DI3		Digital input	DI3 (10.02 DI delayed status, bit 2).	4
	DI4		Digital input	DI4 (10.02 DI delayed status, bit 3).	5
	DI5		Digital input I	DI5 (10.02 DI delayed status, bit 4).	6

No.	Name/Value	Description	Def/FbEq16
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
34.112	Boost time duration	Defines the time inside which the extra time is deactivated after extra time activation signal is switched off. Example: If parameter 34.111 Boost time activation source is set to DI1 and 34.112 Boost time duration is set to 00 01:30, the extra time is active for 1 hour and 30 minutes after digital input DI is deactivated.	00 00:00
	00 00:0007 00:00	Extra time duration.	1 = 1

35 Motor thermal protection		Motor thermal protection settings such as temperature measurement configuration, load curve definition and motor fan control configuration. See also section <i>Motor thermal protection</i> (page <i>81</i>).	
35.01 Motor estima temperature	Motor estimated temperature	Displays the motor temperature as estimated by the internal motor thermal protection model (see parameters <i>35.5035.55</i>). The unit is selected by parameter <i>96.16 Unit selection</i> . This parameter is read-only.	0
	-60…1000 °C or -76…1832 °F	Estimated motor temperature.	1 = 1°C
35.02	Measured temperature 1	Displays the temperature received through the source defined by parameter 35.11 Temperature 1 source. The unit is selected by parameter 96.16 Unit selection. This parameter is read-only.	0
	-605000 °C or -769032 °F, 05000 ohm or [35.12] ohm	Measured temperature 1. Note: With a PTC sensor, the unit is ohm. If the measured temperature source selection (35.11) is PTC analog I/O, the motor thermal protection function converts the analog input signal (35.14 to PTC resistance value (ohms), and shows it in this parameter. This is the case even the parameter name and unit refer to motor temperature (°C or °F). You cannot change the unit to ohm for the time being (96.16).	1 = 1 unit
35.03	Measured temperature 2	Displays the temperature received through the source defined by parameter 35.21 <i>Temperature 2 source</i> . The unit is selected by parameter 96.16 <i>Unit selection</i> .	0
	-605000 °C or -769032 °F, 05000 ohm or [35.22] ohm	Measured temperature 2. Note: With a PTC sensor, the unit is ohms. If the measured temperature source selection (35.21) is PTC analog I/O, the motor thermal protection function converts the analog input signal (35.24) to PTC resistance value (ohms), and shows it in this parameter. This is the case even the parameter name and unit refer to motor temperature (°C or °F). You cannot change the unit to ohm for the time being (96.16).	1 = 1 unit
35.05	Motor overload level	Shows the motor overload level as a percentage of the motor overload fault limit.See section <i>Motor overload protection</i> (page 87). This parameter is read-only.	0.0%

No.	Name/Value	Description	Def/FbEq16
	0.0300.0 %	Motor overload level. 0.0% No motor overloading. 88.0% Motor overloaded to warning level. 100.0% Motor overloaded to fault level.	10 = 1%
35.11	Temperature 1 source	Selects the source from which measured temperature 1 is read. Usually this source is from a sensor connected to the motor controlled by the drive, but it could be used to measure and monitor a temperature from other parts of the process as long as a suitable sensor is used as per the selection list.	Estimated temperature
	Disabled	None. Temperature monitoring function 1 is disabled.	0
	Estimated temperature	Estimated motor temperature (see parameter <i>35.01 Motor estimated temperature</i>). The temperature is estimated from an internal drive calculation. It is important to set up the ambient temperature of the motor in <i>35.50 Motor ambient temperature</i> .	1
	KTY84 analog I/O	 KTY84 sensor connected to the analog input selected by parameter 35.14 Temperature 1 AI source and an analog output. The following settings are required: Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 1 excitation. The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees. 	2
	Reserved		34
	1 × Pt100 analog I/O	 Pt100 sensor connected to a standard analog input selected by parameter 35.14 Temperature 1 AI source and an analog output. The following settings are required: Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 1 excitation. The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees. 	5
	2 × Pt100 analog I/O	As selection 1 × <i>Pt100 analog I/O</i> , but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	6

No.	Name/Value	Description	Def/FbEq16
	3 × Pt100 analog I/O	As selection 1 × <i>Pt100 analog I/O</i> , but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	7
	PTC DI6	PTC sensor is connected to DI6. Note: With a PTC sensor, the value shown is not a valid measurement. Either 0 ohm (normal temperature) or the value of parameter 35.13 Temperature 1 warning limit (excessive temperature) will be shown by 35.02 Measured temperature 1. If a user wants to trigger faults, set the value of parameter 35.12 Temperature 1 fault limit below or equal to the warning limit.	8
	Reserved		910
	Direct temperature	The temperature is taken from the source selected by parameter 35.14 Temperature 1 AI source. The value of the source is assumed to be in the unit of temperature specified by parameter 96.16 Unit selection.	11
	KTY83 analog I/O	 KTY83 sensor connected to the analog input selected by parameter 35.14 Temperature 1 AI source and an analog output. The following settings are required: Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 1 excitation. The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees. 	12
	1 × Pt1000 analog I/O	 Pt1000 sensor connected to a standard analog input selected by parameter 35.14 Temperature 1 AI source and an analog output. The following settings are required: Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 1 excitation. The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees. 	13
	2 × Pt1000 analog I/O	As selection 1 × <i>Pt1000 analog I/O</i> , but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	14
	3 × Pt1000 analog I/O	As selection 1 × <i>Pt1000 analog I/O</i> , but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	15

No.	Name/Value	Description	Def/FbEq16
	Ni1000	 Ni1000 sensor connected to the analog input selected by parameter 35.14 Temperature 1 AI source and an analog output. The following settings are required: Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 1 excitation. The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees. 	16
	Reserved		1718
	PTC extension module	Not applicable.	19
	PTC analog I/O	PTC sensor connected to the analog input selected by parameter 35.14 Temperature 1 AI source and an analog output. The required settings are the same as with selection KTY84 analog I/O. If a PTC sensor is used, the voltage ready by the analog input is converted into ohms Note: With this selection, the control program converts the analog signal to PTC resistance value in ohms and shows it in parameter 35.02. The parameter name and unit still refer to temperature.	20
	Therm(0)	PTC sensor or a normally closed thermistor connected relay to digital input DI6. The motor is overheated when the digital input is 0.	21
	Therm(1)	Normally open thermistor relay connected to digital input DI6. The motor is overheated when the digital input is 1.	22
35.12	Temperature 1 fault limit	Defines the fault limit for temperature supervision function 1. When measured temperature 1 exceeds the limit, the drive trips on fault 4981 External temperature 1. The unit is selected by parameter 96.16 Unit selection. Note: With a PTC sensor, the unit is ohms.	130 °C or 266°F or 4500 ohm
	-60…5000 °C or -76…9032 °F or 0…5000 ohm	Fault limit for temperature monitoring function 1.	1 = 1 unit
35.13	Temperature 1 warning limit	Defines the warning limit for temperature supervision function 1. When measured temperature 1 exceeds the limit, warning <i>A491 External temperature 1</i> is generated. The unit is selected by parameter <i>96.16 Unit selection</i> . Note : With a PTC sensor, the unit is ohms.	110°C or 230°F or 4000 ohm
	-605000 °C or -769032 °F or 05000 ohm	Warning limit for temperature monitoring function 1.	1 = 1 unit


No.	Name/Value	Description	Def/FbEq16
35.14	Temperature 1 Al source	Specifies the analog input when the setting of <i>35.11</i> <i>Temperature 1 source</i> requires measurement through an analog input.	Not selected
	Not selected	None.	0
	Al1 actual value	Analog input Al1 on the control unit.	1
	Al2 actual value	Analog input Al2 on the control unit.	2
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
35.21	Temperature 2 source	Selects the source from which measured temperature 2 is read. Usually this source is from a sensor connected to the motor controlled by the drive, but it could be used to measure and monitor a temperature from other parts of the process as long as a suitable sensor is used as per the selection list.	Estimated temperature
	Disabled	None. Temperature monitoring function 2 is disabled.	0
	Estimated temperature	Estimated motor temperature (see parameter 35.01 Motor estimated temperature). The temperature is estimated from an internal drive calculation. It is important to set up the ambient temperature of the motor in 35.50 Motor ambient temperature.	1
output. The following settin • Set the hardware input to U (voltage control unit reboor • Set the appropria in group <i>12 Stan</i> • In parameter gro selection parame <i>excitation</i> . The analog output f sensor. As the resis its temperature, the		 parameter 35.24 Temperature 2 AI source and an analog output. The following settings are required: Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 2 	2
	Reserved		34
	1 × Pt100 analog I/O	 Pt100 sensor connected to a standard analog input selected by parameter 35.24 Temperature 2 AI source and an analog output. The following settings are required: Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 2 excitation. The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees. 	5

No.	Name/Value Description				
	2 × Pt100 analog I/O	As selection 1 × <i>Pt100 analog I/O</i> , but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	6		
	3 × Pt100 analog I/O	As selection 1 × <i>Pt100 analog I/O</i> , but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	7		
	PTC DI6	PTC sensor is connected to DI6. Note: With a PTC sensor, the value shown is not a valid measurement. Either 0 ohm (normal temperature) or the value of parameter 35.23 <i>Temperature 2 warning limit</i> (excessive temperature) will be shown by 35.03 <i>Measured</i> <i>temperature 2</i> . If a user wants a faults to be triggered, the value of parameter 35.22 <i>Temperature 2 fault limit</i> has to be set below or equal to the warning limit.	8		
	Reserved		910		
	Direct temperature	The temperature is taken from the source selected by parameter 35.24 <i>Temperature 2 AI source</i> . The value of the source is assumed to be in the unit of temperature specified by parameter 96.16 <i>Unit selection</i> .	11		
	KTY83 analog I/O	 KTY83 sensor connected to the analog input selected by parameter 35.24 Temperature 2 AI source and an analog output. The following settings are required: Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 2 excitation. The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees. 	12		
	1 × Pt1000 analog I/O	 Pt1000 sensor connected to a standard analog input selected by parameter 35.24 Temperature 2 AI source and an analog output. The following settings are required: Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 2 excitation. The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees. 	13		
	2 × Pt1000 analog I/O	As selection 1 × <i>Pt1000 analog I/O</i> , but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	14		

No.	Name/Value	Description	Def/FbEq16
	3 × Pt1000 analog I/O	As selection1 × <i>Pt1000 analog I/O</i> , but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	15
Ni1000		 Ni1000 sensor connected to the analog input selected by parameter 35.24 Temperature 2 AI source and an analog output. The following settings are required: Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 2 excitation. The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees. 	16
	Reserved		1718
	PTC extension module	Not applicable.	19
	PTC analog I/O	PTC sensor connected to the analog input selected by parameter 35.24 Temperature 2 AI source and an analog output. The required settings are the same as with selection KTY84 analog I/O. If a PTC sensor is used, the voltage ready by the analog input is converted into ohms Note : With this selection, the control program converts the analog signal to PTC resistance value in ohms and shows it in parameter 35.03. The parameter name and unit still refer to temperature.	20
	Therm(0)	PTC sensor or a normally closed thermistor connected relay to digital input DI6. The motor is overheated when the digital input is 0.	21
	Therm(1)	Normally open thermistor relay connected to digital input DI6. The motor is overheated when the digital input is 1.	22
35.22	Temperature 2 fault limit	Defines the fault limit for temperature supervision function 2. When measured temperature 1 exceeds the limit, the drive trips on fault 4982 External temperature 2. The unit is selected by parameter 96.16 Unit selection. Note: With a PTC sensor, the unit is ohms.	130 °C or 266 °For 4500 ohm
	-605000 °C or -769032 °F or 05000 ohm	Fault limit for temperature monitoring function 2. Note: If the measured temperature source selection (<i>35.21</i>) is PTC analog I/O, the motor thermal protection function converts the analog input signal (<i>35.24</i>) to PTC resistance value (ohms). Also this limit is then a resistance value even the parameter name and unit refer to motor temperature (°C or °F). You cannot change the unit to ohm by the time being (<i>96.16</i>).	1 = 1 unit

No.	Name/Value	Description	Def/FbEq16	
35.23	Temperature 2 warning limit	Defines the warning limit for temperature supervision function 2. When measured temperature 1 exceeds the limit, warning <i>A492 External temperature 2</i> is generated. The unit is selected by parameter <i>96.16 Unit selection</i> . Note: With a PTC sensor, the unit is ohms.	110 °C or 230 °F or 04000 ohm	
	-605000 °C or -769032 °F or 05000 ohm	Warning limit for temperature monitoring function 2. Note: If the measured temperature source selection (35.21) is PTC analog I/O, the motor thermal protection function converts the analog input signal (35.24) to PTC resistance value (ohms). Also this limit is then a resistance value even the parameter name and unit refer to motor temperature (°C or °F). You cannot change the unit to ohm by the time being (96.16).	1 = 1 unit	
35.24	Temperature 2 AI source	Specifies the analog input when the setting of <i>35.11</i> <i>Temperature 1 source</i> requires measurement through an analog input.	Not selected	
	Not selected	None.	0	
	Al1 actual value	Analog input AI1 on the control unit.	1	
	Al2 actual value	Analog input Al2 on the control unit.	2	
	Other	her Source selection (see <i>Terms and abbreviations</i> on page 161).		
35.50	Motor ambient temperature Defines the ambient temperature of the motor for the motor thermal protection model. The unit is selected by parameter 96.16 Unit selection. The motor thermal protection model estimates the motor temperature on the basis of parameters 35.5035.55. The motor temperature increases if it operates in the region above the load curve, and decreases if it operates in the region below the load curve. WARNING! The model cannot protect the motor if the motor does not cool properly because of dust, dirt, etc.		20 °C	
	-60…100 °C or -76 … 212 °F	Ambient temperature.	1 = 1°	

No.	Name/Value	Description	Def/FbEq16
35.51 Motor load curve		Defines the motor load curve together with parameters 35.52 Zero speed load and 35.53 Break point. The load curve is used by the motor thermal protection model to estimate the motor temperature. When the parameter is set to 100%, the maximum load is taken as the value of parameter 99.06 Motor nominal current (higher loads heat up the motor). The load curve level should be adjusted if the ambient temperature differs from the nominal value set in 35.50 Motor ambient temperature.	110%
	// _N (%) ↑	<i>I</i> = Motor current <i>I</i> _N = Nominal motor current	
	150 —		
	100	35.51	
	50 35.52		
		35.53 Drive output frequency	ut
	50150%	Maximum load for the motor load curve.	1 = 1%
35.52 Zero speed load		Defines the motor load curve together with parameters 35.51 Motor load curve and 35.53 Break point. Defines the maximum motor load at zero speed of the load curve. A higher value can be used if the motor has an external motor fan to boost the cooling. See the motor manufacturer's recommendations. See parameter 35.51 Motor load curve.	70%
	25150%	Zero speed load for the motor load curve.	1 = 1%
35.53	Break point	Defines the motor load curve together with parameters 35.51 Motor load curve and 35.52 Zero speed load. Defines the break point frequency of the load curve ie. the point at which the motor load curve begins to decrease from the value of parameter 35.51 Motor load curve towards the value of parameter 35.51 Motor load curve.	45.00 Hz
	1.00500.00 Hz	Break point for the motor load curve.	See par. 46.02



No.	Name/Value	Description	Def/FbEq16	
35.55	Motor thermal time const Defines the thermal time constant for use with the motor thermal protection model, defined as the time to reach 63% of the nominal motor temperature. See the motor manufacturer's recommendations. For thermal protection according to UL requirements for NEMA class motors, use the rule of thumb: Motor thermal time equals 35 times t0, where t0 (in seconds) is specified by the motor manufacturer as the time that the motor can safely operate at six time its rated current.			
		Motor current		
		100% -		
		Time		
		Temperature rise 100%		
		Motor thermal time Time		
	10010000 s	Motor thermal time constant.	1 = 1 s	
35.56	Motor overload action	Selects how the drive reacts when the motor reaches overload condition.	Warning and fault	
	No action	None.	0	
	Warning only	The drive generates an <i>A783 Motor overload</i> warning when the motor is overloaded to the warning level, that is, parameter 35.05 <i>Motor overload level</i> reaches value 88.0%.	1	
	Warning and fault	The drive generates an <i>A783 Motor overload</i> warning when the motor is overloaded to the warning level, that is, parameter <i>35.05 Motor overload level</i> reaches value 88.0%. Drive trips on fault <i>7122 Motor overload</i> when the motor is overloaded to the fault level, that is, parameter <i>35.05 Motor</i> <i>overload level</i> reaches value 100.0%.	2	
35.57	Motor overload class	Selects the motor overload class to be used. The class of protection is specified by the user as the time for tripping at 7.2 times (IEC 60947-4-1) or 6 times (NEMA ICS) the tripping level current. See section <i>Motor overload protection</i> on page 87.	Class 20	
	Class 5	Class 5 relay trip class	0	
	Class 10	Class 10 relay trip class	1	
	Class 20	Class 20 relay trip class	2	

No.	Name/Value	Name/Value Description	
	Class 30	Class 30 relay trip class	3
	Class 40	Class 40 relay trip class	4
36 Loa	ad analyzer	Peak value and amplitude logger settings. See also section <i>Load analyzer</i> (page 94).	
36.01	PVL signal source	Selects the signal to be monitored by the peak value logger. The signal is filtered using the filtering time specified by parameter 36.02 PVL filter time. The peak value is stored, along with other pre-selected signals at the time, into parameters 36.1036.15. The peak value logger can be reset using parameter 36.09 <i>Reset loggers</i> . The logger is also reset whenever the signal source is changed. The date and time of the last reset are stored into parameters 36.16 and 36.17 respectively.	Motor current
	Not selected	None (peak value logger disabled).	0
	Motor speed used	01.01 Motor speed used (page 164).	1
	Output frequency	01.06 Output frequency (page 164).	3
	Motor current	01.07 Motor current (page 164).	4
	Motor torque	01.10 Motor torque (page 164).	6
	DC voltage	01.11 DC voltage (page 164).	7
	Output power	01.14 Output power (page 165).	8
	Speed ref ramp in	23.01 Speed ref ramp input (page 232).	10
	Speed ref ramp out	23.02 Speed ref ramp output (page 232).	11
	Torque ref used	26.02 Torque reference used (page 243).	13
	Freq ref used	28.02 Frequency ref ramp output (page 247).	14
	Process PID out	40.01 Process PID output actual (page 302).	16
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
36.02	PVL filter time	Peak value logger filtering time. See parameter 36.01 PVL signal source.	2.00 s
	0.00120.00 s	Peak value logger filtering time.	100 = 1 s
36.09	Reset loggers	Resets the peak value logger and/or amplitude logger 2. (Amplitude logger 1 cannot be reset.)	Done
	Done	Reset completed or not requested (normal operation).	0
	PVL	Reset the peak value logger.	2
36.10	PVL peak value	Peak value recorded by the peak value logger.	0.00
	-32768.00 32767.00	Peak value.	
36.11	PVL peak date	The date on which the peak value was recorded.	1/1/1980
	1/1/19806/5/2159	Peak occurrence date.	-
36.12	PVL peak time	The time at which the peak value was recorded.	00:00:00
	00:00:0023:59:59	Peak occurrence time.	-
36.13	PVL current at peak	Motor current at the moment the peak value was recorded.	0.00 A
	-32768.00 32767.00 A	Motor current at peak.	1 = 1 A

No.	Name/Value	Description	Def/FbEq16
36.14	PVL DC voltage at peak	Voltage in the intermediate DC circuit of the drive at the moment the peak value was recorded.	0.00 V
	0.002000.00 V	DC voltage at peak.	10 = 1 V
36.15	PVL speed at peak	Motor speed at the moment the peak value was recorded.	0.00 rpm
	-30000.00 30000.00 rpm	Motor speed at peak.	See par. 46.01
36.16	PVL reset date	The date on which the peak value logger was last reset.	1/1/1980
	1/1/19806/5/2159	Last reset date of the peak value logger.	-
36.17	PVL reset time	The time at which the peak value logger was last reset.	00:00:00
	00:00:0023:59:59	Last reset time of the peak value logger.	-

	Settings for user load curve. See also section <i>User Load Curve</i> (page 49).	
37.01 ULC output status word	Displays the status of the monitored signal.	0b0000

	Bit	Name		Description	
	0	Under load	limit	1 = Signal lower than the underload curve.	
	1	1 Within load range 1 = Signal between the underload and overload		curve.	
	2	Overload li	nit	1 = Signal higher than the overload curve.	
	3	Outside loa	d limit	1 = Signal lower than the underload curve or higoverload curve.	gher than the
	315	Reserved			
	0b0000.	0b1111	Status of the n	nonitored signal.	1 = 1
37.02	ULC sup signal	pervision	Selects the sig	nal to be supervised.	Motor torque %
	Not sele	cted	No signal sele	cted. ULC disabled.	0
	Motor sp	eed %	01.03 Motor sp	oeed % (page 164).	1
	Motor cu	Irrent %	01.08 Motor current % of motor nom (page 164).		2
	Motor torque % Output power % of motor nominal		01.10 Motor torque (page 164). 3 01.15 Output power % of motor nom (page 165). 4		3
					4
	Other		Source selection	ource selection (see <i>Terms and abbreviations</i> on page 161).	
37.03	ULC overload actions			Selects an action taken if the signal stays over the overload curve in a sector for a defined time.	
	Disabled		No warnings or fault generated.		0
	Fault The chast		signal has bee	erates an <i>A8BE ULC overload warning</i> if the en continuously over the overload curve for a y parameter <i>37.41 ULC overload timer</i> .	1
			has been conti	erates a 8002 ULC overload fault if the signal inuously over the overload curve for a time ameter 37.41 ULC overload timer.	2
	Warning	/Fault	signal has bee time defined by The drive gene has been cont	erates an <i>A8BE ULC</i> overload warning if the en continuously over the overload curve for a y parameter <i>37.41 ULC</i> overload timer. erates a <i>8002 ULC</i> underload fault if the signal inuously over the overload curve for a time ameter <i>37.41 ULC</i> overload timer.	3

No.	Name/Value	Description	Def/FbEq16
37.04	ULC underload actions	Selects an action taken if the signal stays under the underload curve for a defined time.	Disabled
	Disabled	No warnings or fault generated.	0
	Warning	The drive generates an <i>A8BF ULC underload warning</i> if the signal has been continuously under the underload curve for a time defined by parameter <i>37.42 ULC underload timer</i> .	1
	Fault	The drive generates a <i>8001 ULC underload fault</i> if the signal has been continuously under the underload curve for a time defined by parameter <i>37.42 ULC underload timer</i> .	2
	Warning/Fault	The drive generates an <i>A8BF ULC underload warning</i> if the signal has been continuously under the underload curve for a time defined by parameter <i>37.42 ULC underload timer</i> . The drive generates an <i>A8BF ULC underload warning</i> if the signal has been continuously under the underload curve for a time defined by parameter <i>37.42 ULC underload timer</i> .	3
37.11	ULC speed table point 1	Defines the first of the five speed points on the X-axis of the user load curve. The values of the parameters must satisfy: -30000.0 rpm \leq 37.11 ULC speed table point 1 < 37.12 ULC speed table point 2 < 37.13 ULC speed table point 3 < 37.14 ULC speed table point 4 < 37.15 ULC speed table point 5 < 30000.0 rpm. Speed points are used if parameter 99.04 Motor control mode is set to Vector or if 99.04 Motor control mode is set to Scalar and the reference unit is rpm.	150.0 rpm
	-30000.030000.0 rpm	Speed.	1 = 1 rpm
37.12	ULC speed table point 2	Defines the second speed point. See parameter 37.11 ULC speed table point 1.	750.0 rpm
	-30000.030000.0 rpm	Speed.	1 = 1 rpm
37.13	ULC speed table point 3	Defines the third speed point. See parameter 37.11 ULC speed table point 1.	1290.0 rpm
	-30000.030000.0 rpm	Speed.	1 = 1 rpm
37.14	ULC speed table point 4	Defines the fourth speed point. See parameter 37.11 ULC speed table point 1.	1500.0 rpm
	-30000.030000.0 rpm	Speed.	1 = 1 rpm
37.15	ULC speed table point 5	Defines the fifth speed point. See parameter 37.11 ULC speed table point 1.	1800.0 rpm
	-30000.030000.0 rpm	Speed.	1 = 1 rpm

No.	Name/Value	Description	Def/FbEq16
37.21	ULC underload point 1	Defines the first of the five points on the Y-axis that together with the corresponding point on the X-axis (37.11 ULC speed table point 137.15 ULC speed table point 5) define the underload (lower) curve. The following conditions must be fulfilled: 37.21 ULC underload point 1 <= 37.31 ULC overload point 1 37.22 ULC underload point 2 <= 37.32 ULC overload point 2 37.23 ULC underload point 3 <= 37.33 ULC overload point 3 37.24 ULC underload point 4 <= 37.34 ULC overload point 4 37.25 ULC underload point 5 <= 37.35 ULC overload point 5	10.0%
	-1600.01600.0%	Underload point.	1 = 1%
37.22	ULC underload point 2	Defines the second underload point. See parameter 37.21 ULC underload point 1.	15.0%
	-1600.01600.0%	Underload point.	1 = 1%
37.23	ULC underload point 3	Defines the third underload point. See parameter 37.21 <i>ULC underload point</i> 1	25.0%
	-1600.01600.0%	Underload point.	1 = 1%
37.24	ULC underload point 4	Defines the fourth underload point. See parameter 37.21 ULC underload point 1	30.0%
	-1600.01600.0%	Underload point.	1 = 1%
37.25	ULC underload point 5	Defines the fifth underload point. See parameter 37.21 ULC underload point 1	30.0%
	-1600.01600.0%	Underload point.	1 = 1%
37.31	ULC overload point 1	Defines the first of the five points on the Y-axis that together with the corresponding point on the X-axis (37.11 ULC speed table point 137.15 ULC speed table point 5) define the overload (higher) curve. At each of the five points the value of the underload curve point must be equal to or smaller than the value of the overload curve point. See parameter 37.21 ULC underload point 1.	300.0%
	-1600.01600.0%	Overload point.	1 = 1%
37.32	ULC overload point 2	Defines the second overload point. See parameter 37.31 ULC overload point 1.	300.0%
	-1600.01600.0%	Overload point.	1 = 1%
37.33	ULC overload point 3	Defines the third overload point. See parameter 37.31 ULC overload point 1.	300.0%
	-1600.01600.0%	Overload point.	1 = 1%
37.34	ULC overload point 4	Defines the fourth overload point. See parameter <i>37.31 ULC overload point 1</i> .	300.0%
	-1600.01600.0%	Overload point.	1 = 1%
37.35	ULC overload point 5	Defines the fifth overload point. See parameter 37.31 ULC overload point 1.	300.0%
	-1600.01600.0%	Overload point.	1 = 1%
37.41	ULC overload timer	Defines the time period for which time the monitored signal must remain continuously over the overload curve.	20.0 s
	0.010000.0 s	Time.	1 = 1 s

No.	Name/Value	Description	Def/FbEq16
37.42	ULC underload timer	Defines the time period for which time the monitored signal must remain continuously below the underload curve.	20.0 s
	0.010000.0 s	Time.	1 = 1 s
40 Pro	cess PID set 1	Parameter values for process PID control. The drive output can be controlled by the process PID. When the process PID control is enabled, the drive controls the process feedback to the reference value. Two different parameter sets can be defined for the process PID. One parameter set is in use at a time. The first set is made up of parameters 40.0740.50, the second set is defined by the parameters in group 41 Process PID set 2. The binary source that defines which set is used is selected by parameter 40.57 PID set1/set2 selection. See also the control chain diagrams on pages 499 and 502.	
40.01	Process PID output actual	Displays the output of the process PID controller. See the control chain diagram on page <i>502</i> . This parameter is read-only.	-
	-200000.00 200000.00	Process PID controller output.	1 = 1
40.02	Process PID feedback actual	Displays the value of process feedback after source selection, mathematical function (parameter 40.10 Set 1 feedback function), and filtering. See the control chain diagram on page 499. This parameter is read-only.	-
	-200000.00 200000.00	Process feedback.	1 = 1
40.03	Process PID setpoint actual	Displays the value of process PID setpoint after source selection, mathematical function (<i>40.18 Set 1 setpoint function</i>), limitation and ramping. See the control chain diagram on page <i>499</i> . This parameter is read-only.	-
	-200000.00 200000.00	Setpoint for process PID controller.	1 = 1
40.04	Process PID deviation actual	Displays the process PID deviation. By default, this value equals setpoint - feedback, but deviation can be inverted by parameter 40.31 Set 1 deviation inversion. See the control chain diagram on page 502. This parameter is read-only.	-
	-200000.00 200000.00	PID deviation.	1 = 1
40.05	Process PID trim output act	Displays the trimmed reference output. This parameter is read-only.	-
	-3276832767	Trimmed reference.	1 = 1 unit

No.	Name/Value		e/Value Description		Def/FbEq16	
40.06	Process word	PID status		rs status information on process PID control. arameter is read-only.	0b0000	
	Bit	Name		Value		
	0	PID active		1 = Process PID control active.		
	1	Setpoint fro	zen	1 = Process PID setpoint frozen.		
	2			1 = Process PID controller output frozen.		
	3			1 = Sleep mode active.		
	4	Sleep boost		1 = Sleep boost active.		
	5	Trim mode		1 = Trim mode active		
	6	Tracking m	ode	1 = Tracking function active.		
	7	Output limit	high	1 = PID output is being limited by par. 40.37.		
	8	Output limit	low	1 = PID output is being limited by par. 40.36.		
	9	Deadband	active	1 = Deadband active (see parameter 40.39)		
	10	PID set		0 = Parameter set 1 in use. 1 = Parameter set 2 in use		
	11	Reserved				
	12	Internal set active	point	1 = Internal setpoint active (see par. 40.1640.23)		
	1315	Reserved				
	0b0000.	0b1111	Proces	s PID control status word.	1 = 1	
40.07	Process PID operation mode		Note:	es/deactivates process PID control. Process PID control is only available in external ; see section <i>Local control vs. external control</i> (page	Off	
			<mark>33</mark>).			
	Off			s PID control inactive.	0	
	On		Proces	s PID control active.	1	
	On wher running	n drive	Proces	s PID control is active when the drive is running.	2	
40.08	Set 1 feedback 1 source			the primary source of process feedback. See the chain diagram on page 499.	Al2 percent	
	Not selected		None.		0	
	Al1 scale	ed	12.12	Al1 scaled value (see page 189).	1	
	Al2 scale	ed	12.22	2.22 Al2 scaled value (see page 190). 1.39 Freq in 1 scaled value (see page 186).	2	
	Freq in s	scaled	11.39 F		3	
	Al1 perc	ent	12.101	Al1 percent value (see page 192)	8	
	Al2 perc	ent	12.102	Al2 percent value (see page 192)	9	
	Feedbac storage	k data	40.91	Feedback data storage (see page 315),	10	
	Other		Source selection (see Terms and abbreviations on page 161).		-	
40.09	Set 1 fee source	edback 2	source inputs.	the second source of process feedback. The second is used only if the setpoint function requires two selections, see parameter <i>40.08 Set 1 feedback 1</i>	Not selected	
40.10	Set 1 fee function		feedba	s how process feedback is calculated from the two ck sources selected by parameters <i>40.08 Set 1</i> <i>ck 1 source</i> and <i>40.09 Set 1 feedback 2 source</i> .	In1	
	In1		Source	1.	0	

No.	Name/Value	Description	Def/FbEq16
	In1+In2	Sum of sources 1 and 2.	1
	In1-In2	Source 2 subtracted from source 1.	2
	In1*In2	Source 1 multiplied by source 2.	3
	In1/In2	Source 1 divided by source 2.	4
	MIN(In1,In2)	Smaller of the two sources.	5
	MAX(In1,In2)	Greater of the two sources.	6
	AVE(In1,In2)	Average of the two sources.	7
	sqrt(In1)	Square root of source 1.	8
	sqrt(In1-In2)	Square root of (source 1 - source 2).	9
	sqrt(In1+In2)	Square root of (source 1 + source 2).	10
	sqrt(In1)+sqrt(In2)	Square root of source 1 + square root of source 2.	11
40.11	Set 1 feedback filter time	Defines the filter time constant for process feedback.	0.000 s
	0.00030.000 s	Feedback filter time.	1 = 1 s
40.14	Set 1 setpoint scaling	Defines, together with parameter 40.15 Set 1 output scaling, a general scaling factor for the external PID control chain. The scaling can be utilized when, for example, the process setpoint is input in Hz, and the output of the PID controller is used as an rpm value in speed control. In this case, this parameter might be set to 50, and parameter 40.15 to the nominal motor speed at 50 Hz. In effect, the output of the PID controller [40.15] when deviation (setpoint - feedback) = [40.14] and [40.32] = 1. Note: The scaling is based on the ratio between 40.14 and 40.15. For example, the values 50 and 1500 would produce the same scaling as 1 and 3.	0.00
	-200000.00 200000.00	Process setpoint base.	1=1
40.15	Set 1 output scaling	See parameter 40.14 Set 1 setpoint scaling	0.00
	-200000.00 200000.00	Process PID controller output base.	1=1
40.16	Set 1 setpoint 1 source	Selects the primary source of process PID setpoint. See the control chain diagram on page <i>499</i> .	Al1 percent
	Not selected	None.	0
	Internal setpoint	Internal setpoint. See parameter 40.19 Set 1 internal setpoint sel1.	2
	Al1 scaled	12.12 Al1 scaled value (see page 189).	3
	Al2 scaled	12.22 Al2 scaled value (see page 190).	4
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	8
	Freq in scaled	11.39 Freq in 1 scaled value (see page 186).	10
	Al1 percent	12.101 Al1 percent value (see page 192)	11
	Al2 percent	12.102 AI2 percent value (see page 192)	12

No.	Name/Value	Description	Def/FbEq16
	Control panel (ref saved)	Panel reference (03.01 Panel reference, see page 167) saved by the control system for the location where the control returns is used as the reference. Reference	13
	Control panel (ref copied)	Panel reference (03.01 Panel reference, see page 167) for the previous control location is used as the reference when the control location changes if the references for the two locations are of the same type (eg frequency/speed/torque/PID); otherwise, the actual signal is used as the new reference. Reference	14
	FB A ref1	03.05 FB A reference 1 (see page 167).	15
	FB A ref2	03.06 FB A reference 2 (see page 167).	16
	EFB ref1	03.09 EFB reference 1 (see page 167).	19
	EFB ref2	03.10 EFB reference 2 (see page 167).	20
	Setpoint data storage	40.92 Setpoint data storage (see page 315)	24
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
40.17	Set 1 setpoint 2 source	Selects the second source of process setpoint. The second source is used only if the setpoint function requires two inputs. For the selections, see parameter <i>40.16 Set 1 setpoint 1 source</i> .	Not selected
40.18	Set 1 setpoint function	Selects a function between the setpoint sources selected by parameters 40.16 Set 1 setpoint 1 source and 40.17 Set 1 setpoint 2 source.	In1
	ln1	Source 1.	0
	In1+In2	Sum of sources 1 and 2.	1
	In1-In2	Source 2 subtracted from source 1.	2
	In1*In2	Source 1 multiplied by source 2.	3
	In1/In2	Source 1 divided by source 2.	4
	MIN(In1,In2)	Smaller of the two sources.	5
	MAX(In1,In2)	Greater of the two sources.	6
	AVE(In1,In2)	Average of the two sources.	7
	sqrt(In1)	Square root of source 1.	8
	sqrt(In1-In2)	Square root of (source 1 - source 2).	9
	sqrt(In1+In2)	Square root of (source 1 + source 2).	10

No.	Name/Value	Description			Def/FbEq16
	sqrt(In1)+sqrt(In2)	Square root of sou	urce 1 + square roo	ot of source 2.	11
40.19	Set 1 internal setpoint sel1	internal setpoint of 40.2140.23. Note: Parameters	ut of the presets d 40.16 Set 1 setpo	ernal setpoint sel2 the efined by parameters wint 1 source and 40.17	Not selected
		Set 1 setpoint 2 so Source defined by par. 40.19		to Internal setpoint. Setpoint preset active	
		0	0	Setpoint source	
		1	0	1 (par. 40.21)	
		0	1	2 (par. 40.22)	
		1	1	3 (par. 40.23)	
	Not selected	0.			0
	Selected	1.			1
	DI1	Digital input DI1 (1	10.02 DI delayed s	<i>tatus</i> , bit 0).	2
	DI2	Digital input DI2 (1	10.02 DI delayed s	<i>tatus</i> , bit 1).	3
	DI3	Digital input DI3 (1	10.02 DI delayed s	<i>tatus</i> , bit 2).	4
	DI4	Digital input DI4 (1	10.02 DI delayed s	<i>tatus</i> , bit 3).	5
	DI5	Digital input DI5 (1	10.02 DI delayed s	<i>tatus</i> , bit 4).	6
	DI6	Digital input DI6 (1	7		
	Timed function 1	Bit 0 of 34.01 Time	18		
	Timed function 2	Bit 1 of 34.01 Time	19		
	Timed function 3	Bit 2 of 34.01 Time	20		
	Supervision 1	Bit 0 of 32.01 Sup	21		
	Supervision 2	Bit 1 of 32.01 Sup	ervision status (se	e page <mark>273</mark>).	22
	Supervision 3	Bit 2 of 32.01 Sup	23		
	Other [bit]	Source selection (see Terms and ab	breviations on page 161).	-
40.20	Set 1 internal setpoint sel2	internal setpoint us	sed out of the thre eters <u>40.2140.23</u>	ernal setpoint sel1 the e internal setpoints 8. See table at 40.19 Set	Not selected
	Not selected	0.			0
	Selected	1.			1
	DI1	Digital input DI1 (1	10.02 DI delayed s	<i>tatus</i> , bit 0).	2
	DI2	Digital input DI2 (1	10.02 DI delayed s	<i>tatus</i> , bit 1).	3
	DI3	Digital input DI3 (1	10.02 DI delayed s	<i>tatus</i> , bit 2).	4
	DI4	Digital input DI4 (1	10.02 DI delayed s	<i>tatus</i> , bit 3).	5
	DI5	Digital input DI5 (1	10.02 DI delayed s	<i>tatus</i> , bit 4).	6
	DI6	Digital input DI6 (1	10.02 DI delayed s	<i>tatus</i> , bit 5).	7
	Timed function 1	Bit 0 of 34.01 Time	ed functions status	s (see page <u>280</u>).	18
	Timed function 2	Bit 1 of 34.01 Time	ed functions status	s (see page <u>280</u>).	19
	Timed function 3	Bit 2 of 34.01 Time	ed functions status	s (see page <u>280</u>).	20
	Supervision 1	Bit 0 of 32.01 Sup	ervision status (se	e page 273).	21

No.	Name/Value	Description	Def/FbEq16
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 273).	22
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 273).	23
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
40.21	Set 1 internal setpoint 1	Internal process setpoint 1. See parameter 40.19 Set 1 internal setpoint sel1.	0.00
	-200000.00 200000.00	Internal process setpoint 1.	1 = 1
40.22	Set 1 internal setpoint 2	Internal process setpoint 2. See parameter 40.19 Set 1 internal setpoint sel1.	0.00
	-200000.00 200000.00	Internal process setpoint 2.	1 = 1
40.23	Set 1 internal setpoint 3	Internal process setpoint 3. See parameter 40.19 Set 1 internal setpoint sel1.	0.00
	-200000.00 200000.00	Internal process setpoint 3.	1 = 1
40.24	Set 1 internal setpoint 0	Internal process setpoint 0. See parameter 40.19 Set 1 internal setpoint sel1.	0.00
	-200000.00 200000.00	Internal process setpoint 0.	1 = 1
40.26	Set 1 setpoint min	Defines a minimum limit for the process PID controller setpoint.	0.00
	-200000.00 200000.00	Minimum limit for process PID controller setpoint.	1 = 1
40.27	Set 1 setpoint max	Defines a maximum limit for the process PID controller setpoint.	200000.00
	-200000.00 200000.00	Maximum limit for process PID controller setpoint.	1 = 1
40.28	Set 1 setpoint increase time	Defines the minimum time it takes for the setpoint to increase from 0% to 100%.	0.0 s
	0.01800.0 s	Setpoint increase time.	1 = 1
40.29	Set 1 setpoint decrease time	Defines the minimum time it takes for the setpoint to decrease from 100% to 0%.	0.0 s
	0.01800.0 s	Setpoint decrease time.	1 = 1
40.30	Set 1 setpoint freeze enable	Freezes, or defines a source that can be used to freeze, the setpoint of the process PID controller. This feature is useful when the reference is based on a process feedback connected to an analog input, and the sensor must be serviced without stopping the process. 1 = Process PID controller setpoint frozen See also parameter <i>40.38 Set 1 output freeze</i> .	Not selected
	Not selected	Process PID controller setpoint not frozen.	0
	Selected	Process PID controller setpoint frozen.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6

No.	Name/Value	Description	Def/FbEq16
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 280).	18
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 280).	19
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 280).	20
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 273).	21
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 273).	22
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 273).	23
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
40.31	Set 1 deviation inversion	Inverts the input of the process PID controller. 0 = Deviation not inverted (Deviation = Setpoint - Feedback) 1 = Deviation inverted (Deviation = Feedback - Setpoint) See also section <i>Sleep and boost functions for process PID</i> <i>control</i> (page 52).	Not inverted (Ref - Fbk)
	Not inverted (Ref - Fbk)	0.	0
	Inverted (Fbk - Ref)	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
40.32	Set 1 gain	Defines the gain for the process PID controller. See parameter 40.33 Set 1 integration time.	1.00
	0.01100.00	Gain for PID controller.	100 = 1
40.33	Set 1 integration time	Defines the integration time for the process PID controller. This time needs to be set to the same order of magnitude as the reaction time of the process being controlled, otherwise instability will result. Error/Controller output $G \times I \qquad \qquad$	60.0 s
	0.0.0000.0.c		1 = 1 s
	0.09999.0 s	Integration time.	1=15

No.	Name/Value	Description	Def/FbEq16
40.34	Set 1 derivation time	Defines the derivation time of the process PID controller. The derivative component at the controller output is calculated on basis of two consecutive error values (E_{K-1} and E_K) according to the following formula: PID DERIV TIME × ($E_K - E_{K-1}$)/ T_S , in which $T_S = 2$ ms sample time $E = Error = Process$ reference - process feedback.	0.000 s
	0.00010.000 s	Derivation time.	1000 = 1 s
40.35	Set 1 derivation filter time	Defines the time constant of the 1-pole filter used to smooth the derivative component of the process PID controller. $ \begin{array}{c} & \\ & \\ & \\ & \\ & \\ & \\ & \\ & $	0.0 s
		O = filter output t = time T = filter time constant	
	0.010.0 s	Filter time constant.	10 = 1 s
40.36	Set 1 output min	Defines the minimum limit for the process PID controller output. Using the minimum and maximum limits, it is possible to restrict the operation range.	0.0
	-200000.00 200000.00	Minimum limit for process PID controller output.	1 = 1
40.37	Set 1 output max	Defines the maximum limit for the process PID controller output. See parameter <i>40.36 Set 1 output min</i> .	100.0
	-200000.00 200000.00	Maximum limit for process PID controller output.	1 = 1
40.38	Set 1 output freeze	Freezes (or defines a source that can be used to freeze) the output of the process PID controller, keeping the output at the value it was before freeze was enabled. This feature can be used when, for example, a sensor providing process feedback must to be serviced without stopping the process. 1 = Process PID controller output frozen See also parameter <i>40.30 Set 1 setpoint freeze enable</i> .	Not selected
	Not selected	Process PID controller output not frozen.	0
	Selected	Process PID controller output frozen.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5

	Name/Value	Description	Def/FbEq16
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 280).	18
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 280).	19
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 280).	20
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 273).	21
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 273).	22
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 273).	23
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
40.39	Set 1 deadband range	Defines a deadband around the setpoint. Whenever process feedback enters the deadband, a delay timer starts. If the feedback remains within the deadband longer than the delay $(40.40 \text{ Set 1 deadband delay})$, the PID controller output is frozen. Normal operation resumes after the feedback value leaves the deadband.	0.00
	40.39 Set 1 deadband range Setpo Feedb		
	PID contro out		
		PID col output	
		PID col output	frozen
40.40	out	PID con output	frozen Time
40.40	out 00200000.00 Set 1 deadband	PID con output 40.40 Set 1 deadband delay Deadband range. Delay for the deadband. See parameter 40.39 Set 1	frozen Time
	out 00200000.00 Set 1 deadband delay	Deadband range. Delay for the deadband. See parameter 40.39 Set 1 deadband range.	frozen <i>Time</i> 1 = 1 0.0
	out 00200000.00 Set 1 deadband delay 0.0 3600.0 s	put PID conortication 40.40 Set 1 deadband delay Deadband range. Delay for the deadband. See parameter 40.39 Set 1 deadband range. Delay for deadband area. Defines the start limit for the sleep function. If the value is 0.0, set 1 sleep mode is disabled. The sleep function compares PID output (parameter 40.01 Process PID output actual) to the value of this parameter. If PID output remains below this value longer than the sleep delay defined by 40.44 Set 1 sleep delay, the drive enters the	frozen <i>Time</i> 1 = 1 0.0 1 = 1 s
40.40	out 00200000.00 Set 1 deadband delay 0.0 3600.0 s Set 1 sleep level	put PID conortication 40.40 Set 1 deadband delay Deadband range. Delay for the deadband. See parameter 40.39 Set 1 deadband range. Delay for deadband area. Defines the start limit for the sleep function. If the value is 0.0, set 1 sleep mode is disabled. The sleep function compares PID output (parameter 40.01 Process PID output actual) to the value of this parameter. If PID output remains below this value longer than the sleep delay defined by 40.44 Set 1 sleep delay, the drive enters the sleep mode and stops the motor.	frozen Time 1 = 1 0.0 1 = 1 s 0.0

No.	Name/Value	Description	Def/FbEq16
40.45	Set 1 sleep boost time	Defines a boost time for the sleep boost step. See parameter 40.46 Set 1 sleep boost step.	0.0
	0.03600.0 s	Sleep boost time.	1 = 1
40.46	Set 1 sleep boost step	When the drive is entering sleep mode, the process setpoint is increased by this value for the time defined by parameter 40.45 Set 1 sleep boost time. If active, sleep boost is aborted when the drive wakes up.	0.00
	0.00200000.00	Sleep boost step.	1 = 1
40.47	Set 1 wake-up deviation	Defines the wake-up level as deviation between process setpoint and feedback. When the deviation exceeds the value of this parameter, and remains there for the duration of the wake-up delay (40.48 <i>Set 1 wake-up delay</i>), the drive wakes up. See also parameter 40.31 <i>Set 1 deviation inversion</i> .	0.00
	-200000.00 200000.00	Wake-up level (as deviation between process setpoint and feedback).	1 = 1
40.48	Set 1 wake-up delay	Defines a wake-up delay for the sleep function to prevent nuisance wake-ups. See parameter 40.47 Set 1 wake-up deviation. The delay timer starts when the deviation exceeds the wake- up level (40.47 Set 1 wake-up deviation), and resets if the deviation falls below the wake-up level.	0.50
	0.0060.00 s	Wake-up delay.	1 = 1
40.49	Set 1 tracking mode	Activates (or selects a source that activates) tracking mode. In tracking mode, the value selected by parameter 40.50 Set 1 tracking ref selection is substituted for the PID controller output. See also section Tracking (page 53). 1 = Tracking mode enabled	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 280).	18
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 280).	19
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 280).	20
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 273).	21
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 273).	22
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 273).	23
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
40.50	Set 1 tracking ref selection	Selects the value source for tracking mode. See parameter 40.49 Set 1 tracking mode.	Not selected
	Not selected	None.	0
	Al1 scaled	12.12 Al1 scaled value (see page 189).	1

No.	Name/Value	Description	Def/FbEq16
	Al2 scaled	12.22 Al2 scaled value (see page 190).	2
	FB A ref1	03.05 FB A reference 1 (see page 167).	3
	FB A ref2	03.06 FB A reference 2 (see page 167).	4
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
40.51	Set 1 trim mode	Activates the trim function and selects between direct and proportional trimming (or a combination of both). With trimming, it is possible to apply a corrective factor to the drive reference (setpoint). The output after trimming is available as parameter 40.05 Process PID trim output act.	Off
	Off	The trim function is inactive.	0
	Direct	The trim function is active. The trimming factor is relative to the maximum speed, torque or frequency; the selection between these is made by parameter <i>40.52 Set 1 trim selection</i> .	1
	Proportional	The trim function is active. The trimming factor is relative to the reference selected by parameter 40.53 Set 1 trimmed ref pointer.	2
	Combined	The trim function is active. The trimming factor is a combination of both <i>Direct</i> and <i>Proportional</i> modes; the proportions of each are defined by parameter 40.54 Set 1 trim mix.	3
40.52	Set 1 trim selection	Selects whether trimming is used for correcting the speed, torque or frequency reference.	Speed
	Torque	Torque reference trimming.	1
	Speed	Speed reference trimming.	2
	Frequency	Frequency reference trimming.	3
40.53	Set 1 trimmed ref pointer	Selects the signal source for the trim reference.	Not selected
	Not selected	None.	0
	Al1 scaled	12.12 Al1 scaled value (see page 189).	1
	Al2 scaled	12.22 Al2 scaled value (see page 190).	2
	FBA ref1	03.05 FB A reference 1 (see page 167).	3
	FBA ref2	03.06 FB A reference 2 (see page 167).	4
	Other	Source selection (see Terms and abbreviations).	-
40.54	Set 1 trim mix	When parameter 40.51 Set 1 trim mode is set to Combined, defines the effect of direct and proportional trim sources in the final trimming factor. 0.000 = 100% proportional 0.500 = 50% proportional, 50% direct 1.000 = 100% direct	0.000
	0.0001.000	Trim mix.	1 = 1
40.55	Set 1 trim adjust	Defines a multiplier for the trimming factor. This value is multiplied by the result of parameter 40.51 Set 1 trim mode. Consequently, the result of the multiplication is used to multiply the result of parameter 40.56 Set 1 trim adjust.	1.000
	-100.000100.000	Multiplier for trimming factor.	1 = 1
40.56	Set 1 trim source	Selects the reference to be trimmed.	PID output
	PID ref	PID setpoint.	1

No.	Name/Value	Description	Def/FbEq16	
	PID output	PID controller output.	2	
40.57	PID set1/set2 selection	Selects the source that determines whether process PID parameter set 1 (parameters 40.0740.50) or set 2 (group 41 Process PID set 2) is used.	PID set 1	
	PID set 1	0. Process PID parameter set 1 in use.	0	
	PID set 2	1. Process PID parameter set 2 in use.	1	
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2	
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3	
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4	
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5	
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6	
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7	
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 280).	18	
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 280).	19	
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 280).	20	
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 273).	21	
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 273).	22	
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 273).	23	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-	
40.58	Set 1 increase prevention	Activates increase prevention of PID integration term for PID set 1.	No	
	No	Increase prevention not in use.	0	
	Limiting	The PID integration term is not increased.	1	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-	
40.59	Set 1 decrease prevention	Activates decrease prevention of PID integration term for PID set 1.	No	
	No	Decrease prevention not in use.	0	
	Limiting	The PID integration term is not decreased.	1	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-	
40.60	Set 1 PID activation source	Selects the source of process PID set 1 activation.	On	
	Off	Set 1 PID activation source is Off.	0	
	On	Set 1 PID activation source is On.	1	
	Follow Ext1/Ext2 selection	Selection follows the value of parameter <u>19.11 Ext1/Ext2</u> selection. By changing to Ext2 control location, Process PID set 1 is activated.	2	
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	3	
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	4	
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	5	
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	6	
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	7	
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	8	
	Other [bit]	Source selection (see Terms and abbreviations on page 161).	-	

No.	Name/Value	Description	Def/FbEq16	
40.61	Setpoint scaling actual	Actual setpoint scaling. See parameter 40.14 Set 1 setpoint scaling.	0.00	
	-200000.00 200000.00 PID customer units	Scaling.	1 = 1 PID customer unit	
40.62	PID internal setpoint actual	Displays the value of the internal setpoint. See the control chain diagram on page 502. This parameter is read-only.	-	
	-200000.00 200000.00 %	Process PID internal setpoint.	1 = 1	
40.65	Trim auto connection	Enable the PID trim auto connection and connects the 40.05 Process PID trim output act to either speed, torque or frequency chains based on the trim selection parameter 40.52 Set 1 trim selection or 41.52 Set 2 trim selection.	Disable	
	Disable	Trim auto connection disabled.	0	
	Enable	Trim auto connection enabled.	1	
40.79	Set 1 units	Selects the unit for process PID setpoint, feedback and deviation.	°C	
	User text	User text	0	
	%	%	1	
	bar	bar	2	
	kPa	kPa	3	
	Pa	Pa	4	
	psi	psi	5	
	CFM	CFM	6	
	inH ₂ O	inH ₂ O	7	
	°C	°C	8	
	°F	۴	9	
	mbar	mbar	10	
	m ³ /h	m ³ /h	11	
	dm ³ /h	dm ³ /h	12	
	l/s	l/s	13	
	l/min	l/min	14	
	l/h	l/h	15	
	m ³ /s	m ³ /s	16	
	m ³ /m	m ³ /m	17	
	km ³ /h	km ³ /h	18	
	gal/s	gal/s	19	
	ft ³ /s	ft ³ /s	20	
	ft ³ /m	ft ³ /m	21	
	ft ³ /h	ft ³ /h	22	
	ppm	ppm	23	
	inHg	inHg	24	
	kCFM	kCFM	25	

No.	Name/Value	Description	Def/FbEq16
	inWC	inWC	26
	GPM	GPM	27
	gal/m	gal/m	28
	in wg	in wg	29
	MPa	MPa	30
	ftWC	ftWC	31
40.80	Set 1 PID output min source	Selects the source for set 1 PID output minimum.	Set1 output min
	None	None.	0
	Set1 output min	40.36 Set 1 output min.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
40.81	Set 1 PID output max source	Selects the source for set 1 PID output maximum.	Set1 output max
	None	None.	0
	Set1 output max	40.37 Set 1 output max.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
40.89	Set 1 setpoint multiplier	Defines the multiplier with which the result of the function specified by parameter 40.18 Set 1 setpoint function is multiplied.	1.00
	-200000.00	Multiplier.	-
	200000.00		
40.90	Set 1 feedback multiplier	Defines the multiplier used in formulas of parameter 40.10 Set 1 feedback function.	1.00
	-200000.00 200000.00	Multiplier.	1 = 1
40.91	Feedback data storage	Storage parameter for receiving a process feedback value e.g. through the embedded fieldbus interface. The value can be sent to the drive as Modbus I/O data. Set the target selection parameter of that particular data (58.10158.114) to Feedback data storage. In 40.08 Set 1 feedback 1 source (or 40.09 Set 1 feedback 2 source), select Feedback data storage.	0.00
	-327.68327.67	Storage parameter for process feedback.	100 = 1
40.92	Setpoint data storage	Storage parameter for receiving a process setpoint value e.g. through the embedded fieldbus interface. The value can be sent to the drive as Modbus I/O data. Set the target selection parameter of that particular data (58.10158.114)) to Setpoint data storage. In 40.16 Set 1 setpoint 1 source (or 40.17 Set 1 setpoint 2 source), select Setpoint data storage.	0.00
	-327.68327.67	Storage parameter for process setpoint.	100 = 1
40.96	Process PID output%	Percentage scaled signal of parameter 40.01 Process PID feedback actual. Correct later.	0.00
	-100.00100.00%	Percentage.	1=1
40.97	Process PID feedback%	Percentage scaled signal of parameter 40.02 Process PID feedback actual.	0.00
	-100.00100.00%	Percentage.	1=1

No.	Name/Value	Description	Def/FbEq16
40.98	Process PID setpoint%	Percentage scaled signal of parameter 40.03 Process PID setpoint actual.	0.00
	-100.00100.00%	Percentage.	1=1
40.99	Process PID deviation%	Percentage scaled signal of parameter 40.04 Process PID deviation actual.	0.00
	-100.00100.00%	Percentage.	1=1
41 Pro	ocess PID set 2	A second set of parameter values for process PID control. The selection between this set and first set (parameter group 40 Process PID set 1) is made by parameter 40.57 PID set1/set2 selection. See also parameters 40.0140.06, and the control chain diagrams on pages 499 and 502.	
41.08	Set 2 feedback 1 source	See parameter 40.08 Set 1 feedback 1 source.	AI2 percent
41.09	Set 2 feedback 2 source	See parameter 40.09 Set 1 feedback 2 source.	Not selected
41.10	Set 2 feedback function	See parameter 40.10 Set 1 feedback function.	In1
41.11	Set 2 feedback filter time	See parameter 40.11 Set 1 feedback filter time.	0.000 s
41.14	Set 2 setpoint scaling	See parameter 40.14 Set 2 setpoint scaling.	0.00
41.15	Set 2 output scaling	See parameter 40.15 Set 2 output scaling.	0.00
41.16	Set 2 setpoint 1 source	See parameter 40.16 Set 1 setpoint 1 source.	Al1 percent
41.17	Set 2 setpoint 2 source	See parameter 40.17 Set 1 setpoint 2 source.	Not selected
41.18	Set 2 setpoint function	See parameter 40.18 Set 1 setpoint function.	In1
41.19	Set 2 internal setpoint sel1	See parameter 40.19 Set 1 internal setpoint sel1.	Not selected
41.20	Set 2 internal setpoint sel2	See parameter 40.20 Set 1 internal setpoint sel2.	Not selected
41.21	Set 2 internal setpoint 1	See parameter 40.21 Set 1 internal setpoint 1.	0.00
41.22	Set 2 internal setpoint 2	See parameter 40.22 Set 1 internal setpoint 2.	0.00
41.23	Set 2 internal setpoint 3	See parameter 40.23 Set 1 internal setpoint 3.	0.00
41.24	Set 2 internal setpoint 0	See parameter 40.24 Set 1 internal setpoint 0.	0.00
41.26	Set 2 setpoint min	See parameter 40.26 Set 1 setpoint min.	0.00
41.27	Set 2 setpoint max	See parameter 40.27 Set 1 setpoint max.	200000.00
41.28	Set 2 setpoint increase time	See parameter 40.28 Set 1 setpoint increase time.	0.0 s
41.29	Set 2 setpoint decrease time	See parameter 40.29 Set 1 setpoint decrease time.	0.0 s

No.	Name/Value	ame/Value Description		
41.30	Set 2 setpoint freeze enable	See parameter 40.30 Set 1 setpoint freeze enable.	Not selected	
41.31	Set 2 deviation inversion	See parameter 40.31 Set 1 deviation inversion.	Not inverted (Ref - Fbk)	
41.32	Set 2 gain	See parameter 40.32 Set 1 gain.	1.00	
41.33	Set 2 integration time	See parameter 40.33 Set 1 integration time.	60.0 s	
41.34	Set 2 derivation time	See parameter 40.34 Set 1 derivation time.	0.000 s	
41.35	Set 2 derivation filter time	See parameter 40.35 Set 1 derivation filter time.	0.0 s	
41.36	Set 2 output min	See parameter 40.36 Set 1 output min.	0.0	
41.37	Set 2 output max	See parameter 40.37 Set 1 output max.	100.0	
41.38	Set 2 output freeze	See parameter 40.38 Set 1 output freeze.	Not selected	
41.39	Set 2 deadband range	See parameter 40.39 Set 1 deadband range.	0.00	
41.40	Set 2 deadband delay	See parameter 40.40 Set 1 deadband delay.	0.0	
41.43	Set 2 sleep level	See parameter 40.43 Set 1 sleep level.	0.0	
41.44	Set 2 sleep delay	See parameter 40.44 Set 1 sleep delay.	60.0 s	
41.45	Set 2 sleep boost time	See parameter 40.45 Set 1 sleep boost time.	0.0 s	
41.46	Set 2 sleep boost step	See parameter 40.46 Set 1 sleep boost step.	0.00	
41.47	Set 2 wake-up deviation	See parameter 40.47 Set 1 wake-up deviation.	0.00	
41.48	Set 2 wake-up delay	See parameter 40.48 Set 1 wake-up delay.	0.50 s	
41.49	Set 2 tracking mode	See parameter 40.49 Set 1 tracking mode.	Not selected	
41.50	Set 2 tracking ref selection	See parameter 40.50 Set 1 tracking ref selection.	Not selected	
41.51	Set 2 trim mode	See parameter 40.51 Set 1 trim mode.	Off	
41.52	Set 2 trim selection	See parameter 40.52 Set 1 trim selection.	Speed	
41.53	Set 2 trimmed ref pointer	See parameter 40.53 Set 1 trimmed ref pointer.	Not selected	
41.54	Set 2 trim mix	See parameter 40.54 Set 1 trim mix.	0.000	
41.55	Set 2 trim adjust	See parameter 40.55 Set 1 trim adjust.	1.000	
41.56	Set 2 trim source	See parameter 40.56 Set 1 trim source.	PID output	
41.58	Set 2 increase prevention	See parameter 40.58 Set 1 increase prevention.	Νο	
41.59	Set 2 decrease prevention	See parameter 40.59 Set 1 decrease prevention.	Νο	
41.60	Set 2 PID activation source	See parameter 40.60 Set 1 PID activation source.	On	
41.79	Set 2 units	See parameter 40.79 Set 1 units.	°C	
41.80	Set 1 PID output min source	Selects the source for set 2 PID output minimum.	Set2 output min	

No.	Name/Value	Description	Def/FbEq16
	None	None.	0
	Set2 output min	41.36 Set 2 output min.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
41.81	Set 1 PID output max source	Selects the source for set 2 PID output maximum.	Set2 output max
	None	None.	0
	Set2 output max	41.37 Set 2 output max.	1
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
41.89	Set 2 setpoint multiplier	See parameter 40.89 Set 1 feedback multiplier	1.00
41.90	Set 2 feedback multiplier	Defines the multiplier used in formulas of parameter <i>41.10</i> Set 2 feedback function.	1.00
	-100000.00 100000.00	Multiplier.	1 = 1

43 Bra	ke chopper	Settings for the internal brake chopper. This parameter group is applicable only for frames R0R3	
43.01	Braking resistor temperature	Displays the estimated temperature of the brake resistor, or how close the brake resistor is to being too hot. The value is given in percent where 100% is the eventual temperature the resistor would reach when loaded long enough with its rated maximum load capacity (<i>43.09 Brake</i> <i>resistor Pmax cont</i>). The temperature calculation is based on the values of parameters <i>43.08</i> , <i>43.09</i> and <i>43.10</i> , and on the assumption that the resistor is installed as instructed by the manufacturer (ie it cools down as expected). This parameter is read-only.	0.0
	0.0120.0%	Estimated brake resistor temperature.	1 = 1%
43.06	Brake chopper enable	 Enables brake chopper control and selects the brake resistor overload protection method (calculation or measurement). Note: Before enabling brake chopper control, ensure that a brake resistor is connected overvoltage control is switched off (parameter 30.30 Overvoltage control) the supply voltage range (parameter 95.01 Supply voltage) has been selected correctly. 	Disabled
	Disabled	Brake chopper control disabled.	0
	Enabled with thermal model	Brake chopper control enabled with brake resistor protection based on the thermal model. If you select this, you must also specify the values needed by the model, ie. parameters 43.08 43.12. See the resistor data sheet.	1
	Enabled without thermal model	Brake chopper control enabled without resistor overload protection based on the thermal model. This setting can be used, for example, if the resistor is equipped with a thermal switch that is wired to open the main contactor of the drive if the resistor overheats. For more information, see chapter <i>Resistor braking</i> in the <i>Hardware manual</i> .	2

No.	Name/Value	Description	Def/FbEq16
	Overvoltage peak protection	 Brake chopper control enabled in an overvoltage condition. This setting is intended for situations where the braking chopper is not needed for runtime operation, ie. to dissipate the inertial energy of the motor, the motor is able to store a considerable amount magnetic energy in its windings, and the motor might, deliberately or inadvertently, be stopped by coasting. In such a situation, the motor would potentially discharge enough magnetic energy towards the drive to cause damage. To protect the drive, the brake chopper can be used with a small resistor dimensioned merely to handle the magnetic energy (not the inertial energy) of the motor. With this setting, the brake chopper is activated only whenever the DC voltage exceeds the overvoltage limit. During normal use, the brake chopper is not operating. 	3
43.07	Brake chopper runtime enable	Selects the source for quick brake chopper on/off control. 0 = Brake chopper IGBT pulses are cut off 1 = Normal brake chopper IGBT modulation allowed. This parameter can be used to enable chopper operation only when the supply is missing from a drive with a regenerative supply unit.	On
	Off	0.	0
	On	1.	1
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
43.08	Brake resistor thermal tc	Defines the thermal time constant for the brake resistor thermal model.	0 s
	010000 s	Brake resistor thermal time constant, ie the rated time to achieve 63% temperature.	1 = 1 s
43.09	Brake resistor Pmax cont	Defines the maximum continuous load of the brake resistor that will eventually raise the resistor temperature to the maximum allowed value (= continuous heat dissipation capacity of the resistor in kW) but not above it. The value is used in the resistor overload protection based on the thermal model. See parameter 43.06 Brake chopper enable and the data sheet of the brake resistor used.	0.00 kW
	0.00 10000.00 kW	Maximum continuous load of the brake resistor.	1 = 1 kW
43.10	Brake resistance	Defines the resistance value of the brake resistor. The value is used for the brake resistor protection based on the thermal model. See parameter <i>43.06 Brake chopper enable</i> .	0.0 ohm
	0.01000.0 ohm	Brake resistor resistance value.	1 = 1 ohm
43.11	Brake resistor fault limit	Selects the fault limit for the brake resistor protection based on the thermal model. See parameter 43.06 Brake chopper enable. When the limit is exceeded, the drive trips on fault 7183 BR excess temperature. The value is given in percent of the temperature the resistor reaches when loaded with the power defined by parameter 43.09 Brake resistor Pmax cont.	105%
	0150%	Brake resistor temperature fault limit.	1 = 1%

No.	Name/\	/alue	Descri	ption	Def/FbEq16
43.12	Brake resistor warning limit		based choppe genera The va reache	s the warning limit for the brake resistor protection on the thermal model. See parameter 43.06 Brake or enable. When the limit is exceeded, the drive tes a A793 BR excess temperature warning. Ilue is given in percent of the temperature the resistor is when loaded with the power defined by parameter Brake resistor Pmax cont.	95%
	0150	%	Brake	resistor temperature warning limit.	1 = 1%
44 Me	chanica	l brake	Config	uration of mechanical brake control.	
contro)		See als	so section Mechanical brake control (page 60).	
44.01	Brake c	ontrol status		ys the mechanical brake control status word. arameter is read-only.	0b0000
	Bit	Name		Information	
	0	Open comr		Close/open command to brake actuator (0 = close, 1 Connect this bit to desired output.	= open).
	1	Opening to request	•	1 = Opening torque requested from drive logic.	
	2	Hold stoppe request		1 = Hold requested from drive logic	
	3	Ramp to sto	opped	1 = Ramping down to zero speed requested from drive logic	
	4	Enabled		1 = Brake control is enabled	
	5 6	Closed		1 = Brake control logic in <i>BRAKE CLOSED</i> state 1 = Brake control logic in <i>BRAKE OPENING</i> state	
	7	Opening Open		1 = Brake control logic in <i>BRAKE OPEN</i> state	
	8	Closing		1 = Brake control logic in <i>BRAKE CLOSING</i> state	
	915	Reserved			
	060000	061111	Maaba	nical brake control status word.	1 = 1
11.00	0b00000b1111 Brake control				
44.06	enable ac 0 =		activate 0 = Bra	es/deactivates (or selects a source that es/deactivates) the mechanical brake control logic. ake control inactive ake control active	Not selected
	Not sele	ected	0.		0
	Selecte	d	1.		1
	DI1		Digital	input DI1 (10.02 DI delayed status, bit 0).	2
	DI2		Digital	input DI2 (10.02 DI delayed status, bit 1).	3
	DI3		Digital	input DI3 (10.02 DI delayed status, bit 2).	4
	DI4		Digital	input DI4 (10.02 DI delayed status, bit 3).	5
	DI5		Digital	input DI5 (10.02 DI delayed status, bit 4).	6
	DI6		Digital	input DI6 (10.02 DI delayed status, bit 5).	7
	Timed f	unction 1	Bit 0 of	f 34.01 Timed functions status (see page 280).	18
	Timed f	unction 2	Bit 1 of	34.01 Timed functions status (see page 280).	19
	Timed f	unction 3	Bit 2 of	f 34.01 Timed functions status (see page 280).	20
	Supervi	sion 1	Bit 0 of	f 32.01 Supervision status (see page 273).	24
	Supervi	sion 2		32.01 Supervision status (see page 273).	25
		sion 3		32.01 Supervision status (see page 273).	26

No.	Name/Value	Description	Def/FbEq16
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
44.08	Brake open delay	Defines the brake open delay, ie. the delay between the internal open brake command and the release of motor speed control. The delay timer starts when the drive has magnetized the motor. Simultaneously with the timer start, the brake control logic energizes the brake control output and the brake starts to open. Set this parameter to the value of mechanical opening delay specified by the brake manufacturer.	0.00 s
	0.005.00 s	Brake open delay.	100 = 1 s
44.13	Brake close delay	Specifies a delay between a close command (that is, when the brake control output is de-energized) and when the drive stops modulating. This is to keep the motor live and under control until the brake actually closes. Set this parameter equal to the value specified by the brake manufacturer as the mechanical wake-up time of the brake.	0.00 s
	0.0060.00 s	Brake close delay.	100 = 1 s
44.14	Brake close level	Defines the brake close speed as an absolute value. After motor speed has decelerated to this level, a close command is given.	100.00 rpm
	0.001000.00 rpm	Brake close speed.	See par. 46.01
45 Ene	ergy efficiency	Settings for the energy saving calculators.	
		See also section <i>Energy saving calculators</i> (page 93).	
45.01	Saved GW hours	Energy saved in GWh compared to direct-on-line motor connection. This parameter is incremented when 45.02 Saved MW hours rolls over. This parameter is read-only (see parameter 45.21 Energy calculations reset).	0
	065535 GWh	Energy savings in GWh.	1 = 1 GWh
45.02	Saved MW hours	Energy saved in MWh compared to direct-on-line motor connection. This parameter is incremented when 45.03 Saved kW hours rolls over. When this parameter rolls over, parameter 45.01 Saved GW hours is incremented. This parameter is read-only (see parameter 45.21 Energy calculations reset).	0
	0999 MWh	Energy savings in MWh.	1 = 1 MWh
45.03	Saved kW hours	Energy saved in kWh compared to direct-on-line motor connection. If the internal brake chopper of the drive is enabled, all energy fed by the motor to the drive is assumed to be converted into heat, but the calculation still records savings made by controlling the speed. If the chopper is disabled, then regenerated energy from the motor is also recorded here. When this parameter rolls over, parameter <i>45.02 Saved MW hours</i> is incremented. This parameter is read-only (see parameter <i>45.21 Energy calculations reset</i>).	0.0
	0.0999.9 kWh	Energy savings in kWh.	10 = 1 kWh
		·	

No.	Name/Value	Description	Def/FbEq16
45.04	Saved energy	Energy saved in kWh compared to direct-on-line motor connection. If the internal brake chopper of the drive is enabled, all energy fed by the motor to the drive is assumed to be converted into heat. This parameter is read-only (see parameter 45.21 Energy calculations reset).	0.0
	0.0214748364.0 kWh	Energy savings in kWh.	1 = 1 kWh
45.05	Saved money x1000	Monetary savings in thousands compared to direct-on-line motor connection. This parameter is incremented when 45.06 Saved money rolls over. This parameter is read-only (see parameter 45.21 Energy calculations reset).	0 INR
	04294967295 thousands	Monetary savings in thousands of units.	1 = 1 unit
45.06	Saved money	Monetary savings compared to direct-on-line motor connection. This value is a calculated by multiplying the saved energy in kWh by the currently active energy tariff (45.14 Tariff selection). When this parameter rolls over, parameter 45.05 Saved money x1000 is incremented. This parameter is read-only (see parameter 45.21 Energy calculations reset).	0.00 INR
	0.00999.99 units	Monetary savings.	1 = 1 unit
45.07	Saved amount	Monetary savings compared to direct-on-line motor connection. This value is a calculated by multiplying the saved energy in kWh by the currently active energy tariff (45.14 Tariff selection). This parameter is read-only (see parameter 45.21 Energy calculations reset).	0.00 INR
	0.00… 21474830.08 units	Monetary savings.	1 = 1 unit
45.08	CO2 reduction in kilotons	Reduction in CO_2 emissions in metric kilotons compared to direct-on-line motor connection. This value is incremented when parameter 45.09 CO2 reduction in tons rolls over. This parameter is read-only (see parameter 45.21 Energy calculations reset).	0
	0…65535 metric kilotons	Reduction in CO ₂ emissions in metric kilotons.	1 = 1 metric kiloton
45.09	CO2 reduction in tons	Reduction in CO ₂ emissions in metric tons compared to direct-on-line motor connection. This value is calculated by multiplying the saved energy in MWh by the value of parameter 45.18 CO2 conversion factor (by default, 0.5 metric tons/MWh). When this parameter rolls over, parameter 45.08 CO2 reduction in kilotons is incremented. This parameter is read-only (see parameter 45.21 Energy calculations reset).	0.0
	0.0999.9 metric tons	Reduction in CO_2 emissions in metric tons.	1 = 1 metric ton

No.	Name/Value	Description	Def/FbEq16
45.10	Total saved CO2	Reduction in CO_2 emissions in metric tons compared to direct-on-line motor connection. This value is calculated by multiplying the saved energy in MWh by the value of parameter 45.18 CO2 conversion factor (by default, 0.5 metric tons/MWh).	0.0
		This parameter is read-only (see parameter 45.21 Energy calculations reset).	
	0.0214748300.8 metric tons	Reduction in CO ₂ emissions in metric tons.	1 = 1 metric ton
45.11	Energy optimizer	Enables/disables the energy optimization function. The function optimizes the motor flux so that total energy consumption and motor noise level are reduced when the drive operates below the nominal load. The total efficiency (motor and drive) can be improved by 120% depending on load torque and speed.	Disable
	Disable	Energy optimization disabled.	0
	Enable	Energy optimization enabled.	1
45.12	Energy tariff 1	Defines energy tariff 1 (price of energy per kWh). Depending on the setting of parameter 45.14 Tariff selection, either this value or 45.13 Energy tariff 2 is used for reference when monetary savings are calculated. Note: Tariffs are read only at the instant of selection, and are not applied retroactively.	5.000 INR
	0.000… 4294966.296 units	Energy tariff 1.	-
45.13	Energy tariff 2	Defines energy tariff 2 (price of energy per kWh). See parameter 45.12 Energy tariff 1.	6.000 INR
	0.000… 4294966.296 units	Energy tariff 2.	-
45.14	Tariff selection	Selects (or defines a source that selects) which pre-defined energy tariff is used. 0 = 45.12 Energy tariff 1 1 = 45.13 Energy tariff 2	Energy tariff 1
	Energy tariff 1	0.	0
	Energy tariff 2	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
45.17	Tariff currency unit	Selects the currency unit based on which the values of parameters 45.05, 45.06, 45.07, 45.12, 45.13 are displayed.	Local currency
	Local currency	Displays the values of parameters 45.05, 45.06, 45.07, 45.12, 45.13 in Indian rupee.	100
	EUR	Displays the values of parameters 45.05, 45.06, 45.07, 45.12, 45.13 in euro.	101
	USD	Displays the values of parameters <i>45.05</i> , <i>45.06</i> , <i>45.07</i> , <i>45.12</i> , <i>45.13</i> in US dollars.	102

No.	Name/Value	Description	Def/FbEq16
45.18	CO2 conversion factor	Defines a factor for conversion of saved energy into CO_2 emissions (kg/kWh or tn/MWh).	0.500 tn/MWh (metric ton)
	0.00065.535 tn/MWh	Factor for conversion of saved energy into CO_2 emissions.	1 = 1 tn/MWh
45.19	Comparison power	Actual power that the motor absorbs when connected direct- on-line and operating the application. The value is used for reference when energy savings are calculated. Note: The accuracy of the energy savings calculation is directly dependent on the accuracy of this value. If nothing is entered here, then the nominal motor power is used by the calculation, but that may inflate the energy savings reported as many motors do not absorb nameplate power.	0.00 kW
	0.0010000000.00 kW	Motor power.	1 = 1 kW
45.21	Energy calculations reset	Resets the savings counter parameters 45.0145.10.	Done
	Done	Reset not requested (normal operation), or reset complete.	0
	Reset	Reset the savings counter parameters. The value reverts automatically to <i>Done</i> .	1
45.24	Hourly peak power value	Value of the peak power during the last hour, that is, the most recent 60 minutes after the drive has been powered up. The parameter is updated once every 10 minutes unless the hourly peak is found in the most recent 10 minutes. In that case, the values is shown immediately.	0.00 kW
	-3000.00 3000.00 kW	Peak power value.	10 = 1 kW
45.25	Hourly peak power time	Time of the peak power value during the last hour.	00:00:00
		Time.	N/A
45.26	Hourly total energy (resettable)	Total energy consumption during the last hour, that is, the most recent 60 minutes. You can reset the value by setting it to zero.	0.00 kWh
	-3000.00 3000.00 kWh	Total energy.	10 = 1 kWh
45.27	Daily peak power value (resettable)	Value of the peak power since midnight of the present day. You can reset the value by setting it to zero.	0.00 kW
	-3000.00 3000.00 kW	Peak power value.	10 = 1 kW
45.28	Daily peak power time	Time of the peak power since midnight of the present day.	00:00:00
		Time.	N/A
45.29	Daily total energy (resettable)	Total energy consumption since midnight of the present day. You can reset the value by setting it to zero.	0.00 kWh
	-30000.00 30000.00 kWh	Total energy.	1 = 1 kWh
45.30	Last day total energy	Total energy consumption during the previous day, that is, between midnight of the previous day and midnight of the present day	0.00 kWh
	-30000.00 30000.00 kWh	Total energy.	1 = 1 kWh

No.	Name/Value	Description	Def/FbEq16
45.31	Monthly peak power value (resettable)	Value of the peak power during the present month, that is, since midnight of the first day of the present month. You can reset the value by setting it to zero.	0.00 kW
	-3000.00 3000.00 kW	Peak power value.	10 = 1 kW
45.32	Monthly peak power date	Date of the peak power during the present month.	1/1/1980
	1/1/19806/5/2159	Date.	N/A
45.33	Monthly peak power time	Time of the peak power during the present month.	00:00:00
		Time.	N/A
45.34	Monthly total energy (resettable)	Total energy consumption from the beginning of the present month. You can reset the value by setting it to zero.	0.00 kWh
	-1000000.00 1000000.00 kWh	Total energy.	0.01 = 1 kWh
45.35	Last month total energy	Total energy consumption during the previous month, that is, between midnight of the first day or the previous month and midnight of the first day of the present month.	0.00 kWh
	-1000000.00 1000000.00 kWh		0.01 = 1 kWh
45.36	Lifetime peak power value	Value of the peak power over the drive lifetime.	0.00 kW
	-3000.00 3000.00 kW	Peak power value.	10 = 1 kW
45.37	Lifetime peak power date	Date of the peak power over the drive lifetime.	1/1/1980
		Date.	N/A
45.38	Lifetime peak power time	Time of the peak power over the drive lifetime.	00:00:00
		Time.	N/A
46 Monitoring/scaling settings		Speed supervision settings; actual signal filtering; general scaling settings.	
46.01	Speed scaling	Defines the maximum speed value used to define the acceleration ramp rate and the initial speed value used to define the deceleration ramp rate (see parameter group 23 <i>Speed reference ramp</i>). The speed acceleration and deceleration ramp times are therefore related to this value (not to parameter <i>30.12 Maximum speed</i>). Also defines the 16-bit scaling of speed-related parameters. The value of this parameter corresponds to 20000 in e.g. fieldbus communication.	1500.00 rpm
i	0.1030000.00	Acceleration/deceleration terminal/initial speed.	1 = 1 rpm

rpm

No.	Name/Value	Description	Def/FbEq16
46.02	Frequency scaling	Defines the maximum frequency value used to define the acceleration ramp rate and the initial frequency value used to define deceleration ramp rate (see parameter group 28 <i>Frequency reference chain</i>). The frequency acceleration and deceleration ramp times are therefore related to this value (not to parameter 30.14 <i>Maximum frequency</i>). Also defines the 16-bit scaling of frequency-related parameters. The value of this parameter corresponds to 20000 in e.g. fieldbus communication.	50.00 Hz
	0.101000.00 Hz	Acceleration/deceleration terminal/initial frequency.	10 = 1 Hz
46.03	Torque scaling	Defines the 16-bit scaling of torque parameters. The value of this parameter (in percent of nominal motor torque) corresponds to 10000 in e.g. fieldbus communication.	100.0%
	0.11000.0%	Torque corresponding to 10000 on fieldbus.	10 = 1%
46.04	Power scaling	Defines the output power value that corresponds to 10000 in e.g. fieldbus communication. The unit is selected by parameter 96.16 Unit selection.	1000.00 kW
	0.1030000.00 kW or hp	Power corresponding to 10000 on fieldbus.	1 = 1 unit
46.05	Current scaling	Defines the 16-bit scaling of current parameters. The value of this parameter corresponds to 10000 in fieldbus communication.	10000 A
	030000 A		
46.06	Speed ref zero scaling	Defines a speed corresponding to a zero reference received from fieldbus (either the embedded fieldbus interface, or interface FBAA). For example, with a setting of 500, the fieldbus reference range of 020000 would correspond to a speed of 500[46.01] rpm. Note: This parameter is effective only with the ABB Drives communication profile.	0.00 rpm
	0.00 30000.00 rpm	Speed corresponding to minimum fieldbus reference.	1 = 1 rpm
46.07	Frequency ref zero scaling	Defines a frequency corresponding to a zero reference received from fieldbus (either the embedded fieldbus interface, or interface FBA A or FBA B). For example, with a setting of 30, the fieldbus reference range of 020000 would correspond to a speed of 30[46.02] Hz. Note: This parameter is effective only with the ABB Drives communication profile.	0.00 Hz
	0.00 1000.00 Hz	Speed corresponding to minimum fieldbus reference.	10 = 1 Hz
46.11	Filter time motor speed	Defines a filter time for signals 01.01 Motor speed used and 01.02 Motor speed estimated.	500 ms
	220000 ms	Motor speed signal filter time.	1 = 1 ms
46.12	Filter time output frequency	Defines a filter time for signal 01.06 Output frequency.	500 ms
	220000 ms	Output frequency signal filter time.	1 = 1 ms
46.13	Filter time motor torque	Defines a filter time for signal 01.10 Motor torque.	100 ms
	220000 ms	Motor torque signal filter time.	1 = 1 ms
46.14	Filter time power	Defines a filter time for signal 01.14 Output power.	100 ms
	220000 ms	Output power signal filter time.	1 = 1 ms

No.	Name/Value	Description	Def/FbEq16
46.21	At speed hysteresis	Defines the "at setpoint" limits for speed control of the drive. When the difference between speed reference (22.87 Speed reference act 7) and the speed feedback (24.02 Used speed feedback) is smaller than 46.21 At speed hysteresis, the drive is considered to be "at setpoint". This is indicated by bit 8 of 06.11 Main status word. 24.02 (rpm) Drive at setpoint (06.11 bit 8 = 1) Drive at setpoint 0 rpm	50.00 rpm
	0.0030000.00 rpm	Limit for "at setpoint" indication in speed control.	See par. 46.01
46.22	At frequency hysteresis	Defines the "at setpoint" limits for frequency control of the drive. When the absolute difference between reference (28.96 Frequency ref ramp input) and actual frequency (01.06 Output frequency) is smaller than 46.22 At frequency hysteresis, the drive is considered to be "at setpoint". This is indicated by bit 8 of 06.11 Main status word. 01.06 (Hz) Drive at setpoint (06.11 bit 8 = 1) Drive at setpoint 0 Hz	2.00 Hz
	0.001000.00 Hz	Limit for "at setpoint" indication in frequency control.	See par. 46.02
46.31	6.31 Above speed limit Defines the trigger level for "above limit" indication in spee control. When actual speed exceeds the limit, bit 10 of 06 Drive status word 2 is set.		1500.00 rpm
	0.0030000.00 rpm	"Above limit" indication trigger level for speed control.	See par. 46.01
46.32	Above frequency limit	Defines the trigger level for "above limit" indication in frequency control. When actual frequency exceeds the limit, bit 10 of <i>06.17 Drive status word 2</i> is set.	50.00 Hz
	0.001000.00 Hz	"Above limit" indication trigger level for frequency control.	See par. 46.02

No.	Name/Value	Description	Def/FbEq16
46.33	Above torque limit	Defines the trigger level for "above limit" indication in torque control. When actual torque exceeds the limit, bit 10 of 06.17 <i>Drive status word 2</i> is set.	300.0%
	0.01600.0%	"Above limit" indication trigger level for torque control.	See par. 46.03
46.41	kWh pulse scaling	Defines the trigger level for the "kWh pulse" on for 50 ms. The output of the pulse is bit 9 of 05.22 Diagnostic word 3.	1.000 kWh
	0.001 1000.000 kWh	"kWh pulse" on trigger level.	1 = 1 kWh
46.43	Power decimals	Defines the number of decimal places of power-related parameters.	2
	03	Number of decimal places of power parameters.	1 = 1
46.44	Current decimals	Defines the number of decimal places of current-related parameters.	1
	03	Number of decimal places of current parameters.	1 = 1
47 Dat	ta storage	Data storage parameters that can be written to and read from using other parameters' source and target settings. Note that there are different storage parameters for different data types. See also section <i>Data storage parameters</i> (page 96).	
47.01	Data storage 1 real32	Data storage parameter 1.	0.000
	-2147483.000 2147483.000	32-bit data.	-
47.02	Data storage 2 real32	Data storage parameter 2.	0.000
	-2147483.000 2147483.000	32-bit data.	-
47.03	Data storage 3 real32	Data storage parameter 3.	0.000
	-2147483.000 2147483.000	32-bit data.	-
47.04	Data storage 4 real32	Data storage parameter 4.	0.000
	-2147483.000 2147483.000	32-bit data.	-
47.11	Data storage 1 int32	Data storage parameter 9.	0
	-2147483648 2147483647	32-bit data.	-
47.12	Data storage 2 int32	Data storage parameter 10.	0
	-2147483648 2147483647	32-bit data.	-
47.13	Data storage 3 int32	Data storage parameter 11.	0
	-2147483648 2147483647	32-bit data.	-

No.	Name/Value	Description	Def/FbEq16
47.14	Data storage 4 int32	Data storage parameter 12.	0
	-2147483648 2147483647	32-bit data.	-
47.21	Data storage 1 int16	Data storage parameter 17.	0
	-3276832767	16-bit data.	1 = 1
47.22	Data storage 2 int16	Data storage parameter 18.	0
	-3276832767	16-bit data.	1 = 1
47.23	Data storage 3 int16	Data storage parameter 19.	0
	-3276832767	16-bit data.	1 = 1
47.24	Data storage 4 int16	Data storage parameter 20.	0
	-3276832767	16-bit data.	1 = 1

	nel port nunication	Communication settings for the control panel port on the drive.	
49.01	Node ID number	Defines the node ID of the drive. All devices connected to the network must have a unique node ID. Note: For networked drives, it is advisable to reserve ID 1 for spare/replacement drives.	1
	132	Node ID.	1 = 1
49.03	Baud rate	Defines the transfer rate of the link.	115.2 kbps
	38.4 kbps	38.4 kbit/s.	1
	57.6 kbps	57.6 kbit/s.	2
	86.4 kbps	86.4 kbit/s.	3
	115.2 kbps	115.2 kbit/s.	4
	230.4 kbps	230.4 kbit/s.	5
49.04	Communication loss time	Sets a timeout for control panel (or PC tool) communication. If a communication break lasts longer than the timeout, the action specified by parameter 49.05 Communication loss action is taken.	10.0 s
	0.33000.0 s	Panel/PC tool communication timeout.	10 = 1 s
49.05	Communication loss action	Selects how the drive reacts to a control panel (or PC tool) communication break.	Fault
	No action	No action taken.	0
	Fault	Drive trips on 7081 Control panel loss.	1
	Last speed	Drive generates an ATEE Panel loss warning and freezes the speed to the level the drive was operating at. The speed is determined on the basis of actual speed using 850 ms low-pass filtering. WARNING! Make sure that it is safe to continue operation in case of a communication break.	2

No.	Name/Value	Description	Def/FbEq16
	Speed ref safe	Drive generates an ATEE Panel loss warning and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used). WARNING! Make sure that it is safe to continue operation in case of a communication break.	3
49.06	Refresh settings	Applies the settings of parameters 49.0149.05. Note: Refreshing may cause a communication break, so reconnecting the drive may be required.	Done
	Done	Refresh done or not requested.	0
	Configure	Refresh parameters 49.0149.05. The value reverts automatically to <i>Done</i> .	1
49.19	Basic panel home view 1	Selects the parameters that is shown in <i>Home view 1</i> of the Basic panel (ACS-BP-S) when the active external control location is EXT1. Home view 1 is toggled automatically between Home view 4 (parameter 49.01) according to the active external control location EXT1 or EXT2, respectively	Auto
	Auto	01.06 Output frequency (page 164) in scalar control mode, otherwise 01.01 Motor speed used used (page 164).	0
	Motor speed used	01.01 Motor speed used	1
	Output frequency	01.06 Output frequency	3
	Motor current	01.07 Motor current	4
	Motor current% of motor nominal	01.08 Motor current % of motor nom	5
	Motor torque	01.10 Motor torque	6
	DC voltage	01.11 DC voltage	7
	Output power	01.14 Output power	8
	Speed ref ramp in	23.01 Speed ref ramp input	10
	Speed ref ramp out	23.02 Speed ref ramp output	11
	Freq ref used	28.02 Frequency ref ramp output	14
	Process PID out	40.01 Process PID output actual	16
	Temp sensor 1 excitation	The output is used to feed an excitation current to the temperature sensor 1, see parameter 35.11 Temperature 1 source. See also section <i>Motor thermal protection</i> (page 81).	20
	Temp sensor 2 excitation	The output is used to feed an excitation current to the temperature sensor 2, see parameter 35.21 Temperature 2 source. See also section <i>Motor thermal protection</i> (page 81).	21
	Abs motor speed used	01.61 Abs motor speed used	26
	Abs motor speed%	01.62 Abs motor speed %	27
	Abs output frequency	01.63 Abs output frequency	28
	Abs motor torque	01.64 Abs motor torque	30
	Abs output power	01.65 Abs output power	31
	Abs motor shaft power	01.68 Abs motor shaft power	32
	AO1 data storage	13.91 AO1 data storage.	37

No.	Name/Value	Description	Def/FbEq16
	AO2 data storage	13.92 AO2 data storage.	38
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
49.20	Basic panel home view 2	Selects the parameters that is shown in <i>Home view 2</i> of the Basic panel (ACS-BP-S) when the active external control location is EXT1. Home view 2 is toggled automatically between Home view 5 (parameter 49.21) according to the active external control location EXT1 or EXT2, respectively See parameter 49.19 for the other selections than Auto.	Auto
	Auto	01.07 Motor current (page 164).	0
49.21	Basic panel home view 3	Selects the parameters that is shown in <i>Home view 3</i> of the Basic panel (ACS-BP-S) when the active external control location is EXT1. Home view 3 is toggled automatically between Home view 6 (parameter 49.221) according to the active external control location EXT1 or EXT2, respectively See parameter 49.19 for the other selections than Auto.	Auto
	Auto	01.10 Motor torque (page 164)	0
49.21	Basic panel home view 3	Selects the parameters that is shown in <i>Home view 4</i> of the Basic panel (ACS-BP-S) when the active external control location is EXT2. Home view 1 is toggled automatically between Home view 4 (parameter 49.19) according to the active external control location EXT1 or EXT2, respectively. See parameter 49.19 for the other selections than Auto.	Auto
	Auto	Selects the same parameter as selected by parameter 49.19 Basic panel home view 1 for external control location EXT 1.	0
49.21	Basic panel home view 3	Selects the parameters that is shown in <i>Home view 5</i> of the Basic panel (ACS-BP-S) when the active external control location is EXT2. Home view 2 is toggled automatically between Home view 5 (parameter <i>49.20</i>) according to the active external control location EXT1 or EXT2, respectively. See parameter <i>49.19</i> for the other selections than Auto.	Auto
	Auto	Selects the same parameter as selected by parameter 49.20 Basic panel home view 2 for external control location EXT 1.	0
49.221	Basic panel home view 6	Selects the parameters that is shown in <i>Home view 6</i> of the Basic panel (ACS-BP-S) when the active external control location is EXT2. Home view 3 is toggled automatically between Home view 6 (parameter 49.21) according to the active external control location EXT1 or EXT2, respectively. See parameter 49.19 for the other selections than Auto.	Auto
	Auto	Selects the same parameter as selected by parameter 49.21 Basic panel home view 3 for external control location EXT 1.	0

No.	Name/Value	Description	Def/FbEq16
50 Fie (FBA)	ldbus adapter	Fieldbus communication configuration. See also chapter <i>Fieldbus control through a fieldbus adapter</i> (page 471).	
50.01	FBA A enable	Enables/disables communication between the drive and fieldbus adapter A, and specifies the slot the adapter is installed into.	Disable
	Disable	Communication between drive and fieldbus adapter A disabled.	0
	Enable	Communication between drive and fieldbus adapter A enabled. The adapter is in slot 1.	1
50.02	FBA A comm loss func	Selects how the drive reacts upon a fieldbus communication break. The time delay is defined by parameter 50.03 FBA A comm loss t out.	No action
	No action	No action taken.	0
	Fault	Communication break detection active. Upon a communication break, the drive trips on a 7510 FBA A communication fault and coasts to a stop.	1
	Last speed	Communication break detection active. Upon a communication break, the drive generates a warning (A7C1 <i>FBA A communication</i>) and freezes the speed to the level the drive was operating at. The speed is determined on the basis of actual speed using 850 ms low-pass filtering.	2
	Speed ref safe	Communication break detection active. Upon a communication break, the drive generates a warning (A7C1 FBA A communication) and sets the speed to the value defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used). MARNING! Make sure that it is safe to continue operation in case of a communication break.	3
	Fault always	Drive trips on 7510 FBA A communication. This occurs even though no control is expected from the fieldbus.	4
	Warning	Drive generates an A7C1 FBA A communication warning. This occurs even though no control is expected from the fieldbus. Marking! Make sure that it is safe to continue operation in case of a communication break.	5
50.03	FBA A comm loss t out	Defines the time delay before the action defined by parameter 50.02 FBA A comm loss func is taken. Time count starts when the communication link fails to update the message.	0.3 s
	0.36553.5 s	Time delay.	1 = 1 s

No.	Name/Value	Description		Def/FbEq16
50.04	FBA A ref1 type	fieldbus adapter A. The scaling parameters 46.0146.04, dep	Selects the type and scaling of reference 1 received from fieldbus adapter A. The scaling of the reference is defined by parameters <i>46.0146.04</i> , depending on which reference type is selected by this parameter.	
	Speed or frequency	Type and scaling is chosen aut currently active operation mode		0
		Operation mode (see par. 19.01)	Reference 1 type	
		Speed control	Speed	
		Torque control	Speed	
		Frequency control	Frequency	
	Transparent	No scaling is applied.		1
	General	Generic reference without a sp	ecific unit.	2
	Torque	The scaling is defined by parar	meter 46.03 Torque scaling.	3
	Speed	The scaling is defined by parar	meter 46.01 Speed scaling.	4
	Frequency	The scaling is defined by parar	neter 46.02 Frequency scaling.	5
50.05	FBA A ref2 type	Selects the type and scaling of fieldbus adapter A. The scaling parameters 46.0146.04, dep type is selected by this parameters	Speed or frequency	
	Speed or frequency	Type and scaling is chosen aut currently active operation mode	0	
		Operation mode (see par. 19.01)	Reference 2 type	
		Speed control	Torque	
		Torque control	Torque	
		Frequency control	Torque	
	Transparent	No scaling is applied.		1
	General	Generic reference without a sp	ecific unit.	2
	Torque	The scaling is defined by parar	meter 46.03 Torque scaling.	3
	Speed	The scaling is defined by parar	meter 46.01 Speed scaling.	4
	Frequency	The scaling is defined by parar	neter 46.02 Frequency scaling.	5
50.06	FBA A SW sel	Selects the source of the Status word to be sent to the fieldbus network through fieldbus adapter A.		Auto
	Auto	Source of the Status word is ch	nosen automatically.	0
	Transparent mode	transparent source is transmitte	The source selected by parameter 50.09 FBA A SW transparent source is transmitted as the Status word to the fieldbus network through fieldbus adapter A.	

No.	Name/Value	Description		Def/FbEq16
50.07	7 FBA A actual 1 type Selects the type and scaling of actual value 1 transmitted to the fieldbus network through fieldbus adapter A. The scaling of the value is defined by parameters 46.0146.04, depending on which actual value type is selected by this parameter. Speed or frequency Type and scaling is chosen automatically according to the currently active operation mode as follows:		eldbus adapter A. The scaling meters 46.0146.04,	Speed or frequency
				0
		Operation mode (see par. 19.01)	Actual value 1 type	
		Speed control Torque control Frequency control	Speed Frequency	
	Transparent	No scaling is applied.		1
	General	Generic reference without a sp	ecific unit.	2
	Torque	The scaling is defined by parar	meter 46.03 Torque scaling.	3
	Speed	The scaling is defined by parar	meter 46.01 Speed scaling.	4
	Frequency	The scaling is defined by paran	neter 46.02 Frequency scaling.	5
50.08	FBA A actual 2 type	e Selects the type and scaling of actual value 2 transmitted to the fieldbus network through fieldbus adapter A. The scaling of the value is defined by parameters 46.0146.04, depending on which actual value type is selected by this parameter.		Speed or frequency
	Speed or frequency	Type and scaling is chosen aut currently active operation mode	0	
		Operation mode (see par. 19.01)	Actual value 2 type	
		Speed control Torque control	Speed	
		Frequency control	Frequency	
	Transparent	No scaling is applied.		1
	General	Generic reference without a specific unit.		2
	Torque	01.01 Motor speed used is sent is defined by parameter 46.03	t as actual value 2. The scaling	3
	Speed	The scaling is defined by parar	meter 46.01 Speed scaling.	4
	Frequency	The scaling is defined by paran	neter 46.02 Frequency scaling.	5
50.09	FBA A SW transparent source	Selects the source of the fieldbus status word when parameter 50.06 FBA A SW sel is set to Transparent mode.		Not selected
	Not selected	No source selected.	-	
	Other	Source selection (see Terms and	nd abbreviations on page 161).	-
50.10	FBA A act1 transparent source	When parameter 50.07 FBA A Transparent, this parameter sel 1 transmitted to the fieldbus ne A.	Not selected	
	Not selected	No source selected.		-
	Other	Source selection (see Terms and	-	

No.	Name/Value	Description	Def/FbEq16
50.11	FBA A act2 transparent source	When parameter 50.08 FBA A actual 2 type is set to <i>Transparent</i> , this parameter selects the source of actual value 2 transmitted to the fieldbus network through fieldbus adapter A.	Not selected
	Not selected	No source selected.	-
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
50.12	FBA A debug mode	This parameter enables debug mode. Displays raw (unmodified) data received from and sent to fieldbus adapter A in parameters <i>50.1350.18</i> .	Disable
	Disable	Debug mode disabled.	0
	Fast	Debug mode enabled. Cyclical data update is as fast as possible which increases CPU load on the drive.	1
50.13	FBA A control word	Displays the raw (unmodified) control word sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter <i>50.12 FBA A debug mode</i> . This parameter is read-only.	0.0.0.0
	0.0.0.0.0FF.FF.FF .FF	Control word sent by master to fieldbus adapter A.	-
50.14	FBA A reference 1	Displays raw (unmodified) reference REF1 sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter <i>50.12 FBA A debug mode</i> . This parameter is read-only.	0
	-2147483648 2147483647	Raw REF1 sent by master to fieldbus adapter A.	0
50.15	FBA A reference 2	Displays raw (unmodified) reference REF2 sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter <i>50.12 FBA A debug mode</i> . This parameter is read-only.	0
	-2147483648 2147483647	Raw REF2 sent by master to fieldbus adapter A.	-
50.16	FBA A status word	Displays the raw (unmodified) status word sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter 50.12 FBA A debug mode. This parameter is read-only.	0.0.0.0
	0.0.0.0.0FF.FF.FF .FF	Status word sent by fieldbus adapter A to master.	-
50.17	FBA A actual value 1	Displays raw (unmodified) actual value ACT1 sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter <i>50.12 FBA A debug mode</i> . This parameter is read-only.	0
	-2147483648 2147483647	Raw ACT1 sent by fieldbus adapter A to master.	-
50.18	FBA A actual value 2	Displays raw (unmodified) actual value ACT2 sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter <i>50.12 FBA A debug mode</i> . This parameter is read-only.	0
	-2147483648 2147483647	Raw ACT2 sent by fieldbus adapter A to master.	-

No.	Name/Value	Description	Def/FbEq16
51 FB	A A settings	Fieldbus adapter A configuration.	
51.01	FBA A type	Displays the type of the connected fieldbus adapter module. 0 = Module is not found or is not properly connected, or is disabled by parameter 50.01 FBA A enable; 0 = None; 1 = PROFIBUS-DP; 32 = CANopen; 128 = Ethernet; 132 = PROFInet IO; 135 = EtherCAT; 485 = RS-485 comm. This parameter is read-only.	0
51.02	FBA A Par2	Parameters 51.0251.26 are adapter module-specific. For more information, see the documentation of the fieldbus adapter module. Note that not all of these parameters are necessarily in use.	0
	065535	Fieldbus adapter configuration parameter.	1 = 1
51.26	FBA A Par26	See parameter 51.02 FBA A Par2.	0
	065535	Fieldbus adapter configuration parameter.	1 = 1
51.27	FBA A par refresh	Validates any changed fieldbus adapter module configuration settings. After refreshing, the value reverts automatically to <i>Done</i> . Note: This parameter cannot be changed while the drive is running.	Done
	Done	Refreshing done.	0
	Configure	Refreshing.	1
51.28	FBA A par table ver	Displays the parameter table revision of the fieldbus adapter module mapping file (stored in the memory of the drive). In format axyz, where ax = major table revision number; yz = minor table revision number. This parameter is read-only.	0x0000
	0x00000xffff	Parameter table revision of adapter module.	-
51.29	FBA A drive type code	Displays the drive type code in the fieldbus adapter module mapping file (stored in the memory of the drive). This parameter is read-only.	-
	065535	Drive type code stored in the mapping file.	1 = 1
51.30	FBA A mapping file ver	Displays the fieldbus adapter module mapping file revision stored in the memory of the drive in decimal format. This parameter is read-only.	-
	065535	Mapping file revision.	1 = 1
51.31	D2FBA A comm status	Displays the status of the fieldbus adapter module communication.	Not configured
	Not configured	Adapter is not configured.	0
	Initializing	Adapter is initializing.	1
	Time out	A timeout has occurred in the communication between the adapter and the drive.	2
	Configuration error	Adapter configuration error: mapping file not found in the file system of the drive, or mapping file upload has failed more than three times.	3
	Off-line	Fieldbus communication is off-line.	4

No.	Name/Value	Description	Def/FbEq16
	On-line	Fieldbus communication is on-line, or fieldbus adapter has been configured not to detect a communication break. For more information, see the documentation of the fieldbus adapter.	5
	Reset	Adapter is performing a hardware reset.	6
51.32	FBA A comm SW ver	Displays the common program revision of the adapter module in format axyz, where a = major revision number, xy = minor revision number, z = correction number or letter. Example: 190A = revision 1.90A.	0x0000
	0x00000xffff	Common program revision of adapter module.	-
51.33	FBA A appl SW ver	Displays the application program revision of the adapter module in format axyz, where a = major revision number, xy = minor revision number, z = correction number or letter. Example: 190A = revision 1.90A.	0x0000
	0x00000xffff	Application program version of adapter module.	-
52 FBJ	A A data in	Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter A. Note: 32-bit values require two consecutive parameters. Whenever a 32-bit value is selected in a data parameter, the next parameter is automatically reserved.	
52.01	FBA A data in1	Parameters 52.0152.12 select data to be transferred from the drive to the fieldbus controller through fieldbus adapter A.	None
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	SW 16bit	Status Word (16 bits)	4
	Act1 16bit	Actual value ACT1 (16 bits)	5
	Act2 16bit	Actual value ACT2 (16 bits)	6
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	SW 32bit	Status Word (32 bits)	14
	Act1 32bit	Actual value ACT1 (32 bits)	15
	Act2 32bit	Actual value ACT2 (32 bits)	16
	SW2 16bit	Status Word 2 (16 bits)	24

No.	Name/Value	Description	Def/FbEq16
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
52.12	FBA A data in12	See parameter 52.01 FBA A data in1.	None
53 FBA A data out		Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter A. Note: 32-bit values require two consecutive parameters. Whenever a 32-bit value is selected in a data parameter, the next parameter is automatically reserved.	
53.01	FBA A data out1	Parameters 53.0153.12 select data to be transferred from the fieldbus controller to the drive through fieldbus adapter A.	None
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	CW2 16bit	Control Word 2 (16 bits)	21
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
53.12	FBA A data out12	See parameter 53.01 FBA A data out1.	None

58 Embedded fieldbus		Configuration of the embedded fieldbus (EFB) interface. See also chapter <i>Fieldbus control through the embedded</i> <i>fieldbus interface (EFB)</i> (page 441).	
58.01	Protocol enable	Enables/disables the embedded fieldbus interface and selects the protocol to use.	None
	None	None (communication disabled).	0
	Modbus RTU	Embedded fieldbus interface is enabled and uses the Modbus RTU protocol.	1
58.02	Protocol ID	Displays the protocol ID and revision. This parameter is read-only.	-
		Protocol ID and revision.	1 = 1
58.03	Node address	Defines the node address of the drive on the fieldbus link. Values 1247 are allowable. Two devices with the same address are not allowed on-line. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 <i>Communication control (Refresh settings)</i> .	1
	0255	Node address (values 1247 are allowed).	1 = 1
58.04	Baud rate	Selects the transfer rate of the fieldbus link. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 <i>Communication control (Refresh settings)</i> .	19.2 kbps
	Autodetect	Baud rate detected automatically	0
	4.8 kbps	4.8 kbit/s.	1
	9.6 kbps	9.6 kbit/s.	2

No.	Name/Value	Description	Def/FbEq16
	19.2 kbps	19.2 kbit/s.	3
	38.4 kbps	38.4 kbit/s.	4
	57.6 kbps	57.6 kbit/s.	5
	76.8 kbps	76.8 kbit/s.	6
	115.2 kbps	115.2 kbit/s.	7
58.05	Parity	Selects the type of parity bit and number of stop bits. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 <i>Communication control (Refresh settings)</i> .	8 EVEN 1
	8 NONE 1	Eight data bits, no parity bit, one stop bit.	0
	8 NONE 2	Eight data bits, no parity bit, two stop bits.	1
	8 EVEN 1	Eight data bits, even parity bit, one stop bit.	2
	8 ODD 1	Eight data bits, odd parity bit, one stop bit.	3
58.06	Communication control	Takes changed EFB settings in use, or activates silent mode.	Enabled
	Enabled	Normal operation.	0
	Refresh settings	Refreshes settings (parameters <i>58.0158.05</i> , <i>58.1458.17</i> , <i>58.25</i> , <i>58.2858.34</i>) and takes changed EFB configuration settings in use. Reverts automatically to <i>Enabled</i> .	1
	Silent mode	Activates silent mode (no messages are transmitted). Silent mode can be terminated by activating the <i>Refresh</i> <i>settings</i> selection of this parameter.	2

No.	Name/\	/alue	Description	1	Def/FbEq16	
58.07	Commu diagnos	nication tics	This param	e status of the EFB communication. eter is read-only. e name is only visible when the error is present 1).	-	
	Bit Name Description					
	0	Init failed		1 = EFB initialization failed		
	1	Addr confi	g err	1 = Node address not allowed by protocol		
	2	Silent mode		1 = Drive not allowed to transmit		
				0 = Drive allowed to transmit		
	3	Reserved				
	4	Wiring erro		1 = Errors detected (A/B wires possibly swapped)		
	5	Parity erro		1 = Error detected: check parameters 58.04 and 5		
	6	Baud rate		1 = Error detected: check parameters 58.05 and 5	58.04	
	7	No bus ac	,	1 = 0 bytes received during last 5 seconds		
	8	No packet		1 = 0 packets (addressed to any device) detected seconds	•	
	9	Noise or addressing error		1 = Errors detected (interference, or another devic same address on line)		
	10	Comm los	s	1 = 0 packets addressed to the drive received within timeout (58.16)		
	11	CW/Ref loss Not active		 1 = No control word or references received within timeout (58.16) 1 = Not active. EFB is not the active channel. Only used in redundant communication control. 		
	12					
	13	Protocol 1		1 = Used for protocol-dependent statuses. See protocol documentation.		
	14	Protocol 2		See Bit 13.		
	15	Internal error		1 = internal error. Problem with the communication to the drive software.		
	0000hFFFFh EFB comm		EFB comm	unication status.	1 = 1	
58.08	Receive	ed packets	During norn	count of valid packets addressed to the drive. nal operation, this number increases constantly. et from the control panel by keeping Reset down econds.	-	
	04294967295		Number of I	received packets addressed to the drive.	1 = 1	
58.09	Transm	itted packets	During norn	count of valid packets transmitted by the drive. nal operation, this number increases constantly. et from the control panel by keeping Reset down econds.	-	
	0429	4967295	Number of t	ransmitted packets.	1 = 1	
58.10	i8.10 All packets Displays a the bus. D constantly Can be read		the bus. Du constantly.	count of valid packets addressed to any device on ring normal operation, this number increases et from the control panel by keeping Reset down econds.	-	
	0429	4967295	Number of a	all received packets.	1 = 1	
58.11	UART errors Displays a d increasing d bus. Can be rese		Displays a c increasing c bus.	count of character errors received by the drive. An count indicates a configuration problem on the et from the control panel by keeping Reset down	-	
	04294967295		Number of	UART errors.	1 = 1	

No.	Name/Value	Description	Def/FbEq16
58.12	CRC errors	Displays a count of packets with a CRC error received by the drive. An increasing count indicates interference on the bus. Can be reset from the control panel by keeping Reset down for over 3 seconds.	-
	04294967295	Number of CRC errors.	1 = 1
58.14	Communication loss action	Selects how the drive reacts to an EFB communication break. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 <i>Communication control (Refresh settings).</i> See also parameters 58.15 <i>Communication loss mode</i> and 58.16 <i>Communication loss time.</i>	Fault
	No action	No action taken (monitoring disabled).	0
	Fault	The drive monitors communication loss when start/stop is expected from the EFB on the currently active control location. Drive trips on 6681 EFB comm loss if control in the currently active control location is expected from the EFB or reference is coming from the EFB, and the communication is lost.	1
	Last speed	Drive generates an A7CE EFB comm loss warning and freezes the speed to the level the drive was operating at. The speed is determined on the basis of actual speed using 850 ms low-pass filtering. This occurs if control or reference is expected from the EFB. WARNING! Make sure that it is safe to continue operation in case of a communication break.	2
	Speed ref safe	Drive generates an A7CE EFB comm loss warning and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used). This occurs if control or reference is expected from the EFB. WARNING! Make sure that it is safe to continue operation in case of a communication break.	3
	Fault always	Drive continuously monitors for communication loss. Drive trips on <i>6681 EFB comm loss</i> . This happens even thought the drive is in a control location where the EFB start/stop or reference is not used.	4
	Warning	Drive generates an A7CE EFB comm loss warning. This occurs even though no control is expected from the EFB. WARNING! Make sure that it is safe to continue operation in case of a communication break.	5
58.15	Communication loss mode	Defines which message types reset the timeout counter for detecting an EFB communication loss. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter <i>58.06</i> <i>Communication control</i> (<i>Refresh settings</i>). See also parameters <i>58.14 Communication loss action</i> and <i>58.16 Communication loss time</i> .	Cw / Ref1 / Ref2
	Any message	Any message addressed to the drive resets the timeout.	1
	Cw / Ref1 / Ref2	A write of the control word or a reference resets the timeout.	2

No.	Name/Value	Description		Def/FbEq16	
58.16	Communication loss time	Sets a timeout for EFB commu break lasts longer than the tim parameter 58.14 Communicati Changes to this parameter tak rebooted or the new settings v Communication control (Refres See also parameter 58.15 Con	3.0 s		
	0.06000.0 s	EFB communication timeout.		1 = 1	
58.17	Transmit delay	Defines a minimum response of delay imposed by the protocol. Changes to this parameter take rebooted or the new settings vi <i>Communication control</i> (<i>Refres</i>	e effect after the control unit is alidated by parameter 58.06	3.0 ms	
	065535 ms	Minimum response delay.		1 = 1	
58.18	EFB control word	Displays the raw (unmodified) s the Modbus controller. For deb This parameter is read-only.		-	
	0000hFFFFh	Control word sent by Modbus of	controller to the drive.	1 = 1	
58.19	EFB status word	Displays the raw (unmodified) purposes. This parameter is read-only.	status word for debugging	-	
	0000hFFFFh	Status word sent by the drive t	o the Modbus controller.	1 = 1	
58.25	Control profile	Changes to this parameter take	Defines the communication profile used by the protocol. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control (Befrach settings)		
	ABB Drives	ABB Drives control profile (with	n a 16-bit control word)	0	
	DCU Profile	DCU control profile (with a 16 o	or 32-bit control word)	5	
58.26	EFB ref1 type	Selects the type and scaling of the embedded fieldbus interfac The scaled reference is display	ce.	Speed or frequency	
	Speed or frequency	Type and scaling is chosen aut currently active operation mode		0	
		Operation mode (see par. 19.01)	Reference 1 type		
		Speed control	Speed		
		Torque control Frequency control	Speed Frequency		
			ricquericy		
	Transparent	No scaling is applied.	1		
	General	Generic reference without a sp	2		
	Torque	Torque reference. The scaling <i>Torque scaling</i> .	3		
	Speed	Speed reference. The scaling i <i>Speed scaling</i> .	is defined by parameter 46.01	4	
	Frequency	Frequency reference. The scal 46.02 Frequency scaling.	ling is defined by parameter	5	

No.	Name/Value Description				
58.27	EFB ref2 type	Selects the type and scaling of the embedded fieldbus interfac see58.26 EFB ref1 type. The scaled reference is display	Torque		
58.28				Speed or frequency	
	Speed or frequency	Type and scaling is chosen aut currently active operation mode		0	
		Operation mode (see par. 19.01)			
		Speed control	Speed		
		Torque control	Speed		
		Frequency control	Frequency		
	Transparent	No scaling is applied.		1	
	General	Generic reference without a sp	ecific unit. Scaling: 1 = 100.	2	
	Torque	Scaling is defined by paramete	r 46.03 Torque scaling.	3	
	Reserved			3	
	Speed	Scaling is defined by paramete	er 46.01 Speed scaling.	4	
	Frequency	Scaling is defined by paramete	r 46.02 Frequency scaling.	5	
58.29	EFB act2 type	Selects the type of actual value For the selections, see parame	Transparent		
58.31	EFB act1 transparent source	Selects the source of actual va EFB act1 type is set to Transpa		Not selected	
	Not selected	None.	0		
	Other	Source selection (see Terms and	nd abbreviations on page 161).	-	
58.32	EFB act2 transparent source	Selects the source of actual va EFB act2 type is set to Transpa		Other (par. 01.07 Motor current)	
	Not selected	None.	0		
	Other	Source selection (see Terms and	nd abbreviations on page 161).	-	
58.33	Addressing mode	Defines the mapping between registers in the 4001014655 Changes to this parameter take rebooted or the new settings va <i>Communication control</i> (<i>Refres</i>	Mode 0		
	Mode 0	16-bit values (groups 199, in Register address = 400000 + 1 parameter index. For example, mapped to register 400000 + 2 <u>32-bit values (groups 199, in</u> Register address = 420000 + 2 2 × parameter index. For exam mapped to register 420000 + 4	00 × parameter group + parameter 22.80 would be 200 + 80 = 402280. dexes 199): 00 × parameter group + ple, parameter 22.80 would be	0	
	Mode 1	<u>16-bit values (groups 1255, i</u> Register address = 400000 + 2 parameter index. For example, mapped to register 400000 + 5	256 × parameter group + parameter 22.80 would be	1	

No.	Name/Value	Description	Def/FbEq16
	Mode 2	32-bit values (groups 1127, indexes 1255): Register address = 400000 + 512 × parameter group + 2 × parameter index. For example, parameter 22.80 would be mapped to register 400000 + 11264 + 160 = 411424.	2
58.34	Word order	Selects in which order 16-bit registers of 32-bit parameters are transferred. For each register, the first byte contains the high order byte and the second byte contains the low order byte. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 <i>Communication control (Refresh settings)</i> .	LO-HI
	HI-LO	The first register contains the high order word, the second contains the low order word.	0
	LO-HI	The first register contains the low order word, the second contains the high order word.	1
58.101	Data I/O 1	Defines the address in the drive which the Modbus master accesses when it reads from or writes to the register address corresponding to Modbus register 1 (400001). The master defines the type of the data (input or output). The value is transmitted in a Modbus frame consisting of two 16- bit words. If the value is 16-bit, it is transmitted in the LSW (least significant word). If the value is 32-bit, the subsequent parameter is also reserved for it and must be set to <i>None</i> .	CW 16bit
	None	No mapping, register is always zero.	0
	CW 16bit	ABB Drives profile: 16-bit ABB drives control word; DCU Profile: lower 16 bits of the DCU control word	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	SW 16bit	ABB Drives profile: 16-bit ABB drives status word; DCU Profile: lower 16 bits of the DCU status word	4
	Act1 16bit	Actual value ACT1 (16 bits)	5
	Act2 16bit	Actual value ACT2 (16 bits)	6
	Reserved		710
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	SW 32bit	Status Word (32 bits)	14
	Act1 32bit	Actual value ACT1 (32 bits)	15
	Act2 32bit	Actual value ACT2 (32 bits)	16
	Reserved		1720
	CW2 16bit	ABB Drives profile: not used; DCU Profile: upper 16 bits of the DCU control word	21
	SW2 16bit	ABB Drives profile: not used / always zero; DCU Profile: upper 16 bits of the DCU status word	24
	Reserved		2530
	RO/DIO control word	Parameter 10.99 RO/DIO control word.	31
	AO1 data storage	Parameter 13.91 AO1 data storage.	32

No.	Name/Value Description		Def/FbEq16
	AO2 data storage	Parameter 13.92 AO2 data storage.	33
	Reserved		3439
	Feedback data storage	Parameter 40.91 Feedback data storage.	40
	Setpoint data storage	Parameter 40.92 Setpoint data storage.	41
	Other	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
58.102	Data I/O 2	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400002. For the selections, see parameter 58.101 Data I/O 1.	Ref1 16bit
58.103	Data I/O 3	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400003. For the selections, see parameter 58.101 Data I/O 1.	Ref2 16bit
58.104	Data I/O 4	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400004. For the selections, see parameter 58.101 Data I/O 1.	SW 16bit
58.105	Data I/O 5	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400005. For the selections, see parameter 58.101 Data I/O 1.	Act1 16bit
58.106	Data I/O 6	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400006. For the selections, see parameter 58.101 Data I/O 1.	Act2 16bit
58.107	Data I/O 7	Parameter selector for Modbus register address 400007. For the selections, see parameter 58.101 Data I/O 1.	None
58.114	Data I/O 14	Parameter selector for Modbus register address 400014. For the selections, see parameter 58.101 Data I/O 1.	None

No.	Name/Value		Descriptio	on	Def/FbEq16
70 Override			isabling of override function, override activation override speed/frequency.		
70.01	Overrid	e status		override status. neter is read-only.	0b0000
	Bit	Name		Description	
	0	Override er	nabled	0 = Override is disabled; 1 = Override is enabled.	
	1	Override ad	tive	0 = Override is inactive; 1 = Drive is active.	
	2	Override di forward	rection is	0 = Override direction is not forward; 1 = Override of forward.	direction is
	3	Override di reverse	rection is	0 = Override direction is not reverse; 1 = Override or reverse.	direction is
	4	Override st active	op mode is	0 = Override stop mode is not active; 1 = Override active.	stop mode is
	511	Reserved			
	12	Test mode	active	0 = Test mode is inactive; 1 = Test mode is active	
	1315	Reserved			
	0b0000	0b1111			1=1
70.02	Overrid	e enable	Enables th	e override function.	Off
	Off		Override d	isabled.	0
	On		Override e	nabled.	1
70.03	Override source	e activation	Value 0 of	e source of the override activation. the source deactivates the override. the source activates the override.	Not used
	Not used		0.		0
	Used		1.		1
	DI1		Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0).		2
	DI2		a 1	at DI2 (10.02 DI delayed status, bit 1).	3
	DI3		a 1	at DI3 (10.02 DI delayed status, bit 2).	4
	DI3		a 1	at DI3 (10.02 DI delayed status, bit 2).	5
			a 1		
	DI5		a 1	ut DI5 (10.02 DI delayed status, bit 4).	6
	DI6		• ·	ut DI6 (10.02 DI delayed status, bit 5).	7
	-DI1		a 1	at DI1 (10.02 DI delayed status, bit 0).	8
	-DI2			ut DI2 (10.02 DI delayed status, bit 1).	9
	-DI3		a 1	ut DI3 (10.02 DI delayed status, bit 2).	10
	-DI4		Digital inpu	ut DI4 (10.02 DI delayed status, bit 3).	11
	-DI5		Digital inpu	ut DI5 (10.02 DI delayed status, bit 4).	12
	-DI6		Digital inpu	ut DI6 (10.02 DI delayed status, bit 5).	13
	Other [b	oit]	Source sel	ection (see <i>Terms and abbreviations</i> on page 161).	-
70.04	Overrid source	e reference	Selects the	e source for the speed used in the override mode.	Override speed/freq
	Constar speed/f		Constant s	peed used as the reference	0
	Al1		12.12 AI1	scaled value (page 189).	1
	Al2		12.22 AI2	scaled value (page 190).	2

No.	Name/Value	Description	Def/FbEq16
	Override speed/freq	Parameter 70.06 Override frequency/ 70.07 Override speed is used as the reference.	3
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the Motor potentiometer)	4
	Stop	The output of the drive is shut off and the motor no longer runs. Override is displayed on the panel but the motor does not run. Drive follows the specified stop type.	5
	Process PID set 1	Output of the process PID Set 1 (40.96) is used as the reference.	6
70.05	Override direction	Selects the source of the motor direction used in the override mode.	Forward
	Forward	Direction is forward.	0
	Reverse	Direction is reverse.	1
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7
	-DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	8
	-DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	9
	-DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	10
	-DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	11
	-DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	12
	-DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	13
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
70.06	Override frequency	Defines the frequency used as reference in the override mode if 70.04 Override reference source is set to Override speed/freq and the drive is in frequency mode	0.0 Hz
	-500.0500.0 Hz	Override frequency.	1 = 1 Hz
70.07	Override speed	Defines the speed used as reference in the override mode if 70.04 Override reference source is set to Override speed/freq and the drive is in speed mode.	0.0 rpm
	-30000.0 30000.0 rpm	Override speed.	1 = 1 rpm
70.20	Override fault handling	Faults are grouped into high priority faults and low priority faults. The following faults are high priority, and they are displayed and they will stop the drive: 2310 Overcurrent, 2340 Short circuit, 3210 DC link overvoltage, 4981 External temperature 1, 4982 External temperature 2, 5090 STO hardware failure, 5091 Safe torque off, FA81 Safe torque off 1, FA81 Safe torque off 2. Other faults are low priority faults. Active low priority faults are reset when the drive enters override mode. Low priority faults are ignored when the drive is in override mode.	Fault on high priority
	Fault on high priority	Fault on high priority faults. The fault must be reset from the control panel or from a digital input.	0

No.	Name/Value	ne/Value Description	
	Autoreset	Fault on high priority faults (except STO related faults) with automatic fault reset and run. See the list of high priority faults above. See parameter 70.21 Override auto reset trials.	1
70.21	Override auto reset trials	Defines the number of automatic fault resets the drive performs during override operation When the parameter is set to 0, reset trials are made continuously during the override operation. A value of 15 defines a specific number of automatic reset trials.	5
	060	Number of automatic reset trials.	1 = 1
70.22	Override auto reset time	Defines the time the drive will wait after a fault before attempting an automatic fault reset.	5.0 s
	0.1120.0 s	Auto reset delay time.	10 = 1 s

71 External PID1		Configuration of external PID. See the control chain diagrams on pages 501 and 504.	
71.01	External PID act value	See parameter 40.01 Process PID output actual.	-
71.02	Feedback act value	See parameter 40.02 Process PID feedback actual.	-
71.03	Setpoint act value	See parameter 40.03 Process PID setpoint actual.	-
71.04	Deviation act value	See parameter 40.04 Process PID deviation actual.	-
71.06	PID status word	Displays status information on process external PID control. This parameter is read-only.	-

Bit	Name		Value		
0	PID active		1 = Process PID control active.		
1	Reserved				
2	Output froz	Output frozen 1 = Process PID controller output frozen. Bit is set if parameter 71.38 Output freeze enable is TRUE, or the deadband function is active (bit 9 is set).			
36	Reserved		·		
7	Output limit	high	1 = PID output is being limited by par. 71.37.	eing limited by par. 71.37.	
8	Output limit	low	1 = PID output is being limited by par. 71.36.		
9	Deadband a	active	1 = Deadband is active (see par. 71.39)		
1011	Reserved				
12	Internal set active	point	1 = Internal setpoint active (see par. 71.1671.23)		
1315	Reserved		·		
	•				
0000hFFFFh Proces		Proces	ss PID control status word.	1 = 1	
		-			

	0000hFFFFh	Process PID control status word.	1 = 1
71.07	PID operation mode	See parameter 40.07 Process PID operation mode.	Off
71.08	Feedback 1 source	See parameter 40.08 Set 1 feedback 1 source.	Not selected
71.11	Feedback filter time	See parameter 40.11 Set 1 feedback filter time.	0.000 s

No.	Name/Value	Description	Def/FbEq16	
71.14 Setpoint scaling		Defines, together with parameter 71.15 Output scaling, a general scaling factor for the external PID control chain. The scaling can be utilized when, for example, the process setpoint is input in Hz, and the output of the PID controller is used as an rpm value in speed control. In this case, this parameter might be set to 50, and parameter 71.15 to the nominal motor speed at 50 Hz. In effect, the output of the PID controller [71.15] when deviation (setpoint - feedback) = [71.14] and [71.32] = 1. Note: The scaling is based on the ratio between 71.14 and 71.15. For example, the values 50 and 1500 would produce the same scaling as 1 and 3.	1500.00	
	-200000.00 200000.00	Process setpoint base.	1 = 1	
71.15	Output scaling	See parameter 71.14 Setpoint scaling.	1500.00	
	-200000.00 200000.00	Process PID controller output base.	1 = 1	
71.16	Setpoint 1 source	See parameter 40.16 Set 1 setpoint 1 source.	Not selected	
71.19	Internal setpoint sel1	See parameter 40.19 Set 1 internal setpoint sel1.	Not selected	
71.20	Internal setpoint sel2	See parameter 40.20 Set 1 internal setpoint sel2.	Not selected	
71.21	Internal setpoint 1	See parameter 40.21 Set 1 internal setpoint 1.	0.00 PID customer units	
71.22	Internal setpoint 2	See parameter 40.22 Set 1 internal setpoint 2.	0.00 PID customer units	
71.23	Internal setpoint 3	See parameter 40.23 Set 1 internal setpoint 3.	0.00 PID customer units	
71.26	Setpoint min	See parameter 40.26 Set 1 setpoint min.	0.00	
71.27	Setpoint max	See parameter 40.27 Set 1 setpoint max.	200000.00	
71.31	Deviation inversion	See parameter 40.31 Set 1 deviation inversion.	Not inverted (Ref - Fbk)	
71.32	Gain	See parameter 40.32 Set 1 gain.	1.00	
71.33	Integration time	See parameter 40.33 Set 1 integration time.	60.0 s	
71.34	Derivation time	See parameter 40.34 Set 1 derivation time.	0.000 s	
71.35	Derivation filter time	See parameter 40.35 Set 1 derivation filter time.	0.0 s	
71.36	Output min	See parameter 40.36 Set 1 output min.	-200000.00	
71.37	Output max	See parameter 40.37 Set 1 output max.	200000.00	
71.38	Output freeze enable	See parameter 40.38 Set 1 output freeze.	Not selected	

No. Name/Value		Description	Def/FbEq16
71.39	Deadband range The control program compares the absolute value of parameter 71.04 Deviation act value to the deadband range defined by this parameter. If the absolute value is within the deadband range for the time period defined by parameter 71.40 Deadband delay, PID's deadband mode is activated and 71.06 PID status word bit 9 Deadband active is set. Then PID's output is frozen and 71.06 PID status word bit 2 Output frozen is set. If the absolute value is equal or greater than the deadband range, PID's deadband mode is deactivated.		0.0
	0.0200000.0	Range	1 = 1
71.40	Deadband delay	Defines the deadband delay for the deadband function. See parameter 71.39 Deadband range.	0.0 s
	0.03600.0 s	Delay	1 = 1 s
71.58	Increase prevention	Activates increase prevention of PID integration term for Ext PID 1.	No
	No	Increase prevention not in use.	0
	Limiting	The Ext PID integration term is not increased.	1
	Process PID min lim	The Ext PID integration term is not increased when the output of the process PID has reached its minimum limit. In this setup, the external PID is used as a source for the process PID.	2
	Process PID max lim	The Ext PID integration term is not increased when the output of the process PID has reached its maximum limit. In this setup, the external PID is used as a source for the process PID.	3
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
71.59	Decrease prevention	Activates decrease prevention of PID integration term for Ext PID 1.	No
	No	Decrease prevention not in use.	0
	Limiting	The Ext PID integration term is not decreased	1
	Process PID min lim	The Ext PID integration term is not increased when the output of the process PID has reached its minimum limit. In this setup, the external PID is used as a source for the process PID.	2
	Process PID max lim	The Ext PID integration term is not increased when the output of the process PID has reached its maximum limit. In this setup, the external PID is used as a source for the process PID.	3
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-
71.62	Internal setpoint actual	See parameter 40.62 PID internal setpoint actual.	-
71.79	External PID units	Selects the unit for process PID setpoint, feedback and deviation.	%
	User text	User text	0
	%	%	1
	bar	bar	2
	kPa	kPa	3
	Pa	Ра	4
	psi	psi	5

Name/Value	Description	Def/FbEq16
CFM	CFM	6
inH ₂ O	inH ₂ O	7
°C	°C	8
°F	°F	9
mbar	mbar	10
m ³ /h	m ³ /h	11
dm ³ /h	dm ³ /h	12
l/s	l/s	13
l/min	l/min	14
l/h	l/h	15
m ³ /s	m ³ /s	16
m ³ /m	m ³ /m	17
km ³ /h	km ³ /h	18
gal/s	gal/s	19
ft ³ /s	ft ³ /s	20
ft ³ /m	ft ³ /m	21
ft ³ /h	ft ³ /h	22
ppm	ppm	23
inHg	inHg	24
kCFM	kCFM	25
inWC	inWC	26
GPM	GPM	27
gal/m	gal/m	28
in wg	in wg	29
MPa	MPa	30
ftWC	ftWC	31
	CFM inH2O °C °F mbar m³/h dm³/h l/s l/min l/s state m³/h gm³/h km³/h gal/s ft³/s ft³/s ft³/h ppm inHg kCFM inWC GPM gal/m in wg MPa	CFM CFM inH2O inH2O °C °C °F °F mbar mbar m³/h dm³/h dm³/h dm³/h //s l/s l/min l/min l/min l/min l/h l/h m³/s m³/s m³/s m³/s m³/n m³/s m³/n m³/s m³/n th³/s ft³/s ft³/s ft³/s ft³/s ft³/s ft³/s ft³/n ft³/s ft³/n ft³/s ft³/n ft³/n ftg inHg inHg inHg gal/m gal/m <

No.	Name/Va	alue	Description		Def/FbEq16
76 PF(C config	uration		fan control) and Autochange configuration also section <i>Pump and Fan Control (PFC)</i> 25.	
76.01	PFC stat	us	PFC1, PFC2, PF 1st4th motor of auxiliary PFC aux represents the m first auxiliary mot set to All motors,	hing/stopped status of the PFC motors. C3 and PFC4 always correspond to the f the PFC system. If 76.74 Autochange kiliary PFC is set to Aux motors only, PFC1 otor connected to the drive and PFC2 the or (the 2nd motor of the system). If 76.74 is PFC1 is the first motor, PFC2 the 2nd. The nected to any of these motors depending on unctionality.	06000
	Bit	Name		Value	
	0	PFC 1 runn	ing	0 = Stop, 1 = Start	
	1	PFC 2 runn	*	0 = Stop, 1 = Start	
	2	PFC 3 runn	ing	0 = Stop, 1 = Start	
	3	PFC 4 runn	ing	0 = Stop, 1 = Start	
	415	Reserved		·	
	0b0000.	0b1111	Status of the PFC	C relay outputs.	1 = 1
76.02	PFC sys	tem status	Displays the statu quick PFC syster	us of the PFC system in text form. Provides a m overview, e.g. if the parameter is added to n the control panel.	PFC disabled
	PFC disa	abled	-		0
	PFC ena started)	bled (not	-		1
	SPFC er started)	abled (not	-		2
	MPFC e	nabled	-		3
	Invalid c	onfiguration	-		4
	PFC inac control)	ctive (local	-		5
	PFC inac (invalid c mode)	ctive operation	-		6
	Drive mo		-		7
	All motor		-		8
	inactive active)	(ext1	-		9
	Running	with VSD	-		100
	Running + 1 Aux	with VSD	-		101
	Running with VSD + 2 Aux		-		102
	Running + 3 Aux	with VSD	-		103
	Starting	Aux1	-		200

No.	Name/\	/alue	Description		Def/FbEq16
	Starting	Aux2	-		201
	Starting	Aux3	-		202
Stopping Aux1		-		300	
	Stoppin	g Aux2	-		301
	Stoppin	g Aux3	-		302
	Autocha	ange active	-		400
	No auxi availabl started	liary motors e to be	-		500
	Regulat active	or bypass	-		600
	MPFC ok	connection	-		700
	PID sle	ер	-		800
	PID sle	ep boost	-		801
76.11	Pump/fa	an status 1	Shows the sta	tus of pump or fan 1.	0b0000
	Bit	Name	Vi	alue	1
	0	Ready	0	= False, 1 = True	
	2	Running	0	= False, 1 = True	
	5	In PFC cont	rol 0	= False, 1 = True	
	1, 3, 4, 610	Reserved			
	11	Interlocked	0	= False, 1 = True	
	1215	Reserved			
	0b00000b1111		Status of pum	p or fan 1.	1 = 1
76.12	Pump/fa	an status 2	See paramete	r 76.11 Pump/fan status 1.	-
76.13	Pump/fa	an status 3	See paramete	r 76.11 Pump/fan status 1.	-
76.14	Pump/fa	an status 4	See paramete	r 76.11 Pump/fan status 1.	-
76.21	PFC co	nfiguration	Selects the mu	ulti-pump/fan control (PFC) mode.	Off
	Off		PFC disabled.		0
PFC		The remaining started and sto The frequency (group 22 Spe defined as PIE SPFC enabled	One pump at a time is controlled by the drive. pumps are direct-on-line pumps that are popped by the drive logic (group 28 Frequency reference chain) / speed ed reference selection) reference must be 0 for the PFC functionality to work properly. 1. For more information, see Pump and Fan macro on page.125	2	
	SPFC			I. For more information, see <i>Soft Pump and Fan</i> <i>c) macro</i> on page. <i>134</i>	3
76.25	Number of motors			of motors used in the application, including the ted directly to the drive.	1
	14		Number of mo	tors.	1 = 1
76.26	Min nur motors		Minimum num	ber of motors running simultaneously.	1
	04		Minimum num	ber of motors	1 = 1

No.	Name/Value	Description	Def/FbEq16
76.27	Max number of motors allowed	Maximum number of motors running simultaneously.	1
	14	Maximum number of motors.	1 = 1
76.30	Start point 1	Defines the start speed (Hz/rpm) for the first auxiliary pump. As the motor speed or frequency exceeds the limit defined by this parameter, a new auxiliary pump is started. To avoid nuisance starts of the auxiliary pump, the speed of the variable speed pump should be higher than the start speed for the duration defined by parameter 76.55 Start <i>delay</i> . If the speed decreases below the start speed, the auxiliary pump is not started. To maintain the process conditions during the start of the auxiliary pump, a speed hold on time can be defined with parameter 76.57 <i>PFC speed hold on</i> . Certain pump types do not produce significant flow with low frequencies. The speed hold on time can be used to compensate the time needed to accelerate the auxiliary pump to a speed where it produces flow.	Vector: 1300 rpm; Scalar 48 Hz; 58 Hz (95.20 b0)
	032767 rpm/Hz	Speed/frequency.	1 = 1 unit
76.31	Start point 2	Defines the start speed (Hz/rpm) for the second auxiliary motor. See parameter 76.31 Start point 1.	Vector: 1300 rpm; Scalar 48 Hz; 58 Hz (95.20 b0)
76.32	Start point 3	Defines the start speed (Hz/rpm) for the third auxiliary motor. See parameter 76.31 Start point 1.	Vector: 1300 rpm; Scalar 48 Hz; 58 Hz (95.20 b0)
76.41	Stop point 1	Defines the stop speed (Hz/rpm) for the first auxiliary motor. When the speed of the motor connected directly to the drive falls below this value and one auxiliary motor is running, the stop delay defined by parameter 76.56 <i>Stop delay</i> is started. If the speed is still at the same level or lower when the stop delay elapses, the first auxiliary motor stops. The running speed of the drive is increased by [<i>Start point</i> 1 - <i>Stop point</i> 1] after the auxiliary motor stops	Vector: 800 rpm; Scalar 25 Hz; 30 Hz (95.20 b0)
	032767 rpm/Hz	Speed/frequency	1 = 1 unit
76.42	Stop point 2	Defines the stop speed (Hz/rpm) for the second auxiliary motor. See parameter <i>76.31 Stop point 1</i> .	Vector: 800 rpm; Scalar 25 Hz; 30 Hz (95.20 b0)
76.43	Stop point 3	Defines the stop speed (Hz/rpm) for the third auxiliary motor. See parameter 76.31 Stop point 1.	Vector: 800 rpm; Scalar 25 Hz; 30 Hz (95.20 b0)
76.55	Start delay	Defines a start delay for auxiliary motors. See parameter 76.31 Start point 1.	10.00 s
	0.0012600.00 s	Time delay.	1 = 1 s
76.56	Stop delay	Defines a stop delay for auxiliary motors. See parameter 76.31 Stop point 1.	10.00 s
	0.0012600.00 s	Time delay.	1 = 1 s

No. Name/Value Description			Def/FbEq16
76.57	PFC speed hold on	Hold time for auxiliary motor switch-on. See parameter 76.31 Start point 1.	0.00 s
	0.001000.00 s	Time.	1 = 1 s
76.58	PFC speed hold off	Hold time for auxiliary motor switch-off. See parameter 76.31 <i>Stop point</i> 1.	0.00 s
	0.001000.00 s	Time.	1 = 1 s
76.59	PFC contactor delay	Start delay for the motor that is directly controlled by the drive. This does not affect the starting of the auxiliary motors. WARNING! There must always be a delay set if the motors are equipped with star-delta starters. The delay must be set longer than the time setting of the starter. After the motor is switched on by the relay output of the drive, there must be enough time for the star-delta starter to first switch to star and then back to delta before the motor is connected to the drive.	0.50 s
	0.20600.00 s	Time delay.	1 = 1 s
76.60	PFC ramp acceleration time	Defines the acceleration time for the drive motor speed compensation, when an auxiliary motor is stopped. This ramp time is also used for the drive motor to accelerate after an autochange has occurred. The parameter sets the ramp-up time as seconds from zero to maximum frequency (not from the previous reference to the new reference).	1.00 s
	0.001800.00 s	Time.	1 = 1 s
76.61	PFC ramp deceleration time	Defines the deceleration time for the drive motor speed compensation, when an auxiliary motor is started. This ramp time is also used for the drive motor to decelerate after an autochange has occurred. The parameter sets the ramp-up time as seconds from maximum to zero frequency (not from the previous reference to the new reference).	1.00 s
	0.001800.00 s	Time.	1 = 1 s
76.70	PFC autochange	Defines the way the autochange is triggered. In all cases except <i>Even wear</i> , the start order is moved one step forward each time the autochange occurs. If the start order initially is 1-2-3-4, after the first autochange the order will be 2-3-4-1, etc. For <i>Even wear</i> , the start order will be determined so that the running times of all motors remain within the defined limit. Note: Autochange only occurs when the speed of the drive is below the speed defined by parameter 76.73 <i>Autochange</i> <i>level.</i> See also section <i>Autochange</i> on page 128.	Not selected
	Not selected	Autochange disabled.	0
	Selected	Rising edge starts the autochange if autochange conditions are met.	1
	DI1	Autochange triggered by the rising edge of digital input DI1 (10.02 DI delayed status, bit 0).	2
	DI2	Autochange triggered by the rising edge of digital input DI2 (10.02 DI delayed status, bit 1).	3
	DI3	Autochange triggered by the rising edge of digital input DI3 (10.02 DI delayed status, bit 2).	4

No.	Name/Value	Description	Def/FbEq16	
	DI4	Autochange triggered by the rising edge of digital input DI4 (10.02 DI delayed status, bit 3).	5	
	DI5	Autochange triggered by the rising edge of digital input DI5 (10.02 DI delayed status, bit 4).	6	
	DI6	Autochange triggered by the rising edge of digital input DI6 (10.02 DI delayed status, bit 5).	7	
	Timed function 1	Autochange triggered by timed function 1 (bit 0 of 34.01 Timed functions status (see page 280)).	8	
	Timed function 2	Autochange triggered by timed function 2 (bit 1 of 34.01 Timed functions status (see page 280)).	9	
	Timed function 3	Autochange triggered by timed function 3 (bit 2 of 34.01 Timed functions status (see page 280)).	10	
	Fixed interval	Autochange is done when the interval determined in the parameter 76.71 PFC autochange interval has elapsed.	11	
	All stop	Autochange is done when all the motors are stopped. The PID sleep feature (parameters 40.43 Set 1 sleep level 40.48 Set 1 wake-up delay) must be used for the drive to stop when the process demand is low.	12	
	Even wear	The running time of the motors are balanced by the drive. When the difference in running time between the motors with the least and most running hours exceeds the time defined by parameter 76.72 <i>Maximum wear imbalance</i> , the autochange occurs. The running hours of the motors can be found in group 77 <i>PFC maintenance and monitoring</i> .	13	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-	
76.71	PFC autochange interval	Specifies the interval that is used in setting <i>Fixed interval</i> of parameter 76.70 <i>PFC autochange</i> .	1.00 h	
	0.0042949672.95 h	Time.	1 = 1 h	
76.72	Maximum wear imbalance	Specifies the maximum wear imbalance, or difference in running times between any motor, used by the <i>Even wear</i> setting of parameter 76.70 <i>PFC autochange</i> .	10.00 h	
	0.001000000.00 h	Time.	1 = 1 h	
76.73	Autochange level	 Upper speed limit for the Autochange to occur. The Autochange occurs when: the condition defined in 76.70 PFC autochange is fulfilled and, the speed of the drive motor 01.03 Motor speed % is below the speed limit defined in this parameter. Note: When the value is selected as 0%, this speed limit check is disabled. 	100.0%	
	0.0300.0%	Speed/frequency in percentage of the nominal speed or frequency of the drive motor.	1 = 1%	
76.74	Autochange auxiliary PFC	Selects whether only auxiliary motors or all motors are included in the Autochange function.	Aux motors only	

No.	Name/Value	Description	Def/FbEq16	
	All motors	All motors, including the one connected to the drive participates in the autochange. The Autochange logic will connect the drive to each of the motors according to setting of parameter 76.70 <i>PFC autochangee</i> . Note: The first motor (PFC1) also requires the appropriate hardware contactor connections and PFC1 must be defined in one of the relay output source parameters.	0	
	Aux motors only	Only auxiliary (direct-on-line) motors are affected by the autochange function. Note: PFC1 refers to the motor that is fixed to the drive and must not be selected in any of the relay output source parameters. Only the starting order of the auxiliary motors will be rotated.	1	
76.81	PFC interlock 1	Defines if the PFC motor 1 can be started. An interlocked PFC motor cannot be started. 0 = Interlocked (not available), 1 = Available.	Available. PFC motor is available	
	Interlocked. PFC motor is not in use	PFC motor is interlocked and not available.	0	
	Available. PFC motor is available	PFC motor is available.	1	
	DI1	Digital input DI1 (10.02 DI delayed status, bit 0).	2	
	DI2	Digital input DI2 (10.02 DI delayed status, bit 1).	3	
	DI3	Digital input DI3 (10.02 DI delayed status, bit 2).	4	
	DI4	Digital input DI4 (10.02 DI delayed status, bit 3).	5	
	DI5	Digital input DI5 (10.02 DI delayed status, bit 4).	6	
	DI6	Digital input DI6 (10.02 DI delayed status, bit 5).	7	
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 280).	8	
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 280).	9	
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 280).	10	
	Other [bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-	
76.82	PFC interlock 2	See parameter 76.82 PFC interlock 1.	Available. PFC motor is available	
76.83	PFC interlock 3	See parameter 76.82 PFC interlock 1.	Available. PFC motor is available	
76.84	PFC interlock 4	See parameter 76.82 PFC interlock 1.	Available. PFC motor is available	
76.95	Regulator bypass control	Defines if direct-on-line pumps are automatically started and stopped. This setting can be used in applications with a low number of sensors and low accuracy requirements.	Disable	
	Disable	Automatic starting and stopping is disabled.	0	
	Enable	Automatic starting and stopping is enabled.	1	
	Other [bit]	Source selection (see Terms and abbreviations on page 161).	-	

No.	Name/Value	Description	Def/FbEq16	
77 PFC maintenance and monitoring		PFC (Pump and fan control) maintenance and monitoring parameters.		
77.10 PFC runtime change		Enables the reset, or arbitrary setting, of 77.11 Pump/fan 1 running time 77.14 Pump/fan 4 running time.	Done	
	Done	The parameter automatically reverts back to this value.	0	
	Set any PFC run time	Enables the setting of 77.11 <i>Pump/fan 1 running time …</i> 77.14 <i>Pump/fan 4 running time</i> to an arbitrary value.	1	
	Reset PFC1 run time	Resets parameter 77.11 Pump/fan 1 running time.	2	
	Reset PFC2 run time	Resets parameter 77.12 Pump/fan 2 running time.	3	
	Reset PFC3 run time	Resets parameter 77.13 Pump/fan 3 running time.	4	
	Reset PFC4 run time	Resets parameter 77.14 Pump/fan 4 running time.	5	
77.11	Pump/fan 1 running time	Running time counter of pump/fan 1. Can be set or reset by parameter 77.10 Pump/fan 1 running time.	0.00 h	
	0.0042949672.95 h	Time	1 = 1 h	
77.12	Pump/fan 2 running time	See parameter 77.11 Pump/fan 1 running time.	0.00 h	
77.13	Pump/fan 3 running time	See parameter 77.11 Pump/fan 1 running time.	0.00 h	
77.14	Pump/fan 4 running time	See parameter 77.11 Pump/fan 1 running time.	0.00 h	

90 Feedback selection		Load feedback configuration.	
90.03	Load speed	Displays the estimated load speed. Load speed = (90.62 Gear denominator 90.61 Gear numerator) X 01.01 Motor speed used	
	-32768.00 32767.00 rpm	Load speed.	1 = 1 rpm
90.52	LoadSpeed filter time	Defines a filter time for load speed feedback (90.03 Load speed).	10 ms
	010000 ms	Load speed filter time.	1 = 1 ms
90.61	Gear numerator	Parameter 90.61 and 90.62 define a gear function between the motor and load speed. 90.61 Gear numerator = Motor speed	1
		90.62 Gear denominator Load speed	
	-2147483648 2147483647	Gear numerator (motor-side)	-
90.62	Gear denominator	See parameter 90.61 Gear numerator.	1

No. Name/Value		Description	Def/FbEq16
	-2147483648 2147483647	Gear denominator (load - side)	-
90.99	Load speed unit	Selects the unit for parameter 90.03 Load speed.	rpm
	No unit	No unit	0
	rpm	rpm	7
	m/s	m/s	41
	m/min	m/min	42
	ft/s	ft/s	43
	ft/min	ft/min	45

95 HW	[/] configuration	Various hardware-related settings.	
95.01	Supply voltage	Selects the supply voltage range. This parameter is used by the drive to determine the nominal voltage of the supply network. The parameter also affects the current ratings and the DC voltage control functions (trip and brake chopper activation limits) of the drive. Mathematical Activation and the DC voltage control functions (trip and brake chopper activation limits) of the drive. Mathematical Activation and the brake chopper of the brake chopper or resistor to rush uncontrollably, or the brake chopper or resistor to overload. Note: The selections shown depend on the hardware of the drive. If only one voltage range is valid for the drive in question, it is selected by default.	380415 V
	Automatic / not selected	No voltage range selected. The drive will not start modulating before a range is selected, unless parameter <i>95.02 Adaptive voltage limits</i> is set to <i>Enable</i> , in which case the drive estimates the supply voltage itself.	0
	380415 V	380415 V	2
95.02	Adaptive voltage limits	Enables adaptive voltage limits. Adaptive voltage limits can be used if, for example, an IGBT supply unit is used to raise the DC voltage level. If the communication between the inverter and IGBT supply unit is active, the voltage limits are related to the DC voltage reference from the IGBT supply unit. Otherwise the limits are calculated based on the measured DC voltage at the end of the pre-charging sequence. This function is also useful if the AC supply voltage to the drive is high, as the warning levels are raised accordingly.	Disable
	Disable	Adaptive voltage limits disabled.	0
	Enable	Adaptive voltage limits enabled.	1
95.03	Estimated AC supply voltage	AC supply voltage estimated by calculation. Estimation is done every time the drive is powered up and is based on the rise speed of voltage level of the DC bus while the drive charges the DC bus.	0
	065535 V	Voltage.	10 = 1 V
95.04	Control board supply	Specifies how the control board of the drive is powered.	Internal 24V
	Internal 24V	The drive control board is powered from the drive power unit it is connected to.	0
	External 24V	The drive control board is powered from an external power supply.	1

lo.	o. Name/Value		Descri	Description		
5.15	Special HW Conta settings disab Note: parar		disable Note: 7 param	ription Def/FbEq1 ains hardware-related settings that can be enabled and led by toggling the specific bits. 0b0000 The installation of the hardware specified by this neter may require derating of drive output, or impose limitations. Refer to the hardware manual of the drive. 0b0000		
	Bit	Name		Information		
	0	Reserved				
	1	ABB Sine filter		1 = An ABB sine filter is connected to the output of the	drive.	
	215	Reserved				
	060000	0b1111	Hardw	are options configuration word.	1 = 1	
5.20		ions word 1		ies hardware-related options that require differentiated	060000	
5.20	πνν ορι			eter defaults.	000000	
				arameter is not affected by a parameter restore.		
			1		Ĩ	
	Bit	Name		Value		
	0	Supply frequency 60 Hz Reserved du/dt filter activation		If you change the value of this bit, you have to do a complete reset to the drive after the change. After reset you have to reselect the macro to be used. See section <i>Differences in the default values between 50 Hz and</i> 60 Hz supply frequency settings on page 378.0 = 50 Hz.		
	112			1 = 60 Hz.		
	13			When active, an external du/dt filter is connected to the drive/inveroutput. The setting will limit the output switching frequency, and force the fan of the drive/inverter module to full speed. 0 = du/dt filter inactive. 1 = du/dt filter active.		
	14	Output contactor		 When active, an output contactor is connected betwee and motor and resets the below faults in parameter 31. selection Bit 0 Overcurrent Bit 5 OverFrequency, Bit 6 EarthFault, Bit 7 Shortcircuit Note: The Output contactor bit does not effect other bit parameter 31.12. When enabled, the values of parameters 31.14, 31.15, should be set as follows: 31.14 Number of trials = 1, 31.15 Total trials time = 2s, 31.16 Delay time = 1s. 0 = output contactor inactive 1 = output contactor active 	12 Autoreset	
	15	Reserved		. super contractor detire		
	-					

No.	Name/Value		Descri	ption	Def/FbEq16
95.21 HW options word 2		differe	es more hardware-related options that require titated parameter defaults. See parameter 95.20 HW s word 2. WARNING! An incorrect setting may cause the motor to rush uncontrollably, or the brake chopper or resistor to overload.	060000	
	Bit	Name		Value	
	05	Reserved			
	6	Cabinet driv	ve	0 = Inactive, 1 = Active. Only for drive frames R6 or large	ger.
	7	Reserved		0 = Inactive, 1 = Active. Only for drive frames R6 or large	ger.
	815	Reserved			
	0b0000.	0b1111	Hardw	are options configuration word.	1 = 1
95.26	5.26 Motor disconnect switch		enable does n but ren after a When ' the foll 1. Mot and ope 2. Mot rem last Note: ⁻	s the use of the motor disconnect switch. When d, the drive ot trip to a fault when it detects the disconnection nains operational and returns to normal operation reconnection. this parameter is enabled, the drive will go through owing sequence: or is disconnected: Drive detects the disconnection indicates it with warning <i>A784</i> . The drive remains in ration and waits for motor reconnection. or is reconnected: Drive detects the reconnection, oves the warning and returns to normal operation. The active reference before the disconnection is in use. This feature is only available in scalar mode. This eter does not affect vector mode behavior.	Disable
Disable		Motor disconnect switch disabled. Motor disconnect switch enabled.		0	
	Enable			1	
95.200 Cooling fan mode		enable	s the fan control type. The fan control functionality s heat dissipation from the drive and avoids dust ulation in the drive.	Auto	
	Auto			Is the fan automatically according to the temperature as of the drive.	0
	Always c	n		ns continuously with maximum speed (main fan al speed).	1
96 System		param	age selection; access levels; macro selection; eter save and restore; control unit reboot; user eter sets; unit selection.		
96.01	Languag	le	display Notes: • Not • This Driv	s the language of the parameter interface and other red information when viewed on the control panel. all languages listed below are necessarily supported. parameter does not affect the languages visible in the e composer PC tool. (Those are specified under View sttings – Drive default language .)	Not selected
	Not selee	cted	None.		0
	English		English	n.	1033
	Hindi (In	dia)	Hindi.		2052

No.	Name/V	alue	Description	Def/FbEq16	
96.02 Pass code			Pass codes can be entered into this parameter to activate further access levels (see parameter 96.03 Access level status) or to configure the user lock. Entering "358" toggles the parameter lock, which prevents the changing of all other parameters through the control panel or the Drive composer PC tool. Entering the user pass code (by default, "10000000") enables parameters 96.10096.102, which can be used to define a new user pass code and to select the actions that are to be prevented. Entering an invalid pass code will close the user lock if open, ie. hide parameters 96.10096.102. After entering the code, check that the parameters are in fact hidden. Note: You must change the default user pass code to maintain a high level of cybersecurity. Store the code in a safe place – the protection cannot be disabled even by ABB if the code is lost.	0	
			Pass code.	-	
96.03	Access	level status	Shows which access levels have been activated by pass codes entered into parameter <i>96.02 Pass code</i> .	0b0000	
	0b00000b1111			1=1	
	Bit	Name			
	0	End user	user		
	19	Reserved	erved		
	10	Override pa	Override parameter lock		
	11	OEM acces	DEM access level 1		
	12	OEM acces	DEM access level 2		
	13	OEM acces			
	14	Parameter	lock		
	15 Reserved				
	0b0000.	0b1111	Active access levels.	-	
96.04	4 Macro select		Selects the control macro. See chapter <i>Control macros</i> (page 101) for more information. After a selection is made, the parameter reverts automatically to <i>Done</i> .	Done	
	Done		Macro selection complete; normal operation.	0	
	ABB sta	ndard	Factory macro (see page 102). For scalar motor control.	1	
	ABB sta (vector)	ndard	ABB standard (vector) macro (see page 105). For vector motor control.	17	
	3-wire		3-wire macro (see page 108)		
	Motor potentiometer		Motor potentiometer macro (see page 111).	13	
	potentio			14	
	potentio PID		PID macro (see page 116).	14	
	•		PID macro (see page 116). Panel PID macro (see page 119).	15	
	PID				
	PID Panel P		Panel PID macro (see page 119).	15	

No.	Name/Value	Description	Def/FbEq16
	Plastic Extrusion	Plastic extrusion (see page 146)	20
	Torque control	Torque control (see page 122)	28
	Jigar	Jigar macro (see page 149)	30
96.05	Macro active	Shows which control macro is currently selected. See chapter <i>Control macros</i> (page 101) for more information. To change the macro, use parameter 96.04 <i>Macro select</i> .	ABB standard
	ABB standard	Factory macro (see page 102). For scalar motor control.	1
	ABB standard (vector)	ABB standard (vector) macro (see page 105). For vector motor control.	17
	3-wire	3-wire macro (see page 108)	
	Motor potentiometer	Motor potentiometer macro (see page 111).	13
	PID	PID macro (see page 116).	14
	Panel PID	Panel PID macro (see page 119).	15
	PFC	PFC macro (see page 125).	16
	SPFC	SPFC macro (see page 134)	18
	Pharma Application	Pharma application (see page 143)	19
	Plastic Extrusion	Plastic extrusion (see page 146)	20
	Torque control	Torque control (see page 122)	28
	Jigar	Jigar macro (see page 149)	30
96.06	Parameter restore	Restores settings and all editable parameters back to initial factory values, except differentiated defaults implemented by parameters <i>95.20 HW options word 1</i> and <i>95.21 HW options word 2</i> . Note: This parameter cannot be changed while the drive is running.	Done
	Done	Restoring is completed.	0
	Reset motor data	Restore all motor rating ID run results to default values	2
	Restore defaults	 Restores all editable parameter values to default values, except motor data and ID run results I/O extension module settings end user texts, such as customized warnings and faults, and the drive name control panel/PC communication settings fieldbus adapter settings control macro selection and the parameter defaults implemented by it parameter 95.20 HW options word 1 and the differentiated defaults implemented by it. 	8
	Reset all fieldbus settings	Restores all fieldbus and communication related settings to default values. Note: Fieldbus, control panel and PC tool communication are interrupted during the restore.	32

No.	Name/Value	Description	Def/FbEq16
	Clear all	 Restores all editable parameter values to default values, except end user texts, such as customized warnings and faults, and the drive name control macro selection and the parameter defaults implemented by it parameter 95.20 HW options word 1 and the differentiated defaults implemented by it group 49 Panel port communication parameters. 	62
	Reset home view	Restores the home view layout back to show the values of the default parameters defined by the control macro in use	512
	Reset end user texts	Restores all end user texts to default values, including the drive name, contact info, customized fault and warning texts and currency unit. Note: PID unit is reset only if it is user editable text, that is, parameter <i>40.79 Set 1 units</i> is set to User text.	1024
	All to factory defaults	 Restores settings and all editable parameters back to initial factory values, except, differentiated defaults implemented by parameters 95.20 <i>HW options word 1</i> and 95.21 <i>HW options word 2</i>. 	34560
96.07	Parameter save manually	 Saves the valid parameter values to the permanent memory on the drive control unit to ensure that operation can continue after cycling the power. Save the parameters with this parameter to store values sent from the fieldbus when using external +24 V DC power supply to the control unit: to save parameter changes before you power down the control unit. The supply has a very short hold-up time when powered off. Note: A new parameter value is saved automatically when changed from the PC tool or control panel but not when altered through a fieldbus adapter connection. 	Done
	Done	Save completed.	0
	Save	Save in progress.	1
96.08	Control board boot	Changing the value of this parameter to 1 reboots the control unit (without requiring a power off/on cycle of the complete drive module). The value reverts to 0 automatically.	No action
	No action	1 = No action.	0
	Reboot	1 = Reboot the control unit.	1
96.10	User set status	Shows the status of the user parameter sets. This parameter is read-only. See also section <i>User parameter sets</i> (page <i>95</i>).	n/a
	n/a	No user parameter sets have been saved.	0
	Loading	A user set is being loaded.	1
	Saving	A user set is being saved.	2
	Faulted	Invalid or empty parameter set.	3
	User1 IO active	User set 1 has been selected by parameters 96.12 User set I/O mode in1 and 96.13 User set I/O mode in2.	4
	User2 IO active	User set 2 has been selected by parameters 96.12 User set I/O mode in1 and 96.13 User set I/O mode in2.	5

No.	Name/Value	Description			Def/FbEq16
	User3 IO active	User set 3 has been I/O mode in1 and 96			6
	User4 IO active	User set 4 has been I/O mode in1 and 96			7
	Reserved				819
	User1 backup	User set 1 has been	saved or loaded.		20
	User2 backup	User set 2 has been	saved or loaded.		21
	User3 backup	backup User set 3 has been saved or loaded.			22
	User4 backup	User set 4 has been	23		
96.11	User set save/load	 Enables the saving and restoring of up to four custom sets of parameter settings. The set that was in use before powering down the drive is in use after the next power-up. Notes: Some hardware configuration settings, such as I/O extension module and fieldbus configuration parameters (groups 1416, 47, 5058 and 9293) are not included in user parameter sets. Parameter changes made after loading a set are not automatically stored – they must be saved using this parameter. This parameter cannot be changed while the drive is 			No action
	No action Load or save operation complete; normal operation.			operation.	0
	User set I/O mode	t I/O mode Load user parameter set using parameters 96.12 User set I/O mode in1 and 96.13 User set I/O mode in2.			1
	Load set 1	Load user paramete	2		
	Load set 2	Load user paramete	3		
	Load set 3	Load user paramete	4		
	Load set 4	Load user paramete	5		
	Save to set 1	Save user paramete	18		
	Save to set 2	Save user paramete	19		
	Save to set 3	Save user paramete	20		
	Save to set 4	Save user paramete	21		
96.12	User set I/O mode in1	When parameter 96. I/O mode, selects the parameter 96.13 Use Status of source defined by par. 96.12	e user parameter set	together with	Not selected
		0	0	Set 1	
		1	0	Set 2	
		0	1	Set 3	
		1	1	Set 4	
	Not selected 0.				0
	Selected	1.			1

No.	Name/\	/alue	Description	Def/FbEq16	
	DI1		Digital input DI1 (10.02 DI delayed status, bit 0).	2	
	DI2		Digital input DI2 (10.02 DI delayed status, bit 1).	3	
	DI3 DI4 DI5 DI6 Timed function 1		Digital input DI3 (10.02 DI delayed status, bit 2).	4	
			Digital input DI4 (10.02 DI delayed status, bit 3).	5	
			Digital input DI5 (10.02 DI delayed status, bit 4).	6	
			Digital input DI6 (10.02 DI delayed status, bit 5).	7	
			Bit 0 of 34.01 Timed functions status (see page 280).	18	
	Timed f	unction 2	Bit 1 of 34.01 Timed functions status (see page 280).	19	
	Timed f	unction 3	Bit 2 of 34.01 Timed functions status (see page 280).	20	
	Superv	ision 1	Bit 0 of 32.01 Supervision status (see page 273).	24	
	Superv	ision 2	Bit 1 of 32.01 Supervision status (see page 273).	25	
	Superv	ision 3	Bit 2 of 32.01 Supervision status (see page 273).	26	
	Other [l	bit]	Source selection (see <i>Terms and abbreviations</i> on page 161).	-	
96.13	User se in2	et I/O mode	See parameter 96.12 User set I/O mode in1.	Not selected	
96.16	Unit sei	lection	Selects the unit of parameters indicating power, temperature and torque.	0b0000	
	Bit Name		Information		
	0	Power unit	0 = kW		
			1 = hp		
	1 2	Reserved	0 = °C		
	2	Temperatu unit	e 0 = C 1 = °F		
	3	Reserved			
	4	Torque unit	0 = Nm (N·m)		
			1 = lbft (lb·ft)		
	515 Reserved				
	0b00000b1111		Unit selection word.	1 = 1	
96.20	Time sync primary source		Defines the 1st priority external source for synchronization of the drive's time and date. The date and time can also be directly set into parameters $96.2496.26$, in which case this parameter is ignored.	Panel link	
			No external source selected.	0	
			FENA/FPNO can get the time from SNTP server and set it as time for the drive.	3	
			EFB BACnet MS/TP time-sync service can be used to set the time for the drive.	6	
	Panel li	nk	You can set the time using control panel, or Drive composer PC tool connected to the control panel.	8	
	Etherne	et tool link	You can set the time manually by using DCP over Ethernet. The time can be set in the same way when you do it with USB and panel.	9	

No.	Name/Value	Description	Def/FbEq16
96.24	Full days since 1st Jan 1980	The number of full days passed since beginning of the year 1980. This parameter, together with <i>96.25 Time in minutes within 24h</i> and <i>96.26 Time in ms within one minute</i> makes it possible to set the date and time in the drive via the parameter interface from a fieldbus or application program. This may be necessary if the fieldbus protocol does not support time synchronization.	12055
	159999	Days since beginning of 1980.	1 = 1
96.25	Time in minutes within 24h	The number of full minutes passed since midnight. For example, the value 860 corresponds to 2:20 pm. See parameter 96.24 <i>Full days since 1st Jan 1980</i> .	0 min
	11439	Minutes since midnight.	1 = 1
96.26	<i>Time in ms within one minute</i>	The number of milliseconds passed since the previous minute. See parameter 96.24 <i>Full days since 1st Jan 1980</i> .	0 ms
	059999	Number of milliseconds since last minute.	1 = 1
96.51	Clear fault and event logger	Clears all events from the drive's fault and event logs.	Done
	Done	1 = No action	0
	Reset	1 = Resets (clears) fault and event logger.	1
96.78	550 compatibility mode	Enables/disables a Modbus user to access a select set of parameters using 550 register numbering.	Enable
	Disable	Using 550 compatibility mode is disabled.	0
	Enable	Using 550 compatibility mode is enabled.	1
96.100	Change user pass code	(Visible when user lock is open) To change the current user pass code, enter a new code into this parameter as well as 96.101 Confirm user pass code. A warning will be active until the new pass code is confirmed. To cancel changing the pass code, close the user lock without confirming. To close the lock, enter an invalid pass code in parameter 96.02 Pass code, activate parameter 96.08 Control board boot, or cycle the power. See also section User lock (page 96).	1000000
	10000000 99999999	New user pass code.	-
96.101	Confirm user pass code	(Visible when user lock is open) Confirms the new user pass code entered in 96.100 Change user pass code.	
	10000000 99999999	Confirmation of new user pass code.	-

No.	Name/Value		Descript	ion	Def/FbEq16
96.102	User lock (Visible when user lock is open) functionality Selects the actions or functionalities to be prevented by the user lock. Note that the changes made take effect only when the user lock is closed. See parameter 96.02 Pass code. Note: We recommend you select all the actions and functionalities unless otherwise required by the application.				0000h
	Bit	Bit Name Information			
	0	Disable AB levels	B access	 1 = ABB access levels (service, advanced programmer, etc.; see 96.03) disabled 1 = Changing the parameter lock state prevented, ie. pass code 358 has no effect 	
	1	Freeze para lock state	ameter		
	2 Disable file download 1 = Loading of files to drive prevented. This applies • firmware upgrades • parameter restore • changing home view of control panel • editing drive texts • editing the favorite parameters list on control pane • configuration settings made through control pane time/date formats and enabling/disabling clock di				
	35	Reserved			
	6	Protect AP		1 = Creating a backup and restoring from a backup p	revented.
	7	Disable par Bluetooth	nel	1 = Bluetooth disabled on ACS-AP-W control panel. If the drive is part of a panel bus, Bluetooth is disabled on all panels.	
	810	Reserved			
	11	Disable OE level 1	M access	s 1 = OEM access level 1 disabled	
	12	Disable OE level 2	M access	1 = OEM access level 2 disabled	
	13	Disable OE level 3	M access	1 = OEM access level 3 disabled	
	1415	Reserved			
	0000h.	FFFFh	Selection	of actions to be prevented by user lock.	-

97 Motor control		Switching frequency; slip gain; voltage reserve; flux braking; anti-cogging (signal injection); IR compensation.	
97.01	Switching frequency reference	 Defines the switching frequency of the drive that is used as long as the drive does not heat too much. See section <i>Switching frequency</i> on page 71. Higher switching frequency results in lower acoustic noise-Notes If you have a multimotor system, contact your local ABB representative. 2 kHz option is not available in R0R2 frames. 	4 kHz
	2 kHz	2 kHz	2
	4 kHz	4 kHz	4
	8 kHz	8 kHz	8

No.	Name/Value	Description	Def/FbEq16
	12 kHz	12 kHz	12
97.02	Minimum switching frequency	Lowest switching frequency that is allowed. Depends on the frame size.	1.5 kHz
	1.5 kHz	1.5 kHz (available only in R0R2 frames)	1.5
	2 kHz	2 kHz.	2
	4 kHz	4 kHz.	4
	8 kHz	8 kHz.	8
	12 kHz	12 kHz	12
97.03	Slip gain	Defines the slip gain which is used to improve the estimated motor slip. 100% means full slip gain; 0% means no slip gain. The default value is 100%. Other values can be used if a static speed error is detected despite having the setting at full slip gain. Example (with nominal load and nominal slip of 40 rpm): A 1000 rpm constant speed reference is given to the drive. Despite having full slip gain (= 100%), a manual tachometer measurement from the motor axis gives a speed value of 998 rpm. The static speed error is 1000 rpm - 998 rpm = 2 rpm. To compensate the error, the slip gain should be increased to 105% (2 rpm / 40 rpm = 5%).	100%
	0200%	Slip gain.	1 = 1%
97.04	Voltage reserve	Defines the minimum allowed voltage reserve. When the voltage reserve has decreased to the set value, the drive enters the field weakening area. Note: This is an expert level parameter and should not be adjusted without appropriate skill. If the intermediate circuit DC voltage $U_{dc} = 550$ V and the voltage reserve is 5%, the RMS value of the maximum output voltage in steady-state operation is 0.95×550 V / sqrt(2) = 369 V The dynamic performance of the motor control in the field weakening area can be improved by increasing the voltage reserve value, but the drive enters the field weakening area earlier. Warning: Decreasing the voltage reserve parameter to -5% to get higher voltage leads to higher harmonics in output current, typically 8 - 10%, as the drive is operating in overmodulation region.	-2%
	-450%	Voltage reserve.	1 = 1%
97.05	Flux braking	Defines the level of flux braking power. (Other stopping and braking modes can be configured in parameter group <i>21 Start/stop mode</i>). Note: This is an expert level parameter and should not be adjusted without appropriate skill.	Disabled
	Disabled	Flux braking is disabled.	0
	Moderate	Flux level is limited during the braking. Deceleration time is longer compared to full braking.	1

No.	Name/Value	Description	Def/FbEq16	
	Full Maximum braking power. Almost all available current is used to convert the mechanical braking energy to thermal energy in the motor. WARNING! Using full flux braking heats up the motor especially in cyclic operation. Make sure that the motor can withstand this if you have a cyclic application.			
97.08	Optimizer minimum torque	As a rule of thumb, define a level to which the output torque must rise with minimum delay. This will increase the motor current and improve the torque response at low speeds.	0.0	
	0.01600.0%	Optimizer torque limit.	10 = 1%	
97.13	IR compensation	Defines the relative output voltage boost at zero speed (IR compensation). The function is useful in applications with a high break-away torque where vector control cannot be applied. U / U _N (%) Relative output voltage. IR compensation set to 15%. 100% IS% Field weakening point 50% of nominal frequency See also section <i>IR compensation for scalar motor control</i> on page 65. Typical IR compensation values are shown below.	3.50%	
		3-phase 380415V drives		
		$\begin{array}{ c c c c c c c c c c c c c c c c c c c$		
	0.0050.00%	operated for longer periods at low speed. Voltage boost at zero speed in percent of nominal motor voltage.	1 = 1%	
97.20	U/F ratio	Selects the form for the <i>Ulf</i> (voltage to frequency) ratio below field weakening point. For scalar control only.	Linear	
	Linear	Linear ratio for constant torque applications.	0	

No.	Name/Value	Description	Def/FbEq16
	Squared	Squared ratio for centrifugal pump and fan applications. With squared U/f ratio the noise level is lower for most operating frequencies.	1
97.48	Udc stabilizer	Disabled	
	Disabled	DC bus voltage stabilizer disabled.	0
	Enabled min	DC bus voltage stabilizer enabled, minimum stabilization.	50
	Enabled mild	DC bus voltage stabilizer enabled, mild stabilization.	100
	Enabled medium	DC bus voltage stabilizer enabled, medium stabilization.	300
	Enabled strong	DC bus voltage stabilizer enabled, strong stabilization.	500
	Enabled max	DC bus voltage stabilizer enabled, maximum stabilization.	800
97.49	 7.49 Slip gain for scalar Sets gain for slip compensation (in %) while drive is oper in scalar control mode. A squirrel-cage motor slips under load. Increasing the frequency as the motor torque increases compensate the slip. Requires parameter 99.04 Motor control mode = Sca 0 = No slip compensation. 1200 = Increasing slip compensation. 100% means fu compensation according to parameters 99.08 Motor nor frequency and 99.09 Motor nominal speed. 		0
	0200 %	Slip compensation in %.	1 = 1%
97.94	IR comp max frequency	Sets the frequency at which IR compensation (set by parameter 97.13 <i>IR compensation</i>) reaches 0 V. The unit is % of motor nominal frequency. IR compensation When enabled, IR compensation provides an extra voltage boost to the motor at low speeds. Use IR compensation, for example, in applications that require a high breakaway torque. Motor voltage 97.13 97.13 97.94	80.0
	1.0200.0 %	IR compensation maximum frequency in %.	1 = 1%
97.135	UDC ripple	Displays ripple voltage.	0.0 V

No.	Name/Value	Description	Def/FbEq16
98 Use param	er motor neters	Motor values supplied by the user that are used in the motor model. These parameters are useful for non-standard motors, or to just get more accurate motor control of the motor on site. A better motor model always improves the shaft performance.	
98.01	User motor model mode	 Activates the motor model parameters 98.0298.12. Notes: Parameter value is automatically set to zero when ID run is selected by parameter 99.13 ID run requested. The values of parameters 98.0298.12 are then updated according to the motor characteristics identified during the ID run. Measurements made directly from the motor terminals during the ID run are likely to produce slightly different values than those on a data sheet from a motor manufacturer. This parameter cannot be changed while the drive is running. 	Not selected
	Not selected	Parameters 98.0298.12 inactive.	0
	Motor parameters	The values of parameters <i>98.02 98.12</i> are used as the motor model.	1
98.02	Rs user	Defines the stator resistance $R_{\rm S}$ of the motor model. With a star-connected motor, $R_{\rm S}$ is the resistance of one winding. With a delta-connected motor, $R_{\rm S}$ is one-third of the resistance of one winding.	0.00000 p.u.
	0.000000.50000 p.u.	Stator resistance in per unit.	-
98.03	Rr user	Defines the rotor resistance R_R of the motor model.	0.00000 p.u.
	0.000000.50000 p.u.	Rotor resistance in per unit.	-
98.04	Lm user	Defines the main inductance L_{M} of the motor model.	0.00000 p.u.
	0.0000010.00000 p.u.	Main inductance in per unit.	-
98.05	SigmaL user	Defines the leakage inductance $\mathbf{\sigma}_{L_{S}}$.	0.00000 p.u.
	0.000001.00000 p.u.	Leakage inductance in per unit.	-
98.09	Rs user SI	Defines the stator resistance $R_{\rm S}$ of the motor model.	0.00000 ohm
	0.00000100.0000 0 ohm	Stator resistance.	-
98.10	Rr user SI	Defines the rotor resistance R_R of the motor model.	0.00000 ohm
	0.00000100.0000 0 ohm	Rotor resistance.	-
98.11	Lm user SI	Defines the main inductance L_{M} of the motor model.	0.00 mH
	0.00100000.00 mH	Main inductance.	1 = 10000 mH
98.12	SigmaL user SI	Defines the leakage inductance $\mathbf{\sigma}_{L_{S}}$.	0.00 mH
	0.00100000.00 mH	Leakage inductance.	1 = 10000 mH

No.	Name/Value	Description	Def/FbEq16
99 Mo	tor data	Motor configuration settings.	
99.03	Motor type	Selects the motor type. Note: This parameter cannot be changed while the drive is running.	Asynchro- nous motor
	Asynchronous motor	Standard squirrel cage AC induction motor (asynchronous induction motor).	0
99.04	Motor control mode	Selects the motor control mode.	Scalar
	Vector	Vector control. Vector control has better accuracy than scalar control but cannot be used in all situations (see selection <i>Scalar</i> below). Requires motor identification run (ID run). See parameter <i>99.13 ID run requested</i> .	0
		Note: In vector control the drive performs a standstill ID run at the first start if ID run has not been previously performed. A new start command is required after standstill ID run. Note: To achieve a better motor control performance, you can perform a normal ID run without load.	
		See also section <i>Operating modes of the drive</i> (page 37).	
	Scalar	 Scalar control. Suitable for most applications, if top performance is not required. Motor identification run is not required. Note: Scalar control must be used in the following situations: with multimotor systems 1) if the load is not equally shared between the motors, 2) if the motors are of different sizes, or 3) if the motors are going to be changed after the motor identification (ID run) if the nominal current of the motor is less than 1/6 of the nominal output current of the drive if the drive is used with no motor connected (for example, for test purposes). Note: Correct motor operation requires that the magnetizing current of the inverter. See also section Speed compensated stop (page 75), and section Operating modes of the drive (page 37). 	1
99.06	Motor nominal current	 Defines the nominal motor current. Must be equal to the value on the motor rating plate. If multiple motors are connected to the drive, enter the total current of the motors. Notes: Correct motor operation requires that the magnetizing current of the motor does not exceed 90% of the nominal current of the drive. This parameter cannot be changed while the drive is running. 	4.7 A
	0.011.2 A	 Nominal current of the motor. The allowable range: vector control mode: 1/62 × I_N of the drive scalar control mode: 02 × I_N with scalar control mode. Note: When using flying start in scalar control mode (see parameter 21.19 Scalar start mode), the nominal current must be in the range allowed for vector control mode. 	1 = 0.01 A See 46.05

No.	Name/Value	Description	Def/FbEq16
99.07	Motor nominal voltage	 Defines the nominal motor voltage supplied to the motor. This setting must match the value on the rating plate of the motor. Notes: The stress on the motor insulation is always dependent on the drive supply voltage. This also applies to the case where the motor voltage rating is lower than that of the drive and the supply. This parameter cannot be changed while the drive is running. 	400.0 V
	0.032767.0 V	Nominal voltage of the motor.	10 = 1 V
99.08	Motor nominal frequency	Defines the nominal motor frequency. This setting must match the value on the rating plate of the motor. Note: This parameter cannot be changed while the drive is running.	50.00 Hz
	0.00500.00 Hz	Nominal frequency of the motor.	10 = 1 Hz
99.09	Motor nominal speed	Defines the nominal motor speed. The setting must match the value on the rating plate of the motor. Note: This parameter cannot be changed while the drive is running.	1430 rpm
	030000 rpm	Nominal speed of the motor.	1 = 1 rpm
99.10	Motor nominal power	Defines the nominal motor power. The setting must match the value on the rating plate of the motor. If multiple motors are connected to the drive, enter the total power of the motors. The unit is selected by parameter 96.16 Unit selection. Note: This parameter cannot be changed while the drive is running.	0.75 kW
	0.00… 10000.00 kW or hp	Nominal power of the motor.	1 = 1 unit
99.11	Motor nominal cos Φ	 Defines the cosphi of the motor for a more accurate motor model. The value is not obligatory, but is useful with an asynchronous motor, especially when performing a standstill identification run. Notes: Do not enter an estimated value. If you do not know the exact value, leave the parameter at zero. This parameter cannot be changed while the drive is running. 	0.00
	0.001.00	Cosphi of the motor.	100 = 1
99.12	Motor nominal torque	Defines the nominal motor shaft torque for a more accurate motor model. Not obligatory. The unit is selected by parameter <i>96.16 Unit selection</i> . Note: This parameter cannot be changed while the drive is running.	0.000 N·m or lb∙ft
	0.0004000000.000 N·m or 0.0002950248.597 Ib·ft	Nominal motor torque.	1 = 100 unit

No.	Name/Value	Description	Def/FbEq16
99.13	ID run requested	 Selects the type of the motor identification routine (ID run) performed at the next start of the drive. During the ID run, the drive will identify the characteristics of the motor for optimum motor control. If no ID run has been performed yet (or if default parameter values have been restored using parameter 96.06 Parameter restore), this parameter is automatically set to Standstill, signifying that an ID run must be performed. After the ID run, the drive stops and this parameter is automatically set to None. Notes: To ensure that the ID run can work properly, the drive limits in group 30 (maximum speed and minimum speed, and maximum torque and minimum torque) must to be large enough (the range specified by the limits must be wide enough. If e.g. speed limits are less than the motor nominal speed, the ID run cannot be completed. For the Advanced ID run, the machinery must always be de-coupled from the motor. Once the ID run is activated, it can be canceled by stopping the drive. The ID run must be performed every time any of the motor parameters (99.04, 99.0699.12) have been changed. Ensure that the Safe Torque Off and emergency stop circuits (if any) are closed during the ID run. Mechanical brake (if present) is not opened by the logic for the ID run. 	None
	None	No motor ID run is requested. This mode can be selected only if the ID run (<i>NormallReduced/Standstill/Advanced</i>) has already been performed once.	0
	Normal	 Normal ID run. Guarantees good control accuracy for all cases. The ID run takes about 90 seconds. This mode should be selected whenever it is possible. Notes: If the load torque will be higher than 20% of motor nominal torque, or if the machinery is not able to withstand the nominal torque transient during the ID run, then the driven machinery must be de-coupled from the motor during a Normal ID run. Check the direction of rotation of the motor before starting the ID run. During the run, the motor will rotate in the forward direction. WARNING! The motor will run at up to approximately 50100% of the nominal speed during the ID run. Make sure that it is safe to run the motor before performing the ID run. 	1

No.	Name/Value	Description	Def/FbEq16
	Reduced	 Reduced ID run. This mode should be selected instead of the <i>Normal</i> or <i>Advanced</i> ID Run if mechanical losses are higher than 20% (ie. the motor cannot be de-coupled from the driven equipment), or if flux reduction is not allowed while the motor is running (ie. in case of a motor with an integrated brake supplied from the motor terminals). With this ID run mode, the resultant motor control in the field weakening area or at high torques is not necessarily as accurate as motor control following a Normal ID run. Reduced ID run is completed faster than the Normal ID Run (< 90 seconds). Note: Check the direction of rotation of the motor before starting the ID run. During the run, the motor will rotate in the forward direction. MARNING! The motor will run at up to approximately 50100% of the nominal speed during the ID run. ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE ID RUN! 	2
	Standstill	Standstill ID run. The motor is injected with DC current. With an AC induction (asynchronous) motor, the motor shaft is not rotated. Note: This mode should be selected only if the <i>Normal</i> , <i>Reduced</i> or <i>Advanced</i> ID run is not possible due to the restrictions caused by the connected mechanics (e.g. with lift or crane applications).	3
	Advanced	Advanced ID run. Only for frames R6R8. Guarantees the best possible control accuracy. The ID run takes a very long time to complete. This mode should be selected when top performance is needed across the whole operating area. Note: The driven machinery must be de-coupled from the motor because of high torque and speed transients that are applied. WARNING! The motor may run at up to the maximum (positive) and minimum (negative) allowed speed during the ID run. Several accelerations and decelerations are done. The maximum torque, current and speed allowed by the limit parameters may be utilized. ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE ID RUN!	6
	Adaptive	Adaptive ID run. Initially, drive runs in Standstill ID run mode and then refines the motor parameters during the normal operation. This helps to achieve more optimal performance. Note: This is applicable for R0R5 frames only.	7
99.14	Last ID run performed	Shows the type of ID run that was performed last. For more information about the different modes, see the selections of parameter 99.13 ID run requested.	None
	None	No ID run has been performed.	0
	Normal	Normal ID run.	1
	Reduced	Reduced ID run.	2
	Standstill	Standstill ID run.	3
	Advanced	Advanced ID run.	6
	Adative	Adaptive ID run.	7

No.	Name/Value	Description	Def/FbEq16
99.15	Motor polepairs calculated	Calculated number of pole pairs in the motor.	0
	01000	Number of pole pairs.	1 = 1
99.16	Motor phase order	 Switches the rotation direction of motor. This parameter can be used if the motor turns in the wrong direction (for example, because of the wrong phase order in the motor cable), and correcting the cabling is considered impractical. Note: Changing this parameter does not affect speed reference polarities, so positive speed reference will rotate the motor forward. The phase order selection just ensures that "forward" is in fact the correct direction. 	UVW
	UVW	Normal.	0
	UWV	Reversed rotation direction.	1

Differences in the default values between 50 Hz and 60 Hz supply frequency settings

Parameter 95.20 HW options word 1 bit 0 Supply frequency 60 Hz changes the drive parameter default values according to the supply frequency, 50 Hz or 60 Hz. The bit is set according to the market before the drive is delivered.

If you need to change from 50 Hz to 60 Hz, or vice versa, change the value of the bit and then do a complete reset to the drive. After that you have to reselect the macro to be used.

The table below shows the parameters whose default values depend on the supply frequency setting. The supply frequency setting, with the type designation of the drive, also affects Group *99 Motor data* parameter values though these parameters are not listed in the table.

No	Name	95.20 HW options word 1 bit Supply frequency 60 Hz = 50 Hz	95.20 HW options word 1 bit Supply frequency 60 Hz = 60 Hz
11.45	Freq in 1 at scaled max	1500.000	1800.000
12.20	Al1 scaled at Al1 max	1500.000	1800.000
13.18	AO1 source max	1500.0	1800.0
22.26	Constant speed 1	300.00 rpm	360.00 rpm
22.27	Constant speed 2	600.00 rpm	720.00 rpm
22.28	Constant speed 3	900 .00 rpm	1080.00 rpm
22.29	Constant speed 4	1200.00 rpm	1440.00 rpm
22.30	Constant speed 5	1500.00 rpm	1800.00 rpm
22.30	Constant speed 6	2400.00 rpm	2880.00 rpm
22.31	Constant speed 7	3000.00 rpm	3600.00 rpm
28.26	Constant frequency 1	5.00 Hz	6.00 Hz
28.27	Constant frequency 2	10.00 Hz	12.00 Hz
28.28	Constant frequency 3	15.00 Hz	18.00 Hz
28.29	Constant frequency 4	20.00 Hz	24.00 Hz
28.30	Constant frequency 5	25.00 Hz	30.00 Hz
28.31	Constant frequency 6	40.00 Hz	48.00 Hz
28.32	Constant frequency 7	50.00 Hz	60.00 Hz
30.11	Minimum speed	-1500.00 rpm	-1800.00 rpm
30.12	Maximum speed	1500.00 rpm	1800.00 rpm
30.13	Minimum frequency	-50.00 Hz	-60.00 Hz
30.14	Maximum frequency	50.00 Hz	60.00 Hz
31.26	Stall speed limit	150.00 rpm	180.00 rpm
31.27	Stall frequency limit	15.00 Hz	18.00 Hz
31.30	Overspeed trip margin	500.00 rpm	500.00 rpm
46.01	Speed scaling	1500.00 rpm	1800.00 rpm
46.02	Frequency scaling	50.00 Hz	60.00 Hz

Parameters supported by Modbus backwards compatibility with 550

ACx550 compatibility mode is a way to communicate with an ACx580 drive in such a way that it looks like an ACx550 drive over Modbus RTU or Modbus TCP. This mode can be enabled by changing parameter 96.78 550 compatibility mode to Enable.

In the 550 compatibility mode all supported parameters can be read as if the drive were an ACx550. Some parameters are read only and do not support writes. See the table below to see which parameters support writes.

And onlyAnd only01.02SPEEDRead only01.03OUTPUT FREQRead only01.04CURRENTRead only01.05TORQUERead only01.06POWERRead only01.07DC BUS VOLTAGERead only01.09OUTPUT VOLTAGERead only01.10DRIVE TEMPRead only01.15KWH COUNTERRead only01.16DI 1-3 STATUSRead only01.17DI 4-6 STATUSRead only01.18DI 1-3 STATUSRead only01.20Al 1Read only01.22RO 1-3 STATUSRead only01.24AO 1Read only01.25AO 2Read only01.28PID 1 SETPNTRead only01.30PID 2 SETPNTRead only01.31PID 2 FBKRead only01.32PID 1 DEVIATIONRead only	ACx550 parameter	Name	Read/Write	ACx550 parameter	Name
01.03OUTPUT FREQRead only01.04CURRENTRead only01.05TORQUERead only01.06POWERRead only01.07DC BUS VOLTAGERead only01.09OUTPUT VOLTAGERead only01.10DRIVE TEMPRead only01.15KWH COUNTERRead only01.18DI 1-3 STATUSRead only01.20Al 1Read only01.22RO 1-3 STATUSRead only01.24AO 1Read only01.25AO 2Read only01.20PID 1 SETPNTRead only01.22PID 1 SETPNTRead only01.30PID 2 FBKRead only01.31PID 2 FBKRead only01.32PID 1 DEVIATIONRead only	01.01	SPEED & DIR	Read only	01.34	COMM RO WO
01.04CURRENTRead only01.05TORQUERead only01.41MWH COUNTER01.06POWERRead only01.45MOTOR TEMP01.06POWERRead only03.01FB CMD WORD01.07DC BUS VOLTAGERead only03.02FB CMD WORD01.09OUTPUT VOLTAGERead only03.03FB STS WORD01.10DRIVE TEMPRead only03.04FB STS WORD01.15KWH COUNTERRead only03.05FAULT WORD 101.16DI 1-3 STATUSRead only03.07FAULT WORD 201.19DI 4-6 STATUSRead only03.08ALARM WORD01.20Al 1Read only03.09ALARM WORD01.22RO 1-3 STATUSRead only04.01LAST FAULT01.24AO 1Read only04.12PREVIOUS FAU01.25AO 2Read only04.13PREVIOUS FAU01.29PID 1 SETPNTRead only04.13PREVIOUS FAU01.30PID 1 FBKRead only04.13PREVIOUS FAU01.31PID 2 FBKRead only04.13PREVIOUS FAU01.32PID 1 DEVIATIONRead only04.13PREVIOUS FAU	01.02	SPEED	Read only	01.35	COMM VALUE 1
D1.05TORQUERead onlyD1.06POWERRead onlyD1.07DC BUS VOLTAGERead onlyD1.09OUTPUT VOLTAGERead onlyD1.10DRIVE TEMPRead onlyD1.14RUN TIMERead onlyD1.15KWH COUNTERRead onlyD1.18DI 1-3 STATUSRead onlyD1.20AI 1Read onlyD1.22RO 1-3 STATUSRead onlyD1.24AO 1Read onlyD1.25AO 2Read onlyD1.20PID 1 SETPNTRead onlyD1.21DI SETPNTRead onlyD1.22PID 1 SETPNTRead onlyD1.30PID 1 FBKRead onlyD1.32PID 1 DEVIATIONRead onlyD1.32PID 1 DEVIATIONRead only	01.03	OUTPUT FREQ	Read only	01.36	COMM VALUE 2
01.06POWERRead only01.07DC BUS VOLTAGERead only01.09OUTPUT VOLTAGERead only01.10DRIVE TEMPRead only01.11DRIVE TEMPRead only01.15KWH COUNTERRead only01.18DI 1-3 STATUSRead only01.19DI 4-6 STATUSRead only01.20AI 1Read only01.22RO 1-3 STATUSRead only01.28PID 1 SETPNTRead only01.29PID 2 SETPNTRead only01.30PID 1 FBKRead only01.31PID 2 FBKRead only01.32PID 1 DEVIATIONRead only	01.04	CURRENT	Read only	01.41	MWH COUNTER
D.1.07DC BUS VOLTAGERead only01.09OUTPUT VOLTAGERead only01.10DRIVE TEMPRead only01.11DRIVE TEMPRead only01.12DRIVE TEMPRead only01.15KWH COUNTERRead only01.16DI 1-3 STATUSRead only01.19DI 4-6 STATUSRead only01.20AI 1Read only01.22RO 1-3 STATUSRead only01.24AO 1Read only01.25AO 2Read only01.29PID 1 SETPNTRead only01.20PID 1 SETPNTRead only01.23PID 1 DEVIATIONRead only01.32PID 1 DEVIATIONRead only	01.05	TORQUE	Read only	01.45	MOTOR TEMP
01.09OUTPUT VOLTAGERead only01.09OUTPUT VOLTAGERead only01.10DRIVE TEMPRead only01.14RUN TIMERead only01.15KWH COUNTERRead only01.16DI 1-3 STATUSRead only01.19DI 4-6 STATUSRead only01.20AI 1Read only01.22RO 1-3 STATUSRead only01.24AO 1Read only01.25AO 2Read only01.20PID 1 SETPNTRead only01.22PID 1 SETPNTRead only01.23PID 1 FBKRead only01.30PID 1 FBKRead only01.31PID 2 FBKRead only01.32PID 1 DEVIATIONRead only	01.06	POWER	Read only	03.01	FB CMD WORD 1
D1.10DRIVE TEMPRead only01.14RUN TIMERead only01.15KWH COUNTERRead only01.16DI 1-3 STATUSRead only01.19DI 4-6 STATUSRead only01.20Al 1Read only01.22RO 1-3 STATUSRead only01.24AO 1Read only01.25AO 2Read only01.28PID 1 SETPNTRead only01.29PID 2 SETPNTRead only01.20PID 1 FBKRead only01.21AI 2Read only01.22RO 1-3 STATUSRead only01.23PID 1 SETPNTRead only01.30PID 1 FBKRead only01.31PID 2 FBKRead only01.32PID 1 DEVIATIONRead only	01.07	DC BUS VOLTAGE	Read only	03.02	FB CMD WORD 2
01.14RUN TIMERead only01.14RUN TIMERead only01.15KWH COUNTERRead only01.16DI 1-3 STATUSRead only01.19DI 4-6 STATUSRead only01.20Al 1Read only01.21Al 2Read only01.22RO 1-3 STATUSRead only01.24AO 1Read only01.25AO 2Read only01.29PID 1 SETPNTRead only01.29PID 2 SETPNTRead only01.30PID 1 FBKRead only01.31PID 2 FBKRead only01.32PID 1 DEVIATIONRead only	01.09	OUTPUT VOLTAGE	Read only	03.03	FB STS WORD 1
01.15KWH COUNTERRead only01.15KWH COUNTERRead only01.18DI 1-3 STATUSRead only01.19DI 4-6 STATUSRead only01.20Al 1Read only01.21Al 2Read only01.22RO 1-3 STATUSRead only01.24AO 1Read only01.25AO 2Read only01.20PID 1 SETPNTRead only01.22PID 1 SETPNTRead only01.23PID 1 FBKRead only01.30PID 1 FBKRead only01.32PID 1 DEVIATIONRead only	01.10	DRIVE TEMP	Read only	03.04	FB STS WORD 2
D1.18DI 1-3 STATUSRead only01.19DI 4-6 STATUSRead only01.19DI 4-6 STATUSRead only01.20AI 1Read only01.21AI 2Read only01.22RO 1-3 STATUSRead only01.24AO 1Read only01.25AO 2Read only01.29PID 1 SETPNTRead only01.30PID 1 FBKRead only01.31PID 2 FBKRead only01.32PID 1 DEVIATIONRead only	01.14	RUN TIME	Read only	03.05	FAULT WORD 1
D1.19DI 4-6 STATUSRead only01.19DI 4-6 STATUSRead only01.20Al 1Read only01.21Al 2Read only01.22RO 1-3 STATUSRead only01.24AO 1Read only01.25AO 2Read only01.28PID 1 SETPNTRead only01.29PID 2 SETPNTRead only01.30PID 1 FBKRead only01.31PID 2 FBKRead only01.32PID 1 DEVIATIONRead only	01.15	KWH COUNTER	Read only	03.06	FAULT WORD 2
01.20Al 1Read only01.21Al 2Read only01.22RO 1-3 STATUSRead only01.24AO 1Read only01.25AO 2Read only01.28PID 1 SETPNTRead only01.29PID 2 SETPNTRead only01.30PID 1 FBKRead only01.31PID 2 FBKRead only01.32PID 1 DEVIATIONRead only	01.18	DI 1-3 STATUS	Read only	03.07	FAULT WORD 3
D1.21AI 2Read onlyD1.22RO 1-3 STATUSRead onlyD1.24AO 1Read onlyD1.25AO 2Read onlyD1.28PID 1 SETPNTRead onlyD1.29PID 2 SETPNTRead onlyD1.30PID 1 FBKRead onlyD1.31PID 2 FBKRead onlyD1.32PID 1 DEVIATIONRead only	01.19	DI 4-6 STATUS	Read only	03.08	ALARM WORD 1
01.22RO 1-3 STATUSRead only01.24AO 1Read only01.25AO 2Read only01.28PID 1 SETPNTRead only01.29PID 2 SETPNTRead only01.30PID 1 FBKRead only01.31PID 2 FBKRead only01.32PID 1 DEVIATIONRead only	01.20	AI 1	Read only	03.09	ALARM WORD 2
01.24AO 1Read only01.24AO 1Read only01.25AO 2Read only01.28PID 1 SETPNTRead only01.29PID 2 SETPNTRead only01.30PID 1 FBKRead only01.31PID 2 FBKRead only01.32PID 1 DEVIATIONRead only	01.21	AI 2	Read only	04.01	LAST FAULT
01.25 AO 2 Read only 01.28 PID 1 SETPNT Read only 01.29 PID 2 SETPNT Read only 01.30 PID 1 FBK Read only 01.31 PID 2 FBK Read only 01.32 PID 1 DEVIATION Read only	01.22	RO 1-3 STATUS	Read only	04.12	PREVIOUS FAUL
D1.28 PID 1 SETPNT Read only D1.29 PID 2 SETPNT Read only D1.30 PID 1 FBK Read only D1.31 PID 2 FBK Read only D1.32 PID 1 DEVIATION Read only	01.24	AO 1	Read only	04.13	PREVIOUS FAUL
D1.29 PID 2 SETPNT Read only 01.30 PID 1 FBK Read only 01.31 PID 2 FBK Read only 01.32 PID 1 DEVIATION Read only	01.25	AO 2	Read only		
D1.30 PID 1 FBK Read only 01.31 PID 2 FBK Read only 01.32 PID 1 DEVIATION Read only	01.28	PID 1 SETPNT	Read only		
D1.31 PID 2 FBK Read only 01.32 PID 1 DEVIATION Read only	01.29	PID 2 SETPNT	Read only		
01.32 PID 1 DEVIATION Read only	01.30	PID 1 FBK	Read only		
	01.31	PID 2 FBK	Read only		
01.33 PID 2 DEVIATION Read only	01.32	PID 1 DEVIATION	Read only		
	01.33	PID 2 DEVIATION	Read only		

380 Parameters

ACx550 parameter	Name	Read/Write	ACx550 parameter	Name	Read/Write
11.05	REF1 MAX	Read/Write	33.04	DRIVE RATING	Read only
11.08	REF2 MAX	Read/Write	40.01	GAIN	Read/Write
16.02	PARAMETER LOCK	Read/Write	40.02	INTEGRATION TIME	Read/Write
20.01	MINIMUM SPEED	Read/Write	40.03	DERIVATION TIME	Read/Write
20.02	MAXIMUM SPEED	Read/Write	40.04	PID DERIV FILTER	Read/Write
20.03	MAX CURRENT	Read/Write	40.27	PID 1 PARAM SET	Read/Write
20.07	MINIMUM FREQ	Read/Write	41.01	GAIN	Read/Write
20.08	MAXIMUM FREQ	Read/Write	41.02	INTEGRATION TIME	Read/Write
22.02	ACCELER TIME 1	Read/Write	41.03	DERIVATION TIME	Read/Write
22.03	DECELER TIME 1	Read/Write	41.04	PID DERIV FILTER	Read/Write
30.05	MOT THERM POT	Read/Write	42.11	INTERNAL SETPNT	Read/Write
30.06	MOT THERM TIME	Read/Write	99.05	MOTOR NOM VOLT	Read/Write
30.07	MOT LOAD CURVE	Read/Write	99.06	MOTOR NOM CURR	Read/Write
33.01	FIRMWARE	Read only	99.07	MOTOR NOM FREQ	Read/Write
33.02	LOADING PACKAGE	Read only	99.08	MOTOR NOM SPEED	Read/Write
33.03	TEST DATE	Read only	99.09	MOTOR NOM POWER	Read/Write

382 Parameters

Additional parameter data

What this chapter contains

This chapter lists the parameters with some additional data such as their ranges and 32-bit fieldbus scaling. For parameter descriptions, see chapter *Parameters* (page 161).

The ACS560 parameter list uses long and short menu structure. ACS560 parameter list adopts long and short menu structure. The short menu displays common parameter list and the long menu displays complete parameter list. The long and short menus are adjusted by parameter 96.02 password. The default value is short menu.

Parameters	Indut bassword	Long and short menu
96.02 password	1	Short menu
50.02 passworu	2	Long menu

Terms and abbreviations

Term	Definition
Actual signal	Signal measured or calculated by the drive. Usually can only be monitored but not adjusted; some counter-type signals can however be reset.
Analog src	Analog source: the parameter can be set to the value of another parameter by choosing "Other", and selecting the source parameter from a list. In addition to the "Other" selection, the parameter may offer other pre- selected settings.

Term	Definition
Binary src	Binary source: the value of the parameter can be taken from a specific bit in another parameter value ("Other"). Sometimes the value can be fixed to 0 (false) or 1 (true). In addition, the parameter may offer other pre-selected settings.
Data	Data parameter
FbEq32	32-bit fieldbus equivalent: The scaling between the value shown on the panel and the integer used in communication when a 32-bit value is selected for transmission to an external system. The corresponding 16-bit scalings are listed in chapter <i>Parameters</i> (page 161).
List	Selection list.
No.	Parameter number.
РВ	Packed Boolean (bit list).
Real	Real number.
Туре	Parameter type. See Analog src, Binary src, List, PB, Real.

Fieldbus addresses

Refer to the User's manual of the fieldbus adapter.

Parameter groups 1...9

No.	Name	Туре	Range	Unit	FbEq32
01 Actu	al values		I		
01.01	Motor speed used	Real	-30000.0030000.00	rpm	100 = 1 rpm
01.02	Motor speed estimated	Real	-30000.0030000.00	rpm	100 = 1 rpm
01.03	Motor speed %	Real	-1000.001000.00	%	100 = 1%
01.06	Output frequency	Real	-500.00500.00	Hz	100 = 1 Hz
01.07	Motor current	Real	0.0030000.00	А	100 = 1 A
01.08	Motor current % of motor nom	Real	0.01000.0	%	10 = 1%
01.09	Motor current % of drive nom	Real	0.01000.0	%	10 = 1%
01.10	Motor torque	Real	-1600.01600.0	%	10 = 1%
01.11	DC voltage	Real	0.002000.00	V	100 = 1 V
01.13	Output voltage	Real	02000	V	1 = 1 V
01.14	Output power	Real	-32768.0032767.00	kW	100 = 1 unit
01.15	Output power % of motor nom	Real	-300.00300.00	%	100 = 1%
01.17	Motor shaft power	Real	-32768.0032767.00	kW or hp	100 = 1 unit
01.18	Inverter GWh counter	Real	065535	GWh	1 = 1 GWh
01.19	Inverter MWh counter	Real	01000	MWh	1 = 1 MWh
01.20	Inverter kWh counter	Real	01000	kWh	1 = 1 kWh
01.24	Flux actual %	Real	0200	%	1 = 1%
01.30	Nominal torque scale	Real	0.0004000000	N∙m	1000 = 1 unit
01.31	Ambient temperature	Real	-40120	°C or °F	10 = 1 °
01.50	Current hour kWh	Real	0.001000000.00	kWh	100 = 1 kWh
01.51	Previous hour kWh	Real	0.001000000.00	kWh	100 = 1 kWh
01.52	Current day kWh	Real	0.001000000.00	kWh	100 = 1 kWh
01.53	Previous day kWh	Real	0.001000000.00	kWh	100 = 1 kWh
01.54	Cumulative inverter energy	Real	-20000000.0 200000000.0	kWh	100 = 1 kWh
01.55	Inverter GWh counter (resettable)	Real	065535	GWh	1 = 1 GWh
01.56	Inverter MWh counter (resettable)	Real	01000	MWh	1 = 1 MWh
01.57	Inverter kWh counter (resettable)	Real	01000	kWh	1 = 1 kWh
01.58	Cumulative inverter energy (resettable)	Real	-20000000.0 200000000.0	kWh	1 = 1 kWh
01.61	Abs motor speed used	Real	0.0030000.00	rpm	100 = 1 rpm
01.62	Abs motor speed %	Real	0.001000.00%	%	100 = 1%
01.63	Abs output frequency	Real	0.00500.00 Hz	Hz	100 = 1 Hz
01.64	Abs motor torque	Real	0.01600.0	%	10 = 1%
01.65	Abs output power	Real	0.0032767.00	kW	100 = 1 kW
01.66	Abs output power % motor nom	Real	0.00300.00	%	100 = 1%
01.68	Abs motor shaft power	Real	0.0032767.00	kW or hp	100 = 1 kW

No.	Name	Туре	Range	Unit	FbEq32
03 Inpu	references			•	
03.01	Panel reference	Real	-10000.00100000.00	-	100 = 1
03.02	Panel reference remote	Real	-10000.00100000.00	-	100 = 1
03.05	FB A reference 1	Real	-10000.00100000.00	-	100 = 1
03.06	FB A reference 2	Real	-10000.00100000.00	-	100 = 1
03.09	EFB reference 1	Real	-30000.0030000.00	-	100 = 1
03.10	EFB reference 2	Real	-30000.0030000.00	-	100 = 1
04 Warr	ings and faults			•	
04.01	Tripping fault	Data	0x00000xffff	-	1 = 1
04.02	Active fault 2	Data	0x00000xffff	-	1 = 1
04.03	Active fault 3	Data	0x00000xffff	-	1 = 1
04.06	Active warning 1	Data	0x00000xffff	-	1 = 1
04.07	Active warning 2	Data	0x00000xffff	-	1 = 1
04.08	Active warning 3	Data	0x00000xffff	-	1 = 1
04.11	Latest fault	Data	0x00000xffff	-	1 = 1
04.12	2nd latest fault	Data	0x00000xffff	-	1 = 1
04.13	3rd latest fault	Data	0x00000xffff	-	1 = 1
04.16	Latest warning	Data	0x00000xffff	-	1 = 1
04.17	2nd latest warning	Data	0x00000xffff	-	1 = 1
04.18	3rd latest warning	Data	0x00000xffff	-	1 = 1
04.40	Event word 1	PB	0000hFFFFh	-	1 = 1
04.40	Event word 1	PB	0000hFFFFh	-	1 = 1
04.41	Event word 1 bit 0 code	Data	0x2310FFFFh	-	1 = 1
04.43	Event word 1 bit 1 code	Data	0x3210FFFFh	-	1 = 1
04.45, 04,47, 04,49,					
04,49, 					
04.71	Event word 1 bit 15 code	Data	0x2330FFFFh	-	1 = 1
05 Diag	nostics	•			
05.01	On-time counter	Real	065535	d	1 = 1 d
05.02	Run-time counter	Real	065535	d	1 = 1 d
05.03	Hours run	Real	0.0429496729.5	h	10 = 1 h
05.04	Fan on-time counter	Real	065535	d	1 = 1 d
05.10	Control board temperature	Real	-100300	°C	10 = 1 °
05.11	Inverter temperature	Real	-40.0160.0	%	10 = 1%
05.20	Diagnostic word 1	PB	0b00000b1111	-	0b0000
05.21	Diagnostic word 2	PB	0b00000b1111	-	0b0000
05.22	Diagnostic word 3	PB	0b00000b1111	-	0b0000
05.80	Motor speed at fault	Real	-30000.0030000.00	rpm	100 = 1 rpm
05.81	Output frequency at fault	Real	-500.00500.00	Hz	100 = 1 Hz
05.82	DC voltage at fault	Real	0.002000.00	V	100 = 1 V

No.	Name	Туре	Range	Unit	FbEq32
05.83	Motor current at fault	Real	0.0030000.00	А	100 = 1 A
05.84	Motor torque at fault	Real	-1600.01600.0	%	10 = 1%
05.85	Main status word at fault	PB	0000hFFFFh	-	1 = 1
05.86	DI delayed status at fault	PB	0b00000b1111	-	1 = 1
05.87	Inverter temperature at fault	PB	-40.0160.0	°C	10 = 1°C
05.88	Reference used at fault	Real	-500.00500.00 Hz/ -1600.01600.0%/ 30000.0030000.00 rpm	Hz/ %/ rpm	100 = 1 Hz/ 10 = 1%/ 100 = 1 rpm
05.99	BIO-01 DIP switch status	PB	0000hFFFh	-	1 = 1
06 Cont	rol and status words				
06.01	Main control word	PB	0x00000xffff	-	1 = 1
06.11	Main status word	PB	0x00000xffff	-	1 = 1
06.16	Drive status word 1	PB	0b00000b1111	-	1 = 1
06.17	Drive status word 2	PB	0b00000b1111	-	1 = 1
06.18	Start inhibit status word	PB	0b00000b1111	-	1 = 1
06.19	Speed control status word	PB	0b00000b1111	-	1 = 1
06.20	Constant speed status word	PB	0b00000b1111	-	1 = 1
06.21	Drive status word 3	PB	0b00000b1111	-	1 = 1
06.29	MSW bit 10 selection	Binary src	02	-	1 = 1
06.30	MSW bit 11 selection	Binary src	-	-	1 = 1
06.31	MSW bit 12 selection	Binary src	-	-	1 = 1
06.32	MSW bit 13 selection	Binary src	-	-	1 = 1
06.33	MSW bit 14 selection	Binary src	-	-	1 = 1
07 Syst	em info				
07.03	Drive rating id	List	-	-	1 = 1
07.04	Firmware name	List	-	-	1 = 1
07.05	Firmware version	Data	0.00.0.0255.255.255.255	-	1 = 1
07.06	Loading package name	List	-	-	1 = 1
07.07	Loading package version	Data	0.00.0.0255.255.255.255	-	1 = 1
07.11	Cpu usage	Real	0100	%	1 = 1%
07.35	Drive configuration	Binary src	-	-	1=1
07.36	Drive configuration 2	Binary src	-	-	1=1

Parameter groups 10...99

No.	Name	Туре	Range	Unit	FbEq32
10 Stan	dard DI, RO				
10.01	DI status	PB	0b00000b1111	-	1 = 1
10.02	DI delayed status	PB	0b00000b1111	-	1 = 1
10.03	DI force selection	PB	0b00000b1111	-	1 = 1
10.04	DI forced data	PB	0b00000b1111	-	1 = 1
10.05	DI1 ON delay	Real	0.003000.00	s	10 = 1
10.06	DI1 OFF delay	Real	0.003000.00	s	10 = 1
10.07	DI2 ON delay	Real	0.003000.00	s	10 = 1
10.08	DI2 OFF delay	Real	0.003000.00	s	10 = 1
10.09	DI3 ON delay	Real	0.003000.00	s	10 = 1
10.10	DI3 OFF delay	Real	0.003000.00	s	10 = 1
10.11	DI4 ON delay	Real	0.003000.00	s	10 = 1
10.12	DI4 OFF delay	Real	0.003000.00	s	10 = 1
10.13	DI5 ON delay	Real	0.003000.00	s	10 = 1
10.14	DI5 OFF delay	Real	0.003000.00	s	10 = 1
10.15	DI6 ON delay	Real	0.003000.00	s	10 = 1
10.16	DI6 OFF delay	Real	0.003000.00	s	10 = 1
10.21	RO status	PB	0b00000b1111	-	1 = 1
10.22	RO force selection	PB	0b00000b1111	-	1 = 1
10.23	RO forced data	PB	0b00000b1111	-	1 = 1
10.24	RO1 source	Binary src	-	-	1 = 1
10.25	RO1 ON delay	Real	0.03000.0	s	10 = 1 s
10.26	RO1 OFF delay	Real	0.03000.0	s	10 = 1 s
10.27	RO2 source	Binary src	-	-	1 = 1
10.28	RO2 ON delay	Real	0.03000.0	s	10 = 1 s
10.29	RO2 OFF delay	Real	0.03000.0	s	10 = 1 s
10.30	RO3 source	Binary src	-	-	1 = 1
10.31	RO3 ON delay	Real	0.03000.0	s	10 = 1 s
10.32	RO3 OFF delay	Real	0.03000.0	s	10 = 1 s
10.99	RO/DIO control word	PB	0b00000b1111	-	1 = 1
10.101	RO1 toggle counter	Real	04294967000	-	1 = 1
10.102	RO2 toggle counter	Real	04294967000	-	1 = 1
10.103	RO3 toggle counter	Real	04294967000	-	1 = 1
11 Stan	dard DIO, FI, FO				
11.21	DI5 configuration	List	01	-	1 = 1
11.38	Freq in 1 actual value	Real	016000	Hz	1 = 1 Hz
11.39	Freq in 1 scaled value	Real	-32768.00032767.000	-	1000 = 1

No.	Name	Туре	Range	Unit	FbEq32
11.42	Freq in 1 min	Real	016000	Hz	1 = 1 Hz
11.43	Freq in 1 max	Real	016000	Hz	1 = 1 Hz
11.44	Freq in 1 at scaled min	Real	-32768.00032767.000	-	1000 = 1
11.45	Freq in 1 at scaled max	Real	-32768.00032767.000	-	1000 = 1
12 Stan	dard Al			•	
12.02	AI force selection	PB	0b0000b1111	-	1 = 1
12.03	AI supervision function	List	0b0000b1111	-	1 = 1
12.04	AI supervision selection	PB	0b0000b1111	-	1 = 1
12.05	AI supervision force	PB	0b0000b1111	-	1 = 1
12.11	Al1 actual value	Real	0.00011.000 V	V	1000 = 1 unit
12.12	AI1 scaled value	Real	-32768.00032767.000	-	1000 = 1
12.13	Al1 forced value	Real	0.00011.000 V	V	1000 = 1 unit
12.15	Al1 unit selection	List	2, 10	-	1 = 1
12.16	Al1 filter time	Real	0.00030.000	s	1000 = 1 s
12.17	Al1 min	Real	0.00011.000 V	V	1000 = 1 unit
12.18	Al1 max	Real	0.00011.000 V	V	1000 = 1 unit
12.19	Al1 scaled at Al1 min	Real	-32768.00032767.000	-	1000 = 1
12.20	Al1 scaled at Al1 max	Real	-32768.00032767.000	-	1000 = 1
12.21	Al2 actual value	Real	0.00022.000	mA	1000 = 1 unit
12.22	AI2 scaled value	Real	-32768.00032767.000	-	1000 = 1
12.23	Al2 forced value	Real	0.00022.000	mA	1000 = 1 unit
12.25	AI2 unit selection	List	2, 10	-	1 = 1
12.26	AI2 filter time	Real	0.00030.000	s	1000 = 1 s
12.27	Al2 min	Real	0.00022.000	mA	1000 = 1 unit
12.28	Al2 max	Real	0.00022.000	mA	1000 = 1 unit
12.29	AI2 scaled at AI2 min	Real	-32768.00032767.000	-	1000 = 1
12.30	Al2 scaled at Al2 max	Real	-32768.00032767.000	-	1000 = 1
12.101	Al1 percent value	Real	0.00100.00	%	100 = 1%
12.102	Al2 percent value	Real	0.00100.00	%	100 = 1%
12.110	AI dead band	Real	0.00100.00	%	1 = 1%
13 Stan	dard AO				
13.02	AO force selection	PB	0b00000b1111	-	1 = 1
13.11	AO1 actual value	Real	0.00022.000 or 0.00011000 V	mA	1000 = 1 mA
13.12	AO1 source	Analog src	-	-	1 = 1
13.13	AO1 forced value	Real	0.00022.000 or 0.00011000 V	mA	1000 = 1 mA
13.15	AO1 unit selection	List	2, 10	-	1 = 1
13.16	AO1 filter time	Real	0.00030.000	s	1000 = 1 s
13.17	AO1 source min	Real	-32768.032767.0	-	10 = 1
13.18	AO1 source max	Real	-32768.032767.0	-	10 = 1

No.	Name	Туре	Range	Unit	FbEq32
13.19	AO1 out at AO1 src min	Real	0.00022.000 or 0.00011000 V	mA	1000 = 1 mA
13.20	AO1 out at AO1 src max	Real	0.00022.000 or 0.00011000 V	mA	1000 = 1 mA
13.21	AO2 actual value	Real	0.00022.000	mA	1000 = 1 mA
13.22	AO2 source	Analog src	-	-	1 = 1
13.23	AO2 forced value	Real	0.00022.000	mA	1000 = 1 mA
13.26	AO2 filter time	Real	0.00030.000	S	1000 = 1 s
13.27	AO2 source min	Real	-32768.032767.0	-	10 = 1
13.28	AO2 source max	Real	-32768.032767.0	-	10 = 1
13.29	AO2 out at AO2 src min	Real	0.00022.000	mA	1000 = 1 mA
13.30	AO2 out at AO2 src max	Real	0.00022.000	mA	1000 = 1 mA
13.91	AO1 data storage	Real	-327.68327.67	-	100 = 1
13.92	AO2 data storage	Real	-327.68327.67	-	100 = 1
15 I/O e	xtension module				
15.01	Extension module type	List	0, 5	-	1 = 1
15.02	Detected extension module	List	0, 5	-	1 = 1
15.04	RO/DO status	PB	0000hFFFFh	-	1 = 1
15.05	RO/DO force selection	PB	0000hFFFFh	-	1 = 1
15.06	RO/DO forced data	PB	0000hFFFFh	-	1 = 1
15.07	RO4 source	Binary src	-	-	1 = 1
15.08	RO4 ON delay	Real	0.03000.0	s	10 = 1 s
15.09	RO4 OFF delay	Real	0.03000.0	s	10 = 1 s
15.10	RO5 source	Binary src	-	-	1 = 1
15.11	RO5 ON delay	Real	0.03000.0	s	10 = 1 s
15.12	RO5 OFF delay	Real	0.03000.0	s	10 = 1 s
15.13	RO6 source	Binary src	-	-	1 = 1
15.14	RO6 ON delay	Real	0.03000.0	s	10 = 1 s
15.15	RO6 OFF delay	Real	0.03000.0	s	10 = 1 s
15.16	RO7 source	Binary src	-	-	1 = 1
15.17	RO7 ON delay	Real	0.03000.0	S	10 = 1 s
15.18	RO7 OFF delay	Real	0.03000.0	S	10 = 1 s
19 Oper	ration mode				
19.01	Actual operation mode	List	-	-	1 = 1
19.11	Ext1/Ext2 selection	Binary src	-	-	1 = 1
19.12	Ext1 control mode	List	15	-	1 = 1
19.14	Ext2 control mode	List	15	-	1 = 1
19.16	Local control mode	List	0, 1	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
19.17	Local control disable	List	01	-	1 = 1
20 Start	/stop/direction				•
20.01	Ext1 commands	List	06, 4, 11, 12, 14	-	1 = 1
20.02	Ext1 start trigger type	List	01	-	1 = 1
20.03	Ext1 in1 source	Binary src	-	-	1 = 1
20.04	Ext1 in2 source	Binary src	-	-	1 = 1
20.05	Ext1 in3 source	Binary src	-	-	1 = 1
20.06	Ext2 commands	List	06, 4, 11, 12, 14	-	1 = 1
20.07	Ext2 start trigger type	List	01	-	1 = 1
20.08	Ext2 in1 source	Binary src	-	-	1 = 1
20.09	Ext2 in2 source	Binary src	-	-	1 = 1
20.10	Ext2 in3 source	Binary src	-	-	1 = 1
20.11	Run enable stop mode	List	02	-	1 = 1
20.12	Run enable 1 source	Binary src	-	-	1 = 1
20.19	Enable start command	Binary src	-	-	1 = 1
20.21	Direction	List	02	-	1 = 1
20.22	Enable to rotate	Binary src	-	-	1 = 1
20.25	Jogging enable	Binary src	-	-	1 = 1
20.26	Jogging 1 start source	Binary src	-	-	1 = 1
20.27	Jogging 2 start source	Binary src	-	-	1 = 1
20.28	Remote to local action	List	01	-	1 = 1
20.30	Enable signal warning function	PB	0000hFFFFh	-	1 = 1
21 Start	/stop mode				
21.01	Start mode	List	02	-	1 = 1
21.02	Magnetization time	Real	010000	ms	1 = 1 ms
21.03	Stop mode	List	02	-	1 = 1
21.04	Emergency stop mode	List	02	-	1 = 1
21.05	Emergency stop source	Binary src	-	-	1 = 1
21.06	Zero speed limit	Real	0.0030000.00	rpm	100 = 1 rpm
21.07	Zero speed delay	Real	030000	ms	1 = 1 ms
21.08	DC current control	PB	0b00000b1111	-	1 = 1
21.09	DC hold speed	Real	0.001000.00	rpm	100 = 1 rpm

No.	Name	Туре	Range	Unit	FbEq32
21.10	DC current reference	Real	0.0100.0	%	10 = 1%
21.11	Post magnetization time	Real	03000	s	1 = 1 s
21.14	Pre-heating input source	Binary src	-	-	1 = 1
21.15	Pre-heating time delay	Real	103000	s	1 = 1
21.16	Pre-heating current	Real	0.030.0	%	10 = 1%
21.18	Auto restart time	Real	0.010.0	s	10 = 1 s
21.19	Scalar start mode	List	06	-	1 = 1
21.21	DC hold frequency	Real	0.001000.00	Hz	100 = 1 Hz
21.22	Start delay	Real	0.0060.00	s	100 = 1 s
21.26	Torque boost current	Real	15.0300.0	%	100 = 1%
21.27	Torque boost time	Real	0.060.0	s	10 = 1 s
21.30	Speed compensated stop mode	Real	03	-	1 = 1
21.31	Speed comp stop delay	Real	0.001000.00	s	100 = 1 s
21.32	Speed comp stop threshold	Real	0100	%	1 = 1%
21.34	Force auto restart	List	01	-	1 = 1
22 Spee	d reference selection				•
22.01	Speed ref unlimited	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.11	Ext1 speed ref1	Analog src	-	-	1 = 1
22.12	Ext1 speed ref2	Analog src	-	-	1 = 1
22.13	Ext1 speed function	List	05	-	1 = 1
22.18	Ext2 speed ref1	Analog src	-	-	1 = 1
22.19	Ext2 speed ref2	Analog src	-	-	1 = 1
22.20	Ext2 speed function	List	05	-	1 = 1
22.21	Constant speed function	PB	0b00000b1111	-	1 = 1
22.22	Constant speed sel1	Binary src	-	-	1 = 1
22.23	Constant speed sel2	Binary src	-	-	1 = 1
22.24	Constant speed sel3	Binary src	-	-	1 = 1
22.26	Constant speed 1	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.27	Constant speed 2	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.28	Constant speed 3	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.29	Constant speed 4	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.30	Constant speed 5	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.31	Constant speed 6	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.32	Constant speed 7	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.41	Speed ref safe	Real	-30000.0030000.00	rpm	100 = 1 rpm

No.	Name	Туре	Range	Unit	FbEq32
22.42	Jogging 1 ref	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.43	Jogging 2 ref	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.51	Critical speed function	PB	0b00000b1111	-	1 = 1
22.52	Critical speed 1 low	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.53	Critical speed 1 high	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.54	Critical speed 2 low	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.55	Critical speed 2 high	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.56	Critical speed 3 low	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.57	Critical speed 3 high	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.70	Motor potentiometer reference enable	List	02	-	1 = 1
22.71	Motor potentiometer function	List	04	-	1 = 1
22.72	Motor potentiometer initial value	Real	-32768.0032767.00	-	100 = 1
22.73	Motor potentiometer up source	Binary src	-	-	1 = 1
22.74	Motor potentiometer down source	Binary src	-	-	1 = 1
22.76	Motor potentiometer min value	Real	-32768.0032767.00	-	100 = 1
22.77	Motor potentiometer max value	Real	-32768.0032767.00	-	100 = 1
22.78	Motor potentiometer ramp up	Real	0.03600.0	s	-
22.79	Motor potentiometer ramp down	Real	0.03600.0	s	-
22.80	Motor potentiometer ref act	Real	-32768.0032767.00	-	100 = 1
22.86	Speed reference act 6	Real	-30000.0030000.00	rpm	100 = 1 rpm
22.87	Speed reference act 7	Real	-30000.0030000.00	rpm	100 = 1 rpm
23 Spee	d reference ramp				
23.01	Speed ref ramp input	Real	-30000.0030000.00	rpm	100 = 1 rpm
23.02	Speed ref ramp output	Real	-30000.0030000.00	rpm	100 = 1 rpm
23.11	Ramp set selection	Binary src	-	-	1 = 1
23.12	Acceleration time 1	Real	0.0001800.000	s	1000 = 1 s
23.13	Deceleration time 1	Real	0.0001800.000	s	1000 = 1 s
23.14	Acceleration time 2	Real	0.0001800.000	s	1000 = 1 s
23.15	Deceleration time 2	Real	0.0001800.000	s	1000 = 1 s
23.20	Acc time jogging	Real	0.0001800.000	S	1000 = 1 s
23.21	Dec time jogging	Real	0.0001800.000	s	1000 = 1 s
23.23	Emergency stop time	Real	0.0001800.000	S	1000 = 1 s
23.28	Variable slope	List	01	-	1 = 1
23.29	Variable slope rate	Real	230000	ms	1 = 1 ms
23.32	Shape time 1	Real	0.0001800.000	s	1000 = 1 s
23.33	Shape time 2	Real	0.0001800.000	s	1000 = 1 s

388 Additional parameter data

No.	Name	Туре	Range	Unit	FbEq32
24 Spee	d reference conditioning				
24.01	Used speed reference	Real	-30000.0030000.00	rpm	100 = 1 rpm
24.02	Used speed feedback	Real	-30000.0030000.00	rpm	100 = 1 rpm
24.03	Speed error filtered	Real	-30000.0030000.00	rpm	100 = 1 rpm
24.12	Speed error filter time	Real	010000	ms	1 = 1ms
25 Spee	d control				
25.01	Torque reference speed control	Real	-1600.01600.0	%	10 = 1%
25.02	Speed proportional gain	Real	0.00250.00	-	100 = 1
25.03	Speed integration time	Real	0.001000.00	s	100 = 1 s
25.04	Speed derivation time	Real	0.00010.000	s	1000 = 1 s
25.05	Derivation filter time	Real	010000	ms	1 = 1 ms
25.06	Acc comp derivation time	Real	0.001000.00	s	100 = 1 s
25.07	Acc comp filter time	Real	0.01000.0	ms	10 = 1 ms
25.30	Flux adaptation enable	List	01	-	-
25.33	Speed controller autotune	List	-	-	1 = 1
25.34	Speed controller autotune mode	List	-	-	1 = 1
25.37	Mechanical time constant	Real	0.001000.00	s	100 = 1 s
25.38	Autotune torque step	Real	0.00100.00	%	100 = 1%
25.39	Autotune speed step	Real	0.00100.00	%	100 = 1%
25.40	Autotune repeat times	Real	110	-	1 = 1
25.53	Torque prop reference	Real	-30000.030000.0	%	10 = 1%
25.54	Torque integral reference	Real	-30000.030000.0	%	10 = 1%
25.55	Torque deriv reference	Real	-30000.030000.0	%	10 = 1%
25.56	Torque acc compensation	Real	-30000.030000.0	%	10 = 1%
26 Torq	ue reference chain				<u>.</u>
26.01	Torque reference to TC	Real	-1600.01600.0	%	10 = 1%
26.02	Torque reference used	Real	-1600.01600.0	%	10 = 1%
26.08	Minimum torque ref	Real	-1000.00.0	%	10 = 1%
26.09	Maximum torque ref	Real	0.01000.0	%	10 = 1%
26.11	Torque ref1 source	Analog src	-	-	1 = 1
26.12	Torque ref2 source	Analog src	-	-	1 = 1
26.13	Torque ref1 function	List	05	-	1 = 1
26.14	Torque ref1/2 selection	Binary src	-	-	1 = 1
26.17	Torque ref filter time	Real	0.00030.000	s	1000 = 1 s
26.18	Torque ramp up time	Real	0.00060.000	s	1000 = 1 s
26.19	Torque ramp down time	Real	0.00060.000	s	1000 = 1 s
26.20	Torque reversal	List	-	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
26.70	Torque reference act 1	Real	-1600.01600.0	%	10 = 1%
26.71	Torque reference act 2	Real	-1600.01600.0	%	10 = 1%
26.72	Torque reference act 3	Real	-1600.01600.0	%	10 = 1%
26.73	Torque reference act 4	Real	-1600.01600.0	%	10 = 1%
26.74	Torque ref ramp out	Real	-1600.01600.0	%	10 = 1%
26.75	Torque reference act 5	Real	-1600.01600.0	%	10 = 1%
26.76	Torque reference act 6		-1600.01600.0	%	10 = 1%
26.81	Rush control gain	Real	0.010000.0	-	10=1
26.82	Rush control integration time	Real	0.010.0	s	10=1 s
28 Freq	uency reference chain			•	•
28.01	Frequency ref ramp input	Real	-500.00500.00	Hz	100 = 1 Hz
28.02	Frequency ref ramp output	Real	-500.00500.00	Hz	100 = 1 Hz
28.11	Ext1 frequency ref1	Analog src	-	-	1 = 1
28.12	Ext1 frequency ref2	Analog src	05	-	1 = 1
28.13	Ext1 frequency function	List	05	-	1 = 1
28.15	Ext2 frequency ref1	Analog src	-	-	1 = 1
28.16	Ext2 frequency ref2	Analog src	-	-	1 = 1
28.17	Ext2 frequency function	List	05	-	1 = 1
28.21	Constant frequency function	PB	0b00000b1111	-	1 = 1
28.22	Constant frequency sel1	Binary src	-	-	1 = 1
28.23	Constant frequency sel2	Binary src	-	-	1 = 1
28.24	Constant frequency sel3	Binary src	-	-	1 = 1
28.26	Constant frequency 1	Real	-500.00500.00	Hz	100 = 1 Hz
28.27	Constant frequency 2	Real	-500.00500.00	Hz	100 = 1 Hz
28.28	Constant frequency 3	Real	-500.00500.00	Hz	100 = 1 Hz
28.29	Constant frequency 4	Real	-500.00500.00	Hz	100 = 1 Hz
28.30	Constant frequency 5	Real	-500.00500.00	Hz	100 = 1 Hz
28.31	Constant frequency 6	Real	-500.00500.00	Hz	100 = 1 Hz
28.32	Constant frequency 7	Real	-500.00500.00	Hz	100 = 1 Hz
28.41	Frequency ref safe	Real	-500.00500.00	Hz	100 = 1 Hz
28.42	Jogging 1 frequency ref	Real	-500.00500.00	Hz	100 = 1 Hz
28.43	Jogging 2 frequency ref	Real	-500.00500.00	Hz	100 = 1 Hz
28.51	Critical frequency function	PB	0b00000b1111	-	1 = 1
28.52	Critical frequency 1 low	Real	-500.00500.00	Hz	100 = 1 Hz
28.53	Critical frequency 1 high	Real	-500.00500.00	Hz	100 = 1 Hz
28.54	Critical frequency 2 low	Real	-500.00500.00	Hz	100 = 1 Hz

No.	Name	Туре	Range	Unit	FbEq32
28.55	Critical frequency 2 high	Real	-500.00500.00	Hz	100 = 1 Hz
28.56	Critical frequency 3 low	Real	-500.00500.00	Hz	100 = 1 Hz
28.57	Critical frequency 3 high	Real	-500.00500.00	Hz	100 = 1 Hz
28.71	Freq ramp set selection	Binary src	-	-	1 = 1
28.72	Freq acceleration time 1	Real	0.0001800.000	s	1000 = 1 s
28.73	Freq deceleration time 1	Real	0.0001800.000	s	1000 = 1 s
28.74	Freq acceleration time 2	Real	0.0001800.000	s	1000 = 1 s
28.75	Freq deceleration time 2	Real	0.0001800.000	s	1000 = 1 s
28.76	Freq ramp in zero source	Binary src	-	-	1 = 1
28.82	Shape time 1	Real	0.0001800.000	s	1000 = 1 s
28.83	Shape time 2	Real	0.0001800.000	s	1000 = 1 s
28.92	Frequency ref act 3	Real	-500.00500.00	Hz	100 = 1 Hz
28.96	Frequency ref act 7	Real	-500.00500.00	Hz	100 = 1 Hz
28.97	Frequency ref unlimited	Real	-500.00500.00	Hz	100 = 1 Hz
30 Limi	S				
30.01	Limit word 1	PB	0b00000b1111	-	1 = 1
30.02	Torque limit status	PB	0b00000b1111	-	1 = 1
30.09	Current limit monitor time	Real	0.00120.00	s	-
30.10	Current limit actions	List	02	-	1=1
30.11	Minimum speed	Real	-30000.0030000.00	rpm	100 = 1 rpm
30.12	Maximum speed	Real	-30000.0030000.00	rpm	100 = 1 rpm
30.13	Minimum frequency	Real	-500.00500.00	Hz	100 = 1 Hz
30.14	Maximum frequency	Real	-500.00500.00	Hz	100 = 1 Hz
30.17	Maximum current	Real	0.00.3.24	Α	100 = 1 A
30.18	Torq lim sel	Binary src	-	-	1 = 1
30.19	Minimum torque 1	Real	-1600.00.0	%	10 = 1%
30.20	Maximum torque 1	Real	0.01600.0	%	10 = 1%
30.21	Min torque 2 source	Analog src	-	-	1 = 1
30.22	Max torque 2 source	Analog src	-	-	1 = 1
30.23	Minimum torque 2	Real	-1600.00.0	%	10 = 1%
30.24	Maximum torque 2	Real	0.01600.0	%	10 = 1%
30.26	Power motoring limit	Real	0.00600.00	%	100 = 1%
30.27	Power generating limit	Real	-600.000.00	%	100 = 1%
30.30	Overvoltage control	List	01	-	1 = 1
30.31	Undervoltage control	List	01	-	1 = 1
30.35	Thermal current limitation	List	01	-	1 = 1
30.36	Speed limit selection	Binary src	-	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
30.37	Min speed source	Analog	-	-	1 = 1
		src			
30.38	Max speed source	Analog src	-	-	1 = 1
31 Faul	t functions				
31.01	External event 1 source	Binary	-	-	1 = 1
		src			
31.02	External event 1 type	List	01	-	1 = 1
31.03	External event 2 source	Binary src	-	-	1 = 1
31.04	External event 2 type	List	01	-	1 = 1
31.05	External event 3 source	Binary src	-	-	1 = 1
31.06	External event 3 type	List	01	-	1 = 1
31.07	External event 4 source	Binary src	-	-	1 = 1
31.08	External event 4 type	List	01	-	1 = 1
31.09	External event 5 source	Binary src	-	-	1 = 1
31.10	External event 5 type	List	01	-	1 = 1
31.11	Fault reset selection	Binary src	-	-	1 = 1
31.12	Autoreset selection	PB	0x00000xffff	-	1 = 1
31.13	Selectable fault	Real	0x00000xffff	-	1 = 1
31.14	Number of trials	Real	05	-	1 = 1
31.15	Total trials time	Real	1.0600.0	s	10 = 1 s
31.16	Delay time	Real	0.0120.0	s	10 = 1 s
31.19	Motor phase loss	List	01	-	1 = 1
31.21	Supply phase loss	List	01	-	1 = 1
31.20	Earth fault	List	02	-	1 = 1
31.22	STO indication run/stop	List	05	-	1 = 1
31.23	Wiring or earth fault	List	01	-	1 = 1
31.24	Stall function	List	02	-	1 = 1
31.25	Stall current limit	Real	0.01600.0	%	10 = 1%
31.26	Stall speed limit	Real	0.0010000.00	rpm	100 = 1 rpm
31.27	Stall frequency limit	Real	0.001000.00	Hz	100 = 1 Hz
31.28	Stall time	Real	03600	s	1 = 1 s
31.30	Overspeed trip margin	Real	0.0010000.00	rpm	100 = 1 rpm
31.31	Frequency trip margin	Real	0.0010000.00	Hz	100 = 1 Hz
31.36	Aux fan fault function	List	01	-	1 = 1
31.40	Disable warning messages	PB	0000hFFFFh	-	1 = 1
32 Supe	ervision				
32.01	Supervision status	PB	0b00000b1111	-	1 = 1
32.05	Supervision 1 function	List	07	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
32.06	Supervision 1 action	List	03	-	1 = 1
32.07	Supervision 1 signal	Analog src	-	-	1 = 1
32.08	Supervision 1 filter time	Real	0.00030.000	s	1000 = 1 s
32.09	Supervision 1 low	Real	-21474836.00 21474836.00	-	-
32.10	Supervision 1 high	Real	-21474836.00 21474836.00	-	-
32.11	Supervision 1 hysteresis	Real	0.00100000.00	-	100 = 1
32.15	Supervision 2 function	List	07	-	1 = 1
32.16	Supervision 2 action	List	03	-	1 = 1
32.17	Supervision 2 signal	Analog src	-	-	1 = 1
32.18	Supervision 2 filter time	Real	0.00030.000	s	1000 = 1 s
32.19	Supervision 2 low	Real	-21474836.00 21474836.00	-	100 = 1
32.20	Supervision 2 high	Real	-21474836.00 21474836.00	-	100 = 1
32.21	Supervision 2 hysteresis	Real	0.00100000.00	-	100 = 1
32.25	Supervision 3 function	List	06	-	1 = 1
32.26	Supervision 3 action	List	03	-	1 = 1
32.27	Supervision 3 signal	Analog src	0, 1, 3, 4, 610, 2327	-	1 = 1
32.28	Supervision 3 filter time	Real	0.00030.000	s	1000 = 1 s
32.29	Supervision 3 low	Real	-21474836.00 21474836.00	-	100 = 1
32.30	Supervision 3 high	Real	-21474836.00 21474836.00	-	100 = 1
32.31	Supervision 3 hysteresis	Real	0.00100000.00	-	100 = 1
32.35	Supervision 4 function	List	07	-	1 = 1
32.36	Supervision 4 action	List	03	-	1 = 1
32.37	Supervision 4 signal	Analog src	-	-	1 = 1
32.38	Supervision 4 filter time	Real	0.00030.000	s	1000 = 1 s
32.39	Supervision 4 low	Real	-21474836.00 21474836.00	-	100 = 1
32.40	Supervision 4 high	Real	-21474836.00 21474836.00	-	100 = 1
32.41	Supervision 4 hysteresis	Real	0.00100000.00	-	100 = 1
32.45	Supervision 5 function	List	07	-	1 = 1
32.46	Supervision 5 action	List	03	-	1 = 1
32.47	Supervision 5 signal	Analog src	-	-	1 = 1
32.48	Supervision 5 filter time	Real	0.00030.000	S	1000 = 1 s
32.49	Supervision 5 low	Real	-21474836.00 21474836.00	-	100 = 1

No.	Name	Туре	Range	Unit	FbEq32
32.50	Supervision 5 high	Real	-21474836.00 21474836.00	-	100 = 1
32.51	Supervision 5 hysteresis	Real	0.00100000.00	-	100 = 1
32.55	Supervision 6 function	List	07	-	1 = 1
32.56	Supervision 6 action	List	03	-	1 = 1
32.57	Supervision 6 signal	Analog src	-	-	1 = 1
32.58	Supervision 6 filter time	Real	0.00030.000	s	1000 = 1 s
32.59	Supervision 6 low	Real	-21474836.00 21474836.00	-	100 = 1
32.60	Supervision 6 high	Real	-21474836.00 21474836.00	-	100 = 1
32.61	Supervision 6 hysteresis	Real	0.00100000.00	-	100 = 1
34 Time	d functions				
34.01	Timed functions status	PB	0b00000b1111	-	1 = 1
34.02	Timer status	PB	0b00000b1111	-	1 = 1
34.04	Season/exception day status	PB	0b00000b1111	-	1 = 1
34.10	Timed functions enable	Binary src	07	-	1 = 1
34.11	Timer 1 configuration	PB	0b00000b1111	-	1 = 1
34.12	Timer 1 start time	Time	00:00:0023:59:59	-	1 = 1
34.13	Timer 1 duration	Duration	00 00:0007 00:00	-	1 = 1
34.14	Timer 2 configuration	PB	0b00000b1111	-	1 = 1
34.15	Timer 2 start time	Time	00:00:0023:59:59	-	1 = 1
34.16	Timer 2 duration	Duration	00 00:0007 00:00	-	1 = 1
34.17	Timer 3 configuration	PB	0b00000b1111	-	1 = 1
34.18	Timer 3 start time	Time	00:00:0023:59:59	-	1 = 1
34.19	Timer 3 duration	Duration	00 00:0007 00:00	-	1 = 1
34.20	Timer 4 configuration	PB	0b00000b1111	-	1 = 1
34.21	Timer 4 start time	Time	00:00:0023:59:59	-	1 = 1
34.22	Timer 4 duration	Duration	00 00:0007 00:00	-	1 = 1
34.23	Timer 5 configuration	PB	0b00000b1111	-	1 = 1
34.24	Timer 5 start time	Time	00:00:0023:59:59	-	1 = 1
34.25	Timer 5 duration	Duration	00 00:0007 00:00	-	1 = 1
34.26	Timer 6 configuration	PB	0b00000b1111	-	1 = 1
34.27	Timer 6 start time	Time	00:00:0023:59:59	-	1 = 1
34.28	Timer 6 duration	Duration	00 00:0007 00:00	-	1 = 1
34.29	Timer 7 configuration	PB	0b00000b1111	-	1 = 1
34.30	Timer 7 start time	Time	00:00:0023:59:59	-	1 = 1
34.31	Timer 7 duration	Duration	00 00:0007 00:00	-	1 = 1
34.32	Timer 8 configuration	PB	0b00000b1111	-	1 = 1
34.33	Timer 8 start time	Time	00:00:0023:59:59	-	1 = 1
34.34	Timer 8 duration	Duration	00 00:0007 00:00	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
34.35	Timer 9 configuration	PB	0b00000b1111	-	1 = 1
34.36	Timer 9 start time	Time	00:00:0023:59:59	-	1 = 1
34.37	Timer 9 duration	Duration	00 00:0007 00:00	-	1 = 1
34.38	Timer 10 configuration	PB	0b00000b1111	-	1 = 1
34.39	Timer 10 start time	Time	00:00:0023:59:59	-	1 = 1
34.40	Timer 10 duration	Duration	00 00:0007 00:00	-	1 = 1
34.41	Timer 11 configuration	PB	0b00000b1111	-	1 = 1
34.42	Timer 11 start time	Time	00:00:0023:59:59	-	1 = 1
34.43	Timer 11 duration	Duration	00 00:0007 00:00	-	1 = 1
34.44	Timer 12 configuration	PB	0b00000b1111	-	1 = 1
34.45	Timer 12 start time	Time	00:00:0023:59:59	-	1 = 1
34.46	Timer 12 duration	Duration	00 00:0007 00:00	-	1 = 1 -
34.60	Season 1 start date	Date	-	-	1 = 1
34.61	Season 2 start date	Date	-	-	1 = 1
34.62	Season 3 start date	Date	-	-	1 = 1
34.63	Season 4 start date	Date	-	-	1 = 1
34.70	Number of active exceptions	Real	016	-	1 = 1
34.71	Exception types	PB	0b00000b1111	-	1 = 1
34.72	Exception 1 start	Date	-	d	1 = 1 d
34.73	Exception 1 length	Real	060	d	1 = 1 d
34.74	Exception 2 start	Date	-	d	1 = 1 d
34.75	Exception 2 length	Real	060	d	1 = 1 d
34.76	Exception 3 start	Date	-	d	1 = 1 d
34.77	Exception 3 length	Real	060	d	1 = 1 d
34.78	Exception day 4	Date	-	d	1 = 1 d
34.79	Exception day 5	Date	-	d	1 = 1 d
34.80	Exception day 6	Date	-	d	1 = 1 d
34.81	Exception day 7	Date	-	d	1 = 1 d
34.82	Exception day 8	Date	-	d	1 = 1 d
34.83	Exception day 9	Date	-	d	1 = 1 d
34.84	Exception day 10	Date	-	d	1 = 1 d
34.85	Exception day 11	Date	-	d	1 = 1 d
34.86	Exception day 12	Date	-	d	1 = 1 d
34.87	Exception day 13	Date	-	d	1 = 1 d
34.88	Exception day 14	Date	-	d	1 = 1 d
34.89	Exception day 15	Date	-	d	1 = 1 d
34.90	Exception day 16	Date	-	d	1 = 1 d
34.100	Timed function 1	PB	0b00000b1111	-	1 = 1
34.101	Timed function 2	PB	0b00000b1111	-	1 = 1
34.102	Timed function 3	PB	0b00000b1111	-	1 = 1
34.110	Boost time function	PB	0b00000b1111	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
34.111	Boost time activation source	Binary src	-	-	1 = 1
34.112	Boost time duration	Duration	00 00:0007 00:00	min	1 = 1 min
35 Moto	r thermal protection				
35.01	Motor estimated temperature	Real	-60…1000 °C or -76…1832 °F	°C or °F	1 = 1 °
35.02	Measured temperature 1	Real	-605000 °C or -769032 °F	°C, °F	1 = 1 unit
35.03	Measured temperature 2	Real	-60…5000 °C or -76…9032 °F	°C, °F	1 = 1 unit
35.05	Motor overload level	Real	0.0300.0	%	1 = 1unit
35.11	Temperature 1 source	List	-	-	1 = 1
35.12	Temperature 1 fault limit	Real	-60…5000 °C or -76…9032 °F	°C, °F	1 = 1 unit
35.13	Temperature 1 warning limit	Real	-605000 °C or -769032 °F	°C, °F	1 = 1 unit
35.14	Temperature 1 AI source	Analog src	-	-	1 = 1
35.21	Temperature 2 source	List	-	-	1 = 1
35.22	Temperature 2 fault limit	Real	-60…5000 °C or -76…9032 °F	°C, °F	1 = 1 unit
35.23	Temperature 2 warning limit	Real	-60…5000 °C or -76…9032 °F	°C, °F	1 = 1 unit
35.24	Temperature 2 AI source	Analog src	-	-	1 = 1
35.50	Motor ambient temperature	Real	-60…100 °C or -76 … 212 °F	°C, °F	1 = 1 °
35.51	Motor load curve	Real	50150	%	1 = 1%
35.52	Zero speed load	Real	50150	%	1 = 1%
35.53	Break point	Real	1.00 500.00	Hz	100 = 1 Hz
35.54	Motor nominal temperature rise	Real	0300 °C or 32572 °F	°C or °F	1 = 1 °
35.55	Motor thermal time const	Real	10010000	s	1 = 1 s
35.56	Motor overload action	List	02	-	1 = 1
35.57	Motor overload class	List	04	-	1 = 1
36 Load	l analyzer				
36.01	PVL signal source	Analog src	-	-	1 = 1
36.02	PVL filter time	Real	0.00120.00	s	100 = 1 s
36.09	Reset loggers	List	03	-	1 = 1
36.10	PVL peak value	Real	-32768.0032767.00	-	100 = 1
36.11	PVL peak date	Data	1/1/19806/5/2159	-	1 = 1
36.12	PVL peak time	Data	00:00:0023:59:59	-	1 = 1
36.13	PVL current at peak	Real	-32768.0032767.00	Α	100 = 1 A
36.14	PVL DC voltage at peak	Real	0.002000.00	V	100 = 1 V

No.	Name	Туре	Range	Unit	FbEq32
36.15	PVL speed at peak	Real	-30000.00-30000.00	rpm	100 = 1 rpm
36.16	PVL reset date	Data	1/1/19806/5/2159	-	1 = 1
36.17	PVL reset time	Data	00:00:0023:59:59	-	1 = 1
37 User	load curve	•			•
37.01	ULC output status word	PB	0b00000b1111	-	1 = 1
37.02	ULC supervision signal	Analog src	-	-	1 = 1
37.03	ULC overload actions	List	03	-	1 = 1
37.04	ULC underload actions	List	03	-	1 = 1
37.11	ULC speed table point 1	Real	-30000.030000.0	rpm	10 = 1 rpm
37.12	ULC speed table point 2	Real	-30000.030000.0	rpm	10 = 1 rpm
37.13	ULC speed table point 3	Real	-30000.030000.0	rpm	10 = 1 rpm
37.14	ULC speed table point 4	Real	-30000.030000.0	rpm	10 = 1 rpm
37.15	ULC speed table point 5	Real	-30000.030000.0	rpm	10 = 1 rpm
37.21	ULC underload point 1	Real	-1600.01600.0	%	10 = 1%
37.22	ULC underload point 2	Real	-1600.01600.0	%	10 = 1%
37.23	ULC underload point 3	Real	-1600.01600.0	%	10 = 1%
37.24	ULC underload point 4	Real	-1600.01600.0	%	10 = 1%
37.25	ULC underload point 5	Real	-1600.01600.0	%	10 = 1%
37.31	ULC overload point 1	Real	-1600.01600.0	%	10 = 1%
37.32	ULC overload point 2	Real	-1600.01600.0	%	10 = 1%
37.33	ULC overload point 3	Real	-1600.01600.0	%	10 = 1%
37.34	ULC overload point 4	Real	-1600.01600.0	%	10 = 1%
37.35	ULC overload point 5	Real	-1600.01600.0	%	10 = 1%
37.41	ULC overload timer	Real	0.010000.0	s	10 = 1 s
37.42	ULC underload timer	Real	0.010000.0	s	10 = 1 s
40 Proc	ess PID set 1				
40.01	Process PID output actual	Real	-200000.00200000.00	-	100 = 1 PID customer unit
40.02	Process PID feedback actual	Real	-200000.00200000.00	PID customer units	100 = 1 PID customer unit
40.03	Process PID setpoint actual	Real	-200000.00200000.00	PID customer units	100 = 1 PID customer unit
40.04	Process PID deviation actual	Real	-200000.00200000.00	PID customer units	100 = 1 PID customer unit
40.05	Process PID trim output act	Real	-3276832767	PID customer units	100 = 1 PID customer unit
40.06	Process PID status word	PB	0b00000b1111	-	1 = 1
40.07	Process PID operation mode	List	02	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
40.08	Set 1 feedback 1 source	Analog	-	-	1 = 1
40.09	Set 1 feedback 2 source	src Analog src	-	-	1 = 1
40.10	Set 1 feedback function	List	011	-	1 = 1
40.11	Set 1 feedback filter time	Real	0.00030.000	S	1000 = 1 s
40.14	Set 1 setpoint scaling	Real	-200000.00200000.00	-	-
40.15	Set 1 output scaling	Real	-200000.00200000.00	-	-
40.16	Set 1 setpoint 1 source	Analog src	-	-	1 = 1
40.17	Set 1 setpoint 2 source	Analog src	-	-	1 = 1
40.18	Set 1 setpoint function	List	011	-	1 = 1
40.19	Set 1 internal setpoint sel1	Binary src	-	-	1 = 1
40.20	Set 1 internal setpoint sel2	Binary src	-	-	1 = 1
40.21	Set 1 internal setpoint 1	Real	-200000.00200000.00	PID customer units	100 = 1 PID customer unit
40.22	Set 1 internal setpoint 2	Real	-200000.00200000.00	PID customer units	100 = 1 PID customer unit
40.23	Set 1 internal setpoint 3	Real	-200000.00200000.00	PID customer units	100 = 1 PID customer unit
40.24	Set 1 internal setpoint 0	Real	-200000.00200000.00	PID customer units	100 = 1 PID customer unit
40.26	Set 1 setpoint min	Real	-200000.00200000.00	-	100 = 1
40.27	Set 1 setpoint max	Real	-200000.00200000.00	-	100 = 1
40.28	Set 1 setpoint increase time	Real	0.01800.0	s	10 = 1 s
40.29	Set 1 setpoint decrease time	Real	0.01800.0	s	10 = 1 s
40.30	Set 1 setpoint freeze enable	Binary src	-	-	1 = 1
40.31	Set 1 deviation inversion	Binary src	-	-	1 = 1
40.32	Set 1 gain	Real	0.01100.00	-	100 = 1
40.33	Set 1 integration time	Real	0.09999.0	s	10 = 1 s
40.34	Set 1 derivation time	Real	0.00010.000	s	1000 = 1 s
40.35	Set 1 derivation filter time	Real	0.010.0	s	10 = 1 s
40.36	Set 1 output min	Real	-200000.00200000.00	-	10 = 1
40.37	Set 1 output max	Real	-200000.00200000.00	-	10 = 1
40.38	Set 1 output freeze	Binary src	-	-	1 = 1
40.39	Set 1 deadband range	Real	0.003600.00	-	100 = 1
40.40	Set 1 deadband delay	Real	0.0200000.0	s	10 = 1 s

No.	Name	Туре	Range	Unit	FbEq32
40.43	Set 1 sleep level	Real	0.0200000.0	-	10 = 1
40.44	Set 1 sleep delay	Real	0.03600.0	s	10 = 1 s
40.45	Set 1 sleep boost time	Real	0.03600.0	s	10 = 1 s
40.46	Set 1 sleep boost step	Real	0.00200000.00	PID customer units	100 = 1 PID customer unit
40.47	Set 1 wake-up deviation	Real	-20000000200000.00	PID customer units	100 = 1 PID customer unit
40.48	Set 1 wake-up delay	Real	0.0060.00	s	100 = 1 s
40.49	Set 1 tracking mode	Binary src	-	-	1 = 1
40.50	Set 1 tracking ref selection	Analog src	-	-	1 = 1
40.51	Set 1 trim mode	List	03	-	1 = 1
40.52	Set 1 trim selection	List	13	-	1 = 1
40.53	Set 1 trimmed ref pointer	Analog src	-	-	1 = 1
40.54	Set 1 trim mix	Real	0.0001.000	-	1 = 1
40.55	Set 1 trim adjust	Real	-100.000100.000	-	1 = 1
40.56	Set 1 trim source	List	12	-	1 = 1
40.57	PID set1/set2 selection	Binary src	07, 1823	-	1 = 1
40.58	Set 1 increase prevention	Binary src	-	-	1 = 1
40.59	Set 1 decrease prevention	Binary src	-	-	1 = 1
40.60	Set 1 PID activation source	Binary src	-	-	1 = 1
40.61	Setpoint scaling actual	Real	200000.00200000.00	-	100 = 1
40.62	PID internal setpoint actual	Real	-200000.00200000.00	PID customer units	100 = 1 PID customer unit
40.65	Trim auto connection	TBD			
40.79	Set 1 units	List	031	Depends on selection	-
40.80	Set 1 PID output min source	Analog src	-	-	1 = 1
40.81	Set 1 PID output max source	Analog src	-	-	1 = 1
40.89	Set 1 setpoint multiplier	Real	-200000.00200000.00	-	-
40.90	Set 1 feedback multiplier	Real	-200000.00200000.00	-	100 = 1
40.91	Feedback data storage	Real	-327.68327.67	-	100 = 1
40.92	Setpoint data storage	Real	-327.68327.67	-	100 = 1
40.96	Process PID output%	Real	-100.00100.00	%	-

No.	Name	Туре	Range	Unit	FbEq32				
40.97	Process PID feedback%	Real	-100.00100.00	%	-				
40.98	Process PID setpoint%	Real	-100.00100.00	%	-				
40.99	Process PID deviation%	Real	-100.00100.00	%	-				
41 Proc	41 Process PID set 2								
41.08	Set 2 feedback 1 source	Analog src	-	-	1 = 1				
41.09	Set 2 feedback 2 source	Analog src	-	-	1 = 1				
41.10	Set 2 feedback function	List	011	-	1 = 1				
41.11	Set 2 feedback filter time	Real	0.00030.000	s	1000 = 1 s				
41.14	Set 2 setpoint scaling	Real	-200000.00 200000.00	-	100=1				
41.15	Set 2 output scaling	Real	-200000.00 200000.00	-	100=1				
41.16	Set 2 setpoint 1 source	Analog src	-	-	1 = 1				
41.17	Set 2 setpoint 2 source	Analog src	-	-	1 = 1				
41.18	Set 2 setpoint function	List	011	-	1 = 1				
41.19	Set 2 internal setpoint sel1	Binary src	-	-	1 = 1				
41.20	Set 2 internal setpoint sel2	Binary src	-	-	1 = 1				
41.21	Set 2 internal setpoint 1	Real	-200000.00 200000.00	PID customer unit	100 = 1 PID customer unit				
41.22	Set 2 internal setpoint 2	Real	-200000.00 200000.00	PID customer units	100 = 1 PID customer unit				
41.23	Set 2 internal setpoint 3	Real	-200000.00 200000.00	PID customer units	100 = 1 PID customer unit				
41.24	Set 2 internal setpoint 0	Real	-200000.00 200000.00	PID customer units	100 = 1 PID customer unit				
41.26	Set 2 setpoint min	Real	-200000.00 200000.00	-	100 = 1				
41.27	Set 2 setpoint max	Real	-200000.00 200000.00	-	100 = 1				
41.28	Set 2 setpoint increase time	Real	0.01800.0	s	10 = 1 s				
41.29	Set 2 setpoint decrease time	Real	0.01800.0	s	10 = 1 s				
41.30	Set 2 setpoint freeze enable	Binary src	-	-	1 = 1				
41.31	Set 2 deviation inversion	Binary src	-	-	1 = 1				
41.32	Set 2 gain	Real	0.01100.00	-	100 = 1				
41.33	Set 2 integration time	Real	0.09999.0	s	10 = 1 s				
41.34	Set 2 derivation time	Real	0.00010.000	s	1000 = 1 s				
41.35	Set 2 derivation filter time	Real	0.010.0	s	10 = 1 s				
41.36	Set 2 output min	Real	-200000.00 200000.00	-	10 = 1				

No.	Name	Туре	Range	Unit	FbEq32
41.37	Set 2 output max	Real	-200000.00 200000.00	-	10 = 1
41.38	Set 2 output freeze	Binary src	-	-	1 = 1
41.39	Set 2 deadband range	Real	0.003600.00	-	100 = 1
41.40	Set 2 deadband delay	Real	0.0200000.0	s	10 = 1 s
41.43	Set 2 sleep level	Real	0.0200000.0	-	10 = 1
41.44	Set 2 sleep delay	Real	0.03600.0	s	10 = 1 s
41.45	Set 2 sleep boost time	Real	0.03600.0	s	10 = 1 s
41.46	Set 2 sleep boost step	Real	0.00200000.00	PID customer units	100 = 1 PID customer unit
41.47	Set 2 wake-up deviation	Real	-200000.00 200000.00	PID customer units	100 = 1 PID customer unit
41.48	Set 2 wake-up delay	Real	0.0060.00	s	100 = 1 s
41.49	Set 2 tracking mode	Binary src	-	-	1 = 1
41.50	Set 2 tracking ref selection	Analog src	-	-	1 = 1
41.51	Set 2 trim mode	List	03	-	1 = 1
41.52	Set 2 trim selection	List	13	-	1 = 1
41.53	Set 2 trimmed ref pointer	Analog src	-	-	1 = 1
41.54	Set 2 trim mix	Real	0.0001.000	-	1 = 1
41.55	Set 2 trim adjust	Real	-100.000100.000	-	1 = 1
41.56	Set 2 trim source	List	12	-	1 = 1
41.58	Set 2 increase prevention	Binary src	-	-	1 = 1
41.59	Set 2 decrease prevention	Binary src	-	-	1 = 1
41.60	Set 2 PID activation source	Binary src	-	-	1 = 1
41.79	Set 2 units	Real	031	Depends on selection	-
41.80	Set 1 PID output min source	Analog src	-	-	1 = 1
41.81	Set 1 PID output max source	Analog src	-	-	1 = 1
41.89	Set 2 setpoint multiplier	Real	-100000.00100000.00	-	100 = 1
41.90	Set 2 feedback multiplier	Real	-100000.00100000.00	-	100 = 1
43 Brak	e chopper				
43.01	Braking resistor temperature	Real	0.0120.0	%	10 = 1%
43.06	Brake chopper enable	List	03	-	1 = 1
43.07	Brake chopper runtime enable	Binary src	01	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
43.08	Brake resistor thermal tc	Real	010000	s	1 = 1 s
43.09	Brake resistor Pmax cont	Real	0.0010000.00	kW	100 = 1 kW
43.10	Brake resistance	Real	0.01000.0	Ohm	10 = 1 ohm
43.11	Brake resistor fault limit	Real	0150	%	1 = 1%
43.12	Brake resistor warning limit	Real	0150	%	1 = 1%
44 Mech	nanical brake control		•		
44.01	Brake control status	PB	0b00000b1111	-	1 = 1
44.06	Brake control enable	Binary src	-	-	1 = 1
44.08	Brake open delay	Real	0.005.00	s	100 = 1 s
44.13	Brake close delay	Real	0.0060.00	s	100 = 1 s
44.14	Brake close level	Real	0.001000.00	rpm	100 = 1 rpm
45 Ener	gy efficiency				
45.01	Saved GW hours	Real	065535	GWh	1 = 1 GWh
45.02	Saved MW hours	Real	0999	MWh	1 = 1 MWh
45.03	Saved kW hours	Real	0.0999.9	kWh	10 = 1 kWh
45.04	Saved energy	Real	0.0214748364.0	kWh	10 = 1 kWh
45.05	Saved money x1000	Real	04294967295 thousands	INR	1 = 1
45.06	Saved money	Real	0.00999.99	INR	100 = 1
45.07	Saved amount	Real	0.0021474830.00	INR	100 = 1
45.08	CO2 reduction in kilotons	Real	065535	metric kiloton	1 = 1 metric kiloton
45.09	CO2 reduction in tons	Real	0.0999.9	metric ton	10 = 1 metric ton
45.10	Total saved CO2	Real	0.0214748300.0	metric ton	10 = 1 metric ton
45.11	Energy optimizer	List	01	-	1 = 1
45.12	Energy tariff 1	Real	0.0004294966.296	INR	1000 = 1
45.13	Energy tariff 2	Real	0.0004294966.296	INR	1000 = 1
45.14	Tariff selection	Binary src	-	-	1 = 1
45.17	Tariff currency unit	List	100, 101, 102	INR	1=1
45.18	CO2 conversion factor	Real	0.00065.535	tn/ MWh	1000 = 1 tn/MWh
45.19	Comparison power	Real	0.001000000.00	kW	10 = 1 kW
45.21	Energy calculations reset	List	01	-	1 = 1
45.24	Hourly peak power value	Real	-3000.00 3000.00	kW	1 = 1 kW
45.25	Hourly peak power time	Real			N/A
45.26	Hourly total energy (resettable)	Real	-3000.00 3000.00	kWh	1 = 1 kWh
45.27	Daily peak power value (resettable)	Real	-3000.00 3000.00	kW	1 = 1 kW
45.28	Daily peak power time	Real			N/A
45.29	Daily total energy (resettable)	Real	-30000.00 30000.00	kWh	1 = 1 kWh

No.	Name	Туре	Range	Unit	FbEq32
45.30	Last day total energy	Real	-30000.00 30000.00	kWh	1 = 1 kWh
45.31	Monthly peak power value (resettable)	Real	-3000.00 3000.00	kW	1 = 1 kW
45.32	Monthly peak power date	Real	1/1/19806/5/2159		N/A
45.33	Monthly peak power time	Real			N/A
45.34	Monthly total energy (resettable)	Real	-100000.00 100000.00	kWh	1 = 1 kWh
45.35	Last month total energy	Real	-1000000.00 1000000.00	kWh	1 = 1 kWh
45.36	Lifetime peak power value	Real	-3000.00 3000.00	kW	1 = 1 kW
45.37	Lifetime peak power date	Real	1/1/19806/5/2159		N/A
45.38	Lifetime peak power time	Real			N/A
46 Moni	toring/scaling settings				
46.01	Speed scaling	Real	0.0030000.00	rpm	100 = 1 rpm
46.02	Frequency scaling	Real	0.101000.00	Hz	100 = 1 Hz
46.03	Torque scaling	Real	0.11000.0	%	10 = 1%
46.04	Power scaling	Real	0.1030000.00 kW or 0.1040200.00 hp	kW or hp	10 = 1 unit
46.05	Current scaling	Real	030000	А	1 = 1 A
46.06	Speed ref zero scaling	Real	0.00 30000.00	rpm	100 = 1 rpm
46.07	Frequency ref zero scaling	Real	0.00 1000.00	Hz	100 = 1 Hz
46.11	Filter time motor speed	Real	220000	ms	1 = 1 ms
46.12	Filter time output frequency	Real	220000	ms	1 = 1 ms
46.13	Filter time motor torque	Real	220000	ms	1 = 1 ms
46.14	Filter time power	Real	220000	ms	1 = 1 ms
46.21	At speed hysteresis	Real	0.0030000.00	rpm	100 = 1 rpm
46.22	At frequency hysteresis	Real	0.001000.00	Hz	100 = 1 Hz
46.31	Above speed limit	Real	0.0030000.00	rpm	100 = 1 rpm
46.32	Above frequency limit	Real	0.001000.00	Hz	100 = 1 Hz
46.33	Above torque limit	Real	0.01600.0	%	10 = 1%
46.41	kWh pulse scaling	Real	0.0011000.000	kWh	1000 = 1 kWh
46.43	Power decimals	Real	03	-	1 = 1
46.44	Current decimals	Real	03	-	1 = 1
47 Data	storage				
47.01	Data storage 1 real32	Real	-2147483.000 2147483.000	-	1000 = 1
47.02	Data storage 2 real32	Real	-2147483.000 2147483.000	-	1000 = 1
47.03	Data storage 3 real32	Real	-2147483.000 2147483.000	-	1000 = 1
47.04	Data storage 4 real32	Real	-2147483.000 2147483.000	-	1000 = 1
47.11	Data storage 1 int32	Real	-2147483648 2147483647	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
47.12	Data storage 2 int32	Real	-2147483648 2147483647	-	1 = 1
47.13	Data storage 3 int32	Real	-2147483648 2147483647	-	1 = 1
47.14	Data storage 4 int32	Real	-2147483648 2147483647	-	1 = 1
47.21	Data storage 1 int16	Real	-3276832767	-	1 = 1
47.22	Data storage 2 int16	Real	-3276832767	-	1 = 1
47.23	Data storage 3 int16	Real	-3276832767	-	1 = 1
47.24	Data storage 4 int16	Real	-3276832767	-	1 = 1
49 Pane	I port communication				
49.01	Node ID number	Real	132	-	1 = 1
49.03	Baud rate	List	15	-	1 = 1
49.04	Communication loss time	Real	0.33000.0	s	10 = 1 s
49.05	Communication loss action	List	03	-	1 = 1
49.06	Refresh settings	List	01	-	1 = 1
49.19	Basic panel home view 1	List	-	-	1 = 1
49.20	Basic panel home view 2	List	-	-	1 = 1
49.21	Basic panel home view 3	List	-	-	1 = 1
49.219	Basic panel home view 4	List	-	-	1 = 1
49.220	Basic panel home view 5	List	-	-	1 = 1
49.221	Basic panel home view 6	List	-	-	1 = 1
50 Field	bus adapter (FBA)				
50.01	FBA A enable	List	01	-	1 = 1
50.02	FBA A comm loss func	List	05	-	1 = 1
50.03	FBA A comm loss t out	Real	0.36553.5	s	10 = 1 s
50.04	FBA A ref1 type	List	0 5	-	1 = 1
50.05	FBA A ref2 type	List	02, 4, 5	-	1 = 1
50.06	FBA A SW sel	List	01	-	1 = 1
50.07	FBAA actual 1 type	List	05	-	1 = 1
50.08	FBAA actual 2 type	List	05	-	1 = 1
50.09	FBAA SW transparent source	Analog src	-	-	1 = 1
50.10	FBAA act1 transparent source	Analog src	-	-	1 = 1
50.11	FBAA act2 transparent source	Analog src	-	-	1 = 1
50.12	FBAA debug mode	List	01	-	1 = 1
50.13	FBAA control word	Data	0.0.0.0.0FF.FF.FF.FF	-	1 = 1
50.14	FBAA reference 1	Real	-2147483648 2147483647	-	1 = 1
50.15	FBAA reference 2	Real	-2147483648 2147483647	-	1 = 1
50.16	FBA A status word	Data	0.0.0.0.0FF.FF.FF.FF	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
50.17	FBAA actual value 1	Real	-2147483648 2147483647	-	1 = 1
50.18	FBAA actual value 2	Real	-2147483648 2147483647	-	1 = 1
51 FBA	A settings				
51.01	FBA A type	List	0, 1, 32, 37, 128, 132, 135, 136, 485, 101, 47808	-	1 = 1
51.02	FBA A Par2	Real	065535	-	1 = 1
51.26	FBA A Par26	Real	065535	-	1 = 1
51.27	FBA A par refresh	List	01	-	1 = 1
51.28	FBAA par table ver	Data	0x00000xffff	-	1 = 1
51.29	FBA A drive type code	Real	065535	-	1 = 1
51.30	FBA A mapping file ver	Real	065535	-	1 = 1
51.31	D2FBAA comm status	List	06	-	1 = 1
51.32	FBA A comm SW ver	Data	0x00000xffff	-	1 = 1
51.33	FBAA appl SW ver	Data	0x00000xffff	-	1 = 1
52 FBA	A data in				•
52.01	FBAA data in1	List	06, 1116, 24	-	1 = 1
52.12	FBA A data in 12	List	06, 1116, 24	-	1 = 1
53 FBA	A data out				
53.01	FBA A data out1	List	03, 1113, 21	-	1 = 1
53.12	FBA A data out12	List	03, 1113, 21	-	1 = 1
58 Emb	edded fieldbus		, -,		I
58.01	Protocol enable	List	01		1 = 1
58.02	Protocol ID	Real	0000hFFFFh		1 = 1
58.03	Node address	Real	0255	-	1 = 1
58.04	Baud rate	List	07	-	1 = 1
58.05	Parity	List	03	-	1 = 1
58.06	Communication control	List	02	-	1 = 1
58.07	Communication diagnostics	PB	0000hFFFFh		1 = 1
58.08	Received packets	Real	04294967295		1 = 1
58.09	Transmitted packets	Real	04294967295	-	1 = 1
58.10	All packets	Real	04294967295	-	1 = 1
58.11	UART errors	Real	04294967295	-	1 = 1
58.12	CRC errors	Real	04294967295	_	1 = 1
58.14	Communication loss action	List	04294907293	-	1 = 1
58.15	Communication loss mode	List	12	-	1 = 1
58.16	Communication loss time	Real	0.06000.0	s	10 = 1 s
58.17		Real	065535		10 – 1 s 1 = 1 ms
JO.17	Transmit delay	Real	0000000	ms	1 – 1 ms

No.	Name	Туре	Range	Unit	FbEq32
58.18	EFB control word	PB	0000hFFFFh	-	1 = 1
58.19	EFB status word	PB	0000hFFFFh	-	1 = 1
58.25	Control profile	List	0, 5	-	1 = 1
58.26	EFB ref1 type	List	05	-	1 = 1
58.27	EFB ref2 type	List	05	-	1 = 1
58.28	EFB act1 type	List	05	-	1 = 1
58.29	EFB act2 type	List	05	-	1 = 1
58.31	EFB act1 transparent source	Analog src	-	-	1 = 1
58.32	EFB act2 transparent source	Analog src	-	-	1 = 1
58.33	Addressing mode	List	02	-	1 = 1
58.34	Word order	List	01	-	1 = 1
58.101	Data I/O 1	Analog src	-	-	1 = 1
58.102	Data I/O 2	Analog src	-	-	1 = 1
58.103	Data I/O 3	Analog src	-	-	1 = 1
58.104	Data I/O 4	Analog src	-	-	1 = 1
58.105	Data I/O 5	Analog src	-	-	1 = 1
58.106	Data I/O 6	Analog src	-	-	1 = 1
58.107	Data I/O 7	Analog src	-	-	1 = 1
58.114	Data I/O 14	Analog src	-	-	1 = 1
70 Over	ride	•		•	
70.01	Override status	PB	0b00000b1111	-	1 = 1
70.02	Override enable	List	-	-	1 = 1
70.03	Override activation source	List	-	-	1 = 1
70.04	Override reference source	List	-	-	1 = 1
70.05	Override direction	List	-	-	1 = 1
70.06	Override frequency	Real	-500.0500.0	Hz	100 = 1 Hz
70.07	Override speed	Real	-30000.030000.0	rpm	100 = 1 rpm
70.20	Override fault handling	List	01	-	1 = 1
70.21	Override auto reset trials	Real	060	-	1 = 1
70.22	Override auto reset time	Real	0.1120.0	s	10 = 1
71 Exte	rnal PID1				
71.01	External PID act value	Real	-200000.00200000.00	%	100 = 1 PID customer unit

No.	Name	Туре	Range	Unit	FbEq32
71.02	Feedback act value	Real	-200000.00200000.00	PID customer units	100 = 1 PID customer unit
71.03	Setpoint act value	Real	-200000.00200000.00	PID customer units	100 = 1 PID customer unit
71.04	Deviation act value	Real	-200000.00200000.00	PID customer units	100 = 1 PID customer unit
71.06	PID status word	PB	0000hFFFFh	-	1 = 1
71.07	PID operation mode	List	02	-	1 = 1
71.08	Feedback 1 source	Analog src	-	-	1 = 1
71.11	Feedback filter time	Real	0.00030.000	s	1000 = 1 s
71.14	Setpoint scaling	Real	-200000.00200000.00	-	100 = 1
71.15	Output scaling	Real	-200000.00200000.00	-	100 = 1
71.16	Setpoint 1 source	Analog src	-	-	1 = 1
71.19	Internal setpoint sel1	Binary src	-	-	1 = 1
71.20	Internal setpoint sel2	Binary src	-	-	1 = 1
71.21	Internal setpoint 1	Real	-200000.00200000.00	PID customer units	100 = 1 PID customer unit
71.22	Internal setpoint 2	Real	-200000.00200000.00	PID customer units	100 = 1 PID customer unit
71.23	Internal setpoint 3	Real	-200000.00200000.00	PID customer units	100 = 1 PID customer unit
71.26	Setpoint min	Real	-200000.00200000.00	-	100 = 1
71.27	Setpoint max	Real	-200000.00200000.00	-	100 = 1
71.31	Deviation inversion	Binary src	-	-	1 = 1
71.32	Gain	Real	0.10100.00	-	100 = 1
71.33	Integration time	Real	0.09999.0	s	10 = 1 s
71.34	Derivation time	Real	0.00010.000	s	1000 = 1 s
71.35	Derivation filter time	Real	0.010.0	s	1000 = 1 s
71.36	Output min	Real	-200000.00200000.00	-	10 = 1
71.37	Output max	Real	-200000.00200000.00	-	10 = 1
71.38	Output freeze enable	Binary src	-	-	1 = 1
71.39	Deadband range	Real	0.0200000.0	-	10 = 1
71.40	Deadband delay	Real	0.03600.0	s	1000 = 1 s
71.58	Increase prevention	Binary src	-	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
71.59	Decrease prevention	Binary src	-	-	1 = 1
71.62	Internal setpoint actual	Real	-200000.00200000.00	PID customer units	100 = 1 PID customer unit
71.79	External PID units	List	031	Depends on selection	-
76 PFC	configuration				
76.01	PFC status	PB	0b00000b1111	-	1 = 1
76.02	PFC system status	PB	09, 100103, 200202, 300302, 400, 500, 600, 700, 800, 801	-	1 = 1
76.11	Pump/fan status 1	PB	0b00000b1111	-	1 = 1
76.12	Pump/fan status 2	PB	0b00000b1111	-	1 = 1
76.13	Pump/fan status 3	PB	0b00000b1111	-	1 = 1
76.14	Pump/fan status 4	PB	0b00000b1111	-	1 = 1
76.21	PFC configuration	List	0, 23	-	1 = 1
76.25	Number of motors	Real	14	-	1 = 1
76.26	Min number of motors allowed	Real	04	-	1 = 1
76.27	Max number of motors allowed	Real	14	-	1 = 1
76.30	Start point 1	Real	032767	rpm/Hz	1 = 1 unit
76.31	Start point 2	Real	032767	rpm/Hz	1 = 1 unit
76.32	Start point 3	Real	032767	rpm/Hz	1 = 1 unit
76.41	Stop point 1	Real	032767	rpm/Hz	1 = 1 unit
76.42	Stop point 2	Real	032767	rpm/Hz	1 = 1 unit
76.43	Stop point 3	Real	032767	rpm/Hz	1 = 1 unit
76.55	Start delay	Real	0.0012600.00	s	100 = 1 s
76.56	Stop delay	Real	0.0012600.00	s	100 = 1 s
76.57	PFC speed hold on	Real	0.001000.00	s	100 = 1 s
76.58	PFC speed hold off	Real	0.001000.00	s	100 = 1 s
76.59	PFC contactor delay	Real	0.20600.00	s	100 = 1 s
76.60	PFC ramp acceleration time	Real	0.001800.00	s	100 = 1 s
76.61	PFC ramp deceleration time	Real	0.001800.00	s	100 = 1 s
76.70	PFC autochange	List	013	-	1 = 1
76.71	PFC autochange interval	Real	0.0042949672.95	h	100 = 1 h
76.72	Maximum wear imbalance	Real	0.001000000.00	h	100 = 1 h
76.73	Autochange level	Real	0.0300.0	%	10 = 1%
76.74	Autochange auxiliary PFC	List	01	-	1 = 1
76.81	PFC interlock 1	List	010	-	1 = 1
76.82	PFC interlock 2	List	010	-	1 = 1
76.83	PFC interlock 3	List	010	-	1 = 1
76.84	PFC interlock 4	List	010	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32
76.95	Regulator bypass control	Binary src	-	-	-
77 PFC	maintenance and monitoring				
77.10	PFC runtime change	List	05	-	1 = 1
77.11	Pump/fan 1 running time	Real	0.0042949672.95	h	100 = 1 h
77.12	Pump/fan 2 running time	Real	0.0042949672.95	h	100 = 1 h
77.13	Pump/fan 3 running time	Real	0.0042949672.95	h	100 = 1 h
77.14	Pump/fan 4 running time	Real	0.0042949672.95	h	100 = 1 h
90 Feed	back selection				•
90.03	Load speed	Real	-32768.0032768.00	rpm	100 = 1 rpm
90.52	LoadSpeed filter time	Real	010000	ms	1 = 1 ms
90.61	Gear numerator	Real	-2147483648 2147483648	-	1 = 1
90.62	Gear denominator	Real	-2147483648 2147483648	-	1 = 1
90.99	Load speed unit	List	-	rpm	1 = 1
95 HW (configuration	•			•
95.01	Supply voltage	List	0, 2	-	1 = 1
95.02	Adaptive voltage limits	List	01	-	1 = 1
95.03	Estimated AC supply voltage	Real	065535	V	1 = 1 V
95.04	Control board supply	List	01	-	1 = 1
95.15	Special HW settings	PB	0b00000b1111	-	1 = 1
95.20	HW options word 1	PB	0b00000b1111	-	1 = 1
95.21	HW options word 2	PB	0b00000b1111	-	1 = 1
95.26	Motor disconnect switch	List	01	-	1 = 1
95.200	Cooling fan mode	List	0, 1	-	1 = 1
96 Syst	em				•
96.01	Language	List	0, 1033, 2052	-	1 = 1
96.02	Pass code	Data	-	-	1 = 1
96.03	Access level status	PB	0b00000b1111	-	1 = 1
96.04	Macro select	List	-	-	1 = 1
96.05	Macro active	List	-	-	1 = 1
96.06	Parameter restore	List	0, 2, 8, 32, 62, 512, 1024, 34560	-	1 = 1
96.07	Parameter save manually	List	0, 1	-	1 = 1
96.08	Control board boot	List	0, 1	-	1 = 1
96.10	User set status	List	011	-	1 = 1
96.11	User set save/load	List	05, 1821	-	1 = 1
96.12	User set I/O mode in1	Binary src	-	-	1=1
96.13	User set I/O mode in2	Binary src	-	-	1=1
96.16	Unit selection	PB	0b00000b1111	-	1 = 1

No.	Name	Туре	Range	Unit	FbEq32	
96.20	Time sync primary source	List	-	-	1 = 1	
96.24	Full days since 1st Jan 1980	Real	159999	d	1 =1 d	
96.25	Time in minutes within 24h	Real	11439	min	1 = 1 min	
96.26	Time in ms within one minute	Real	059999	ms	1 = 1 ms	
96.51	Clear fault and event logger	Real	01	-	1 = 1	
	(Parameters 96.10096.	.102 only v	isible when enabled by param	neter <mark>96.02</mark>))	
96.78	550 compatibility mode	List	01	-	1 = 1	
96.100	Change user pass code	Data	1000000999999999	-	1 = 1	
96.101	Confirm user pass code	Data	100000099999999	-	1 = 1	
96.102	User lock functionality	PB	0000hFFFFh	-	1 = 1	
97 Moto	or control					
97.01	Switching frequency reference	List	2, 4, 8, 12	kHz	1 = 1 kHz	
97.02	Minimum switching frequency	List	1.5, 2, 4, 8, 12	kHz	1 = 1 kHz	
97.03	Slip gain	Real	0200	%	1 = 1%	
97.04	Voltage reserve	Real	-450	%	1 = 1%	
97.05	Flux braking	List	02	-	1 = 1	
97.08	Optimizer minimum torque	Real	0.01600.0	%	1 = 1	
97.13	IR compensation	Real	0.0050.00	%	100 = 1%	
97.20	U/F ratio	List	020	-	1 = 1	
97.48	Udc stabilizer	List	0, 50, 100, 300, 500, 800	-	1 = 1	
97.49	Slip gain for scalar	Real	0200	%	1 = 1%	
97.94	IR comp max frequency	Real	1.0200.0	%	10 = 1%	
97.135	UDC ripple	Real	0.0200.0	V	10 = 1V	
98 User	motor parameters					
98.01	User motor model mode	List	01	-	1 = 1	
98.02	Rs user	Real	0.00000.50000	p.u.	100000 = 1 p.u.	
98.03	Rr user	Real	0.00000.50000	p.u.	100000 = 1 p.u.	
98.04	Lm user	Real	0.0000010.00000	p.u.	100000 = 1 p.u.	
98.05	SigmaL user	Real	0.000001.00000	p.u.	100000 = 1 p.u.	
98.09	Rs user SI	Real	0.00000100.00000	ohm	100000 = 1 p.u.	
98.10	Rr user SI	Real	0.00000100.00000	ohm	100000 = 1 p.u.	
98.11	Lm user SI	Real	0.00100000.00	mH	100 = 1 mH	
98.12	SigmaL user SI	Real	0.00100000.00	mH	100 = 1 mH	
99 Moto	99 Motor data					
99.03	Motor type	List	0	-	1 = 1	
99.04	Motor control mode	List	01	-	1 = 1	
			0.032767.0	А	10 = 1 A	

410 Additional parameter data

No.	Name	Туре	Range	Unit	FbEq32
99.07	Motor nominal voltage	Real	0.032767.0	V	10 = 1 V
99.08	Motor nominal frequency	Real	0.00 500.00	Hz	100 = 1 Hz
99.09	Motor nominal speed	Real	0 30000	rpm	1 = 1 rpm
99.10	Motor nominal power	Real	0.0010000.00 kW or 0.00 13404.83 hp	kW or hp	100 = 1 unit
99.11	Motor nominal cos Φ	Real	0.00 1.00	-	100 = 1
99.12	Motor nominal torque	Real	0.000…400000.000 N·m or 0.000…2950248.597 lb∙ft	N·m or Ib∙ft	1000 = 1 unit
99.13	ID run requested	List	03, 6, 7	-	1 = 1
99.14	Last ID run performed	List	03, 6	-	1 = 1
99.15	Motor polepairs calculated	Real	01000	-	1 = 1
99.16	Motor phase order	List	01	-	1 = 1

8

Fault tracing

What this chapter contains

The chapter lists the warning and fault messages including possible causes and corrective actions. The causes of most warnings and faults can be identified and corrected using the information in this chapter. If not, contact an ABB service representative. If you have a possibility to use the Drive composer PC tool, send the Support package created by the Drive composer to the ABB service representative.

Warnings and faults are listed below in separate tables. Each table is sorted by warning/fault code.

Safety

WARNING! Only qualified electricians are allowed to service the drive. Read the instructions in chapter *Safety instructions* at the beginning of the *Hardware manual* of the drive before working on the drive.

Indications

Warnings and faults

Warnings and faults indicate an abnormal drive status. The codes of active warnings and faults are displayed on the control panel of the drive as well as in the Drive composer PC tool with warning and fault names. Only the codes of warnings and faults are available over fieldbus.

Warnings do not need to be reset; they stop showing when the cause of the warning ceases. Warnings do not latch and the drive will continue to operate the motor.

Faults latch inside the drive and cause the drive to trip, and the motor stops. After the cause of a fault has been removed, the fault can be reset from a selectable source (parameter 31.11 Fault reset selection) such as the control panel, Drive composer PC tool, the digital inputs of the drive, or fieldbus. Reseting the fault creates an event 64FF Fault reset. After the reset, the drive can be restarted.

Note that some faults require a reboot of the control unit either by switching the power off and on, or using parameter 96.08 Control board boot – this is mentioned in the fault listing wherever appropriate.

Pure events

In addition to warnings and faults, there are pure events that are only recorded in the event log of the drive. The codes of these events are included in the *Warning messages* table on page (414).

Editable messages

For external events, the action (fault or warning), name and the message text can be edited. To specify external events, use parameter *31 Fault functions*.

Warning/fault history

Event log

All indications are stored in the event log with a time stamp and other information. The event log stores information on

- the last 8 fault recordings, that is, faults that tripped the drive or fault resets
- · the last 10 warnings or pure events that occurred.

See section Viewing warning/fault information on page 412.

Auxiliary codes

Some events generate an auxiliary code that often helps in pinpointing the problem. On the control panel, the auxiliary code is stored as part of the details of the event; in the Drive composer PC tool, the auxiliary code is shown in the event listing.

Viewing warning/fault information

The drive is able to store a list of the active faults actually causing the drive to trip at the present time. The drive also stores a list of faults and warnings that have previously occurred.

For active faults and warnings, see

- Menu ≡ Diagnostics 𝒴 Active warnings ⚠ 0
- parameters in group 04 Warnings and faults (page 168).

For previously occurred faults, see

- parameters in group 04 Warnings and faults (page 168).

The event log can also be accessed (and reset) using the Drive composer PC tool. See *Drive composer PC tool user's manual* (3AUA0000094606 [English]).

Warning messages

Note: The list also contains events that only appear in the Event log.

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
64FF	Fault reset	A fault has been reset from the panel, Drive composer PC tool, fieldbus or I/O.	Event. Informative only.
A2B1	Overcurrent	Output current has exceeded internal fault limit. In addition to an actual overcurrent situation, this warning may also be caused by an earth fault or supply phase loss.	Check motor load. Check acceleration times in parameter group 23 Speed reference ramp (speed control), 26 Torque reference chain (torque control) or 28 Frequency reference chain (frequency control). Also check parameters 46.01 Speed scaling, 46.02 Frequency scaling and 46.03 Torque scaling. Check motor and motor cable (including phasing and delta/star connection). Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable. See chapter Electrical installation, section Checking the insulation of the assembly in the Hardware manual of the drive. Check there are no contactors opening and closing in motor cable. Check that the start-up data in parameter group 99 Motor data corresponds to the motor rating plate. Check that there are no power factor correction capacitors or surge absorbers in motor cable.
A2B3	Earth leakage	Drive has detected load unbalance typically due to earth fault in motor or motor cable.	Check there are no power factor correction capacitors or surge absorbers in motor cable. Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable. See chapter <i>Electrical installation</i> , section <i>Checking the insulation of the</i> <i>assembly</i> in the <i>Hardware manual</i> of the drive. If an earth fault is found, fix or change the motor cable and/or motor. If no earth fault cab le detected, contact your local ABB representative.

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
A2B4	Short circuit	Short-circuit in motor cable(s) or motor.	Check motor and motor cable for cabling errors.
	0001 Short circuit in the upper transistor of the U-phase.		Check motor and motor cable (including phasing and delta/star connection). Check for an earth fault in motor or motor
	0002	Short circuit in the lower transistor of the U-phase.	cables by measuring the insulation resistances of motor and motor cable.
	0004	Short circuit in the upper transistor of the V-phase.	See chapter <i>Electrical installation</i> , section <i>Checking the insulation of the</i> assembly in the Hardware manual of the
	0008	Short circuit in the lower transistor of the V-phase.	drive. Check there are no power factor
	0010	Short circuit in the upper transistor of the WU-phase.	correction capacitors or surge absorbers in motor cable.
	0020	Short circuit in the lower transistor of the W-phase.	For frames R6 to R8, check the auxiliary code.
	0040	DC capacitor short circuit.	
	0080	State feedback from output phases does not match control signals. For frames R6 and R7.	
A2BA	IGBT overload	Excessive IGBT junction to case temperature. This warning protects the IGBT(s) and can be activated by a short circuit in the motor cable.	Check motor cable. Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
A3A1	DC link overvoltage	Intermediate circuit DC voltage too high (when the drive is stopped).	Check the supply voltage setting (parameter 95.01 Supply voltage). Note that the wrong setting of the parameter
A3A2	DC link undervoltage	Intermediate circuit DC voltage too low (when the drive is stopped). See also section DC undervoltage (page 80).	may cause the motor to rush uncontrollably, or may overload the brake chopper or resistor. Check the supply voltage.
A3AA	DC not charged	The voltage of the intermediate DC circuit has not yet risen to operating level.	If the problem persists, contact your local ABB representative.
A490	Incorrect temperature sensor setup	Sensor type mismatch	Check the settings of temperature source parameters <i>35.11</i> and <i>35.21</i> against <i>91.21</i> and <i>91.25</i> .
A491	External temperature 1 (Editable message text)	Measured temperature 1 has exceeded warning limit.	Check the value of parameter 35.02 Measured temperature 1. Check the cooling of the motor (or other equipment whose temperature is being measured). Check the value of 35.13 Temperature 1 warning limit.

416 Fault tracing

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
A492	External temperature 2 (Editable message text)	Measured temperature 2 has exceeded warning limit.	Check the value of parameter 35.03 Measured temperature 2. Check the cooling of the motor (or other equipment whose temperature is being measured). Check the value of 35.23 Temperature 2 warning limit.
A4A0	Control board temperature.	Control board temperature is excessive. 1 – Sensor fault.	Check the sensor and change the control board.
A4A1	IGBT overtemperature	Estimated drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
A4A9	Cooling	Drive module temperature is excessive.	Check ambient temperature. If it exceeds 40%/104 °F (frames R4R8) or if it exceeds 50% /122 °F (frames R0R8), ensure that load current does not exceed derated load capacity of drive. See chapter <i>Technical data</i> , section <i>Derating</i> in the <i>Hardware manual</i> of the drive. Check drive module cooling air flow and fan operation. Check inside of cabinet and heatsink of drive module for dust pick-up. Clean whenever necessary.
A4B0	Excess temperature	Power unit module temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
A4B1	Excess temperature difference	High temperature difference between the IGBTs of different phases.	Check the motor cabling. Check cooling of drive module(s).
A4F6	IGBT temperature	Drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
A580	PU communication	Communication errors between drive control unit and power unit.	Check connections between drive control unit and power unit and value of parameter <i>95.04 Control board supply</i> .
A581	Fan	Cooling fan feedback missing.	Check the auxiliary code to identify the fan. Code 0 denotes main fan 1. Other codes (format XYZ): "X" specifies state code (1: ID run, 2: normal). "Y" = 0, "Z" specifies the index of the fan (1: Main fan 1, 2: Main fan 2, 3: Main fan 3). Check fan operation and connection. Replace fan if faulty.

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
A582	Auxiliary fan missing	An auxiliary cooling fan (connected to the fan connectors on the control board) is stuck or disconnected.	Check the auxiliary code. Check auxiliary fan(s) and connection(s). Replace faulty fan. Make sure the front cover of the drive is in place and tightened. If the commissioning of the drive requires that the cover is off, this warning will be generated even if the corresponding fault is defeated. See fault <i>5081 Auxiliary fan</i> <i>broken</i> (page <i>431</i>).
	0001	Auxiliary fan 1 missing.	
	0002	Auxiliary fan 2 missing.	
A590	Drive HW initialization.	Drive hardware setup is initializing. 1 - Initializing HW settings for the first time.	See auxiliary code.
A591	Drive HW initialization	Initialization of the drive hardware.	Check the auxiliary code. See actions for each code below.
	0000	Drive hardware setup is initializing.	Wait for the setup to initialize.
	0001	Initializing HW settings for the first time.	Wait for the setup to initialize.
A5A0	Safe torque off Programmable warning: 31.22 STO indication run/stop	Safe torque off function is active, ie safety circuit signal(s) connected to connector STO is lost.	Check safety circuit connections. For more information, chapter <i>The Safe</i> <i>torque off function</i> in the <i>Hardware</i> <i>manual</i> of the drive and description of parameter 31.22 STO <i>indication run/stop</i> (page 269). Check the value of parameter 95.04 <i>Control board supply</i> .
A5EA	Measurement circuit temperature	Problem with internal temperature measurement of the drive.	Check the auxiliary code (format XXXY YYZZ). "Y YY" specifies through which BCU control unit channel the fault was received ("0 00" with a ZCU control unit). "ZZ" specifies the location: With control program version 2.8x and later: 1: U-phase IGBT, 2: V-phase IGBT, 3: W-phase IGBT, 4: Power supply board, 5: Power unit xINT board, 6: Brake chopper, 7: Air inlet (TEMP3, X10), 8: du/dt filter (TEMP2, X7), 9: TEMP1 (X6). With control program version up to and including 2.7x: 1: U-phase IGBT, 2: V-phase IGBT, 3: W-phase IGBT, 4: Power unit INT board, 5: Brake chopper, 6: Air inlet, 7: Power supply board, 8: du/dt filter, FAh: Air in temp.
A5EB	PU board powerfail	Power unit power supply failure.	Contact your local ABB representative.

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
A5ED	Measurement circuit ADC	Measurement circuit fault.	Check the connections between the drive control unit and the power unit.
A5EE	Measurement circuit DFF	Measurement circuit fault.	Contact your local ABB representative.
A5EF	PU state feedback	State feedback from output phases does not match control signals.	Contact your local ABB representative.
A5F0	Charging feedback	Charging feedback signal missing.	Check the feedback signal coming from the charging system.
A5F1	Redundant measurement	Duplicated measurements are beyond limits.	Contact your local ABB representative.
A5F2	Overtemperature hw	Excessive hardware temperature.	Contact your local ABB representative.
A682	Flash erase speed	The flash memory (in the memory unit) has been erased too frequently, compromising the lifetime of the memory.	Avoid forcing unnecessary parameter saves by parameter 96.07 Parameter save manually or cyclic parameter writes (such as user logger triggering through parameters). Check the auxiliary code (format XYYY YZZZ). "X" specifies the source of warning (1: generic flash erase supervision). "ZZZ" specifies the flash subsector number that generated the warning.
A6A4	Motor nominal value	The motor parameters are set incorrectly.	Check the auxiliary code. See actions for each code below.
		The drive is not dimensioned correctly.	
	1	Slip frequency is too small.	Check the settings of the motor
	2	Synchronous and nominal speeds differ too much.	configuration parameters in groups 98 and 99. Check that the drive is sized correctly for
	3	Nominal speed is higher than synchronous speed with 1 pole pair.	the motor.
	4	Nominal current is outside limits	
	5	Nominal voltage is outside limits.	
	6	Nominal power is higher than apparent power.	
	7	Nominal power not consistent with nominal speed and torque.	
A6A5	No motor data	Parameters in group 99 have not been set.	Check that all the required parameters in group 99 have been set. Note: It is normal for this warning to appear during the start-up and continue until the motor data is entered.

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
A6A6	Voltage category unselected	The voltage category has not been defined.	Set voltage category in parameter 95.01 Supply voltage.
A6A7	System time not set	System time is not set.	
A6B0	User lock is open	The user lock is open, ie. user lock configuration parameters <i>96.10096.102</i> are visible.	Close the user lock by entering an invalid pass code in parameter 96.02 Pass code. See section User lock (page 96).
A6B1	User pass code not confirmed	A new user pass code has been entered in parameter 96.100 but not confirmed in 96.101.	Confirm the new pass code by entering the same code in 96.101. To cancel, close the user lock without confirming the new code. See section User lock (page 96).
A6D1	FBA A parameter conflict	The drive does not have a functionality requested by a PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups <i>50</i> <i>Fieldbus adapter (FBA).</i>
A6E5	AI parametrization	The current/voltage hardware setting of an analog input does not correspond to parameter settings.	Check the event log for an auxiliary code. The code identifies the analog input whose settings are in conflict. Adjust either the hardware setting (on the drive control unit) or parameter 12.15/12.25. Note: Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.
A6E6	ULC configuration	User load curve configuration error.	Check the auxiliary code (format XXXX ZZZZ). "ZZZZ" indicates the problem (see actions for each code below).
	0000	Speed points inconsistent.	Check that each speed point (parameters 37.1137.15) has a higher value than the previous point.
	0002	Underload point above overload point.	Check that each overload point (37.3137.35) has a higher value than
	0003	Overload point below underload point.	the corresponding underload point (37.2137.25).
AFFE	Override active	Override active warning.	Informative warning. See parameter 70.02 Override enable.
A780	Motor stall (Programmable warning: <i>31.24 Stall</i> <i>function</i>)	Motor is operating in stall region.	Check motor load, drive ratings and fault function parameters.
A783	Motor overload	Motor current is too high.	Check for overloaded motor Adjust the parameters used for the motor overload function. (<i>35.5135.53</i> , <i>35.55</i> , <i>35.56</i>).

	Warning / Aux. code		
Code (hex)	(aux code visible only on assistant control panel and drive composer)	Cause	What to do
A784	Motor disconnect	All three output phases are disconnected from motor.	 Check if parameter 95.26 enables the use of a motor disconnect switch. If not, check the following: All switches between drive and motor are closed. All cables between drive and motor are connected and secured. If no issue was detected and drive output was actually connected to motor, contact ABB.
A791	Brake resistor	Brake resistor fault.	Check brake resistor.
A792	Brake resistor wiring	Brake resistor short circuit or fault in brake chopper.	Check brake chopper and brake resistor connections.
A793	BR excess temperature	Brake resistor temperature has exceeded warning limit defined by parameter 43.12 Brake resistor warning limit.	Stop drive. Let resistor cool down. Check resistor overload protection function settings (parameter group 43 <i>Brake chopper</i>). Check warning limit setting, parameter 43.12 <i>Brake resistor warning limit.</i> Check that the resistor has been dimensioned correctly. Check that braking cycle meets allowed limits.
A794	BR data	Brake resistor data has not been given.	One or more of the resistor data settings (parameters 43.0843.10) is incorrect. The parameter is specified by the auxiliary code.
	0000 0001	Resistance value too low.	Check value of 43.10.
	0000 0002	Thermal time constant not given.	Check value of 43.08.
	0000 0003	Maximum continuous power not given.	Check value of 43.09.
A79C	BC IGBT excess temperature	Brake chopper IGBT temperature has exceeded internal warning limit.	Let chopper cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet. Check resistor overload protection function settings (parameters <i>43.0643.10</i>). Check minimum allowed resistor value for the chopper being used. Check that braking cycle meets allowed limits. Check that drive supply AC voltage is not excessive.
A7AB	Built in/Extension I/O configuration failure	The I/O built in/extension module is not connected to the device properly.	Make sure that the I/O built in/extension module is connected to the device.

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
A7AC	I/O Module internal error	Calibration data is not stored in the I/O module. Analog signals are not working with full accuracy.	Replace I/O module.
A7A1	Mechanical brake closing failed	Mechanical brake control warning.	Check mechanical brake connection. Check mechanical brake settings in parameter group 44 Mechanical brake control. Check that acknowledgment signal matches the actual status of the brake.
A7A2	Mechanical brake opening failed	Status of mechanical brake acknowledgment is not as expected during brake open.	Check mechanical brake connection. Check mechanical brake settings in parameter group 44 Mechanical brake control. Check that acknowledgment signal matches the actual status of brake.
A7A5	Mechanical brake opening not allowed	Open conditions of mechanical brake cannot be fulfilled.	Check mechanical brake settings in parameter group 44 Mechanical brake control. Check that the acknowledgment signal (if used) matches the actual status of the brake.
A7C1	FBA A communication Programmable warning: 50.02 FBA A comm loss func	Cyclical communication between drive and fieldbus adapter module A or between PLC and fieldbus adapter module A is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter groups 50 <i>Fieldbus adapter (FBA), 51 FBA A</i> <i>settings, 52 FBA A data in</i> and 53 <i>FBA A</i> <i>data out.</i> Check cable connections. Check if communication master is able to communicate.
A7CE	EFB comm loss Programmable warning: 58.14 Communication loss action	Communication break in embedded fieldbus (EFB) communication.	Check the status of the fieldbus master (online/offline/error etc.). Check cable connections to the EIA-485/X5 terminals 29, 30 and 31 on the control unit.
A7EE	Panel loss Programmable warning: 49.05 Communication loss action	Control panel or PC tool selected as active control location for drive has ceased communicating.	Check PC tool or control panel connection. Check control panel connector. Check mounting platform if being used. Disconnect and reconnect the control panel.
A88F	Cooling fan	Maintenance timer limit exceeded.	Replace the drive cooling fan. Parameter 05.04 Fan on-time counter shows the running time of the cooling fan.

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
A8A0	Al supervision	Analog signal is beyond limits.	Check the signal level, input wiring, and the defined limits.
	0001 – Al1 less minim 0002 – Al1 greater ma		2 less minimum 2 greater maximum
A8A1	RO life warning	The relay has changed states more than the recommended number of times.	Change the control board or stop using the relay output.
	0001	Relay output 1	Change the control board or stop using relay output 1.
	0002	Relay output 2	Change the control board or stop using relay output 2.
	0003	Relay output 3	Change the control board or stop using relay output 3.
A8A2	RO toggle warning	The relay output is changing states faster than recommended, eg. if a fast changing frequency signal is connected to it. The relay lifetime will be exceeded shortly.	Replace the signal connected to the relay output source with a less frequently changing signal.
	0001	Relay output 1	Select a different signal with parameter <i>10.24 RO1 source</i> .
	0002	Relay output 2	Select a different signal with parameter <i>10.27 RO2 source</i> .
	0003	Relay output 3	Select a different signal with parameter <i>10.30 RO3 source</i> .
A8B0	Signal supervision 1 (Editable message text) Programmable warning: 32.06 Supervision 1 action	Warning generated by the signal supervision function 1.	Check the source of the warning (parameter 32.07 Supervision 1 signal).
A8B1	Signal supervision 2 (Editable message text) Programmable warning: 32.16 Supervision 2 action	Warning generated by the signal supervision function 2.	Check the source of the warning (parameter 32.17 Supervision 2 signal).
A8B2	Signal supervision 3 (Editable message text) Programmable warning: 32.26 Supervision 3 action	Warning generated by the signal supervision function 3.	Check the source of the warning (parameter 32.27 Supervision 3 signal).
A8B3	Signal supervision 4 (Editable message text) Programmable warning: 32.36 Supervision 4 action	Warning generated by the signal supervision function 4.	Check the source of the warning (parameter 32.37 Supervision 4 signal).
A8B4	Signal supervision 5 (Editable message text) Programmable warning: 32.46 Supervision 5 action	Warning generated by the signal supervision function 5.	Check the source of the warning (parameter <i>32.47 Supervision 5 signal</i>).
A8B5	Signal supervision 6 (Editable message text) Programmable warning: 32.56 Supervision 6 action	Warning generated by the signal supervision function 6.	Check the source of the warning (parameter 32.57 Supervision 6 signal).

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
A8B6	Current limit	Motor actual current exceeded the limit defined in parameter <i>30.17 Maximum current</i> .	Reduce the motor load. Check for any jam or stall in motor.
A8BE	ULC overload warning	User load curve: Signal has been too long over the overload curve.	See parameter 37.03 ULC overload actions.
	001	Overload occurred between speed point 37.11 ULC speed table point 1 and 37.12 ULC speed table point 2.	Check the load.
	002	Overload occurred between speed point 37.12 ULC speed table point 2 and 37.13 ULC speed table point 3.	Check the load.
	003	Overload occurred between speed point 37.13 ULC speed table point 3 and 37.14 ULC speed table point 4.	Check the load.
	004	Overload occurred between speed point 37.14 ULC speed table point 4 and 37.15 ULC speed table point 5.	Check the load.
A8BF	ULC underload warning	User load curve: Signal has been too long under the underload curve.	See parameter 37.04 ULC underload actions.
	001	Underload occurred between speed point 37.11 ULC speed table point 1 and 37.12 ULC speed table point 2.	Check the load.
	002	Underload occurred between speed point 37.12 ULC speed table point 2 and 37.13 ULC speed table point 3.	Check the load.
	003	Underload occurred between speed point 37.13 ULC speed table point 3 and 37.14 ULC speed table point 4.	Check the load.
	004	Underload occurred between speed point 37.14 ULC speed table point 4 and 37.15 ULC speed table point 5.	Check the load.
A8C0	ULC invalid speed table	User load curve: X-axis points (speed) are not valid.	Check that points fulfill conditions. See parameter 37.11 ULC speed table point 1.
A8C5	ULC invalid underload table	User load curve: Underload curve points are not valid.	Check that points fulfill conditions. See parameter 37.21 ULC underload point 1.
A8C6	ULC invalid overload table	User load curve: Overload curve points are not valid.	Check that points fulfill conditions. See parameter 37.31 ULC overload point 1.

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
A981	External warning 1 (Editable message text) Programmable warning: 31.01 External event 1 source 31.02 External event 1 type	Fault in external device 1.	Check the external device. Check setting of parameter 31.01 External event 1 source.
A982	External warning 2 (Editable message text) Programmable warning: 31.03 External event 2 source 31.04 External event 2 type	Fault in external device 2.	Check the external device. Check setting of parameter 31.03 <i>External event 2 source</i> .
A983	External warning 3 (Editable message text) Programmable warning: 31.05 External event 3 source 31.06 External event 3 type	Fault in external device 3.	Check the external device. Check setting of parameter <i>31.05</i> <i>External event 3 source</i> .
A984	External warning 4 (Editable message text) Programmable warning: 31.07 External event 4 source 31.08 External event 4 type	Fault in external device 4.	Check the external device. Check setting of parameter 31.07 External event 4 source.
A985	External warning 5 (Editable message text) Programmable warning: 31.09 External event 5 source 31.10 External event 5 type	Fault in external device 5.	Check the external device. Check setting of parameter 31.09 External event 5 source.
A991	Safe motor temperature	You have configured a season which starts before the previous season.	Configure the seasons with increasing start dates, see parameters 34.60 Season 1 start date34.63 Season 4 start date.
AF88	Season configuration warning	You have configured a season which starts before the previous season.	Configure the seasons with increasing start dates, see parameters 34.60 Season 1 start date34.63 Season 4 start date.
AF90	Speed controller autotuning	The speed controller autotune routine did not complete successfully.	Check the auxiliary code (format XXXX YYYY). "YYYY" indicates the problem (see actions for each code below).
	0000	The drive was stopped before the autotune routine finished.	Repeat autotune until successful.
	0001	The drive was started but was not ready to follow the autotune command.	Make sure the prerequisites of the autotune run are fulfilled. See section <i>Before activating the autotune routine</i> (page <i>46</i>).

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer) 0002	Cause Required torque reference	What to do Decrease torque step (parameter 25.38)
		could not be reached before the drive reached maximum speed.	or increase speed step (25.39).
	0003	Motor could not accelerate/decelerate to maximum/minimum speed.	Increase torque step (parameter 25.38) or decrease speed step (25.39).
	0005	Motor could not decelerate with full autotune torque.	Decrease torque step (parameter 25.38) or speed step (25.39).
AFAA	Autoreset	A fault is about to be autoreset.	Informative warning. See the settings in parameter group <i>31 Fault functions</i> .
AFE1	Emergency stop (off2)	Drive has received an emergency stop (mode selection off2) command.	Check that it is safe to continue operation. Then return emergency stop push button to normal position. Restart drive.
AFE2	Emergency stop (off1 or off3)	Drive has received an emergency stop (mode selection off1 or off3) command.	If the emergency stop was unintentional, check the source selected by parameter 21.05 Emergency stop source.
AFE9	Start delay	The start delay is active and the drive will start the motor after a predefined delay.	Informative warning. See parameter 21.22 Start delay.
AFF5	Override new start required	The Safe torque off function was active and has been reset while in Override.	A new start signal is required to start the drive again.
AFF8	Motor heating active	Pre-heating is being performed	Informative warning. Motor pre-heating is active. Current specified by parameter 21.16 Pre-heating current is being passed through the motor.
AFEB	Run enable missing	No run enable signal is received.	Check setting of parameter 20.12 Run enable 1 source. Switch signal on (e.g. in the fieldbus Control Word) or check wiring of selected source.
AFEC	External power signal missing	95.04 Control board supply is set to External 24V but no voltage is connected to the control unit.	Check the external 24 V DC power supply to the control unit, or change the setting of parameter <i>95.04</i> .
AFED	Enable to rotate	Signal to rotate has not been received within a fixed time delay of 120 s.	Switch enable to rotate signal on (eg. in digital inputs). Check the setting of (and source selected by) parameter 20.22 Enable to rotate.
AFF6	Identification run	Motor ID run will occur at next start.	Informative warning.
B5F6	Identification run	Motor ID run completed successfully.	Informative warning.

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
B5A0	STO event Programmable event: 31.22 STO indication run/stop	Safe torque off function is active, ie. safety circuit signal(s) connected to connector STO is lost.	Check safety circuit connections. For more information, see chapter <i>The Safe</i> <i>torque off function</i> in the <i>Hardware</i> <i>manual</i> of the drive and description of parameter 31.22 STO <i>indication run/stop</i> (page 269).
D501	No more available PFC motors	No more PFC motors can be started because they can be interlocked or in the Hand mode.	Check that there are no interlocked PFC motors, see parameters: 76.8176.84. If all motors are in use, the PFC system is not adequately dimensioned to handle the demand.
D502	All motors interlocked	All the motors in the PFC system are interlocked.	Check that there are no interlocked PFC motors, see parameters 76.8176.84.
D503	VSD controlled PFC motor interlocked	The motor connected to the drive is interlocked (unavailable).	Motor connected to the drive is interlocked and thus cannot be started. Remove the corresponding interlock to start the drive controlled PFC motor. See parameters 76.8176.84.
FA90	STO diagnostics failure	The software is not working properly.	Restart the control unit.

Fault messages

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
1080	Backup/Restore timeout	Panel or PC tool has failed to communicate with the drive when backup was being made or restored.	Request backup or restore again.
1081	Rating ID fault	Drive software is not able to read the rating ID of the drive.	Reset the fault to make the drive try to reread the rating ID. If the fault reappears, cycle the power to the drive. You may have to be repeat this. If the fault persists, contact your local ABB representative.
2281	Calibration	Measured offset of output phase current measurement or difference between output phase U2 and W2 current measurement is too great (the values are updated during current calibration).	Try performing the current calibration again. If the fault persists, contact your local ABB representative.

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
2310	Overcurrent	Output current has exceeded internal fault limit. In addition to an actual overcurrent situation, this fault may also be caused by an earth fault or supply phase loss.	Check the auxiliary code (format XXXYYYZZ): "ZZ" indicates the overcurrent type and phase that triggered the fault: bit 7 =1 indicates SW overcurrent bit 0: Phase U bit 1: Phase V bit 2: Phase W For example: Aux code 0x83 indicates SW overcurrent of phase U and V. If there is no aux code, this indicates that hardware overcurrent is triggered. Check motor load. Check acceleration times in parameter group 23 Speed reference ramp (speed control), 26 Torque reference chain (torque control) or 28 Frequency reference chain (frequency control). Also check parameters 46.01 Speed scaling, 46.02 Frequency scaling and 46.03 Torque scaling. Check there are no contactors opening and closing in motor cable (including phasing and delta/star connection). Check there are no power factor correction capacitors or surge absorbers in motor cable. Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable. See chapter Electrical installation, section Checking the insulation of the assembly in the Hardware manual of the drive.
2330	Earth leakage	Drive has detected load unbalance typically due to earth fault in motor or motor cable.	Check there are no power factor correction capacitors or surge absorbers in motor cable. heck for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable. Try running the motor in scalar control mode if allowed. (See parameter 99.04 <i>Motor control mode.</i>) If no earth fault can be detected, contact your local ABB representative.

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
2340	Short circuit	Short-circuit in motor cable(s) or motor	Check motor and motor cable for cabling errors. Check there are no power factor
	0001	Short circuit in the upper transistor of the U-phase.	correction capacitors or surge absorbers in motor cable. For frames R6 to R8, check the auxiliary
	0002	Short circuit in the lower transistor of the U-phase.	code.
	0004	Short circuit in the upper transistor of the V-phase.	
	0008	Short circuit in the lower transistor of the V-phase.	
	0010	Short circuit in the upper transistor of the W-phase.	
	0020	Short circuit in the lower transistor of the W-phase.	
	0040	DC capacitor short circuit.	
	0080	State feedback from output phases does not match control signals. For frames R6 and R7.	
2381	IGBT overload	Excessive IGBT junction to case temperature. This fault protects the IGBT(s) and can be activated by a short circuit in the motor cable.	Check motor cable. Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
2392	BU earth leakage	Total earth leakage of inverter modules is excessive.	Check there are no power factor correction capacitors or surge absorbers in motor cable. Measure insulation resistances of motor cables and motor. Contact your local ABB representative.
3130	Input phase loss Programmable fault: 31.21 Supply phase loss	Intermediate circuit DC voltage is oscillating due to missing input power line phase or blown fuse.	Check input power line fuses. Check for loose power cable connections. Check for input power supply imbalance.
3181	Wiring or earth fault Programmable fault: 31.23 Wiring or earth fault	Incorrect input power and motor cable connection (ie. input power cable is connected to drive motor connection).	Check input power connections.

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
3210	DC link overvoltage	Excessive intermediate circuit DC voltage.	Check that overvoltage control is on (parameter 30.30 Overvoltage control). Check that the supply voltage matches the nominal input voltage of the drive. Check the supply line for static or transient overvoltage. Check brake chopper and resistor (if present). Check deceleration time. Use coast-to-stop function (if applicable). Retrofit drive with brake chopper and brake resistor. Check that the brake resistor is dimensioned properly and the resistance is between acceptable range for the drive.
3220	DC link undervoltage	Intermediate circuit DC voltage is not sufficient because of a missing supply phase, blown fuse or fault in the rectifier bridge. See also section <i>DC</i> undervoltage (page 80).	Check supply cabling, fuses and switchgear.
3291	BU DC link difference	Difference in DC voltages between parallel-connected inverter modules.	Check the auxiliary code (format XXXY YYZZ). "XXX" specifies the source of the first error (see "YYY"). "YYY" specifies the module through which BCU control unit channel the fault was received (1: Channel 1, 2: Channel 2, 4: Channel 3, 8: Channel 4,, 800: Channel 12).
3381	Output phase loss Programmable fault: 31.19 Motor phase loss	Motor circuit fault due to missing motor connection (any of the three phases not connected). In scalar control mode, the drive detects fault only when the output frequency is above 10% of the motor nominal frequency.	Connect motor cable. If the drive is in scalar mode and nominal current of the motor is less than 1/6 of the nominal output current of the drive, set parameter <i>31.19 Motor phase loss</i> to <i>No</i> <i>action</i> .
4110	Control board temperature	Control board temperature is too high.	Check proper cooling of the drive. Check the auxiliary cooling fan.
4210	IGBT overtemperature	Estimated drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.

	Fault / Aux. code (aux		
Code (hex)	code visible only on assistant control panel and drive composer)	Cause	What to do
4290	Cooling	Drive module temperature is excessive.	Check ambient temperature. If it exceeds 40%/104 °F (frames R4R8) or if it exceeds 50% /122 °F (frames R0R8), ensure that load current does not exceed derated load capacity of drive. See chapter <i>Technical data</i> , section <i>Derating</i> in the <i>Hardware manual</i> of the drive. Check drive module cooling air flow and fan operation. Check inside of cabinet and heatsink of drive module for dust pick-up. Clean whenever necessary.
42F1	IGBT temperature	Drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
4310	Excess temperature	Power unit module temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
4380	Excess temperature difference	High temperature difference between the IGBTs of different phases.	Check the motor cabling. Check cooling of drive module(s).
4981	External temperature 1	Measured temperature 1 has exceeded fault limit.	Check the value of parameter 35.02 Measured temperature 1. Check the cooling of the motor (or other equipment whose temperature is being measured).
4982	External temperature 2	Measured temperature 2 has exceeded fault limit.	Check the value of parameter 35.03 Measured temperature 2. Check the cooling of the motor (or other equipment whose temperature is being measured).
4991	Safe motor temperature	 The CPTC-02 module indicates overtemperature: motor temperature is too high, or the thermistor is in shortcircuit. 	Check the cooling of the motor. Check the motor load and drive ratings. Check the wiring of the temperature sensor. Repair wiring if faulty. Measure the resistance of the sensor. Replace the sensor if faulty.
5080	Fan	Cooling fan is stuck or disconnected.	See A581 Fan (page 416).
5081	Auxiliary fan broken	An auxiliary cooling fan is stuck or disconnected.	Check auxiliary fan(s) and connection(s). Replace fan if faulty.
	0001	Auxiliary fan 1 broken.	
	0002	Auxiliary fan 2 broken.	
5089	SMT circuit malfunction	Safe motor temperature fault is generated and STO event/fault/warning is not generated.	Check connection between the relay output of the module and the STO terminal.

	Fault / Aux. code (aux		
Code (hex)	code visible only on assistant control panel and drive composer)	Cause	What to do
5090	STO hardware failure	STO hardware diagnostics has detected hardware failure.	Contact your local ABB representative, quoting the auxiliary code. The code contains location information, especially with parallel-connected inverter modules. When converted into a 32-bit binary number, the bits of the code indicate the following: 3128: Number of faulty inverter module (011 decimal). 1111: STO_ACT states of control unit and inverter modules in conflict 27: STO_ACT state of inverter modules 26: STO_ACT state of control unit 25: STO1 of control unit 24: STO2 of control unit 2312: STO1 of inverter modules 121 (Bits of non-existing modules set to 1) 110: STO2 of inverter modules 121 (Bits of non-existing modules set to 1)
5091	Safe torque off Programmable fault: 31.22 STO indication run/stop	Safe torque off function is active, ie. safety circuit signal(s) connected to connector STO is broken during start or run.	Check safety circuit connections. For more information, see chapter <i>The Safe</i> <i>torque off function</i> in the <i>Hardware</i> <i>manual</i> of the drive and description of parameter 31.22 STO indication run/stop (page 269). Check the value of parameter 95.04 <i>Control board supply</i> .
5092	PU logic error	Power unit memory has cleared.	Cycle the power to the drive. If the control unit is externally powered, also reboot the control unit (using parameter 96.08 Control board boot) or by cycling its power. If the problem persists, contact your local ABB representative.
5093	Rating ID mismatch	The hardware of the drive does not match the information stored in the memory. This may occur eg. after a firmware update.	Cycle the power to the drive. You may have to be repeat this.
5094	Measurement circuit temperature	Problem with internal temperature measurement of the drive.	See A5EA Measurement circuit temperature (page 417).
5095	Redundant measurement	Duplicated measurements are beyond limits.	Contact ABB.
5096	Overtemperature hw	Excessive hardware temperature.	Contact your local ABB representative.
5098	I/O communication loss	Communication failure to standard I/O.	Try resetting the fault or cycle the power to the drive.
5681	PU communication	Communication errors detected between the drive control unit and the power unit.	Check the connection between the drive control unit and the power unit. Check the value of parameter 95.04 <i>Control board supply</i> .

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
5682	Power unit lost	Connection between the drive control unit and the power unit is lost.	Check the connection between the control unit and the power unit.
5690	PU communication internal	Internal communication error.	Contact your local ABB representative.
5691	Measurement circuit ADC	Measurement circuit fault.	If the control unit is externally powered, check the setting of parameter 95.04 <i>Control board supply</i> . If the problem persists, contact your local ABB representative, quoting the auxiliary code.
5692	PU board powerfail	Power unit power supply failure.	Check the auxiliary code (format ZZZY YYXX). "YY Y" specifies the affected inverter module (0C, always 0 for ZCU control units). "XX" specifies the affected power supply (1: Power supply 1, 2: Power supply 2, 3: both supplies).
5693	Measurement circuit DFF	Measurement circuit fault.	Contact your local ABB representative, quoting the auxiliary code.
5695	Reduced run	Configured power units not found.	Configure the power units.
5697	Charging feedback	Charging feedback signal missing.	Check the feedback signal coming from the charging system
5698	Unknown PU fault	The power unit logic generated a fault which is not known by software.	Check the logic and software compatibility.
50A0	Fan	Cooling fan stuck or disconnected.	Check fan operation and connection. Replace fan if faulty.
6181	FPGA version incompatible	Firmware and FPGA versions are incompatible.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative
6306	FBAA mapping file	Fieldbus adapter A mapping file read error.	Contact your local ABB representative.
6481	Task overload	Internal fault.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative
6487	Stack overflow	Internal fault.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
64A3	Application loading	Application file incompatible or corrupted.	Check the auxiliary code. See actions for each code below.
	8006	Not enough memory for the application.	Reduce the size of the application. Reduce the number of parameter mappings. See the drive-specific log generated by Automation Builder.

	Fault / Aux. code (aux				
Code (hex)	code visible only on assistant control panel and drive composer)	Cause		What to do	
	8007	The application contains the wrong system library version.		Update the system library or reinstall Automation Builder. See the drive-specific log generated by Automation Builder.	
	8008	The application is em	npty.	In Automation Builder, give a "Clean" command and reload the application.	
	8009	The application conta invalid tasks.	ains	In Automation Builder, check application task configuration, give a "Clean all" command, and reload the application.	
	800A	The application conta unknown target (syst library function.		Update the system library or reinstall Automation Builder. See the drive-specific log generated by Automation Builder.	
64A1	Internal file load	File read error.		Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.	
64A4	Rating ID fault	Rating ID load error.		Contact ABB.	
64A6	Adaptive program	Fault in adaptive prog	gram.	Check the fault code extension.	
64B1	Internal SSW fault	A fatal error in the po phase of System Sof (SSW).		SSW runs in partial functionality mode.	
				zing WoRm volumes failed	
	2 – Creating system tasks failed 3 – Initializing file system failed			ing FPGA configuration failed ing application program failed	
	4 – Checking file syste		7 – Loadir		
64B2	User set fault	Loading of user para failed because • requested set doe • set is not compatit control program • drive was switched during loading.	s not exist ole with	Ensure that a valid user parameter set exists. Reload if uncertain.	
64B3	Macro parameterization error	Macro parameterization failed, eg. Parameter default value that cannot be changed has been attempted to write.			
64E1	Kernel overload	Operating system error.		Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative	
6581	Parameter system	Parameter load or save failed.		Try forcing a save using parameter 96.07 <i>Parameter save manually</i> . Retry.	
6591	Backup/Restore timeout	During backup creating or restoring operation a panel or PC-tool has failed to communicate with the drive as part of this operation.		Check panel or PC-tool communication and if it is still in backup or restore state.	

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
65A1	FBA A parameter conflict	The drive does not have a functionality requested by PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups 50 <i>Fieldbus adapter (FBA)</i> and 51 <i>FBA A</i> <i>settings</i> .
6681	EFB comm loss Programmable fault: 58.14 Communication loss action	Communication break in embedded fieldbus (EFB) communication.	Check the status of the fieldbus master (online/offline/error etc.). Check cable connections to the EIA-485/X5 terminals 29, 30 and 31 on the control unit.
6682	EFB config file	Embedded fieldbus (EFB) configuration file could not be read.	Contact your local ABB representative.
6683	EFB invalid parameterization	Embedded fieldbus (EFB) parameter settings inconsistent or not compatible with selected protocol.	Check the settings in parameter group 58 Embedded fieldbus.
6684	EFB load fault	Embedded fieldbus (EFB) protocol firmware could not be loaded.	Contact your local ABB representative.
		Version mismatch between EFB protocol firmware and drive firmware.	
6685	EFB fault 2	Fault reserved for the EFB protocol application.	Check the documentation of the protocol.
6686	EFB fault 3	Fault reserved for the EFB protocol application.	Check the documentation of the protocol.
6882	Text 32-bit table overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
6885	Text file overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
7081	Control panel loss Programmable fault: 49.05 Communication loss action	Control panel or PC tool selected as active control location for drive has ceased communicating.	Check PC tool or control panel connection. Check control panel connector. Disconnect and reconnect the control panel.
7082	I/O module comm loss	Communication between I/O module and drive is not working properly.	Check the I/O module installation.
7085	Incompatible option module	Fieldbus option module not supported.	Replace the module with a supported type.
7086	I/O module AI overvoltage	Overvoltage detected in AI. AI is changed to voltage mode from mA mode. AI will return automatically back to mA mode when the AI signal level is within acceptable limits.	Check AI signal levels.
7087	I/O module configuration	I/O module configuration not supported or illegal.	Check the auxiliary code. See actions for each code below.

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
	001	S1/S2 DIP switch position on BIO-01 has changed after power up.	Reboot control unit either by cycling the power or through parameter 96.08 <i>Control board boot</i> to activate new DIP switch position.
	002	S1/S2 DIP switch positions are such that DO1 would be in both S1 and S2 pins. This is not a supported combination.	Change S1/S2 DIP switch positions to a supported combination, see parameter 05.99 BIO-01 DIP switch status.
71A2	Mechanical brake closing failed	Mechanical brake control fault. Activated e.g., if brake acknowledgment is not as expected during brake closing.	Check mechanical brake connection. Check mechanical brake settings in parameter group 44 Mechanical brake control. Check that the acknowledgment signal matches the actual status of the brake.
71A5	Mechanical brake opening not allowed	Open conditions of mechanical brake cannot be fulfilled.	Check mechanical brake settings in parameter group 44 Mechanical brake control. Check that the acknowledgment signal (if used) matches the actual status of the brake.
7100	Excitation current	Excitation current feedback low or missing	Contact your local ABB representative.
7121	Motor stall Programmable fault: 31.24 Stall function	Motor is operating in stall region because of e.g. excessive load or insufficient motor power.	Check motor load and drive ratings. Check fault function parameters.
7122	Motor overload	Motor current is too high.	Check for overloaded motor Adjust the parameters used for the motor overload function. (35.5135.53, 35.55, 35.56)
7181	Brake resistor	Brake resistor broken or not connected.	Check that a brake resistor has been connected. Check the condition of the brake resistor. Check the dimensioning of the brake resistor.
7183	BR excess temperature	Brake resistor temperature has exceeded fault limit defined by parameter 43.11 Brake resistor fault limit.	Stop drive. Let resistor cool down. Check resistor overload protection function settings (parameter group 43 <i>Brake chopper</i>). Check fault limit setting, parameter 43.11 <i>Brake resistor fault limit</i> . Check that braking cycle meets allowed limits.
7184	Brake resistor wiring	Brake resistor short circuit or brake chopper control fault.	Check brake chopper and brake resistor connection. Ensure brake resistor is not damaged.

	Fault / Aux. code (aux		
Code (hex)	code visible only on assistant control panel and drive composer)	Cause	What to do
7191	BC short circuit	Short circuit in brake chopper IGBT.	Ensure brake resistor is connected and not damaged. Check the electrical specifications of the brake resistor against chapter <i>Resistor</i> <i>braking</i> in the <i>Hardware manual</i> of the drive. Replace brake chopper (if replaceable).
7192	BC IGBT excess temperature	Brake chopper IGBT temperature has exceeded internal fault limit.	Let chopper cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check resistor overload protection function settings (parameter group <i>43</i> <i>Brake chopper</i>). Check that braking cycle meets allowed limits. Check that drive supply AC voltage is not excessive.
71A3	Mech brake opening failed	Mechanical brake control is faulty. Brake open acknowledgment is not matching the actual status.	Check connections, brake settings and brake acknowledgment signal.
7310	Overspeed	Motor is turning faster than highest allowed speed due to incorrectly set minimum/maximum speed, insufficient braking torque or changes in load when using torque reference.	Check minimum/maximum speed settings, parameters 30.11 Minimum speed and 30.12 Maximum speed. Check adequacy of motor braking torque. Check applicability of torque control. Check need for brake chopper and resistor(s).
73B0	Emergency ramp failed	Emergency stop did not finish within expected time.	Check the predefined ramp times (23.1123.15, 23.1223.13 for mode Off1, 23.23 for mode Off3).
73F0	Overfrequency	Maximum allowed output frequency exceeded.	Check the auxiliary code.
	00FA	Motor is turning faster than the highest allowed frequency due to incorrectly set minimum/maximum frequency or the motor rushes because of too high supply voltage or incorrect supply voltage selection in parameter 95.01 Supply voltage.	Check minimum/maximum frequency settings, parameters 30.13 Minimum frequency and 30.14 Maximum frequency. Check used supply voltage and voltage selection parameter 95.01 Supply voltage.
	Other	-	Contact your local ABB representative, quoting the auxiliary code.

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
7510	FBA A communication Programmable fault: 50.02 FBA A comm loss func	Cyclical communication between drive and fieldbus adapter module A or between PLC and fieldbus adapter module A is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter groups 50 <i>Fieldbus adapter (FBA)</i> , 51 <i>FBA A</i> <i>settings</i> , 52 <i>FBA A data in</i> and 53 <i>FBA A</i> <i>data out.</i> Check cable connections. Check if communication master is able to communicate.
8000	Unicos system error	System fault.	Power cycle.
8001	ULC underload fault	User load curve: Signal has been too long under the underload curve.	See parameter 37.04 ULC underload actions.
	001	Underload occurred between speed point 37.11 ULC speed table point 1 and 37.12 ULC speed table point 2.	Check the load.
	002	Underload occurred between speed point 37.12 ULC speed table point 2 and 37.13 ULC speed table point 3.	Check the load.
	003	Underload occurred between speed point 37.13 ULC speed table point 3 and 37.14 ULC speed table point 4.	Check the load.
	004	Underload occurred between speed point 37.14 ULC speed table point 4 and 37.15 ULC speed table point 5.	Check the load.
8002	ULC overload fault	User load curve: Signal has been too long over the overload curve.	See parameter 37.03 ULC overload actions.
	001	Overload occurred between speed point 37.11 ULC speed table point 1 and 37.12 ULC speed table point 2.	Check the load.
	002	Overload occurred between speed point 37.12 ULC speed table point 2 and 37.13 ULC speed table point 3.	Check the load.
	003	Overload occurred between speed point 37.13 ULC speed table point 3 and 37.14 ULC speed table point 4.	Check the load.
	004	Overload occurred between speed point 37.14 ULC speed table point 4 and 37.15 ULC speed table point 5.	Check the load.
8009	Current limit	Motor actual current exceeded the limit defined in parameter <i>30.17 Maximum current</i> .	Reduce the motor load. Check for any jam or stall in motor. See parameter <i>30.17 Maximum current</i> .

	Fault / Aux. code (aux		
Code (hex)	code visible only on assistant control panel and drive composer)	Cause	What to do
80A0	Al supervision Programmable fault: 12.03 Al supervision function	An analog signal is outside the limits specified for the analog input	Check signal level at the analog input. Check the auxiliary code. Check the wiring connected to the input. Check the minimum and maximum limits of the input in parameter group <i>12</i> <i>Standard Al.</i>
	1 – Al1LessMIN		3 – AI2LessMIN
	2 – Al1GreaterMAX		4 – Al2GreaterMAX
80B0	Signal supervision 1 (Editable message text) Programmable fault: 32.06 Supervision 1 action	Fault generated by the signal supervision function 1.	Check the source of the fault (parameter 32.07 Supervision 1 signal).
80B1	Signal supervision 2 (Editable message text) Programmable fault: 32.16 Supervision 2 action	Fault generated by the signal supervision function 2.	Check the source of the fault (parameter 32.17 Supervision 2 signal).
80B2	Signal supervision 3 (Editable message text) Programmable fault: 32.26 Supervision 3 action	Fault generated by the signal supervision function 3.	Check the source of the fault (parameter 32.27 Supervision 3 signal).
80B3	Signal supervision 4 (Editable message text) Programmable fault: 32.36 Supervision 4 action	Fault generated by the signal supervision function 4.	Check the source of the fault (parameter 32.37 Supervision 4 signal).
80B4	Signal supervision 5 (Editable message text) Programmable fault: 32.46 Supervision 5 action	Fault generated by the signal supervision function 5.	Check the source of the fault (parameter 32.47 Supervision 5 signal).
80B5	Signal supervision 6 (Editable message text) Programmable fault: 32.56 Supervision 6 action	Fault generated by the signal supervision function 6.	Check the source of the fault (parameter 32.57 Supervision 6 signal).
9081	External fault 1 (Editable message text) Programmable fault: 31.01 External event 1 source 31.02 External event 1 type	Fault in external device 1.	Check the external device. Check setting of parameter <i>31.01</i> <i>External event 1 source</i> .
9082	External fault 2 (Editable message text) Programmable fault: 31.03 External event 2 source 31.04 External event 2 type	Fault in external device 2.	Check the external device. Check setting of parameter <i>31.03</i> <i>External event 2 source</i> .
9083	External fault 3 (Editable message text) Programmable fault: 31.05 External event 3 source 31.06 External event 3 type	Fault in external device 3.	Check the external device. Check setting of parameter <i>31.05</i> <i>External event 3 source</i> .

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
9084	External fault 4 (Editable message text) Programmable fault: 31.07 External event 4 source 31.08 External event 4 type	Fault in external device 4.	Check the external device. Check setting of parameter <i>31.07</i> <i>External event 4 source</i> .
9085	External fault 5 (Editable message text) Programmable fault: 31.09 External event 5 source 31.10 External event 5 type	Fault in external device 5.	Check the external device. Check setting of parameter <i>31.09</i> <i>External event 5 source</i> .
A2A1	Current calibration	Current offset and gain measurement calibration will occur at next start.	Informative warning. (See parameter 99.13 ID run requested).
FA81	Safe torque off 1	Safe torque off function is active, ie. STO circuit 1 is broken.	Check safety circuit connections. For more information, see chapter <i>The Safe</i> <i>torque off function</i> in the <i>Hardware</i>
FA82	Safe torque off 2	Safe torque off function is active, ie. STO circuit 2 is broken.	manual of the drive and description of parameter 31.22 STO indication run/stop (page 269). Check the value of parameter 95.04 Control board supply.
FF61	ID run	Motor ID run was not completed successfully.	Check the nominal motor values in parameter group <i>99 Motor data</i> . Check that no external control system is connected to the drive. Cycle the power to the drive (and its control unit, if powered separately). Check that no operation limits prevent the completion of the ID run. Restore parameters to default settings and try again. Check that the motor shaft is not locked.
	0001	Maximum current limit too low.	Check settings of parameters 99.06 Motor nominal current and 30.17 Maximum current. Make sure that 30.17 > 99.06. Check that the drive is dimensioned correctly according to the motor.
	0002	Maximum speed limit or calculated field weakening point too low.	Check settings of parameters • 30.11 Minimum speed • 30.12 Maximum speed • 99.07 Motor nominal voltage • 99.08 Motor nominal frequency • 99.09 Motor nominal speed. Make sure that • $30.12 > (0.55 \times 99.09) >$ (0.50 × synchronous speed) • $30.11 \le 0$, and • supply voltage $\ge (0.66 \times 99.07)$.

	Fault / Aux. code (aux		
Code (hex)	code visible only on assistant control panel and drive composer)	Cause	What to do
	0003	Maximum torque limit too low.	Check settings of parameter 99.12 Motor nominal torque, and the torque limits in group 30 Limits. Make sure that the maximum torque limit in force is greater than 100%.
	0004	Current measurement calibration did not finish within reasonable time	Contact your local ABB representative.
	00050008	Internal error.	Contact your local ABB representative.
	0009	(Asynchronous motors only) Acceleration did not finish within reasonable time.	Contact your local ABB representative.
	A000	(Asynchronous motors only) Deceleration did not finish within reasonable time.	Contact your local ABB representative.
	000B	(Asynchronous motors only) Speed dropped to zero during ID run.	Contact your local ABB representative.
	000C	(Permanent magnet motors only) First acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000D	(Permanent magnet motors only) Second acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000E0010	Internal error.	Contact your local ABB representative.
	0011	(Synchronous reluctance motors only) Pulse test error.	Contact your local ABB representative.
	0012	Motor too large for advanced standstill ID run.	Check that the motor and drive sizes are compatible. Contact your local ABB representative.
	0013	(Asynchronous motors only) Motor data error.	Check that the motor nominal value settings in the drive are the same as in the motor nameplate. Contact your local ABB representative.
FF63	STO diagnostics failure.	SW internal malfunction.	Reboot the control unit (using parameter 96.08 Control board boot or by cycling power.
FF81	FB A force trip	A fault trip command has been received through fieldbus adapter A.	Check the fault information provided by the PLC.
FF8E	EFB force trip	A fault trip command has been received through the embedded fieldbus interface.	Check the fault information provided by the PLC.

442 Fault tracing

9

Fieldbus control through the embedded fieldbus interface (EFB)

What this chapter contains

The chapter describes how the drive can be controlled by external devices over a communication network (fieldbus) using the embedded fieldbus interface.

System overview


The drive can be connected to an external control system through a communication link using either a fieldbus adapter or the embedded fieldbus interface.

The embedded fieldbus interface supports the Modbus RTU protocol. The drive control program can handle 10 Modbus registers in a 10-millisecond time level. For example, if the drive receives a request to read 20 registers, it will start its response within 22 ms of receiving the request – 20 ms for processing the request and 2 ms overhead for handling the bus. The actual response time depends on other factors as well, such as the baud rate (a parameter setting in the drive).

The drive can be set to receive all of its control information through the fieldbus interface, or the control can be distributed between the embedded fieldbus interface and other available sources, for example, digital and analog inputs.

Connecting the fieldbus to the drive

Connect the fieldbus to terminal slot, which is attached on the control unit of the drive. The connection diagram is shown below.



The AC500 PLC has a free version library called 'PS553 drives' which help user to communicate and control between PLC and drives easily.

Setting up the embedded fieldbus interface

To configure the parameters automatically

1. Navigate to Main menu $\equiv \rightarrow$ Complete parameter list \blacksquare and set parameter 96.04 to Modbus RTU [21].

The following parameters change automatically.

Parameter	Setting	
20.01 Ext1 commands	Embedded fieldbus [1]	
20.03 Ext1 in1 source	Always off [0]	
20.04 Ext1 in2 source	Always off [0]	
22.11 Ext1 speed ref1	EFB ref1[8]	
22.22 Constant speed sel1	Always off [0]	
22.23 Constant speed sel2	Always off [0]	
23.11 Ramp set selection	Acc/Dec time 1[0]	
28.11 Ext1 frequency ref1	EFB ref1[8]	
28.22 Constant frequency sel1	Always off [0]	
28.23 Constant frequency sel2	Always off [0]	
28.71 Freq ramp set selection	Acc/Dec time 1[0]	
31.11 Fault reset selection	DI1[2]	
58.01 Protocol enable	Modbus RTU 1]	

You can manually set the drive up for the embedded fieldbus communication with the parameters shown in the table below. The **Setting for fieldbus control** column gives either the value to use or the default value. The **Function/Information column** gives a description of the parameter.

Parameter		Setting for fieldbus control	Function/Information
COMM	UNICATION INITIA	LIZATION	
58.01	Protocol enable	Modbus RTU [1]	Initializes embedded fieldbus communication.
EMBED	DED MODBUS CO	ONFIGURATION	
58.03	Node address	1 (default)	Node address. There must be no two nodes with the same node address online.
58.04	Baud rate	19.2 kbps (default) [3]	Defines the communication speed of the link. Use the same setting as in the master station.
58.05	Parity	8 EVEN 1 (default) [2]	Selects the parity and stop bit setting. Use the same setting as in the master station.
58.14	Communication loss action	Fault (default) [1]	Defines the action taken when a communication loss is detected.
58.15	Communication loss mode	<i>Cw / Ref1 / Ref2</i> (default) [2]	Enables/disables communication loss monitoring and defines the means for resetting the counter of the communication loss delay.

Parame	oter	Setting for fieldbus control	Function/Information
58.16	Communication loss time	3.0 s (default)	Defines the timeout limit for the communication monitoring.
58.17	Transmit delay	0 ms (default)	Defines a response delay for the drive.
58.25	Control profile	ABB Drives [0] (default)	Selects the control profile used by the drive. See section <i>Basics of the embedded fieldbus</i> <i>interface</i> (page 447).
58.26 58.27	EFB ref1 type EFB ref2 type	Speed or frequency (default for 58.26) [0], Transparent, General, Torque [3] (default for 58.27), Speed [4], Frequency [5]	Defines the types of fieldbus references 1 and 2. The scaling for each reference type is defined by parameters 46.0146.03. With the <i>Speed or frequency</i> setting, the type is selected automatically according to the currently active drive control mode.
58.28 58.29	EFB act1 type EFB act2 type	Speed or frequency (default for 58.28) [0], Transparent (default for 58.29) [1], General [2], Torque [3], Speed [4], Frequency [5]	Defines the types of actual values 1 and 2. The scaling for each actual value type is defined by parameters 46.0146.03. With the <i>Speed or frequency</i> setting, the type is selected automatically according to the currently active drive control mode.
58.31 58.32	EFB act1 transparent source EFB act2 transparent source	Other	Defines the source of actual values 1 and 2 when the 58.26 <i>EFB ref1 type</i> (58.27 <i>EFB</i> <i>ref2 type</i>) is set to <i>Transparent</i> .
58.33	Addressing mode	<i>Mode 0</i> (default) [0]	Defines the mapping between parameters and holding registers in the 400001465536 (10065535) Modbus register range.
58.34	Word order	LO-HI (default) [1]	Defines the order of the data words in the Modbus message frame.
	Data I/O 1 Data I/O 14	For example, the default settings (I/Os 16 contain the control word, the status word, two references and two actual values) <i>RO/DIO control</i>	Defines the address of the drive parameter which the Modbus master accesses when it reads from or writes to the register address corresponding to Modbus In/Out parameters. Select the parameters that you want to read or write through the Modbus I/O words. These settings write the incoming data into
		word [31], AO1 data storage [32], AO2 data storage [33], Feedback data storage [40], Setpoint data storage [41]	storage parameters 10.99 RO/DIO control word, 13.91 AO1 data storage, 13.92 AO2 data storage, 40.91 Feedback data storage or 40.92 Setpoint data storage.

Parame	eter	Setting for fieldbus control	Function/Information
58.06	Communication control	Refresh settings	Validates the settings of the configuration parameters.

The new settings will take effect when the drive is powered up the next time, or when they are validated by parameter *58.06 Communication control (Refresh settings)*.

Setting the drive control parameters

After the embedded fieldbus interface has been set up, check and adjust the drive control parameters listed in the table below. The **Setting for fieldbus control** column gives the value or values to use when the embedded fieldbus signal is the desired source or destination for that particular drive control signal. The

Function/Information column gives a description of the parameter.

Parameter	Setting for fieldbus control	Function/Information	
CONTROL COMMANE	SOURCE SELECTION	I	
20.01 Ext1 commands	Embedded fieldbus	Selects fieldbus as the source for the start and stop commands when EXT1 is selected as the active control location.	
20.06 Ext2 commands	Embedded fieldbus	Selects fieldbus as the source for the start and stop commands when EXT2 is selected as the active control location.	
SPEED REFERENCE SELECTION			
22.11 Ext1 speed ref1	EFB ref1	Selects a reference received through the embedded fieldbus interface as speed reference 1.	
22.18 Ext2 speed ref1	EFB ref1	Selects a reference received through the	

TORQUE REFERENCE SELECTION		
26.11 Torque ref1 source	EFB ref1	Selects a reference received through the embedded fieldbus interface as torque reference 1.
26.12 Torque ref2 source	EFB ref1	Selects a reference received through the embedded fieldbus interface as torque reference 2.

reference 2.

embedded fieldbus interface as speed

FREQUENCY REFERENCE SELECTION		
28.11 Ext1 frequency ref1		Selects a reference received through the embedded fieldbus interface as frequency reference 1.

Parameter	Setting for fieldbus control	Function/Information
28.15 Ext2 frequency ref1	EFB ref1	Selects a reference received through the embedded fieldbus interface as frequency reference 2.

OTHER SELECTIONS


EFB references can be selected as the source at virtually any signal selector parameter by selecting *Other*, then either 03.09 *EFB reference* 1 or 03.10 *EFB reference* 2.

SYSTEM CONTROL INPUTS		
96.07 Parameter save manually	Done)	Saves parameter value changes (including those made through fieldbus control) to permanent memory.

Basics of the embedded fieldbus interface

The cyclic communication between a fieldbus system and the drive consists of 16-bit data words or 32-bit data words (with a transparent control profile).

The diagram below illustrates the operation of the embedded fieldbus interface. The signals transferred in the cyclic communication are explained further below the diagram.



1. See also other parameters which can be controlled through fieldbus.

 Data conversion if parameter 58.25 Control profile is set to ABB Drives. See section About the control profiles (page 450).

Control word and Status word

The Control Word (CW) is a 16-bit or 32-bit packed boolean word. It is the principal means of controlling the drive from a fieldbus system. The CW is sent by the fieldbus controller to the drive. With drive parameters, the user selects the EFB CW as the source of drive control commands (such as start/stop, emergency stop, selection between external control locations 1/2, or fault reset). The drive switches between its states according to the bit-coded instructions of the CW.

The fieldbus CW is either written to the drive as it is or the data is converted. See section *About the control profiles* (page 450).

The fieldbus Status Word (SW) is a 16-bit or 32-bit packed boolean word. It contains status information from the drive to the fieldbus controller. The drive SW is either written to the fieldbus SW as it is or the data is converted. See section *About the control profiles* (page 450).

References

EFB references 1 and 2 are 16-bit or 32-bit signed integers. The contents of each reference word can be used as the source of virtually any signal, such as the speed, frequency, torque or process reference. In embedded fieldbus communication, references 1 and 2 are displayed by 03.09 EFB reference 1 and 03.10 EFB reference 2 respectively. Whether the references are scaled or not depends on the settings of 58.26 EFB ref1 type and 58.27 EFB ref2 type. See section About the control profiles (page 450).

Actual values

Fieldbus actual signals (ACT1 and ACT2) are 16-bit or 32-bit signed integers. They convey selected drive parameter values from the drive to the master. Whether the actual values are scaled or not depends on the settings of *58.28 EFB act1 type* and *58.29 EFB act2 type*. See section *About the control profiles* (page 450).

Data input/outputs

Data input/outputs are 16-bit or 32-bit words containing selected drive parameter values. Parameters 58.101 Data I/O 1 ... 58.114 Data I/O 14 define the addresses from which the master either reads data (input) or to which it writes data (output).

Register addressing

The address field of Modbus requests for accessing holding registers is 16 bits. This allows the Modbus protocol to support addressing of 65536 holding registers.

Historically, Modbus master devices used 5-digit decimal addresses from 40001 to 49999 to represent holding register addresses. The 5-digit decimal addressing limited to 9999 the number of holding registers that could be addressed.

Modern Modbus master devices typically provide a means to access the full range of 65536 Modbus holding registers. One of these methods is to use 6-digit decimal addresses from 400001 to 465536. This manual uses 6-digit decimal addressing to represent Modbus holding register addresses.

Modbus master devices that are limited to the 5-digit decimal addressing may still access registers 400001 to 409999 by using 5-digit decimal addresses 40001 to 49999. Registers 410000-465536 are inaccessible to these masters.

See parameter 58.33 Addressing mode.

Note: Register addresses of 32-bit parameters cannot be accessed by using 5-digit register numbers.

About the control profiles


A control profile defines the rules for data transfer between the drive and the fieldbus master, for example:

- · if packed boolean words are converted and how
- · if signal values are scaled and how
- how drive register addresses are mapped for the fieldbus master.

You can configure the drive to receive and send messages according to one of the two profiles:

- ABB Drives
- DCU Profile.

For the ABB Drives profile, the embedded fieldbus interface of the drive converts the fieldbus data to and from the native data used in the drive. The DCU Profile involves no data conversion or scaling. The figure below illustrates the effect of the profile selection.



Control Word

Control Word for the ABB Drives profile

The table below shows the contents of the fieldbus Control Word for the ABB Drives control profile. The embedded fieldbus interface converts this word to the form in which it is used in the drive. The upper case boldface text refers to the states shown in *State transition diagram for the ABB Drives profile* on page 458.

Bit	Name	Value	STATE/Description
0	OFF1_ CONTROL	1	Proceed to READY TO OPERATE.
		0	Stop along currently active deceleration ramp. Proceed to OFF1 ACTIVE; proceed to READY TO SWITCH ON unless other interlocks (OFF2, OFF3) are active.
1	OFF2_	1	Continue operation (OFF2 inactive).
	CONTROL	0	Emergency OFF, coast to stop. Proceed to OFF2 ACTIVE , proceed to SWITCH-ON INHIBITED .
2	OFF3_	1	Continue operation (OFF3 inactive).
	CONTROL	0	Emergency stop, stop within time defined by drive parameter. Proceed to OFF3 ACTIVE ; proceed to SWITCH-ON INHIBITED .
			Warning: Ensure that the motor and driven machine can be stopped using this stop mode.
3	INHIBIT_	1	Proceed to OPERATION D.
	OPERATION		Note: Run enable signal must be active; see the drive documentation. If the drive is set to receive the Run enable signal from the fieldbus, this bit activates the signal.
		0	Inhibit operation. Proceed to OPERATION INHIBITED .
4	RAMP_OUT_ ZERO	1	Normal operation. Proceed to RAMP FUNCTION GENERATOR: OUTPUT D.
		0	Force Ramp Function Generator output to zero. Drive ramps to stop (current and DC voltage limits in force).
5	RAMP_HOLD	1	ramp function. Proceed to RAMP FUNCTION GENERATOR: ACCELERATOR D.
		0	Halt ramping (Ramp Function Generator output held).
6	RAMP_IN_ ZERO	1	Normal operation. Proceed to OPERATING .
			Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Force Ramp Function Generator input to zero.
7	RESET	0=>1	Fault reset if an active fault exists. Proceed to SWITCH-ON INHIBITED .
			Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Continue normal operation.

Bit	Name	Value	STATE/Description	
8	JOGGING_1	1	Request running at Jogging 1 speed. Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.	
		0	Continue normal operation.	
9	JOGGING_2	1	Request running at Jogging 2 speed. Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.	
		0	Continue normal operation.	
10	REMOTE_	1	Fieldbus control d.	
	CMD	0	Control Word <> 0 or Reference <> 0: Retain last Control Word and Reference.	
			Control Word = 0 and Reference = 0: Fieldbus control d. Reference and deceleration/acceleration ramp are locked.	
11	EXT_CTRL_ LOC	1	Select External Control Location EXT2. Effective if the control location is parameterized to be selected from the fieldbus.	
		0	Select External Control Location EXT1. Effective if the control location is parameterized to be selected from the fieldbus.	
12	USER_0		Writable control bits that can be combined with drive logic	
13	USER_1		for application-specific functionality.	
14	USER_2			
15	USER_3			

Control Word for the DCU Profile

The embedded fieldbus interface writes the fieldbus Control Word as is to the drive Control Word bits 0 to 15. Bits 16 to 32 of the drive Control Word are not in use.

Bit	Name	Value	State/Description
0	STOP	1	Stop according to the Stop Mode parameter or the stop mode request bits (79).
		0	(no op)
1	START	1	Start the drive.
		0	(no op)

Bit	Name	Value	State/Description				
2	REVERSE	1 Reverse direction of motor rotation. See below how this bit and sign of the refere direction of the motor direction.					
				Sign of the	e reference		
				Positive (+)	Negative (-)		
			Bit REVERSE = 0 Bit REVERSE = 1	Forward Reverse	Reverse Forward		
			DIL REVERSE = 1	Reverse	Forward		
		0	(no op)				
3	Reserved						
4	RESET	0=>1	Fault reset if an active fault exists.				
		0	(no op)				
5	EXT2	1		Select External control location EXT2. Effective if the control location is parameterized to be selected from the fieldbus.			
		0	Select External control location EXT1. Effective if the control location is parameterized to be selected from the fieldbus.				
6	RUN_DISABLE	1	Run disable. If the drive is set to receive the run enable signal from the fieldbus, this bit deactivates the signal.				
		0	Run enable. If the drive is set to receive the run enable signal from the fieldbus, this bit activates the signal.				
7	STOPMODE_RA	1	Normal ramp stop mode				
	MP	0	(no op) Default to parameter stop mode if bits 79 are all 0.				
8	STOPMODE_EM	1	Emergency ramp stop mode.				
	ERGENCY_RAM P	0	(no op) Default to par 0.	rameter stop mode	if bits 79 are all		
9	STOPMODE_CO	1	Coast stop mode.				
	AST	0	(no op) Default to par 0.	rameter stop mode	if bits 79 are all		
10	RAMP_PAIR _2	1	Select ramp set 2 (Acceleration time 2 / Deceleration time 2) when parameter 23.11 Ramp set selection is set to EFB DCU CW bit 10.				
		0	Select ramp set 1 (Acceleration time 1 / Deceleration time 1) when parameter 23.11 Ramp set selection is set to EFB DCU CW bit 10.				
11	RAMP_OUT_ZER O	1	Force Ramp Function ramps to stop (currer				
		0	Normal operation.				
12	RAMP_HOLD	1	Halt ramping (Ramp	Function Generate	or output held).		
		0	Normal operation.				
13	RAMP_IN_ZERO	1	Force Ramp Function	n Generator input	to zero.		
		0	Normal operation.				

Bit	Name	Value	State/Description	
14	REQ_LOCAL_LO CK	1	Drive does not switch to local control mode (see parameter 19.17 Local control disable).	
		0	Drive can switch between local and remote control modes.	
15	Reserved			
16	FB_LOCAL_CTL	1	Local mode for control from the fieldbus is requested. Steal control from the active source.	
		0	(no op)	
17	FB_LOCAL_REF	1	Local mode for reference from the fieldbus is requested. Steal reference from the active source.	
		0	(no op)	
18	Reserved for RUN_DISABLE_1		Not yet implemented.	
19	Reserved			
20	Reserved			
21	Reserved			
22	USER_0		Writable control bits that can be combined with drive logic	
23	USER_1		for application-specific functionality.	
24	USER_2			
25	USER_3		1	
26 31	Reserved			

Status Word

Status Word for the ABB Drives profile

The table below shows the fieldbus Status Word for the ABB Drives control profile. The embedded fieldbus interface converts the drive Status Word into this form for the fieldbus. The upper case boldface text refers to the states shown in *State transition diagram for the ABB Drives profile* on page 458.

Bit	Name	Value	STATE/Description
0	RDY_ON	1	READY TO SWITCH ON.
		0	NOT READY TO SWITCH ON.
1	RDY_RUN	1	READY TO OPERATE.
		0	OFF1 ACTIVE.
2	RDY_REF	1	OPERATION D.
		0	OPERATION INHIBITED.
3	TRIPPED	1	FAULT.
		0	No fault.
4	OFF_2_STATUS	1	OFF2 inactive.
		0	OFF2 ACTIVE.
5	OFF_3_STATUS	1	OFF3 inactive.
		0	OFF3 ACTIVE.
6	SWC_ON_	1	SWITCH-ON INHIBITED.
	INHIB	0	-
7	ALARM	1	Warning/Alarm.
		0	No warning/alarm.
8	AT_ SETPOINT	1	OPERATING . Actual value equals Reference (is within tolerance limits, e.g. in speed control, speed error is 10% max. of nominal motor speed).
		0	Actual value differs from Reference (is outside tolerance limits).
9	REMOTE	1	Drive control location: REMOTE (EXT1 or EXT2).
		0	Drive control location: LOCAL.
10	ABOVE_ LIMIT	1	Actual frequency or speed equals or exceeds supervision limit (set by drive parameter). Valid in both directions of rotation.
		0	Actual frequency or speed within supervision limit.
11	USER_0		Status bits that can be combined with drive logic for
12	USER_1		application-specific functionality.
13	USER_2		
14	USER_3		
15	Reserved	•	•

Status Word for the DCU Profile

The embedded fieldbus interface writes the drive Status Word bits 0 to 15 to the fieldbus Status Word as is. Bits 16 to 32 of the drive Status Word are not in use.


Bit	Name	Value	State/Description
0	READY	1	Drive is ready to receive the start command.
		0	Drive is not ready.
1	D	1	External run enable signal is active.
		0	External run enable signal is not active.
2	Reserved for D_TO_ROTATE		Not yet implemented.
3	RUNNING	1	Drive is modulating.
		0	Drive is not modulating.
4	ZERO_SPEED	1	Drive is at zero speed.
		0	Drive is not at zero speed.
5	ACCELERATING	1	Drive speed is increasing.
		0	Drive speed is not increasing.
6	DECELERATING	1	Drive speed is decreasing.
		0	Drive speed is not decreasing.
7	AT_SETPOINT	1	Drive is at setpoint.
		0	Drive is not at setpoint.
8	LIMIT	1	Drive operation is limited.
		0	Drive operation is not limited.
9	SUPERVISION	1	Actual value (speed, frequency or torque) is above a limit. Limit is set with parameters 46.3146.33
		0	Actual value (speed, frequency or torque) is within limits.
10	REVERSE_REF	1	Drive reference is in the reverse direction.
		0	Drive reference is in the forward direction
11	REVERSE_ACT	1	Drive is running in the reverse direction
		0	Drive is running in the forward direction
12	PANEL_LOCAL	1	Panel/keypad (or PC tool) is in local control mode.
		0	Panel/keypad (or PC tool) is not in local control mode.
13	FIELDBUS_LOC AL	1	Fieldbus is in local control mode.
		0	Fieldbus is not in local control mode.
14	EXT2_ACT	1	External control location EXT2 is active.
		0	External control location EXT1 is active.
15	FAULT	1	Drive is faulted.
		0	Drive is not faulted.

Bit	Name	Value	State/Description	
16	ALARM	1	Warning/Alarm is active.	
		0	No warning/alarm.	
17	Reserved			
18	Reserved for DIRECTION_LO CK		Not yet implemented.	
19	Reserved			
20	CTL_MODE	1	Vector motor control mode is active.	
		0	Scalar motor control mode is active.	
21	Reserved			
22	USER_0		Status bits that can be combined with drive logic for	
23	USER_1		application-specific functionality.	
24	USER_2			
25	USER_3			
26	REQ_CTL	1	Control is requested in this channel.	
		0	Control is not requested in this channel.	
27 31	Reserved			

State transition diagrams

State transition diagram for the ABB Drives profile

The diagram below shows the state transitions in the drive when the drive is using the ABB Drives profile and the drive is configured to follow the commands of the control word from the embedded fieldbus interface. The upper case texts refer to the states which are used in the tables representing the fieldbus Control and Status words. See sections *Control Word for the ABB Drives profile* on page 451 and *Status Word for the ABB Drives profile* on page 455.




References

References for the ABB Drives profile and DCU Profile

The ABB Drives profile supports the use of two references, EFB reference 1 and EFB reference 2. The references are 16-bit words each containing a sign bit and a 15-bit integer. A negative reference is formed by calculating the two's complement from the corresponding positive reference.

The references are scaled as defined by parameters 46.01...46.04; which scaling is in use depends on the setting of 58.26 *EFB ref1 type* and 58.27 *EFB ref2 type* (see page 342).




The scaled references are shown by parameters 03.09 *EFB* reference 1 and 03.10 *EFB* reference 2.

Actual values

Actual values for the ABB Drives profile and DCU Profile

The ABB Drives profile supports the use of two fieldbus actual values, ACT1 and ACT2. The actual values are 16-bit words each containing a sign bit and a 15-bit integer. A negative value is formed by calculating the two's complement from the corresponding positive value.

The actual values are scaled as defined by parameters 46.01...46.04; which scaling is in use depends on the setting of parameters 58.28 EFB act1 type and 58.29 EFB act2 type (see page 343).



Modbus holding register addresses

Modbus holding register addresses for the ABB Drives profile and DCU Profile

The table below shows the default Modbus holding register addresses for the drive data with the ABB Drives profile. This profile provides a converted 16-bit access to the drive data.

Note: Only the 16 least significant bits of the drive's 32-bit Control and Status Words can be accessed.

Note: Bits 16 through 32 of the DCU Control/Status word are not in use if 16-bit control/status word is used with the DCU Profile.

Register address	Register data (16-bit words)
400001	Default: Control word (<i>CW 16bit</i>). See sections <i>Control Word for the ABB Drives profile</i> (page 451) and <i>Control Word for the DCU Profile</i> (page 452).
	The selection can be changed using parameter 58.101 Data I/O 1.
400002	Default: Reference 1 (Ref1 16bit).
	The selection can be changed using parameter 58.104 Data I/O 4.
400003	Default: Reference 2 (Ref2 16bit).
	The selection can be changed using parameter 58.104 Data I/O 4.
400004	Default: Status Word (<i>SW</i> 16bit). See sections <i>Status Word for the ABB Drives profile</i> (page 455) and <i>Status Word for the DCU Profile</i> (page 456).
	The selection can be changed using parameter 58.104 Data I/O 4.
400005	Default: Actual value 1 (Act1 16bit).
	The selection can be changed using parameter 58.105 Data I/O 5.
400006	Actual value 2 (Act2 16bit).
	The selection can be changed using parameter 58.106 Data I/O 6.
400007400014	Data in/out 714.
	Selected by parameters 58.107 Data I/O 7 58.114 Data I/O 14.
400015400089	Unused
400090400100	Error code access. See section <i>Error code registers (holding registers 400090400100)</i> (page 469).
400101465536	Parameter read/write. Parameters are mapped to register addresses according to parameter 58.33 Addressing mode.

Modbus function codes

The table below shows the Modbus function codes supported by the embedded fieldbus interface.

Code	Function name	Description
01h	Read Coils	Reads the 0/1 status of coils (0X references).
02h	Read Discrete Inputs	Reads the 0/1 status of discrete inputs (1X references).
03h	Read Holding Registers	Reads the binary contents of holding registers (4X references).
05h	Write Single Coil	Forces a single coil (0X reference) to 0 or 1.
06h	Write Single Register	Writes a single holding register (4X reference).
08h	Diagnostics	 Provides a series of tests for checking the communication, or for checking various internal error conditions. Supported subcodes: 00h Return Query Data: Echo/loopback test. 01h Restart Comm Option: Restarts and initializes the EFB, clears communications event counters. 04h Force Listen Only Mode 0Ah Clear Counters and Diagnostic Register 0Bh Return Bus Message Count 0Ch Return Bus Comm. Error Count 0Dh Return Bus Exception Error Count 0Eh Return Slave Message Count 0Fh Return Slave No Response Count 10h Return Slave NAK (negative acknowledge) Count 11h Return Slave Busy Count 12h Return Bus Character Overrun Count
0Bh	Get Comm Event Counter	Returns a status word and an event count.
0Fh	Write Multiple Coils	Forces a sequence of coils (0X references) to 0 or 1.
10h	Write Multiple Registers	Writes the contents of a contiguous block of holding registers (4X references).
16h	Mask Write Register	Modifies the contents of a 4X register using a combination of an AND mask, an OR mask, and the register's current contents.
17h	Read/Write Multiple Registers	Writes the contents of a contiguous block of 4X registers, then reads the contents of another group of registers (the same or different than those written) in a server device.

Code	Function name	Description
2Bh / 0Eh	Encapsulated Interface	Supported subcodes:
	Transport	OEh Read Device Identification: Allows reading the identification and other information.
		Supported ID codes (access type):
		00h: Request to get the basic device identification (stream access)
		04h: Request to get one specific identification object (individual access)
		Supported Object IDs:
		O0h: Vendor Name ("ABB")
		O1h: Product Code (for example, "ASCLx or ASCDx")
		O2h: Major Minor Revision (combination of contents of parameters 07.05 Firmware version and 58.02 Protocol ID).
		03h: Vendor URL ("www.abb.com")
		04h: Product name: ("ACS560").

Exception codes

The table below shows the Modbus exception codes supported by the embedded fieldbus interface.

Code	Name	Description
01h	ILLEGAL FUNCTION	The function code received in the query is not an allowable action for the server.
02h	ILLEGAL ADDRESS	The data address received in the query is not an allowable address for the server.
03h	ILLEGAL VALUE	The requested quantity of registers is larger than the device can handle. This error does not mean that a value written to the device is outside of the valid range.
04h	DEVICE FAILURE	An unrecoverable error occurred while the server was attempting to perform the requested action. See section <i>Error code registers (holding registers 400090400100)</i> on page 469.

Coils (0xxxx reference set)

Coils are 1-bit read/write values. Control Word bits are exposed with this data type. The table below summarizes the Modbus coils (0xxxx reference set). Note that the references are 1-based index which match the address transmitted on the wire.

Reference	ABB Drives profile	DCU Profile
000001	OFF1_CONTROL	STOP
000002	OFF2_CONTROL	START
000003	OFF3_CONTROL	Reserved
000004	INHIBIT_OPERATION	Reserved
000005	RAMP_OUT_ZERO	RESET
000006	RAMP_HOLD	EXT2
000007	RAMP_IN_ZERO	RUN_DISABLE
000008	RESET	STOPMODE_RAMP
000009	JOGGING_1	STOPMODE_EMERGENCY_RAMP
000010	JOGGING_2	STOPMODE_COAST
000011	REMOTE_CMD	Reserved
000012	EXT_CTRL_LOC	RAMP_OUT_ZERO
000013	USER_0	RAMP_HOLD
000014	USER_1	RAMP_IN_ZERO
000015	USER_2	Reserved
000016	USER_3	Reserved
000017	Reserved	FB_LOCAL_CTL
000018	Reserved	FB_LOCAL_REF
000019	Reserved	Reserved
000020	Reserved	Reserved
000021	Reserved	Reserved
000022	Reserved	Reserved
000023	Reserved	USER_0
000024	Reserved	USER_1
000025	Reserved	USER_2
000026	Reserved	USER_3
000027	Reserved	Reserved
000028	Reserved	Reserved
000029	Reserved	Reserved
000030	Reserved	Reserved
000031	Reserved	Reserved
000032	Reserved	Reserved

Reference	ABB Drives profile	DCU Profile
000033	Control for relay output RO1 (parameter 10.99 RO/DIO control word, bit 0)	Control for relay output RO1 (parameter <i>10.99 RO/DIO control word</i> , bit 0)
000034	Control for relay output RO2 (parameter 10.99 RO/DIO control word, bit 1)	Control for relay output RO2 (parameter <i>10.99 RO/DIO control word</i> , bit 1)
000035	Control for relay output RO3 (parameter 10.99 RO/DIO control word, bit 2)	Control for relay output RO3 (parameter 10.99 RO/DIO control word, bit 2)
000036	Control for relay output RO4 (parameter 10.99 RO/DIO control word, bit 3)	Control for relay output RO4 (parameter 10.99 RO/DIO control word, bit 3)
000037	Control for relay output RO5 (parameter <i>10.99 RO/DIO control word</i> , bit 4)	Control for relay output RO5 (parameter <i>10.99 RO/DIO control word</i> , bit 4)

Discrete inputs (1xxxx reference set)

Discrete inputs are 1-bit read-only values. Status Word bits are exposed with this data type. The table below summarizes the Modbus discrete inputs (1xxxx reference set). Note that the references are 1-based index which match the address transmitted on the wire.

Reference	ABB Drives profile	DCU Profile
100001	RDY_ON	READY
100002	RDY_RUN	D
100003	RDY_REF	Reserved
100004	TRIPPED	RUNNING
100005	OFF_2_STATUS	ZERO_SPEED
100006	OFF_3_STATUS	Reserved
100007	SWC_ON_INHIB	Reserved
100008	ALARM	AT_SETPOINT
100009	AT_SETPOINT	LIMIT
100010	REMOTE	SUPERVISION
100011	ABOVE_LIMIT	Reserved
100012	USER_0	Reserved
100013	USER_1	PANEL_LOCAL
100014	USER_2	FIELDBUS_LOCAL
100015	USER_3	EXT2_ACT
100016	Reserved	FAULT
100017	Reserved	ALARM
100018	Reserved	Reserved
100019	Reserved	Reserved
100020	Reserved	Reserved
100021	Reserved	CTL_MODE
100022	Reserved	Reserved
100023	Reserved	USER_0
100024	Reserved	USER_1
100025	Reserved	USER_2
100026	Reserved	USER_3
100027	Reserved	REQ_CTL
100028	Reserved	Reserved
100029	Reserved	Reserved
100030	Reserved	Reserved
100031	Reserved	Reserved
100032	Reserved	Reserved

Reference	ABB Drives profile	DCU Profile
100033	Delayed status of digital input DI1 (parameter <i>10.02 DI</i> <i>delayed status</i> , bit 0)	Delayed status of digital input DI1 (parameter <i>10.02 DI</i> <i>delayed status</i> , bit 0)
100034	Delayed status of digital input DI2 (parameter <i>10.02 DI</i> <i>delayed status</i> , bit 1)	Delayed status of digital input DI2 (parameter <i>10.02 DI</i> <i>delayed status</i> , bit 1)
100035	Delayed status of digital input DI3 (parameter <i>10.02 DI</i> <i>delayed status</i> , bit 2)	Delayed status of digital input DI3 (parameter <i>10.02 DI</i> <i>delayed status</i> , bit 2)
100036	Delayed status of digital input DI4 (parameter <i>10.02 DI</i> <i>delayed status</i> , bit 3)	Delayed status of digital input DI4 (parameter <i>10.02 DI</i> <i>delayed status</i> , bit 3)
100037	Delayed status of digital input DI5 (parameter <i>10.02 DI</i> <i>delayed status</i> , bit 4)	Delayed status of digital input DI5 (parameter <i>10.02 DI</i> <i>delayed status</i> , bit 4)
100038	Delayed status of digital input DI6 (parameter 10.02 DI delayed status, bit 5)	Delayed status of digital input DI6 (parameter 10.02 DI delayed status, bit 5)

Error code registers (holding registers 400090...400100)

These registers contain information about the last query. The error register is cleared when a query has finished successfully.

Reference	Name	Description
400090	Reset Error Registers	1 = Reset internal error registers (9195). 0 = Do nothing.
400091	Error Function Code	Function code of the failed query.
400092	Error Code	 Set when exception code 04h is generated (see table above). 00h No error 02h Low/High limit exceeded 03h Faulty Index: Unavailable index of an array parameter 05h Incorrect Data Type: Value does not match the data type of the parameter 65h General Error: Undefined error when handling query
400093	Failed Register	The last register (discrete input, coil, input register or holding register) that failed to be read or written.
400094	Last Register Written Successfully	The last register (discrete input, coil, input register or holding register) that was written successfully.
400095	Last Register Read Successfully	The last register (discrete input, coil, input register or holding register) that was read successfully.

10

Fieldbus control through a fieldbus adapter

What this chapter contains

This chapter describes how the drive can be controlled by external devices over a communication network (fieldbus) through an optional fieldbus adapter module.

The fieldbus control interface of the drive is described first, followed by a configuration example.

System overview


The drive can be connected to an external control system through an optional fieldbus adapter ("fieldbus adapter A" = FBA A) mounted onto the control unit of the drive. The drive can be configured to receive all of its control information through the fieldbus interface, or the control can be distributed between the fieldbus interface and other available sources such as digital and analog inputs, depending on how control locations EXT1 and EXT2 are configured.

Fieldbus adapters are available for various communication systems and protocols, for example:

- PROFIBUS DP (FPBA-01 adapter)
- PROFINET (FPNO-21)
- CANopen (FCAN-01 adapter)
- EtherCAT (FECA-01 adapter)
- EtherNet/IP (FEIP-21)
- Modbus/TCP (FMBT-21)
- EtherNet IPTM/PROFINET IO/Modbus/TCP (FENA-11/-21)
- ModbusRTU (FSCA-01)

Notes:


- The text and examples in this chapter describe the configuration of one fieldbus adapter (FBAA) by parameters 50.01...50.18 and parameter groups 51 FBAA settings...53 FBAA data out.
- The AC 500 PLC has a free version library called PS553 drives which helps user to communicate and control between PLC and drives easily.



Basics of the fieldbus control interface

The cyclic communication between a fieldbus system and the drive consists of 16- or 32-bit input and output data words. The drive is able to support a maximum of 12 data words (16 bits) in each direction.

Data transmitted from the drive to the fieldbus controller is defined by parameters 52.01 FBA A data in1 ... 52.12 FBA A data in12. The data transmitted from the fieldbus controller to the drive is defined by parameters 53.01 FBA A data out1 53.12 FBA A data out1 53.12 FBA A data out12.



1) See also other parameters which can be controlled from fieldbus.

2) The maximum number of data words used is protocol-dependent.

3) Profile/instance selection parameters. Fieldbus module specific parameters. For more

information, see the User's manual of the appropriate fieldbus adapter module.

Control word and Status word

The Control word is the principal means for controlling the drive from a fieldbus system. It is sent by the fieldbus master station to the drive through the adapter module. The drive switches between its states according to the bit-coded instructions in the Control word, and returns status information to the master in the Status word.

The contents of the Control word and the Status word are detailed on pages 478 and 480 respectively. The drive states are presented in the state diagram (page 481).

Debugging the network words

If parameter 50.12 FBA A debug mode is set to Fast [1], the Control word received from the fieldbus is shown by parameter 50.13 FBA A control word, and the Status word transmitted to the fieldbus network by 50.16 FBA A status word. This "raw" data is very useful to determine if the fieldbus master is transmitting the correct data before handing control to the fieldbus network.

References

References are 16-bit words containing a sign bit and a 15-bit integer. A negative reference (indicating reversed direction of rotation) is formed by calculating the two's complement from the corresponding positive reference.


ABB drives can receive control information from multiple sources including analog and digital inputs, the drive control panel and a fieldbus adapter module. In order to have the drive controlled through the fieldbus, the module must be defined as the source for control information such as reference. This is done using the source selection parameters in groups 22 Speed reference selection, 26 Torque reference chain and 28 Frequency reference chain.

Debugging the network words

If parameter 50.12 FBA A debug mode is set to Fast [1], the references received from the fieldbus are displayed by 50.14 FBA A reference 1 and 50.15 FBA A reference 2.

Scaling of references

The references are scaled as defined by parameters 46.01...46.04; which scaling is in use depends on the setting of 50.04 FBA A ref1 type and 50.05 FBA A ref2 type.



The scaled references are shown by parameters 03.05 FB A reference 1 and 03.06 FB A reference 2.

Actual values


Actual values are 16-bit words containing information on the operation of the drive. The types of the monitored signals are selected by parameters 50.07 FBA A actual 1 type and 50.08 FBA A actual 2 type.

Debugging the network words

If parameter 50.12 FBA A debug mode is set to Fast [1], the actual values sent to the fieldbus are displayed by 50.17 FBA A actual value 1 and 50.18 FBA A actual value 2.

Scaling of actual values

The actual values are scaled as defined by parameters 46.01...46.04; which scaling is in use depends on the setting of parameters 50.07 FBA A actual 1 type and 50.08 FBA A actual 2 type.



Contents of the fieldbus Control word

The upper case boldface text refers to the states shown in the state diagram (page 481).


Bit	Name	Value	STATE/Description
0	Off1 control	1	Proceed to READY TO OPERATE.
		0	Stop along currently active deceleration ramp. Proceed to OFF1 ACTIVE ; proceed to READY TO SWITCH ON unless other interlocks (OFF2, OFF3) are active.
1	Off2 control	1	Continue operation (OFF2 inactive).
		0	Emergency OFF, coast to a stop. Proceed to OFF2 ACTIVE, proceed to SWITCH-ON INHIBITED.
2	Off3 control	1	Continue operation (OFF3 inactive).
		0	Emergency stop, stop within time defined by drive parameter. Proceed to OFF3 ACTIVE ; proceed to SWITCH-ON INHIBITED . WARNING: Ensure motor and driven machine can be stopped using this stop mode.
3	Run	1	Proceed to OPERATION D . Note: Run enable signal must be active; see drive documentation. If the drive is set to receive the Run enable signal from the fieldbus, this bit activates the signal.
		0	Inhibit operation. Proceed to OPERATION INHIBITED.
4	Ramp out zero	1	Normal operation. Proceed to RAMP FUNCTION GENERATOR: OUTPUT D.
		0	Force Ramp function generator output to zero. The drive will immediately decelerate to zero speed (observing the torque limits).
5	Ramp hold	1	ramp function. Proceed to RAMP FUNCTION GENERATOR: ACCELERATOR D.
		0	Halt ramping (Ramp Function Generator output held).
6	Ramp in zero	1	Normal operation. Proceed to OPERATING . Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Force Ramp function generator input to zero.
7	Reset	0=>1	Fault reset if an active fault exists. Proceed to SWITCH-ON INHIBITED . Note: This bit is effective only if the fieldbus interface is set as the source of the reset signal by drive parameters.
		0	Continue normal operation.
8	Inching 1	1	Accelerate to inching (jogging) setpoint 1. Notes: • Bits 46 must be 0. • See also section <i>Rush control</i> (page 72).
		0	Inching (jogging) 1 disabled.
9	Inching 2	1	Accelerate to inching (jogging) setpoint 2. See notes at bit 8.
		0	Inching (jogging) 2 disabled.
10	Remote cmd	1	Fieldbus control d.
		0	Control word and reference not getting through to the drive, except for bits 02.

Bit	Name	Value	STATE/Description
11	Ext ctrl loc	1	Select External Control Location EXT2. Effective if control location is parameterized to be selected from fieldbus.
		0	Select External Control Location EXT1. Effective if control location is parameterized to be selected from fieldbus.
12	User bit 0	1	User configurable
		0	
13	User bit 1	1	
		0	
14	User bit 2	1	
		0	
15	User bit 3	1	
		0	

Contents of the fieldbus Status word

The upper case boldface text refers to the states shown in the state diagram (page 481).

Bit	Name	Value	STATE/Description
0	Ready to switch	1	READY TO SWITCH ON.
	ON	0	NOT READY TO SWITCH ON.
1	Ready run	1	READY TO OPERATE.
		0	OFF1 ACTIVE.
2	Ready ref	1	OPERATION D.
		0	OPERATION INHIBITED.
3	Tripped	1	FAULT.
		0	No fault.
4	Off 2 inactive	1	OFF2 inactive.
		0	OFF2 ACTIVE.
5	Off 3 inactive	1	OFF3 inactive.
		0	OFF3 ACTIVE.
6	Switch-on	1	SWITCH-ON INHIBITED.
	inhibited	0	-
7	Warning	1	Warning active.
		0	No warning active.
8	At setpoint	1	OPERATING . Actual value equals reference = is within tolerance limits (see parameters <i>46.2146.22</i>).
		0	Actual value differs from reference = is outside tolerance limits.
9	Remote	1	Drive control location: REMOTE (EXT1 or EXT2).
		0	Drive control location: LOCAL.
10	Above limit	-	See bit 10 of 06.17 Drive status word 2.
11	User bit 0	-	See parameter 06.30 MSW bit 11 selection.
12	User bit 1	-	See parameter 06.31 MSW bit 12 selection.
13	User bit 2	-	See parameter 06.32 MSW bit 13 selection.
14	User bit 3	-	See parameter 06.33 MSW bit 14 selection.
15	Reserved	•	•



The state diagram

Automatic drive configuration for fieldbus control

The parameters set on module detection are shown in the table below. See also parameters 07.35 Drive configuration and 07.36 Drive configuration 2.

Notes:

- The optional modules BIO-01 and RIIO-01 are applicable only for frames R0...R2.
- No parameter changes are done for C-series modules. c-series modules are only supported in frames R3...R8.

Option	10.24 RO1 source	10.27 RO2 source	10.30 RO3 source	20.01 Ext1 commands	20.03 Ext1 in1 source	20.04 Ext1 in2 source
BIO-01	-	-	-	2 (In1 Start, In2 Dir)	2 (DI1)	3 (DI2)
RIIO-01	-	-	-	2 (In1 Start, In2 Dir)	2 (DI1)	3 (DI2)
FENA-21	-	-	-	-	-	-
FECA-01	-	-	-	-	-	-
FPBA-01	-	-	-	-	-	-
FCAN-01	-	-	-	-	-	-
FSCA-01	-	-	-	-	-	-
FEIP-21	-	-	-	-	-	-
FMBT-21	-	-	-	-	-	-
FPNO-21	-	-	-	-	-	-
FEPL-02	-	-	-	-	-	-
FDNA-01	-	-	-	-	-	-
FCNA-01	-	-	-	-	-	-

Option	22.11 Ext1 speed ref1	22.22 Constant speed sel1	22.23 Constant speed sel2
BIO-01	1 (AI1 scaled)	4 (DI3)	5 (DI4)
RIIO-01	1 (AI1 scaled)	4 (DI3)	5 (DI4)
FENA-21	-	-	-
FECA-01	-	-	-
FPBA-01	-	-	-
FCAN-01	-	-	-
FSCA-01	-	-	-
FEIP-21	-	-	-
FMBT-21	-	-	-
FPNO-21	-	-	-
FEPL-02	-	-	-
FDNA-01	-	-	-
FCNA-01	-	-	-

Option	23.11 Ramp set selection	28.11 Ext1 frequency ref1	28.22 Constant frequency sel1	28.23 Constant frequency sel2
BIO-01	6 (DI5)	1 (AI1 scaled)	4 (DI3)	5 (DI4)
RIIO-01	6 (DI5)	1 (AI1 scaled)	4 (DI3)	5 (DI4)
FENA-21	-	-	-	-
FECA-01	-	-	-	-
FPBA-01	-	-	-	-
FCAN-01	-	-	-	-
FSCA-01	-	-	-	-
FEIP-21	-	-	-	-
FMBT-21	-	-	-	-
FPNO-21	-	-	-	-
FEPL-02	-	-	-	-
FDNA-01	-	-	-	-
FCNA-01	-	-	-	-

Option	28.71 Freq ramp set	31.11 Fault reset
	selection	selection
BIO-01	6 (DI5)	0
RIIO-01	6 (DI5)	0
FENA-21	-	-
FECA-01	-	-
FPBA-01	-	-
FCAN-01	-	-
FSCA-01	-	-
FEIP-21	-	-
FMBT-21	-	-
FPNO-21	-	-
FEPL-02	-	-
FDNA-01	-	-
FCNA-01	-	-

Option	50.01 FBA A enable	50.02 FBA A comm loss func	51.02 FBA A Par2	51.04 FBA A Par4
BIO-01	0	0	-	-
RIIO-01	0	0	-	-
FENA-21	1 (Enable)	0	11	0
FECA-01	1 (Enable)	0	0	-
FPBA-01	1 (Enable)	0	-	-
FCAN-01	1 (Enable)	0	-	-
FSCA-01	1 (Enable)	0	-	-

Option	50.01 FBA A enable	50.02 FBA A comm loss func	51.02 FBA A Par2	51.04 FBA A Par4
FEIP-21	1 (Enable)	0	100	0
FMBT-21	1 (Enable)	0	0	0
FPNO-21	1 (Enable)	0	11	0
FEPL-02	1 (Enable)	0	-	-
FDNA-01	1 (Enable)	0	-	-
FCNA-01	1 (Enable)	0	-	-

Option	51.05 FBA A Par5	51.06 FBA A Par6	51.07 FBA A Par7	51.08 FBA A Par8	51.09 FBA A Par9
BIO-01	-	-	-	-	-
RIIO-01	-	-	-	-	-
FENA-21	192	168	0	10	24
FECA-01	0	0	0	0	0
FPBA-01	1	-	-	-	0
FCAN-01	0	-	-	-	-
FSCA-01	-	10	1	-	-
FEIP-21	-	-	-	-	128
FMBT-21	-	-	-	1	-
FPNO-21	-	-	-	-	-
FEPL-02	-	-	-	-	-
FDNA-01	-	-	-	-	-
FCNA-01	-	-	-	-	-

Option	51.21 FBA A Par21	51.23 FBA A Par23	51.24 FBA A Par24
BIO-01	-	-	-
RIIO-01	-	-	-
FENA-21	-	-	-
FECA-01	-	-	-
FPBA-01	-	-	-
FCAN-01	-	-	-
FSCA-01	-	-	-
FEIP-21	-	128	128
FMBT-21	1	-	-
FPNO-21	-	-	-
FEPL-02	-	-	-
FDNA-01	-	-	-
FCNA-01	-	-	-

Option	52.01 FBA data in1	52.02 BA data in2	53.01 FBA data out1	53.02 FBA data out2	58.01 Protocol enable*
BIO-01	-	-	-	-	-
RIIO-01	-	-	-	-	-
FENA-21	4	5	1	2	0
FECA-01	-	-	-	-	0
FPBA-01	4	5	1	2	0
FCAN-01	-	-	-	-	0
FSCA-01	-				0
FEIP-21	-	-	-	-	0
FMBT-21	-	-	-	-	0
FPNO-21	4	5	1	2	0
FEPL-02	-	-	-	-	0
FDNA-01	-	-	-	-	0
FCNA-01	-	-	-	-	0
*Paramete	er 58.01 is set	to 0 in frames	R0R2.		

Setting up the drive for fieldbus control manually

- 1. Install the fieldbus adapter module mechanically and electrically according to the instructions given in the *User's manual* of the module.
- 2. Power up the drive.
- 3. Enable the communication between the drive and the fieldbus adapter module with parameter *50.01 FBA A enable*.
- With 50.02 FBA A comm loss func, select how the drive should react to a fieldbus communication break.
 Note: This function monitors both the communication between the fieldbus master and the adapter module and the communication between the adapter module and the drive.
- 5. With *50.03 FBA A comm loss t out*, define the time between communication break detection and the selected action.
- Select application-specific values for the rest of the parameters in group 50 *Fieldbus adapter (FBA)*, starting from 50.04. Examples of appropriate values are shown in the tables below.
- 7. Set the fieldbus adapter module configuration parameters in group *51 FBA A settings*. As a minimum, set the required node address and the communication profile.
- Define the process data transferred to and from the drive in parameter groups 52 FBA A data in and 53 FBA A data out.
 Note: Depending on the communication protocol and profile being used, the Control word and Status word may already be configured to be sent/received by the communication system.
- 9. Save the valid parameter values to permanent memory by setting parameter 96.07 Parameter save manually to Save.
- 10. Validate the settings made in parameter groups 51, 52 and 53 by setting parameter 51.27 FBA A par refresh to Configure.
- 11. Configure control locations EXT1 and EXT2 to allow control and reference signals to come from the fieldbus. Examples of appropriate values are shown in the tables below.

Parameter setting example: FPBA (PROFIBUS)

This example shows how to configure a basic speed control application that uses the PROFIdrive communication profile with PPO Type 2. The start/stop commands and reference are according to the PROFIdrive profile, speed control mode.

The reference values sent over the fieldbus have to be scaled within the drive so they have the desired effect. The reference value ± 16384 (4000h) corresponds to the range of speed set in parameter 46.01 Speed scaling (both forward and reverse directions). For example, if 46.01 is set to 480 rpm, then 4000h sent over fieldbus will request 480 rpm.

Direction	PZD1	PZD2	PZD3	PZD4	PZD5	PZD6
Out	Control word	Speed reference	Acc time	1	Dec time	e 1
In	Status word	Speed actual value	al value Motor current DC voltag		ge	

The table below gives the recommended drive parameter settings.

Drive parameter	Setting for ACS 560 drives	Description
50.01 FBA A enable	1 = [slot number]	Enables communication between the drive and the fieldbus adapter module.
50.04 FBA A ref1 type	4 = Speed	Selects the fieldbus A reference 1 type and scaling.
50.07 FBA A actual 1 type	0 = Speed or frequency	Selects the actual value type and scaling according to the currently active Ref1 mode defined in parameter <i>50.04</i> .
51.01 FBA A type	1 = FPBA ¹⁾	Displays the type of the fieldbus adapter module.
51.02 Node address	3 ²⁾	Defines the PROFIBUS node address of the fieldbus adapter module.
51.03 Baud rate	12000 ¹⁾	Displays the current baud rate on the PROFIBUS network in kbit/s.
51.04 MSG type	1 = PPO2 ¹⁾	Displays the telegram type selected by the PLC configuration tool.
51.05 Profile	0 = PROFIdrive	Selects the Control word according to the PROFIdrive profile (speed control mode).
51.07 RPBA mode	0 = Disabled	Disables the RPBA emulation mode.
52.01 FBA data in1	4 = SW 16bit ¹⁾	Status word
52.02 FBA data in2	5 = Act1 16bit	Actual value 1
52.03 FBA data in3	01.07 ²⁾	Motor current
52.05 FBA data in5	01.11 ²⁾	DC voltage
53.01 FBA data out1	1 = CW 16bit ¹⁾	Control word
53.02 FBA data out2	2 = Ref1 16bit	Reference 1 (speed)
53.03 FBA data out3	23.12 ²⁾	Acceleration time 1

Drive parameter	Setting for ACS 560 drives	Description
53.05 FBA data out5	23.13 ²⁾	Deceleration time 1
51.27 FBA A par refresh	1 = Configure	Validates the configuration parameter settings.
19.12 Ext1 control mode	2 = Speed	Selects speed control as the control mode 1 for external control location EXT1.
20.01 Ext1 commands	12 = Fieldbus A	Selects fieldbus adapter A as the source of the start and stop commands for external control location EXT1.
20.02 Ext1 start trigger type	1 = <i>Level</i>	Selects a level-triggered start signal for external control location EXT1.
22.11 Ext1 speed ref1	4 = FB A ref1	Selects fieldbus A reference 1 as the source for speed reference 1.

¹⁾ Read-only or automatically detected/set

²⁾ Example

The start sequence for the parameter example above is given below.

Control word:

- 477h (1143 decimal) -> READY TO SWITCH ON
- 47Fh (1151 decimal) -> OPERATING (Speed mode)

11

Control chain diagrams


Contents of this chapter


The chapter presents the reference chains of the drive. The control chain diagrams can be used to trace how parameters interact and where parameters have an effect within the drive parameter system.

For a more general diagram, see section Operating modes of the drive (page 37).

Note: The reference to group 24 parameters in control chain diagrams can be ignored. Group 24 Speed reference conditioning is not available in ACS560.


Frequency reference selection







Frequency reference modification


Speed reference source selection I




Speed reference source selection II












Speed error calculation




Speed controller







Torque reference source selection and modification



Reference selection for torque controller


Torque limitation







Process PID setpoint and feedback source selection


Process PID controller








External PID controller




EXTERNAL PID FUNCTION


Direction lock



Override



OVERRIDE



PID trim auto connection

PID TRIM AUTO CONNECTION

508 Control chain diagrams

12Parameterization with drive
composer

Contents of this chapter

The chapter describes about the drive composer application and how drive parameters can be managed with the drive composer.

Drive composer

Drive composer is a 32-bit PC tool used for commissioning and maintaining ABB common architecture drives. The drive composer can be connected to a drive that has assistant panel or a dummy panel. The full version is called Drive composer pro and the free version is called Drive composer entry. The drive composer free version is available for download from *ABB website*.

Note: The drive composer cannot be connected to the basic panel.

You can perform following actions with the drive composer:

- · View and adjust drive parameters.
- · Control a drive: start, stop, direction, speed/torque/frequency reference.
- Monitor the operation and status of a drive.
- Monitor signals in numerical and graphical (trending) format.
- · Work simultaneously with multiple drives like master and follower drives (pro).
- Display control diagrams of a drive for parameter setting and diagnostic purposes (pro).
- Create user-specific workspaces by customizing parameter windows.
- · Configure the optional FSO-11 and FSO-12 safety functions module (pro).
- · Handle workspaces.
- Create and execute macro scripts (pro).

How to connect the drive composer

To establish a connection between the Drive composer and the drive you need to meet the following requirements:


- · Computer with drive composer installed
- Assistant control panel or Dummy panel
- Mini USB cable (assistant control panel) or BCBL-01 cable (dummy panel)

Communication Connection

- Use BCBL-01 cable to connect the drive with a dummy panel. Connect BCBL-01 cable to the RJ 45 port of the panel and the other end to the USB port of your computer. You can order the BCBL-01 with the order ID 3AXD50000032449.
- Use a mini USB cable to connect the drive with an assistant panel.
- Use Ethernet-based fieldbus adapter modules for PC tool communication (onewire solution, Profinet, Ethernet IP) (pro) or a drive-embedded Ethernet port
- Use an OPC-based commissioning and maintenance tool (pro).

Both versions include a demo that allows testing user interface functionality, edit parameter files offline (pro) or open and analyze saved monitored files without connecting to a physical drive.

Connection Diagram (with assistant panel)



For more information, see *Drive composer start-up and maintenance PC tool user's manual* (3AUA0000094606[English]).

512 Parameterization with drive composer

13

Parameterization with automation builder drive manager

Contents of this chapter

The chapter describes about the automation builder drive manager application and how drive parameters can be managed with the automation builder drive manager.

Automation builder drive manager

Automation builder drive manager is a software tool that enables you to configure ABB drives connected to the PLC through PROFIBUS or PROFINET.

You can perform the following actions with the automation builder drive manager:

- Monitor the drive status like Running, Stopped, EXT1/EXT2 and Running direction.
- Monitor the drive parameter groups and parameters.
- Monitor the drive firmware version and properties.
- Monitor the drive parameter values along with the parameter attributes like parameter minimum and maximum settings, parameter units and parameter protection status.
- User can edit parameters in offline view and then copy to drive when online.
- Open the offline drive parameter settings (project view) and compare to the online drive parameters. The compare function shows the parameters with different

settings in offline and online mode.User can also download the parameter values which have differences in offline and online settings.

- Export the drive parameters from Drive Manager to the respective standalone drive tool parameter file formats (.dsp, mdwp, dcparamsbak).
- Import the drive parameters (.dsp, dwp, dcparamsbak) to the Drive Manager and compare the parameter values of the file with the project view file.
- Update and save a group or a single parameter to the drive.

Connection Diagram



Process data	Configuration	Parameters Parameters (filtered)
Process data	Station address: 3	
Drive Management	Drive type: ACS880	Drive Project Compare Import values:
Monitoring	Drive firmware: AINF2 02.01.00	Parameter name Project Min Max Defa
General	Drive rating: Unconfigured	
	Settings	4 Warnings and faults
I/O mapping list	Drive	Image: Spinostics Image: Spinostic spinosti spinostic spinostic spinostic spinosti spinosti spinostic
Check configuration	bine	🗉 🔲 7 System info
Information	Unknown	🗷 🧰 10 Standard DI, RO
		I1 Standard DIO, FI, FO I2 Standard AI
		12 Standard AI 13 Standard AO
		🗷 📴 15 I/O extension module 2
		🗷 📴 16 I/O extension module 3
	Connect	19 Operation mode
		20 Start/stop/direction
		21 Start/stop mode
		22 Speed reference selection Parameter locking Export to File
	Last full refresh: neve	

Parameter view with drive manager

For more information on automation builder application download, purchase see *http://new.abb.com/plc/automationbuilder/platform/software*. The information about configuring automation builder with drive and other details are available in the online help of the application.

Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to abb.com/searchchannels.

Product training

For information on ABB product training, navigate to new.abb.com/service/training.

Providing feedback on ABB Drives manuals

Your comments on our manuals are welcome. Navigate to new.abb.com/drives/manuals-feedback-form.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at abb.com/drives/documents.



abb.com/drives

