

---

## Options for ABB drives

### Original user's manual

**Emergency stop, stop category 0 with opening mains contactor (option +Q951) for DCS8x0-A enclosed converters equipped with DCS880 modules (+S880)**

### Individual Drive E-Stop

	E-Stop cat.0	E-Stop cat.1	POUS	forced MC opening
+Q951	x			x
+Q952		x		x
+Q963	x			
+Q964		x		
+Q957			x	



## List of related manuals

All the documents available for the drive system DCS880 are listed below:

		Language							
	Publication number	E	D	I	ES	F	CN	RU	
<b>General</b>									
DCS880 Quick guide	<a href="#">3ADW000545</a>	x	x	x	x	x			
Safety instructions all languages	<a href="#">3ADW000481</a>	x	x	x	x	x	x	x	
DCS880 Documentation pack	 <a href="#">DCS880 CD download</a>	x							
<b>DCS880 Units</b>									
DCS880 Flyer	<a href="#">3ADW000475</a>	x	x			x			
DCS880 Technical catalog	<a href="#">3ADW000465</a>	x							
DCS880 Hardware manual	<a href="#">3ADW000462</a>	x							
DCS880 Firmware manual	<a href="#">3ADW000474</a>	x							
DCS880 Service manual	<a href="#">3ADW000488</a>	x							
DCS880 Hardparallel manual	<a href="#">3ADW000530</a>	x							
DCS880 12-pulse manual	<a href="#">3ADW000533</a>	x							
Instructions for mounting the SDCS-CMA-2	<a href="#">3ADW000396</a>	x							
ACS-AP-x assistant control panels user's manual	<a href="#">3AUA0000085685</a>	x							
DCS Thyristor power converter – Technical guide	<a href="#">3ADW000163</a>	x							
<b>Functional safety</b>									
Supplement for functional safety	<a href="#">3ADW000452</a>	x							
<b>Functional safety for enclosed converter</b>									
+Q957 Prevention of unexpected Start Up	<a href="#">3ADW000504</a>	x							
+Q951 Emergency stop, category 0 with MC opening	<a href="#">3ADW000505</a>	x							
+Q952 Emergency stop, category 1 with MC opening	<a href="#">3ADW000506</a>	x							
+Q963 Emergency stop, category 0 without MC opening	<a href="#">3ADW000507</a>	x							
+Q964 Emergency stop, category 1 without MC opening	<a href="#">3ADW000508</a>	x							
<b>Enclosed converter</b>									
Installation manual	<a href="#">3ADW000091</a>	x	x						
DCS800-A +S880 Enclosed converters, flyer	<a href="#">3ADW000523</a>	x	x						
<b>Door mounting kits</b>									
DPMP-01 mounting platform for ACS-AP control panel	<a href="#">3AUA0000100140</a>	x							
DPMP-02 mounting platform for ACS-AP control panel	<a href="#">3AUA0000136205</a>	x							
<b>Serial communication</b>									
FCAN-01 CANopen adapter module	<a href="#">3AFE68615500</a>	x	x						
FDNA-01 DeviceNet™ adapter module	<a href="#">3AFE68573360</a>	x							
FECA-01 EtherCAT adapter module	<a href="#">3AUA0000068940</a>	x	x						
FENA-11/-21 Ethernet adapter module	<a href="#">3AUA0000093568</a>	x							
FEPL-02 Ethernet POWERLINK adapter module	<a href="#">3AUA0000123527</a>	x	x						
FPBA-01 PROFIBUS DP adapter module	<a href="#">3AFE68573271</a>	x	x						
FSCA-01 RS-485 adapter module	<a href="#">3AUA0000109533</a>	x							
FDCO-01/02 DDCS communication modules	<a href="#">3AUA0000114058</a>								
<b>Tool and maintenance manuals and guides</b>									
Drive composer PC tool	<a href="#">3AUA0000094606</a>	x							
Drive (IEC61131-3) application programming manual	<a href="#">3AUA0000127808</a>	x							
Adaptive programming, Application guide	<a href="#">3AXD50000028574</a>	x							
NETA-21 remote monitoring tool	<a href="#">3AUA0000096939</a>	x							
NETA-21 remote monitoring tool guide	<a href="#">3AUA0000096881</a>	x							
DDCS branching unit NDBU-95 user's manual	<a href="#">3BFE64285513</a>	x							
<b>Extension modules</b>									
FIO-11 Analog extension module	<a href="#">3AFE68784930</a>	x							
FIO-01 Digital extension module	<a href="#">3AFE68784921</a>	x							
FAIO-01 Analog extension module	<a href="#">3AUA0000124968</a>	x							
FDIO-01 Digital extension module	<a href="#">3AUA0000124966</a>	x							
FEN-01 TTL encoder interface	<a href="#">3AFE68784603</a>	x							
FEN-31 HTL encoder interface	<a href="#">3AUA0000031044</a>	x							
FEA-03 F series extension adapter	<a href="#">3AUA0000115811</a>	x							
Ethernet tool network for ACS880 drives application guide	<a href="#">3AUA000012563</a>	x							
Status 07.2019                      x → existing                      p → planned		DCS880 Manuals list e i.docx							

# Table of contents

List of related manuals.....	3
<b>Table of contents</b>	<b>4</b>
<b>Safety Instructions</b>	<b>5</b>
<b>Introduction to the manual</b>	<b>6</b>
Contents of this chapter.....	6
Applicability .....	6
Target audience .....	6
Contents .....	6
Related documents .....	6
Abbreviations .....	7
Exclusion of liability .....	8
Quick reference guide for implementing a safety system .....	9
<b>Option description and instructions</b>	<b>10</b>
Contents this chapter.....	10
+Q951 basic function description.....	10
Operation principle +Q951 E-Stop cat.0 with opening Main Contactor.....	11
+Q951 Fault reaction function.....	12
Parameter settings .....	12
Hardware settings.....	13
Wiring .....	13
Start-up and acceptance test.....	14
Use of the safety function .....	15
Activating .....	15
Resetting.....	15
Emergency stop indications .....	15
+Q951 Fault tracing.....	15
+Q951 Maintenance.....	16
Proof test interval .....	16
Diagnostic test interval .....	17
Competence .....	17
Residual risk.....	17
Intentional misuse .....	17
Decommissioning .....	17
Safety data .....	18
Safety data values.....	18
Safety component types .....	18
Safety block diagram .....	18
Relevant failure modes .....	18
Fault exclusions .....	18
Operation delays .....	19
General rules, notes and definitions .....	19
Validation of the safety functions.....	19
Ambient conditions .....	19
Reporting problems and failures related to safety functions .....	19
Related standards and directives .....	20
Compliance with the European Machinery Directive.....	20
<b>Further information</b>	<b>21</b>

# Safety Instructions

Only a qualified electrician who has appropriate knowledge on functional/machine/process safety is allowed to install, start up and maintain the safety circuit.

---

**WARNING!**

This safety function does not disconnect the voltage of the main and auxiliary circuits from the drive. You must not work on the electrical parts of the drive or the motor before you have also disconnected the drive system from the electric supply and ensured by measuring that there is no dangerous voltage present.

**WARNING!**

After making additions to the drive safety circuit or modifying it, or changing circuit boards inside the drive, always test the functioning of the safety circuit according to the acceptance test procedure. Any changes in the electrical installations of the drive may affect the safety performance or operation of the drive unexpectedly. All customer-made changes are on the customer's responsibility.

**WARNING!**

Read and obey all safety instructions given for the drive in its hardware manual. If you ignore them, injury or death, or damage to the equipment can occur.

---

This manual does not repeat the complete safety instructions of the drive, but it only includes the instructions related to the scope of this manual.

# Introduction to the manual

## Contents of this chapter

This chapter describes the manual in short and gives some general information for the reader. The chapter also contains a quick reference for implementing a safety system.

## Applicability

The manual applies only to DCS880-A cabinet drives and to DCS800-A cabinet drives with plus code +S880 (exchange of DCS800 with DCS880 drives modules) which have the option: Emergency stop, stop category 0 with STO, with safety relays (option +Q951). In this emergency stop option, the main contactor/breaker of the drive is opened.

## Target audience

The manual is intended for people who install, start up, use and service the safety option of the drive. Read the manual before working on the drive. You are expected to know the fundamentals of electricity, wiring, electrical components, electrical schematic symbols, and functional safety.

## Contents

The chapters of this manual are briefly described below.

Introduction to the manual (this chapter) introduces this manual.

Option description and instructions describes the safety option and instructs how to wire, start up, test, validate, use and maintain it. The chapter also contains the safety data.

## Related documents

- Product manuals (see the inside of the front cover)
- Circuit diagrams delivered with the drive
- Safety data (if the safety circuit is application engineered)

## Abbreviations

Abbreviations used in this manual are listed below.

Abbreviation	Description	Reference
Cat.	Category 1. Stop category according to EN/IEC 60204-1 The stop categories are: 0 (uncontrolled stop) and 1 (controlled stop) 2. Classification of the safety-related parts of a control system in respect of their resistance to faults and their subsequent behavior in the fault condition, and which is achieved by the structural arrangement of the parts, fault detection and/or by their reliability. The categories are: B, 1, 2, 3 and 4.	EN/IEC 60204-1 EN ISO 13849-1
CCF	Common cause failure (%)	EN ISO 13849-1
DC	Diagnostic coverage	EN ISO 13849-1
DI	Digital input	
E-stop	Emergency stop	
Frame (size)	Relates to the construction type of the drive in question. For example, several drive types with different power ratings can have the same basic construction, and a frame size is used in reference to all those drive types.	
HFT	Hardware fault tolerance	IEC 61508, EN/IEC 62061
PFH	Probability of dangerous failures per hour	IEC 61508, EN ISO 13849-1, EN/IEC 62061, EN/IEC 61800-5-2
PL	Performance level (levels are: a, b, c, d and e). Corresponds to SIL.	EN ISO 13849-1
RO	Relay output	
SC	Systematic capability	IEC 61508
SIL	Safety integrity level	IEC 61508, IEC 61511, EN/IEC 62061, EN/IEC 61800-5-2
SILCL	Maximum SIL that can be claimed for a safety function or subsystem	EN/IEC 62061
SS1	Safe stop 1	EN/IEC 61800-5-2
STO	Safe torque off	EN/IEC 61800-5-2
T1	Proof test interval or lifetime (the smaller one)	IEC 61508, EN/IEC 62061

## **Exclusion of liability**

ABB is not responsible for the implementation, verification and validation of the overall safety system. It is the responsibility of the system integrator (or other party) who is responsible for the overall system and system safety. The system integrator (or other responsible party) must make sure that the entire implementation complies with all relevant standards, directives and local electrical code, and that the system is tested, verified and validated correctly.



## Quick reference guide for implementing a safety system

<input checked="" type="checkbox"/>	Task
<input type="checkbox"/>	Select the appropriate functional safety standard for the implementation: EN ISO 13849-1, EN/IEC 62061, IEC 61511 or other
<input type="checkbox"/>	If you select EN/IEC 62061 or IEC 61511, make a safety plan. See EN/IEC 62061.
<input type="checkbox"/>	Assess safety: analyze and evaluate risks (estimate SIL/PL) and define risk reduction strategies. Define the safety requirements
<input type="checkbox"/>	Design the safety system. The part of the design made by ABB is described in chapter <i>Option</i> description and instructions on page 10.
<input type="checkbox"/>	If you made any changes to the delivered safety system, verify the achieved SIL/PL with, for example, FSDT-01 Functional safety design tool or similar. See <i>Functional safety design tool user's manual</i> (3AXD10000102417 [English]).
<input type="checkbox"/>	Connect the wiring. See section <i>Wiring</i> on page 13.
<input type="checkbox"/>	Set the parameters. See section <i>Parameter settings</i> on page 12.
<input type="checkbox"/>	Validate that the implemented system meets the safety requirements: – Do the acceptance test. See section <i>Start-up and acceptance test</i> on page 14.
<input type="checkbox"/>	Write the necessary documentation.

# Option description and instructions

## Contents this chapter


This chapter describes the +Q951 emergency stop option and instructs how to wire, start up, test, validate, use and maintain it. The safety data is also given.

### +Q951 basic function description


Option +Q951 corresponds to an uncontrolled stop in accordance with stop category 0 (EN/IEC 60204-1). The option corresponds to the Safe torque off (STO) function. After the emergency stop command has been given, the drive option activates the dual channel Safe torque off (STO). This prevents the drive from generating torque. The motor coasts to a stop and the main contactor/breaker of the drive is opened.

For a detailed description of the Safe torque off function, see the appropriate hardware manual. The STO functions comply with EN/IEC 61800-5-2:2016. Option +Q951 has been designed according to the principles of EN ISO13850. For a complete list of related standards and European directives, see section *Related standards and directives* on page 20 .

### Basic timing diagram



## Operation principle +Q951 E-Stop cat.0 with opening Main Contactor



Initial status: The drive is in operation and the motor(s) is running

Step	Operation
1.	The user activates the emergency stop with the emergency stop button [S61].
2.	The emergency stop safety relay [A61] trips and the relay switches off the Safe torque off (STO) control signals on the drive control board [A41]. The STO cuts off the drive control pulses preventing motor control and torque generation.
3.	The delayed contacts of the safety relay [A61] switches of the power supply to the mains contactor or AC-breaker after 0,5s.
4.	The aux. contact of safety relay [A61] energizes the indication lamp [P62].
5.	The motor coasts to zero speed and cannot restart while the emergency stop is active.
6.	Normal operation resumes after the user: <ul style="list-style-type: none"> <li>– releases the emergency stop button [S61] to normal (up) position</li> <li>– resets the emergency stop circuit with the emergency stop reset button [S62] (the user must push the reset button for 0.1 to 3 seconds)</li> <li>– resets the drive (if the STO indication parameter 31.22 has been set so that a fault is generated)</li> <li>– makes sure that the drive has received the start signal (depends on the configuration, see the firmware manual).</li> </ul>

## +Q951 Fault reaction function

Definition: A safety function requires a 'fault reaction function' that attempts to initiate a safe state if the safety function's diagnostics detect a fault within the hardware/software that performs the safety function.

The fault reaction function of the emergency stop safety relay [A61] trips if it detects a failure (short circuit between signals, open circuits, redundancy fault when the emergency stop button is pushed) in the safety circuit. The fault reaction function shifts the drive immediately into the safe state by activating the Safe torque off (STO) function, switching on the drive emergency stop command, and keeping it on until the detected fault has been repaired. The emergency stop indication lamp of the reset button is on until the fault has been repaired.

The emergency stop reset circuit must be open when the user releases the emergency stop button. The emergency stop safety relay [A61] detects if the reset circuit is closed and the relay does not close. The user must reset the safety relay, see section Fault tracing on page 15. For a detailed description of the emergency stop safety relay [A61], see section Hardware settings on page 13.

The DCS880 STO function has its own internal fault diagnostics and fault reaction function


## Parameter settings

This table lists the drive parameters settings for the +Q951 option. For more information, see the firmware manual.

No.	Name	Value	Description
10.24	RO1 source	STO Reset indication P.31.98b11	Selects a drive signal to be connected to relay output RO1. In this case, the RO1 is energized if the Drive is in STO state and no STO related fault is active.
31.22	STO indication run/stop	Warning / Warning	Selects which indications are given when one or both Safe torque off (STO) signals are switched off or lost, depending on whether the drive is Running / Stopped, when they occur. Fault/Warning is the recommended setting. When a fault occurs in the drive, the mains contactor, AC-B or DC-B is opened by the relay XSMC:1/2.

## Hardware settings

Appropriate hardware settings have been preset at the factory for the safety function. The hardware rest of [A61] is preset to manual (Dip Switch).

<p>Use the switch (1) to change settings between automatic reset (2) and manual reset (3).</p> <p>Power cycle (power off and on) the safety relay when a setting has been changed.</p>	
----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------

## Wiring

One emergency stop button and one reset button are installed on the cabinet door and wired to the drive at the factory. There are double contacts in the emergency stop button and double wiring (two-channel connection) between the button and the emergency stop safety relay [A61]. The safety relay detects cross faults and faults across one contact from the emergency stop button.

If needed, install additional emergency stop buttons on site and wire them to the appropriate terminal block inside the drive cabinet. See the circuit diagrams delivered with the drive. Follow the rules below:

1. Use only double-contact buttons approved for the emergency stop circuits.
2. Connect the emergency stop buttons with two conductors (two-channel connection).

**Note:** Keep the channels separate. If you use only one channel, or if the first and second channels are connected together (for example, in a chain), the cross fault detection of the emergency stop safety relay trips and activates the emergency stop command of the drive as it detects a redundancy fault.

3. Use shielded, twisted pair cable. We recommend a double-shielded cable and gold-plated contacts in the emergency stop button.

4. Ensure that the sum resistance for one channel (loop resistance) does not exceed 1 kΩ.


5. Follow the general control cable installation instructions given in the drive hardware manual.

You can also install additional reset buttons and indication lamps for the emergency stop circuit on site. We recommend gold-plated contacts in the reset button. Wire the buttons to the appropriate terminal block inside the drive cabinet. See the circuit diagrams delivered with the drive. Follow the rules below:

1. Sum resistance of the external reset circuit may not exceed 1 kΩ.
2. Follow the general control cable installation instructions given in the drive hardware manual.

## Start-up and acceptance test

You need the Drive composer PC tool or a control panel to perform the start-up and acceptance test. Initial status: Make sure that the drive is ready for use, that is, you have done the tasks of the drive start-up procedure. See the hardware manual.

Action		<input checked="" type="checkbox"/>
	<b>WARNING!</b> Follow the Safety instructions, page 5. Otherwise serious injury, death, or damage to the equipment can occur.	
<b>Checks and settings with no voltage connected</b>		
If any connections of the emergency stop circuit have been changed on site (such as wiring of additional emergency stop buttons, connection of shipping splits of large drives, etc.), verify that the connections are correct with the appropriate circuit diagrams.		<input type="checkbox"/>
Check that the hardware settings relevant to the safety function are set as defined in section Hardware settings on page 13.		<input type="checkbox"/> M
<b>Settings with voltage connected</b>		
Check that the parameters relevant to the safety function are set as defined in section Parameter settings on page 12.		<input type="checkbox"/>
Ensure that the motor can run and be stopped freely during the test.		<input type="checkbox"/>
Start the drive and ensure that the motor is running. If possible, use a motor speed close to the maximum speed of the application.		<input type="checkbox"/>
Push the emergency stop button [S61]. (if installed)		<input type="checkbox"/>
Ensure that the motor coasts to a stop and that the drive displays a related warning. For a description of the messages, see the firmware manual of the drive.		<input type="checkbox"/>
Ensure that the mains contactor, AC or DC breaker has opened. If the mains contactor, AC breaker or DC breaker is not part of the delivery or project, check the auxiliary contactor K10 instead.		<input type="checkbox"/>
Ensure that the indication lamp [P62] switches on. (if installed)		<input type="checkbox"/>
Ensure that you cannot start the drive and motor from any control location: Ensure that the motor does not start even if you switch the start signal off and on or push the start key of the panel.		<input type="checkbox"/>
Ensure that you cannot close the mains contactor, AC breaker or DC breaker from any Location (or auxiliary contactor K10 accordingly).		<input type="checkbox"/>
Turn the emergency stop button [S61] until it releases and returns to the up position		<input type="checkbox"/>
Push the emergency stop reset button [S62]. Ensure that the emergency stop reset indication lamp [P62] switches off (if installed).		<input type="checkbox"/>
Switch off the drive start signal. If a fault message is generated, reset the drive. See section Parameter settings on page 12.		<input type="checkbox"/>
Restart the drive and motor and check that they operate normally.		<input type="checkbox"/>
Repeat the test from each operating location (every emergency stop button and reset button)		<input type="checkbox"/>
Fill in and sign the acceptance test report which verifies that the safety function is safe and approved for operation.		<input type="checkbox"/>

## Use of the safety function

### Activating

1. Push the emergency stop button [S61]. The emergency stop activates and the button locks in “ON” (open) position.

### Resetting

1. Turn the emergency stop button [S61] until it releases.
2. Push the emergency stop reset button [S62]. The emergency stop indication lamp [P62] goes out, the emergency stop deactivates.  
Note: You must push the reset button [S62] for 0.1 to 3 seconds.
3. Reset the drive if necessary.
4. Make sure that the drive has received the start signal (depends on the configuration, see the firmware manual).
5. You can now restart the drive.

**Note:** You have to reset the emergency stop circuit with the reset button [S62] also after you have powered up the drive.

## Emergency stop indications

When the emergency stop is on:

- the drive control program has the warning Safe torque off active,
- the emergency stop indication lamp [P62] is illuminated,
- the mode LED of the emergency stop safety relay [A61] is steady blue.

### +Q951 Fault tracing

This table describes the status LEDs of the emergency stop safety relay [A61].

LED operation and error status for ABB safety relay SSR32				
CH1	Mode	CH2	Comment	Action
off	off	off	The safety relay is not powered.	Check A1–A2 voltage and connections.
green	green	green	CH1 and CH2 accepted. Reset made and outputs activated.	
off	flash green	off	CH1 and CH2 unaccepted. A timer function is counting down while the safety relay remains activated.	
off	flash green	green	CH1 unaccepted and CH2 accepted. A timer function is counting down while the safety relay remains activated.	
green	flash green	off	CH1 accepted and CH2 unaccepted. A timer function is counting down while the safety relay remains activated.	
off	blue	off	No channels accepted.	Check CH1 and CH2
off	blue	green	green CH1 unaccepted, CH2 accepted	Check CH1
green	blue	off	CH1 accepted, CH2 unaccepted	Check CH2

green	blue	green	CH1 and CH2 accepted, the safety relay wait for reset.	Check reset settings, wiring and reset circuit
green	blue	fast flash green	Two-channels error: CH2 has been unaccepted and then accepted again while CH1 remained accepted.	Check installation. Restore by opening and closing both CH:s at the same time.
fast flash green	blue	green	Two-channels error: CH1 has been unaccepted and then accepted again while CH2 remained accepted.	Check installation. Restore by opening and closing both CH:s at the same time.
fast flash green	blue	fast flash green	Reading error on R1 and R2.	Check installation. Restore by opening and closing both CH:s at the same time.
red	flash blue	red	Failsafe mode due to a new setting has been entered.	Power cycle the relay to confirm the new settings.
red	flash red	red	Failsafe mode due to incorrect settings.	Check and correct settings.
red	fast flash red	red	The safety relay is in failsafe mode.	Power cycle.
red	fast flash red	fast flash red	Failsafe mode due to short circuit between CH2 and 24 VDC or T2	Check and remove the short circuit.
fast flash red	fast flash red	red	Failsafe mode due to short circuit between CH1 and 24 VDC or T2	Check and remove the short circuit.

For more information see 2TLC010002M0201

## +Q951 Maintenance

After the operation of the circuit is tested at start-up, it does need scheduled maintenance testing during its specified lifetime depending on its usage.

In addition to proof testing, it is a good practice to check the operation of the function when other maintenance routines of the machinery are carried out.

If you change any wiring or component after the start up, or restore parameters to their default values:

- Use only ABB approved spare parts.
- Register the change to the change log for the safety circuit.
- Test the safety function again after the change.  
Follow the rules given in section Startup and +Q951 acceptance test on page 14.
- Document the tests and store the report in the logbook of the machine.

## Proof test interval

After the operation of the safety function is validated at start-up, the safety function must be maintained by periodic proof testing. In high demand mode of operation, the maximum proof test interval is 20 years. In low demand mode of operation, the maximum proof test interval is one year (high or low demand as defined in IEC 61508, EN/IEC 62061 and EN ISO 13849-1).



## Diagnostic test interval

Regardless of the mode of operation, it is a good practice to check the operation of the safety function at least **once** a year. Do the test as described in section Start-up and +Q951 acceptance test on page 14. The person responsible for the design of the complete safety function should also note the Requirements from IEC61800-5-2:2016 / EN61800-5-2:2017 for the drives STO circuit:

6.2.2.1.4: Diagnostic test interval when the hardware fault tolerance is greater than zero

The diagnostic test interval of any subsystem of the PDS (SR) shall be appropriate to meet the required PFH (see 6.2.2.1.1).

NOTE 2: For redundant parts of a PDS (SR) which cannot be tested without disrupting the application in which the PDS (SR) is used (machine or plant) and where no justifiable technical solution can be implemented, the following maximum diagnostic test intervals can be considered as acceptable:

- one test per year for SIL 2, PL d / category;
- one test per three months for SIL 3, PL e / category 3;
- one test per day for SIL 3, PL e / category 4 (not applicable).

PL and category according to ISO 13849-1.

The noted DC Values are taken from SS-EN ISO 13849-1:2016 (E) chapter 4.5.3.

## Competence

The maintenance and proof test activities of the safety function must be carried out by a competent person with adequate expertise and knowledge of the safety function as well as functional safety, as required by IEC 61508-1 clause 6.

## Residual risk

The safety functions are used to reduce the recognized hazardous conditions. In spite of this, it is not always possible to eliminate all potential hazards. Therefore, the warnings for the residual risks must be given to the operators.

## Intentional misuse

The safety circuit is not designed to protect a machine against intentional misuse.

## Decommissioning

When you decommission an emergency stop circuit or a drive, make sure that the safety of the machine is maintained until the decommissioning is complete.

## Safety data

The safety data given below is valid for the default design of the safety circuit. In case the final design differs from the default, it is obligation of the changing person to calculate new safety data and deliver it separately to the customer.

### Safety data values

Drive module frame size	SIL <sup>1)</sup> / SILCL	SC	PL <sup>1)</sup>	PFH <sup>2)</sup> [1/h]	DC [%]	Cat.	HFT	CCF	Lifetime [a]	T1 <sup>3)4)</sup> [a]
H1 ... H8	3	3	e	5.4 E-8	>90	3	1	80	20	20/1

1) The drive may be used for applications with the given SIL / PL only if the function is tested regularly (see chapter: test interval above).

2) PFH values are according to EN ISO 13849.

3) See the recommendation of use CNB/M/11.050 published by the European co-ordination of notified bodies for lower T1 requirement and also IEC61800-5-2:2016 / EN61800-5-2:2017 6.2.2.1.4 Note 2 for guidance.

4) T1 = 20a is used with high demand mode of operation. See also section Proof test interval on page 16.


### Safety component types

Safety component types as defined in IEC 61508-2:

- emergency stop button: type A
- safety relays: type A
- drive STO circuit:
- frame sizes H1 ... H8: type A

### Safety block diagram

The components that are included in the safety circuit are shown in the safety block diagram below.



Parallel to the Drive STO function the MC / ACB / DCB is forcibly opened by the safety relay. However, this is not part of the safety calculation as it is not needed for the safety function STO. The Drive module already provides a hardware fault tolerance of 1 with a sufficient PFH - Value. Therefore, the calculation gives a worst case approximation and excludes the typically worse and often unknown safety values of the MC / ACB / DCB.

### Relevant failure modes

Internal failures of safety relays, the emergency stop button and STO. These failures are included in the PFH value of the function.

### Fault exclusions

Fault exclusions (not considered in the calculations):

- any short and open circuits in the cables of the safety circuit
- any short and open circuits in the cabinet terminal blocks of the safety circuits.

---

### Option description and instructions

## Operation delays

Emergency stop total delay: Emergency stop relay delay time (500 ms) +mechanical delay times (100 ms).

## General rules, notes and definitions

### Validation of the safety functions

You must do an acceptance test (validation) to validate the correct operation of safety functions.

#### Validation procedure

You must do the acceptance test using the checklist given in section Start-up and acceptance test on page 14:

- at initial start-up of the safety function
- after any changes related to the safety function (wiring, components, safety function related parameter settings etc.)
- after any maintenance action related to the safety function.

The acceptance test must include at least the following steps:

- you must have an acceptance test plan
- you must test all commissioned functions for proper operation, from each operation location
- you must document all acceptance tests.

#### Acceptance test reports

You must store the signed acceptance test reports in the logbook of the machine. The report must include, as required by the referred standards:

- a description of the safety application (including a figure)
- a description and revisions of safety components that are used in the safety application
- a list of all safety functions that are used in the safety application
- a list of all safety related parameters and their values
- documentation of start-up activities, references to failure reports and resolution of failures
- the test results for each safety function, checksums, date of the tests and confirmation by the test personnel.

You must store any new acceptance test reports performed due to changes or maintenance in the logbook of the machine.

#### Competence

The acceptance test of the safety function must be carried out by a competent person with adequate expertise and knowledge of the safety function as well as functional safety, as required by IEC 61508-1 clause 6.

The test procedures and report must be documented and signed by this person.

#### Ambient conditions

For the environmental limits for the safety functions and the drive, refer to the hardware manual.

### Reporting problems and failures related to safety functions

Contact your local ABB representative.

## Related standards and directives

Standard	Name
EN 60204-1:2006 + AC:2010 IEC 60204-1:2005 + A1:2008	Safety of machinery – Electrical equipment of machines – Part 1: General requirements
IEC 61508-1:2010	Functional safety of electrical/electronic/programmable electronic safety related systems - Part 1: General requirements.
IEC 61508-2:2010	Functional safety of electrical/electronic/programmable electronic safety related systems - Part 2: Requirements for electrical/electronic/ programmable electronic safety related systems.
EN 61800-5-2:2017 IEC 61800-5-2:2016	Adjustable speed electrical power drive systems – Part 5-2: Safety requirements – Functional
EN 62061:2005 + AC:2010 + A1:2013 + A2:2015 IEC 62061:2015	Safety of machinery – Functional safety of safety-related electrical, electronic and programmable electronic control systems
EN ISO 12100:2010	Safety of machinery – General principles for design – Risk assessment and risk reduction
ISO 13849-1:2015	Safety of machinery – Safety-related parts of control systems – Part 1: General principles for design
EN ISO 13849-2:2012	Safety of machinery – Safety-related parts of control systems – Part 2: Validation
EN ISO 13850:2015 ISO 13850:2015	Safety of machinery. Emergency stop. Principles for design
IEC 61511-1:2016	Functional safety – Safety instrumented systems for the process industry sector
IEC 61326-3-1: 2008	Electrical equipment for measurement, control and laboratory use – EMC requirements – Part 3-1: Immunity requirements for safety-related systems and for equipment intended to perform safety-related functions (functional safety) – General industrial applications
2006/42/EC	European Machinery Directive
Other	Machine-specific C-type standards

## Compliance with the European Machinery Directive

The drive is an electronic product which is covered by the European Low Voltage Directive. However, the drive internal safety function of this manual (option +Q951) is in the scope of the Machinery Directive as a safety component. This function complies with European harmonized standards such as EN/IEC 61800-5-2. The declaration of conformity is delivered with the drive.

## Further information

### Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to [www.abb.com/searchchannels](http://www.abb.com/searchchannels).

### Product training

For information on ABB product training, navigate to [new.abb.com/service/training](http://new.abb.com/service/training).

### Providing feedback on ABB manuals

Your comments on our manuals are welcome. Navigate to [new.abb.com/drives/manuals-feedback-form](http://new.abb.com/drives/manuals-feedback-form).

### Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at [www.abb.com/drives/documents](http://www.abb.com/drives/documents)

# DCS Family



## DCS550-S modules The compact drive for machinery application

20 ... 1,000 A<sub>DC</sub>  
0 ... 610 V<sub>DC</sub>  
230 ... 525 V<sub>AC</sub>  
IP00

- Compact
- Robust design
- Adaptive and winder program
- High field exciter current



## DCS880 modules For safe productivity

20 ... 5,200 A<sub>DC</sub>  
0 ... 1,600 V<sub>DC</sub>  
230 ... 1,000 V<sub>AC</sub>  
IP00

- Safe torque off (STO) built in as standard
- Compact and robust
- Single drives, 20 A to 5,200 A, up to 1,600 V<sub>DC</sub>
- IEC 61131 programmable
- Intuitive control panel and PC tool with USB connection and start up assistant
- Wide range of options to serve any DC motor application



## DCS800-A enclosed converters Complete drive solutions

20 ... 20,000 A<sub>DC</sub>  
0 ... 1,500 V<sub>DC</sub>  
230 ... 1,200 V<sub>AC</sub>  
IP21 – IP54

- Individually adaptable to customer requirements
- User-defined accessories like external PLC or automation systems can be included
- High power solutions in 6- and 12-pulse up to 20,000 A, 1,500 V
- In accordance to usual standards
- Individually factory load tested
- Detailed documentation



## DCT880 modules Thyristor controller

20 ... 4,200 A<sub>AC</sub>  
110 ... 990 V<sub>AC</sub>  
IP00

- Precise power control in industrial heating applications
- Two or three phase devices
- Power optimizer for peak load reduction
- Built on ABB's all-compatible drives architecture
- Intuitive control panel and PC tool with USB connection and start up assistant
- Application control programs and drive application programming with IEC 61131 programming



ABB Automation Products  
Wallstadter-Straße 59  
68526 Ladenburg • Germany  
Tel: +49 (0) 6203-71-0  
Fax: +49 (0) 6203-71-76 09  
[www.abb.com/dc-drives](http://www.abb.com/dc-drives)



\*505R0301A9300000\*

Ident. No.: 3ADW000505R0301 Rev C  
02.2020