

ABB INDUSTRIAL DRIVES

ACS880-04XT drive module packages

Hardware manual



ACS880-04XT drive module packages

Hardware manual

Table of contents



1. Safety instructions



5. Mechanical installation



7. Electrical installation



12. Commissioning



Table of contents

1 Safety instructions

Contents of this chapter	15
Use of warnings and notes	15
General safety in installation, start-up and maintenance	16
Electrical safety in installation, start-up and maintenance	19
Electrical safety precautions	19
Additional instructions and notes	20
Printed circuit boards	20
Grounding	21
General safety in operation	22
Additional instructions for permanent magnet motor drives	22
Safety in installation, start-up, maintenance	22
Safety in operation	23

2 Introduction to the manual

Contents of this chapter	25
Target audience	25
Categorization by frame size and option code	25
Quick installation, commissioning and operating flowchart	26
Terms and abbreviations	27
Related documents	29

3 Operation principle and hardware description

Contents of this chapter	31
Product overview	32
Drive connection examples	33
Layout	35
Standard drive module configuration	35
Drive module configuration with IP20 shrouds (R10: 3AXD50000024563; R11: 3AXD50000024564) and full-size output cable connection terminals (3AXD50000024519)	36
Drive module with flat mounting (option 3AXD50000024562) and with IP20 shrouds (R10: option 3AXD50000024563; R11: option 3AXD50000024564)	39
Drive module with full power cabling panels (R10: option 3AXD50000024520; R11: option 3AXD50000024561)	40
Drive module configuration with power cable connection terminals on the right-hand side of the drive module (option 3AXD50000026152)	41
Control unit	42
Control panel	42
Overview of power and control connections	43
External control unit connection cables	45
Type designation labels	46
Drive module package label	46
Drive module label	47

Type designation key 47

- Drive module package 48
 - Basic code 48
 - Option codes 48
- Drive module 49
 - Basic code 49
 - Option codes 49

4 Guidelines for planning the mechanical installation

Contents of this chapter 51

Planning the layout 52

- Layout example with IP20 shrouds (option) 52
- Layout example with IP20 shrouds (option) and one “drive module with power cable connection terminals on the right-hand side” (option) 53
- Layout example, doors closed 54
- Layout example, doors open (standard configuration) 55
- Layout example, doors open with IP20 shrouds (option) 57
- Layout example, doors open with IP20 shrouds (option) and “drive module with power cable connection terminals on the right-hand side” (option) 58
- Bookshelf mounting with IP20 shrouds (option) 59
- Bookshelf mounting (standard drive module configuration) 60
- Bookshelf mounting with option “Full power cabling panels to be attached to a cabinet (IP20)” 61
- Flat mounting (option) 62
- Flat mounting (option) with IP20 shrouds (option) 64

Mounting the control panel on the cabinet door 65

Free space requirements 65

- Free space at the top of the drive module 66
- Free space around the drive module 66
- Free space below the drive module 66

Installation positions other than vertical 66

ABB air inlet and outlet kits 67

5 Mechanical installation

Contents of this chapter 69

Safety 70

Examining the installation site 70

Moving and unpacking the unit 71

- Moving the drive module 71
- Unpacking 71
 - Package drawings 72
 - Examining the delivery 77
 - Lifting the drive module 77

Installation alternatives 77

- Standard drive module configuration (bookshelf mounting) 78
- Flat mounting 78
 - Option “Full-size input power cable connection terminals and PE (ground) busbar” 78
 - Option “Full power cabling panels to be attached to a cabinet (IP20)” 79
 - Option “Power cable connection terminals on the right-hand side of the drive module” 79



Attaching the drive module to a mounting plate or wall	79
Alternatives for grounding the drive module	80
Installing the bottom grille for IP20 degree of protection	81
Attaching the external control unit	81
Attaching the type designation label	81
6 Guidelines for planning the electrical installation	
Contents of this chapter	83
Limitation of liability	83
Selecting the main supply disconnecting device	83
European Union and United Kingdom	83
North America	84
Other regions	84
Selecting the main contactor	84
North America	84
Other regions	84
Examining the compatibility of the motor and drive	84
Protecting the motor insulation and bearings	85
Requirements tables	85
Requirements for ABB motors, $P_n < 100$ kW (134 hp)	85
Requirements for ABB motors, $P_n \geq 100$ kW (134 hp)	86
Requirements for non-ABB motors, $P_n < 100$ kW (134 hp)	87
Requirements for non-ABB motors, $P_n \geq 100$ kW (134 hp)	88
Abbreviations	88
Availability of du/dt filter and common mode filter by drive type	89
Additional requirements for explosion-safe (EX) motors	89
Additional requirements for ABB motors of types other than M2_, M3_, M4_, HX_ and AM_	89
Additional requirements for braking applications	89
Additional requirements for ABB high-output and IP23 motors	89
Additional requirements for non-ABB high-output and IP23 motors	89
Additional data for calculating the rise time and the peak line-to-line voltage .	90
Additional note for sine filters	91
Selecting the power cables	91
General guidelines	91
Typical power cable sizes	92
Power cable types	92
Preferred power cable types	92
Alternate power cable types	92
Not allowed power cable types	93
Additional guidelines, North America	93
Metal conduit	94
Power cable shield	94
Grounding requirements	95
Additional grounding requirements – IEC	96
Additional grounding requirements – UL (NEC)	96
Selecting the control cables	96
Shielding	96
Signals in separate cables	97
Signals that can be run in the same cable	97
Relay cable	97
Control panel to drive cable	97



PC tool cable	97
Routing the cables	97
General guidelines – IEC	97
General guidelines – North America	98
Continuous motor cable shield/conduit or enclosure for equipment on the motor cable	99
Separate control cable ducts	99
Protecting the drive, input power cable, motor and motor cable in short circuit situations and against thermal overload	100
Protecting the drive and the input power cable in short-circuits	100
Tested circuit breakers	100
Protecting the motor and motor cable in short-circuits	100
Protecting the motor cables against thermal overload	101
Protecting the motor against thermal overload	101
Protecting the motor against overload without thermal model or temperature sensors	101
Protecting the drive against ground faults	102
Residual current device compatibility	102
Connecting drive modules to a common DC system	102
Implementing a motor temperature sensor connection	102
Connecting a motor temperature sensor to the drive through an option mod- ule	103
Implementing the emergency stop function	104
Implementing the Safe torque off function	104
Implementing the functions provided by the FSO safety functions module	104
Using power factor compensation capacitors with the drive	104
Using a safety switch between the drive and the motor	105
Implementing an ATEX-certified motor thermal protection	105
Implementing the power loss ride-through function	105
Controlling a contactor between drive and motor	106
Implementing a bypass connection	107
Example bypass connection	107
Switching the motor power supply from drive to direct-on-line	108
Switching the motor power supply from direct-on-line to drive	108
Protecting the contacts of relay outputs	108

7 Electrical installation

Contents of this chapter	109
Safety	109
Grounding the motor cable shield at the motor end	109
Measuring the insulation	110
Measuring the insulation resistance of the drive	110
Measuring the insulation resistance of the input power cable	110
Measuring the insulation resistance of the motor and motor cable	110
Measuring the insulation resistance of the brake resistor circuit	110
Grounding system compatibility check	111
Corner-grounded and midpoint-grounded 525...690 V delta systems	111
Installing the EMC filter (option)	111
Connecting the power cables	112
Power cable connection diagram example (6-pulse)	112
Power cable connection diagram example (6-pulse and 12-pulse)	114
Preparing the cable ends and making 360-degree grounding at the cable entry .	115



Power cable connection procedure	117
Connecting the control unit to the drive module	117
Routing the control unit cables into the drive module	117
Connections to the drive module	118
Connections to the control unit	118
Connecting the control cables to the terminals of the control unit	119
Control cable connection procedure	119
Wiring the microswitches of the fuses	119
Connecting a control panel	119
Panel bus (Control of several units from one control panel)	120
Connecting a PC	122
Installing option modules	123
Installation of an FSO safety functions module onto BCU	124
Installation of FSO-xx adjacent to the control unit	126

8 Control unit

Contents of this chapter	127
BCU-x2 layout	128
Default I/O diagram of the inverter control unit (A41)	130
Additional information on the connections	134
External power supply for the control unit (XPOW)	134
DI6 as a PTC sensor input	134
AI1 or AI2 as a Pt100, Pt1000, PTC or KTY84 sensor input	134
DIIL input	135
The XD2D connector	135
Safe torque off (XSTO, XSTO OUT)	136
FSO safety functions module connection (X12)	136
SDHC memory card slot	136
Connector data	137
BCU-x2 ground isolation diagram	140

9 Installation example – standard, optional IP20 shrouds and power cable connection terminals

Contents of this chapter	141
Limitation of liability	141
Safety	141
Required parts	142
Required tools	142
Overall flowchart of the installation process	142
Installing the drive module into the enclosure	143
Connecting the power cables and installing the IP20 shrouds (if present)	144
Installing the roof and door (Rittal parts)	146
Installing the roof and door (ABB air filters and roof)	147
Removing the protective covering from the drive module air outlet	148
Miscellaneous	148
Input power cable entry from top	148

10 Installation example with option “Full power cabling panels to be attached to a cabinet (IP20)”

Contents of this chapter	149
Limitation of liability	149



Safety	149
Required parts	150
Required tools	151
Overall flowchart of the installation process	151
Installing the mechanical accessories into the enclosure	151
Connecting the power cables	152
Power cable connection diagram example (6-pulse and 12-pulse)	152
Power cable connection procedure	153
Installing the drive module into the enclosure	156
Installation procedure	156
Assembly drawing of installing the drive module to the enclosure (frame R10)	160
Assembly drawing of installing the drive module to the enclosure (frame R11)	161
Assembly drawing of installing the roof and door	162
Removing the protective covering from the drive module air outlet	163
Miscellaneous	163
Installations with input and motor cables of size 4 × 240 mm ² per phase	163
Installing the rubber grommet	163
11 Installation checklist	
Contents of this chapter	165
Checklist	165
12 Commissioning	
Contents of this chapter	167
Start-up procedure	167
13 Fault tracing	
Contents of this chapter	169
LEDs	169
Warning and fault messages	169
14 Maintenance	
Contents of this chapter	171
Maintenance intervals	171
Description of symbols	171
Recommended maintenance intervals after start-up	171
Cabinet	173
Cleaning the interior of the cabinet	173
Heatsink	173
Cleaning the interior of the heatsink	173
Fans	175
Replacing the circuit board compartment cooling fans	175
Replacing the main cooling fans	176
Replacing the standard drive module and drive module with option “IP20 shrouds for covering the input and motor cabling area”	177
Replacing the drive module with option “Full power cabling panels to be attached to a cabinet (IP20)”	178
Capacitors	181
Reforming the capacitors	181



Control panel	181
Replacing the memory unit	181
Reduced run	181
Starting reduced run operation	181
Resuming normal operation	182
Functional safety components	182

15 Ordering information

Contents of this chapter	183
Control panel	183
Brake choppers and resistors	184
Output (du/dt) filters	184
Sine filters	184
EMC filter ARFI-10	184
Cabinet ventilation	184
Air inlet kits	184
Air outlet kits	186
Cooling fans	187
FSO accessories kit	188
Control panel mounting platforms	188
Accessory kits	188

16 Technical data

Contents of this chapter	189
Electrical ratings	189
Output derating	191
When is derating necessary	191
Ambient temperature derating	191
Altitude derating	191
Deratings for special settings in the drive control program	192
High speed mode	193
Modules used	195
Fuses (IEC)	196
Calculating the short-circuit current of the installation	197
Calculation example	197
Fuses (UL)	199
Circuit breakers	199
Dimensions, weights and free space requirements	201
Losses, cooling data and noise	202
Typical power cable sizes	203
Terminal and entry data for the power cables	206
Standard drive module configuration	206
Drive modules with full-size cable connection terminals (option)	206
.....	206
Drive modules with option “Full power cabling panels to be attached to a cabinet (IP20)”	207
Terminal data for the control cables	207
Electrical power network specification	207
Motor connection data	208
Brake resistor data	208
du/dt and sine filters	208



Control panel type	209
Efficiency	209
Energy efficiency data (ecodesign)	209
Protection classes for module	209
Ambient conditions	210
Colors	211
Materials	211
Drive	211
Package materials for module products	211
Package materials for options, accessories and spare parts	211
Materials of manuals	211
Disposal	211
Applicable standards	212
Markings	212
EMC compliance (IEC/EN 61800-3)	213
Definitions	213
Category C3	214
Category C4	214
Compliance with the European Machinery Directive	215
UL checklist	216
Disclaimers	216
Generic disclaimer	216
Cybersecurity disclaimer	217

17 Dimension drawings

Contents of this chapter	219
R10 with option +D150	220
R10 with options “Full size input and output cable connection terminals and PE busbar” and “IP20 shrouds for covering the input and motor cabling area”	221
R10 with options “Full size input and output cable connection terminals and PE busbar” and “Power cable connection terminals on the right-hand side of the drive module”	222
R10 with option “Full power cabling panels”	223
R10 with option “Full power cabling panels to be attached to a cabinet (IP20)” installed into a Rittal VX25 cabinet	224
R10 with option “Flat mounting”	225
R11 with option +D150	226
R11 with options “Full size input and output cable connection terminals and PE busbar” and “IP20 shrouds for covering the input and motor cabling area”	227
R11 with options “Full size input and output cable connection terminals and PE busbar” and “Power cable connection terminals on the right-hand side of the drive module”	228
R11 with option “Full power cabling panels”	229
R11 with option “Full power cabling panels to be attached to a cabinet (IP20)” installed into a Rittal VX25 cabinet	230
R11 with option “Flat mounting”	231
Bottom plate for option +H381 in Rittal VX25 400 mm wide enclosure installation	232
Air baffles for the drive module with options “IP20 shrouds for covering the input and motor cabling area” and “Flat mounting”	233
Air baffles for option +H381 in Rittal VX25 400 mm wide enclosure installation ...	234
Material of the air baffles	234

18 Example circuit diagram

Contents of this chapter	235
Example circuit diagram	235

19 The Safe torque off function

Contents of this chapter	237
Description	237
Compliance with the European Machinery Directive and the UK Supply of Machinery (Safety) Regulations	238
Wiring	239
Activation switch	239
Cable types and lengths	239
Grounding of protective shields	239
With internal power supply	240
Dual-channel connection	240
Single-channel connection of activation switch	241
With external power supply	242
Safe torque off function not in use	243
Operation principle	244
Start-up including validation test	245
Competence	245
Validation test reports	245
Validation test procedure	245
Use	247
Maintenance	248
Competence	248
Perfect proof test procedure	249
Simplified proof test procedure	249
Fault tracing	250
Safety data	251
Terms and abbreviations	253
TÜV certificate	254
Declarations of conformity	255

20 Resistor braking

Contents of this chapter	259
When is resistor braking necessary?	259
Operation principle and hardware description	259
Planning the braking system	259
Generic guidelines	259
Resistor cables	260
Resistor thermal switch	260
Protecting the system against thermal overload	260
EMC compliance of the complete installation	261
Placing the brake resistors	261
Protecting the system in fault situations	261
Selecting the default brake system components	261
Calculation example	261
Selecting a custom brake resistor	262
Mechanical installation of resistors	263



Electrical installation	263
Measuring the insulation of the assembly	263
Connection diagram	263
Connection procedure	263
Start-up	264
Parameter settings	264
Technical data	265
Ratings	265
SAFUR resistors	265
Dimensions, weights and ordering codes	266
Terminals and cable entry data	266

21 Filters

Contents of this chapter	267
<i>du/dt</i> filters	267
When is a <i>du/dt</i> filter necessary?	267
Selection table	267
Ordering codes	268
Description, installation and technical data of the FOCH filters	268
Sine filters	268
When is a sine filter necessary?	268
Selection table	268
Ordering codes	268
Derating	268
Description, installation and technical data of the sine filters	268

22 Step-by-step drawings for an installation example of drive module with optional IP20 shrouds and input and output terminals in Rittal VX25 600 mm wide cabinet

23 Step-by-step drawings for installing full cabling panels (option) in a Rittal VX25 400 mm wide enclosure

Installation procedure	273
Installation procedure (continued)	274

24 Step-by-step drawings for a flat installation example in a Rittal 600 mm wide cabinet

25 Step-by-step drawings for option "Power cable connection terminals on the right-hand side of the module" installation example in a Rittal 600 mm wide cabinet

Further information



1

Safety instructions



Contents of this chapter

This chapter contains the safety instructions which you must obey when you install, start-up, operate and do maintenance work on the drive. If you ignore the safety instructions, injury, death or damage can occur.

Use of warnings and notes

Warnings tell you about conditions which can cause injury or death, or damage to the equipment. They also tell you how to prevent the danger. Notes draw attention to a particular condition or fact, or give information on a subject.

The manual uses these warning symbols:

**WARNING!**

Electricity warning tells about hazards from electricity which can cause injury or death, or damage to the equipment.

**WARNING!**

General warning tells about conditions other than those caused by electricity, which can cause injury or death, or damage to the equipment.

**WARNING!**

Electrostatic sensitive devices warning tells you about the risk of electrostatic discharge which can cause damage to the equipment.

General safety in installation, start-up and maintenance


These instructions are for all personnel who do work on the drive.




WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

- Keep the drive in its package until you install it. After unpacking, protect the drive from dust, debris and moisture.
- Use the required personal protective equipment: safety shoes with metal toe cap, safety glasses, protective gloves and long sleeves, etc. Some parts have sharp edges.
- Lift a heavy drive with a lifting device. Use the designated lifting points. See the dimension drawings.
- Incorrect lifting can cause danger or damage. Obey the local laws and regulations applicable to lifting, such as requirements for planning the lift, for capacity and condition of lifting equipment, and for training of personnel.
- Attach the drive cabinet to the floor to prevent it from toppling over. The cabinet has a high center of gravity. When you pull out heavy components or power modules, there is a risk of overturning. Attach the cabinet also to the wall when necessary.



- Do not use the module extraction/installation ramp with plinth heights that exceed the maximum allowed height.
- Attach the module extraction/installation ramp carefully.
- Make sure that the module does not topple over when you move it on the floor: To open the support legs, press each leg a little down and turn it aside (1, 2). Whenever possible attach the module also with chains. Do not tilt the drive module. It is heavy and its center of gravity is high. The module overturns when tilted more than 5 degrees. Do not leave the module unattended on a sloping floor.
- To prevent the drive module from falling, attach its top lifting lugs with chains to the cabinet (1) before you push the module into the cabinet and pull it from the cabinet. Push the module into the cabinet and pull it from the cabinet carefully preferably with help from another person. Keep a constant pressure with one foot on the base of the module (2) to prevent the module from falling on its back.



- Beware of hot surfaces. Some parts, such as heatsinks of power semiconductors, and brake resistors, remain hot for a while after disconnection of the electrical supply.
- Vacuum clean the area around the drive before the start-up to prevent the drive cooling fan from drawing dust inside the drive.
- Make sure that debris from drilling, cutting and grinding does not go into the drive during installation. Electrically conductive debris inside the drive can cause damage or malfunction.
- Make sure that there is sufficient cooling. See the technical data.
- Keep the cabinet doors closed when the drive is powered. With the doors open, a risk of a potentially fatal electric shock, arc flash or high-energy arc blast exists. If you cannot avoid working on a powered drive, obey the local laws and regulations on live working (including – but not limited to – electric shock and arc protection).
- Before you adjust the drive operation limits, make sure that the motor and all driven equipment can operate throughout the set operation limits.
- Before you activate the automatic fault reset or automatic restart functions of the drive control program, make sure that no dangerous situations can occur. These functions reset the drive automatically and continue operation after a fault or supply break. If these functions are activated, the installation must be clearly marked as defined in IEC/EN/UL 61800-5-1, subclause 6.5.3, for example, "THIS MACHINE STARTS AUTOMATICALLY".
- The maximum number of drive power-ups is five in ten minutes. Too frequent power-ups can damage the charging circuit of the DC capacitors.
- If you have connected safety circuits to the drive (for example, Safe torque off or emergency stop), validate them at start-up. See separate instructions for the safety circuits.
- Beware of hot air exiting from the air outlets.
- Do not cover the air inlet or outlet when the drive is running.



Note:

- If you select an external source for the start command and it is on, the drive will start immediately after fault reset unless you configure the drive for pulse start. See the firmware manual.
- If the drive is in remote control mode, you cannot stop or start the drive with the control panel.
- Only authorized persons are allowed to repair a malfunctioning drive.



Electrical safety in installation, start-up and maintenance

■ Electrical safety precautions

These electrical safety precautions are for all personnel who do work on the drive, motor cable or motor.



WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrical professional, do not do installation or maintenance work.

Do these steps before you begin any installation or maintenance work.

1. Clearly identify the work location and equipment.
2. Disconnect all possible voltage sources. Make sure that re-connection is not possible. Lock out and tag out.
 - Open the main disconnecting device of the drive.
 - Open the charging switch if present.
 - Open the disconnecter of the supply transformer. (The main disconnecting device in the drive cabinet does not disconnect the voltage from the AC input power busbars of the drive cabinet.)
 - Open the auxiliary voltage switch-disconnector (if present), and all other possible disconnecting devices that isolate the drive from dangerous voltage sources.
 - If you have a permanent magnet motor connected to the drive, disconnect the motor from the drive with a safety switch or by other means.
 - Disconnect all dangerous external voltages from the control circuits.
 - After you disconnect power from the drive, always wait 5 minutes to let the intermediate circuit capacitors discharge before you continue.
3. Protect any other energized parts in the work location against contact.
4. Take special precautions when close to bare conductors.
5. Measure that the installation is de-energized. Use a quality voltage tester. If the measurement requires removal or disassembly of shrouding or other cabinet structures, obey the local laws and regulations applicable to live working (including – but not limited to – electric shock and arc protection).
 - Before and after measuring the installation, verify the operation of the voltage tester on a known voltage source.
 - Make sure that the voltage between the drive input power terminals (L1, L2, L3) and the grounding (PE) busbar is zero.
 - Make sure that the voltage between the drive output terminals (T1/U, T2/V, T3/W) and the grounding (PE) busbar is zero.

Important! Repeat the measurement also with the DC voltage setting of the tester. Measure between each phase and ground. There is a risk of dangerous DC voltage charging due to leakage capacitances of the motor circuit. This voltage can remain charged for a long time after the drive power-off. The measurement discharges the voltage.

 - Make sure that the voltage between the drive DC terminals (UDC+ and UDC-) and the grounding (PE) terminal is zero.



6. Install temporary grounding as required by the local regulations.
7. Ask for a permit to work from the person in control of the electrical installation work.

■ Additional instructions and notes



WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrical professional, do not do installation or maintenance work.

- Keep the cabinet doors closed when the drive is powered. With the doors open, a risk of a potentially fatal electric shock, arc flash or high-energy arc blast exists.
- Make sure that the electrical power network, motor/generator, and environmental conditions agree with the drive data.
- Do not do insulation or voltage withstand tests on the drive.
- If you have a cardiac pacemaker or other electronic medical device, keep away from the area near motor, drive, and the drive power cabling when the drive is in operation. There are electromagnetic fields present which can interfere with the function of such devices. This can cause a health hazard.
- Remove the code labels attached to mechanical parts such as busbars, shrouds and sheet metal parts before installation. They may cause bad electrical connections, or, after peeling off and collecting dust in time, cause arcing or block the cooling air flow.

Note:

- When the drive is connected to the input power, the motor cable terminals and the DC bus are at a dangerous voltage.
The brake circuit, including the brake chopper (option +D150) and brake resistor (if installed) are also at a dangerous voltage.
After disconnecting the drive from the input power, these remain at a dangerous voltage until the intermediate circuit capacitors have discharged.
- External wiring can supply dangerous voltages to the relay outputs of the control units of the drive.
- The Safe torque off function does not remove the voltage from the main and auxiliary circuits. The function is not effective against deliberate sabotage or misuse.

Printed circuit boards



WARNING!

Use a grounding wristband when you handle printed circuit boards. Do not touch the boards unnecessarily. The boards contain components sensitive to electrostatic discharge.

■ Grounding

These instructions are for all personnel who are responsible for the grounding of the drive.



WARNING!

Obey these instructions. If you ignore them, injury or death, or equipment malfunction can occur, and electromagnetic interference can increase.

If you are not a qualified electrical professional, do not do grounding work.

- Always ground the drive, the motor and adjoining equipment. This is necessary for the personnel safety.
- Make sure that the conductivity of the protective earth (PE) conductors is sufficient and that other requirements are met. See the electrical planning instructions of the drive. Obey the applicable national and local regulations.
- When using shielded cables, make a 360° grounding of the cable shields at the cable entries to reduce electromagnetic emission and interference.
- In a multiple-drive installation, connect each drive separately to the protective earth (PE) busbar of the power supply.



General safety in operation

These instructions are for all personnel that operate the drive.



WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

- Keep the cabinet doors closed when the drive is powered. With the doors open, a risk of a potentially fatal electric shock, arc flash or high-energy arc blast exists.
- If you have a cardiac pacemaker or other electronic medical device, keep away from the area near motor, drive, and the drive power cabling when the drive is in operation. There are electromagnetic fields present which can interfere with the function of such devices. This can cause a health hazard.
- Give a stop command to the drive before you reset a fault. If you have an external source for the start command and the start is on, the drive will start immediately after the fault reset, unless you configure the drive for pulse start. See the firmware manual.
- Before you activate the automatic fault reset or automatic restart functions of the drive control program, make sure that no dangerous situations can occur. These functions reset the drive automatically and continue operation after a fault or supply break. If these functions are activated, the installation must be clearly marked as defined in IEC/EN/UL 61800-5-1, subclause 6.5.3, for example, "THIS MACHINE STARTS AUTOMATICALLY".

Note:

- The maximum number of drive power-ups is five in ten minutes. Too frequent power-ups can damage the charging circuit of the DC capacitors. If you need to start or stop the drive, use the control panel keys or commands through the I/O terminals of the drive.
- If the drive is in remote control mode, you cannot stop or start the drive with the control panel.

Additional instructions for permanent magnet motor drives

■ Safety in installation, start-up, maintenance

These are additional warnings concerning permanent magnet motor drives. The other safety instructions in this chapter are also valid.



WARNING!

Obey these instructions. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrical professional, do not do installation or maintenance work.

- Do not do work on the drive when a rotating permanent magnet motor is connected to it. A rotating permanent magnet motor energizes the drive including its input and output power terminals.

Before installation, start-up and maintenance work on the drive:

- Stop the drive.
- Disconnect the motor from the drive with a safety switch or by other means.
- If you cannot disconnect the motor, make sure that the motor cannot rotate during work. Make sure that no other system, like hydraulic crawling drives, can rotate the motor directly or through any mechanical connection like belt, nip, rope, etc.
- Do the steps in section [Electrical safety precautions](#) (page 19).
- Install temporary grounding to the drive output terminals (T1/U, T2/V, T3/W). Connect the output terminals together as well as to the PE.

During the start-up:

- Make sure that the motor cannot run overspeed, for example, driven by the load. Motor overspeed causes overvoltage that can damage or destroy the capacitors in the intermediate circuit of the drive.

■ Safety in operation



WARNING!

Make sure that the motor cannot run overspeed, for example, driven by the load. Motor overspeed causes overvoltage that can damage or destroy the capacitors in the intermediate circuit of the drive.





Introduction to the manual

Contents of this chapter

This chapter describes the intended audience and contents of the manual. It contains a flowchart of steps in examining the delivery, installing and commissioning the drive. The flowchart refers to chapters/sections in this manual and other manuals.

Target audience

This manual is intended for people who plan the installation, install, commission and do maintenance work on the drive, or create instructions for the end user of the drive concerning the installation and maintenance of the drive.

Read the manual before you work on the drive. You are expected to know the fundamentals of electricity, wiring, electrical components and electrical schematic symbols.

Categorization by frame size and option code

The frame size identifies information which concerns only a certain frame size of the drive. The frame size is shown on the type designation label. All frame sizes are listed in the technical data.

The option code (A123) identifies information which concerns only a certain optional selection. The options included in the drive are listed on the type designation label.

Quick installation, commissioning and operating flowchart

Task	See
<p>Plan the mechanical and electrical installation and acquire the accessories needed (cables, fuses, etc.).</p> <p>Examine the ambient conditions, ratings, required cooling air flow, input power connection, compatibility of the motor, motor connection, and other technical data.</p>	<p>Guidelines for planning the mechanical installation (page 51)</p> <p>Guidelines for planning the electrical installation (page 83)</p> <p>Technical data (page 189)</p> <p>Resistor braking (page 259)</p> <p>Option manual (if optional equipment is included)</p>
↓	
<p>Unpack and examine the units.</p> <p>Make sure that all necessary optional modules and equipment are present and correct.</p> <p>Only intact units can be started up.</p>	<p>Moving and unpacking the unit (page 71)</p> <p>If the drive module has been non-operational for more than one year, the converter DC link capacitors need to be reformed. (Reforming the capacitors (page 181))</p>
↓	
<p>Examine the installation site. Fasten the base of the cabinet to the floor.</p>	<p>Examining the installation site (page 70)</p> <p>Ambient conditions (page 210)</p>
↓	
<p>Route the cables.</p>	<p>Routing the cables (page 97)</p>
↓	
<p>Measure the insulation of the supply cable, the motor and the motor cable and the resistor cable (if present).</p>	<p>Measuring the insulation (page 110)</p>
↓	
<p><u>Standard drive modules</u></p> <ul style="list-style-type: none"> • Install the additional components into the cabinet: eg, main disconnecter, main contactor, main AC fuses, etc. • Install the drive module into the cabinet • Connect the motor cables to the drive module terminals • Connect the brake resistors and DC connection cables (if any) to the drive module terminals • If the main disconnecter is installed into the cabinet, connect it to the drive module terminals and the input power cabling to the disconnecter • Connect the cables from the drive module to the external control unit and install the control unit into the cabinet. 	<p>Mechanical installation (page 69)</p> <p>Connecting the power cables (page 112)</p> <p>Connecting the control unit to the drive module (page 117)</p> <p>Attaching the external control unit (page 81)</p> <p>Manuals for any optional equipment</p>
↓	

Task	See
<p><u>Drive modules with option “Full power cabling panels to be attached to a cabinet (IP20)”</u></p> <ul style="list-style-type: none"> • Install the cabling panels into the cabinet • Install the additional components into the cabinet: eg, main disconnect, main contactor, main AC fuses, etc. • If the main disconnect is installed into the cabinet, connect the input power cabling to it • Connect the input power cables and motor cables to the cabling panel terminals • Connect the brake resistors and DC connection cables (if any) to the cabling panel terminals • Install the drive module into the cabinet • Fasten the cabling panel busbars to the drive module busbars • Connect the cables from the drive module to the control unit and install the control unit into the cabinet. 	<p>Mechanical installation (page 69)</p> <p>Connecting the power cables (page 112)</p> <p>Connecting the control unit to the drive module (page 117)</p> <p>Attaching the external control unit (page 81)</p> <p>Manuals for any optional equipment</p>
↓	
Connect the external control cables to the drive control unit.	Connecting the control cables to the terminals of the control unit (page 119)
↓	
Examine the installation.	Installation checklist (page 165)
↓	
Commission the drive.	Commissioning (page 167)
↓	
Commission the brake chopper (if used).	Resistor braking (page 259)
↓	
Operate the drive: start, stop, speed control etc.	Appropriate firmware manual

Terms and abbreviations

Term	Description
ACS-AP-I	Industrial assistant non-Bluetooth control panel
BCU	Type of control unit
BGDR	Gate driver board
CMF	Common mode filtering
DDCS	Distributed drives communication system protocol
DTC	Direct torque control, a motor control method
EMC	Electromagnetic compatibility
EMI	Electromagnetic interference
FAIO-01	Analog I/O extension module
FEN-01	Optional TTL incremental encoder interface module
FEN-11	Optional TTL absolute encoder interface module
FEN-21	Optional resolver interface module
FEN-31	Optional HTL incremental encoder interface module
FIO-01	Optional digital I/O extension module
FIO-11	Optional analog I/O extension module
FPTC-01	Optional thermistor protection module
FPTC-02	Optional ATEX-certified thermistor protection module for potentially explosive atmospheres
Frame, frame size	Physical size of the drive or power module

Term	Description
FSE-31	Optional pulse encoder interface module for safety encoder
FSO-12, FSO-21	Optional functional safety modules
HTL	High-threshold logic
IGBT	Insulated gate bipolar transistor
IT system	Type of supply network that has no (low-impedance) connection to ground. See IEC 60364-5.
PLC	Programmable logic controller
RFI	Radio-frequency interference
SAFUR	Series of brake resistors
SOIA	Optical interface adapter board
STO	Safe torque off (IEC/EN 61800-5-2)
TN system	Type of supply network that provides a direct connection to ground
TTL	Transistor-transistor logic
ZINT	Main circuit board
ZPOW	Power supply board

Related documents

You can find manuals and other product documents in PDF format on the Internet at www.abb.com/drives/documents and with the following code and link.



ACS880-04 manuals



3

Operation principle and hardware description

Contents of this chapter

This chapter describes the operation principle and construction of the drive module packages.

Product overview


The ACS880-04XT is a drive module package (drive) for controlling asynchronous AC induction motors, permanent magnet motors, AC induction servomotors. The drive consists of two drive modules (ACS880-04 +P943) and a separate control unit.

The drive can measure the output currents of the drive modules and thus control the total output and input currents. It cannot control the input current sharing between the modules. See section *Drive connection examples* (page 33) for the supply side protection.

There needs to be enough inductance at the output of the modules for the output currents to be balanced: the modules need to be equipped with optional du/dt or sine filters, or long enough motor cables from each drive module before connecting them together. See the connection diagrams in *Connecting the power cables* (page 112).

The DC links of the drive modules are to be connected together to ensure correct operation of the drive.


The main circuit of the drive module is shown below.



Drive connection examples

6-pulse connection


No additional protection for the input and motor cables against thermal overload is needed.



6-pulse connection

No additional protection for the input and motor cables against thermal overload is needed.

WARNING!  Make sure that both contactors close at the same time. Otherwise the charging current will flow through one module only and damage the module.



1	Drive module
2	Brake chopper (option +D150)
3	External brake resistors
4	DC connection

34 Operation principle and hardware description

12-pulse connection

Protection against thermal overload for the input cables with fuses is needed.



WARNING!

Make sure that both contactors close at the same time. Otherwise the charging current will flow through one module only and damage the module.



6-pulse connection

Protection against thermal overload for the input cables with fuses is needed.



WARNING!


Make sure that both contactors close at the same time. Otherwise the charging current will flow through one module only and damage the module.



1	Drive module
2	Brake chopper (option +D150)
3	External brake resistors
4	DC connection

Layout

■ Standard drive module configuration



1	Lifting lugs
2	Fastening bracket
3	Input cable connection busbars (L1/U1, L2/V1, L3/W1) and DC+ and DC- busbars
4	Circuit board compartment
5	Output cable connection busbars (T1/U2, T2/V2, T3/W2) and brake resistor connection busbars (R+ and R- with option +D150)
6	External control unit
7	Main cooling fans
8	Pedestal
9	Retractable support legs
10	Base fastening screws
11	Handle for pulling the drive module out of the cabinet
12	Common mode filter (option +E208 as standard)
13	PE busbar
14	Pedestal guide plate
15	Telescopic extraction and insertion ramp
16	Cables for connecting the control unit to the drive modules
17	Front covers (see next page)

- Drive module configuration with IP20 shrouds (R10: 3AXD50000024563; R11: 3AXD50000024564) and full-size output cable connection terminals (3AXD50000024519)




1	Upper front cover
2	Lower front cover
3	Clear plastic shrouds attached (frame R10: option 3AXD50000024563; frame R11: option 3AXD50000024564)
4	Full-size output cable connection terminals (option 3AXD50000024519)
5	Common mode filter (option +E208 as standard)
6	Pedestal
7	External control unit

See the table below for the part descriptions.

Note: All parts that are not included in the standard configuration must be ordered separately. See the ordering codes from [Ordering information](#) (page 183).

The figure below includes these options:

- full-size input cable connection terminals and PE busbar (3AXD50000024518)
- full-size output cable connection terminals (3AXD50000024519)
- for frame R10: IP20 shrouds for covering the input and motor cabling area (3AXD50000024563)
- for frame R11: IP20 shrouds for covering the input and motor cabling area (3AXD50000024564).




38 Operation principle and hardware description

7	Full-size input power cable connection terminals (option 3AXD50000024518)
8	Full-size output power cable connection terminals (option 3AXD50000024519)
9	Grounding terminal for output power cable shields
10	Metallic shroud. With optional full-size input power cable connection terminals, the shroud includes a ground bar.
11	Fiber optic cables
12	PE (ground) terminal
13	Main cooling fans
14	Pedestal guide plate
15	Telescopic extraction and insertion ramp
16	External control unit
17	Cables for connecting the control unit to the drive modules
18	Bottom grille with mounting bracket
19	Front covers

■ **Drive module with flat mounting (option 3AXD5000024562) and with IP20 shrouds (R10: option 3AXD5000024563; R11: option 3AXD5000024564)**

Front view of an assembled drive module for flat mounting is shown below. This option adds flat mounting brackets to the standard drive module configuration. The normal pedestal has been replaced with low pedestal. You must cut the lower part of the output cabling clear plastic shroud off when low pedestal is in use.

Flat mounting position (front view)	Side view
	
1	Flat mounting bracket (two pcs). The brackets are installed to the mounting plate with 2×8 screws. Four combi screws for installing the drive module to the brackets are included in the delivery.
2	External control unit
3	Cables for connecting the control unit to the drive modules
4	Bottom grille to be installed to the base of the drive module for IP20 degree of protection
5	Grounding terminal for output cabling
<p>Note: See Drive module configuration with IP20 shrouds (R10: 3AXD5000024563; R11: 3AXD5000024564) and full-size output cable connection terminals (3AXD5000024519) (page 36) for the part descriptions.</p>	

■ **Drive module with full power cabling panels (R10: option 3AXD50000024520; R11: option 3AXD50000024561)**

Accessories	Assembled drive module
1	Input power cabling panel
2	Side guides
3	Output power cabling panel
4	Top guide plate
5	Pedestal guide plate
6	Telescopic extraction and insertion ramp
7	Shim plates for Rittal VX25 enclosure (9 pcs)
8	Rubber grommet
9	Input power cabling panel to be attached to the drive cabinet
10	Output power cabling panel to be attached to the drive cabinet
11	Front cover
12	External control unit
13	Cables for connecting the control unit to the drive modules

Note: See Step-by-step drawings for installing full cabling panels (option) in a Rittal VX25 400 mm wide enclosure (page 273) for installation of full cabling panels.

■ **Drive module configuration with power cable connection terminals on the right-hand side of the drive module (option 3AXD5000026152)**



1	Lifting lugs
2	Fastening bracket
3	Input cable connection busbars (L1/U1, L2/V1, L3/W1) and DC+ and DC- busbars
4	Circuit board compartment cooling fans
5	Circuit board compartment
6	Output cable connection busbars (T1/U2, T2/V2, T3/W2) and brake resistor connection busbars (R+ and R- with option +D150)
7	Main cooling fans
8	Pedestal
9	Retractable support legs
10	Base fastening screws
11	Handle for pulling the drive module out of the cabinet
12	PE busbar
13	Pedestal guide plate

42 Operation principle and hardware description

14	Telescopic extraction and insertion ramp
15	External control unit
16	Cables for connecting the control unit to the drive modules
17	Cover plate kit (R10: option 3AXD50000236206, R11: option 3AXD50000235582)

Note: The front covers are removed in this photo, see numbers 1 and 2 in section Drive module configuration with IP20 shrouds (R10: 3AXD50000024563; R11: 3AXD50000024564) and full-size output cable connection terminals (3AXD50000024519) (page 36).

■ Control unit

See chapter Control unit (page 127).

■ Control panel


The control panel must be ordered separately. See section Control panel (page 183) in chapter Ordering information.

For the use of the control panel, see the firmware manual or ACS-AP-I, -S, -W and ACH-AP-H, -W assistant control panels user's manual (3AUA0000085685 [English]).

For the control panel mounting platforms, see Mounting the control panel on the cabinet door (page 65).

Overview of power and control connections

The diagram shows the power connections and control interfaces of the drive unit.




44 Operation principle and hardware description

1,2,3	Analog and digital I/O extension modules, feedback interface modules and fieldbus communication modules can be inserted into slots 1, 2 and 3. See section <i>Type designation key</i> (page 47).
4	Slot 4 for RDCO-0x
5	Connector for the FSO-xx safety functions module (X12)
6	Memory unit, see <i>Replacing the memory unit</i> (page 181)
7	I/O terminal blocks, see section <i>Default I/O diagram of the inverter control unit (A41)</i> (page 130)
8	Fiber optic links to the drive modules
9	Ethernet interface (not in use)
10	Control panel, see section <i>Connecting a control panel</i> (page 119)
11	Brake resistor (optional, see chapter <i>Resistor braking</i> (page 259))
12	du/dt or sine filter (optional, see chapter <i>Filters</i> (page 267))
13	XSTO OUT terminals are wired to BGDR connectors if Safe torque off function is taken into use. See chapter <i>The Safe torque off function</i> (page 237).
14	The BCU control unit can be powered from a drive module and from an external uninterruptible power source

■ **External control unit connection cables**

The cables that are delivered with the drive module for connecting the drive module and control panel to the external control unit are shown below. The length of the cables is 3 meters (9.8 feet).

See sections [Connecting the control unit to the drive module](#) (page 117) and [Connecting a control panel](#) (page 119) for the actual connections.




Type designation labels

A type designation label is attached to the drive module. The type designation label of the drive module package is delivered in an envelope.

■ Drive module package label


The type designation label includes a rating, markings, a type designation and a serial number, which allow individual recognition of each drive module package. An example label is shown below.



1	Type designation. See section Type designation key (page 47).
2	Name and address of the manufacturer
3	Frame size
4	Cooling method
5	Degree of protection
6	Short-circuit withstand strength. See section Electrical power network specification (page 207).
7	Maximum input voltage (UL/CSA). See section Electrical power network specification (page 207).
8	Ratings, see Electrical ratings (page 189)
9	Link to product information
10	Valid markings
11	Serial number. The first digit of the serial number refers to the manufacturing plant. The next four digits refer to the unit's manufacturing year and week, respectively. The remaining digits complete the serial number so that there are no two units with the same number.

■ Drive module label

The type designation label includes a rating, markings, a type designation and a serial number, which allow individual recognition of each drive module package. An example label is shown below.



1	Type designation, see section Type designation key (page 47) .
2	Name and address of the manufacturer
3	Frame size
4	Cooling method
5	Degree of protection
6	Short-circuit withstand strength. See section Electrical power network specification (page 207) .
7	Typical drive losses when it operates at 90% of the motor nominal frequency and 100% of the drive nominal output current (calculated according to IEC61800-9-2).
8	Ratings, see section Electrical ratings (page 189)
9	Link to product information
10	Valid markings
11	Serial number. The first digit of the serial number refers to the manufacturing plant. The next four digits refer to the unit's manufacturing year and week, respectively. The remaining digits complete the serial number so that there are no two units with the same number.

Type designation key

The type designation contains information on the specifications and configuration of the drive module package and the drive module. The first digits from left express the basic drive type. The optional selections are given thereafter, separated by plus signs. Codes preceded by zero indicate the absence of the specified feature. The main selections are described below. Not all selections are available for all types. For more information, refer to the ordering instructions available separately on request.

■ Drive module package

Basic code

Code	Description
ACS880	Product series
Type	
-04XT	When no options are selected: two drive modules to be installed in an enclosure, IP00 (UL Open Type), bookshelf mounting with pedestal, external BCU control unit, cables for connecting the control unit to the drive module, build-in input choke, busbars for input, motor and DC connection, no EMC filter, common mode filter (+E208), one ramp, Primary control program, Safe torque off function, coated boards, memory stick containing all manuals with all available languages.
Size	
-xxxxA	Refer to the rating tables
Voltage range	
-3	380...415 V AC. This is indicated in the type designation label as typical input voltage level (3~ 400 V AC)
-5	380...500 V AC. This is indicated in the type designation label as typical input voltage levels (3~ 400/480/500 V AC)
-7	525...690 V AC. This is indicated in the type designation label as typical input voltage levels (3~ 525/600/690 V AC)

Option codes

Code	Description
C132	Marine type approval
C209	Marine product certification issued by Bureau Veritas
D150	Brake choppers
E200	EMC filter for 2nd environment TN (grounded) system, category C3
E201	EMC filter for 2nd environment IT (ungrounded) system, category C3
P904	Extended warranty (24 months from commissioning or 30 months from delivery)
P909	Extended warranty (36 months from commissioning or 42 months from delivery)
P911	Extended warranty (60 months from commissioning or 66 months from delivery)
Q971	ATEX-certified safe disconnection function
R700	Documentation/manuals in English
R701	German

■ Drive module

Basic code

Code	Description
ACS880	Product series
Type	
-04... +P943	When no options are selected: one drive module suitable for parallel connection, to be installed in an enclosure, IP00 (UL Open Type), bookshelf mounting with pedestal, built-in input choke, Safe torque off, boards with coating, terminals for input and motor and DC connection, common mode filter, no EMC filter, no ramp, no control program, no control unit.
Size	
-xxxxA	See the rating tables
Voltage range	
-3	380...415 V AC. This is indicated in the type designation label as typical input voltage level (3~ 400 V AC)
-5	380...500 V AC. This is indicated in the type designation label as typical input voltage levels (3~ 400/480/500 V AC)
-7	525...690 V AC. This is indicated in the type designation label as typical input voltage levels (3~ 525/600/690 V AC)

Option codes

Code	Description
C132	Marine type approved
C209	Marine product certification for BV (C132 also needed)
0B051	No IP20 shrouds for cabling area (standard for +P943 modules)
D150	Brake choppers
E200	EMC filter for 2nd environment TN (grounded) system, category C3
E201	EMC filter for second environment IT (ungrounded) system, category C3
E208	Common mode filter (standard for +P943 modules)
0H371	No full size cable connection terminals for output power cables (standard for +P943 modules)
H356	DC cable connection busbars (standard for +P943 modules)
0J400	No control panel (standard for +P943 modules)
N8200	High speed license for operation over 598 Hz
P904	Extended warranty (24 months from commissioning or 30 months from delivery)
P909	Extended warranty (36 months from commissioning or 42 months from delivery)
P911	Extended warranty (60 months from commissioning or 66 months from delivery)
P943	Drive module for parallel connection (only modules with +P943 can be connected in parallel and used as spare parts for ACS880-04XT)
Q971	ATEX-certified Safe Disconnection Function



4

Guidelines for planning the mechanical installation


Contents of this chapter

This chapter guides in planning drive cabinets and installing the drive module into a user-defined cabinet. The chapter gives cabinet layout examples and free space requirements around the module for cooling. These guidelines are essential for the safe and trouble-free use of the drive system.

For general instructions, see [Cabinet design and construction instructions for drive modules \(3AUA0000107668 \[English\]\)](#).


Planning the layout

- Layout example with IP20 shrouds (option)




3AXD50000023774

- **Layout example with IP20 shrouds (option) and one “drive module with power cable connection terminals on the right-hand side” (option)**



■ **Layout example, doors closed**


This diagram shows a cabinet layout example with the input power cable entry from top and the motor cable entry from bottom.



1a*)	Air inlet for the drive module
1b)	Air inlet for the other equipment
1c*)	Air inlet for circuit boards and DC and output busbars
2a*)	Air outlet with an extra exhaust fan for the drive module
2b*)	Air outlet for the other equipment
2c*)	Air outlet for the drive module and other equipment on the cabinet roof. An exhaust fan if needed. ABB recommends this alternative instead of 2a.
3	Drive control panel with DPMP-01 mounting platform (option). The control panel is connected to the drive module control unit inside the cabinet.
4	Contactor control switch and emergency stop switch (connected to the contactor control circuit inside the cabinet)
5	Operating handle of the disconnecter
6	Rubber grommets for degree of protection
7	Roof air flow viewed from top
*)	Note: The sizes of the air inlet and outlet gratings are critical for proper cooling of the drive module. For losses and cooling data requirements, see the technical data.

■ **Layout example, doors open (standard configuration)**

This diagram shows a layout example for standard drive modules.



56 Guidelines for planning the mechanical installation


1	Supporting frame of the cabinet	8	Motor cable including the protective ground conductor of the drive module
2	Vertical (2a, 2b) and horizontal (2c, 2d) air baffles that separate the cool and hot areas (leakproof lead-throughs)	9	Drive module control unit
2e	Optional air baffle that is needed when there is no fan on the lower part of the cabinet door (see 1b (page 54))	10	External control cables
		11	Grounding screws
3	Cabinet grounding busbar (PE)	12	Alternative to grounding screws (11)
4	Input power cable including the protective ground conductor (PE) of the drive	13	Air flow to the roof
5	Disconnecter and fuses	14	Air flow through the drive module
6	Contactors	15	Air flow to circuit boards and DC and output busbars
7	Drive module	16	Air flow to the brake option

Note: The power cable shields can also be grounded to the drive module grounding terminals.

See also section [Free space requirements \(page 65\)](#) and [Drive modules cabinet design and construction instructions \(3AUA0000107668 \[English\]\)](#).

■ **Layout example, doors open with IP20 shrouds (option)**

Layout example for one module is shown below.




1	Supporting frame of the cabinet	8	Motor cable including the protective ground conductor of the drive module
2a	Vertical (2a) and horizontal (2b) air baffles that separate the cool and hot areas (leakproof lead-throughs).	9	Drive module control unit
2b		10	External control cables
2c	Optional air baffle that is needed when there is no fan on the lower part of the cabinet door (see 1b (page 54))	11	Grounding screws
3	Cabinet grounding busbar (PE)	12	Alternative to grounding screws (11)
4	Input power cable including the protective ground conductor (PE) of the drive	13	Air flow to the roof
5	Disconnecter and fuses	14	Air flow through the drive module
6	Contactor	15	Air flow to circuit boards and DC and output busbars
7	Drive module	16	Air flow to the brake option

See also section [Free space requirements \(page 65\)](#) and [Drive modules cabinet design and construction instructions \(3AUA0000107668 \[English\]\)](#).

■ **Layout example, doors open with IP20 shrouds (option) and “drive module with power cable connection terminals on the right-hand side” (option)**

Layout example for one drive module is shown below.




1	Supporting frame of the cabinet	8	Motor cable including the protective ground conductor of the drive module
2a	Vertical (2a) and horizontal (2b) air baffles that separate the cool and hot areas (leakproof lead-throughs).	9	Drive module control unit
2b		10	External control cables
2c	Optional air baffle that is needed when there is no fan on the lower part of the cabinet door (see 1b (page 54))	11	Grounding screws
3	Cabinet grounding busbar (PE)	12	Alternative to grounding screws (11)
4	Input power cable including the protective ground conductor (PE) of the drive	13	Air flow to the roof
5	Disconnecter and fuses	14	Air flow through the drive module
6	Contactor	15	Air flow to circuit boards and DC and output busbars
7	Drive module	16	Air flow to the brake option

See also section [Free space requirements \(page 65\)](#) and [Drive modules cabinet design and construction instructions \(3AUA0000107668 \[English\]\)](#).


■ **Bookshelf mounting with IP20 shrouds (option)**

This diagram shows the air baffle position inside an example cabinet. For dimensions of the baffle, see Air baffles for the drive module with options “IP20 shrouds for covering the input and motor cabling area” and “Flat mounting” (page 233).



■ **Bookshelf mounting (standard drive module configuration)**

This diagram shows the air baffle position inside an example cabinet. For the descriptions, see the next page.




1a	Air flow to the drive module, max. 40 °C (104 °F)	3	Drive module
1b	Air flow to the drive circuit boards and DC and output busbars	4	Disconnecter and fuses
2a	Vertical air baffle that separates the cool and hot areas in the cabinet	5	Contactator
2b	Vertical air baffle	6	Drive module control unit
2c	Upper horizontal air baffle	7	Air flow out
2d	Lower horizontal air baffle	8	Note: The upper grating in the cabinet door must be located in the area marked with the horizontal shading lines for correctly directed cooling air flow to the circuit board compartment of the drive module.
2e	Optional air baffle that is needed when there is no fan on the lower part of the cabinet door (see 1b (page 54))	9	Cabinet grounding busbar (PE)

■ **Bookshelf mounting with option “Full power cabling panels to be attached to a cabinet (IP20)”**

See Step-by-step drawings for installing full cabling panels (option) in a Rittal VX25 400 mm wide enclosure (page 273) and dimension drawing for R10 with option “Full power cabling panels to be attached to a cabinet (IP20)” installed into a Rittal VX25 cabinet (page 224) or dimension drawing for R11 with option “Full power cabling panels” (page 229).

■ Flat mounting (option)

This diagram shows the air baffle position inside an example cabinet. For dimensions of the baffle, see Air baffles for the drive module with options “IP20 shrouds for covering the input and motor cabling area” and “Flat mounting” (page 233).




1a	Air flow to the drive module, max. 40 °C (104 °F)	4	Disconnecter and fuses
1b	Air flow to the drive circuit boards and DC and output busbars	5	Contactors
2a	Horizontal air baffles that guide cooling air flow	6	Drive module control unit
2b	Horizontal air baffle	7	Air flow out
2c	Vertical air baffle	8	Air gap between the drive module front and cabinet wall for cooling air flow

Guidelines for planning the mechanical installation 63

2d	Vertical air baffle that guides air flow to the inside the drive module	9	Cabinet grounding busbar (PE)
3	Drive module	-	-

■ Flat mounting (option) with IP20 shrouds (option)

This diagram shows the air baffle position inside an example cabinet. For dimensions of the baffle, see Air baffles for the drive module with options “IP20 shrouds for covering the input and motor cabling area” and “Flat mounting” (page 233).



1a	Air flow to the drive module, max. 40 °C (104 °F)	5	Contactors
1b	Air flow to the drive circuit boards and DC and output busbars	6	Drive module control unit
2	Horizontal air baffle	7	Air flow out
3	Drive module	8	Air gap between the drive module front and cabinet wall for cooling air flow
4	Disconnectors and fuses	9	Cabinet grounding busbar (PE)

Mounting the control panel on the cabinet door

You can use a mounting platform to mount the control panel on the cabinet door. Mounting platforms for control panels are available as options from ABB. For more information, see

Manual	Code (English)
DPMP-01 mounting platform for control panels installation guide	3AUA0000100140
DPMP-02/03 mounting platform for control panels installation guide	3AUA0000136205
DPMP-04 and DPMP-05 mounting platform for control panels installation guide	3AXD50000308484
DPMP-06/07 mounting platform for control panels installation guide	3AXD50000289561


		
DPMP-01	DPMP-02	DPMP-04
IP54 (UL Type 12) when control panel is mounted IP20 (UL Open Type) when control panel is not mounted	IP65 (UL Type 12) when control panel is mounted IP20 (UL Open Type) when control panel is not mounted	IP66 (UL Types 3, 3R and 4) when mounted inside or outside the cabinet door

Free space requirements

Free space around the drive module is needed to make sure that sufficient cooling air flows through the module and the module cools correctly.

■ **Free space at the top of the drive module**

The free space requirement at the top of the module is shown below.



■ **Free space around the drive module**

Bookshelf installation: 10 mm (0.39 in) free space around the drive module is required from the cabinet back panel and front door. No free space for cooling is required on the left- and right-hand sides of the module.

The module can be installed in a cabinet with the following dimensions:

- width 400 mm (15.75 in)
- depth 600 mm (23.62 in)
- height 2000 mm (78.74 in).

■ **Free space below the drive module**

Standard drive module: No free space for cooling is required at the bottom of the drive module.

Installation positions other than vertical

You can install the drive module on its back. Make sure that the hot cooling air which flows upwards from the module does not cause danger.

For other installation positions, contact ABB.

ABB air inlet and outlet kits

See Cabinet ventilation (page 184).

5

Mechanical installation

Contents of this chapter

This chapter describes how to install the drive module mechanically without the clear plastic shrouds. The shrouds are attached after the power cabling.




Safety




WARNING!

Lift the drive module only by the lifting lugs:



Make sure that the module does not topple over when you move it on the floor: To open the support legs, press each leg a little down (1, 2) and turn it aside. Whenever possible attach the module also with chains. Do not tilt the module. It is heavy and its center of gravity is high. The module overturns from a sideways tilt of 5 degrees. Do not leave the module unattended on a sloping floor.



Examining the installation site

Examine the installation site. Make sure that:

- The installation site is sufficiently ventilated or cooled to remove heat from the drive. See the technical data.
- The ambient conditions of the drive meet the specifications. See the technical data.

- The material behind, above and below the drive is non-flammable.
- There is sufficient free space around the drive for cooling, maintenance, and operation. See the free space specifications for the drive.
- Make sure that there are no sources of strong magnetic fields such as high-current single-core conductors or contactor coils near the drive. A strong magnetic field can cause interference or inaccuracy in the operation of the drive.

Moving and unpacking the unit



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.


■ Moving the drive module

Move the drive module in its transport package to the installation site.


■ Unpacking

Unpack the package as follows, see section *Package drawings* (page 72):

- Open the lid (10)
- Remove the package sleeve by lifting it (8)
- Unpack the additional boxes
- Remove the pedestal guide plate as shown below.



Package drawings



Transport package contents

1	Support (2 pcs)
2	Assembly cover, cardboard
3	Cardboard tray
4	Manual package
5	Cardboard support
6	Ramp packing support
7	Ramp box. See below for the box contents.

8	Package sleeve, cardboard
9	Wooden pallet
10	Wooden package lid
11	Plywood support (2 pcs)
12	Plastic bag
13	Drive module with factory installed options and multilingual residual voltage warning sticker, top guide plate, pedestal guide plate, fastening screws in a plastic bag, external control unit and factory installed option modules, control panel and cable or control panel with door mounting kit (option), delivery documents, printed multilingual quick start-up guide and memory stick containing all manuals.

3AXD10000407466

Box content of option "Power cable connection terminals on the right-hand side": Top and bottom brackets and handle

1	Top bracket
2	Bottom bracket
3	Handle
4	Screw package
5	Cardboard package



74 Mechanical installation

3AXD50000013807

Box contents of option "IP20 shrouds for covering the input and motor cabling area"	
1	Paper fill
2	Clear plastic shroud for output power cabling
3	Mounting bracket for bottom grille
4	Cardboard box bottom
5	Cardboard box cover
6	Bottom grille
7	Support
8	Straps
9	Screws in a plastic bag
10	Back clear plastic shroud (upper)
11	Back clear plastic shroud (lower)
12	Front clear plastic shroud
13	Clear plastic shroud for input power cabling
14	Top clear plastic shroud
15	Entry clear plastic shroud for side input cabling
16	Clear plastic bottom shroud 1
17	Clear plastic bottom shroud 2
18	Metallic shroud

3AXD50000478613


Box contents of option "Full power cabling panels to be attached to a cabinet (IP20)": Input power cabling panel parts	
1	Screw package
2	Paper fill
3	Grounding busbar to be connected to the input power cabling panel and the drive module
4	Bracket
5	Cardboard tray
6	Top cardboard cover
7	Rubber grommet
8	Support
9	Bands
10	Plastic bag
11	Input power cabling panel
12	Top guide

Box contents of option “Full size output cable connection terminals”	
1	Paper fill
2	Output cable connection terminal T3/W2
3	Output cable connection terminal T2/V2
4	Output cable connection terminal T1/U2
5	Grounding terminal
6	Cardboard box
7	Screws and insulators in a plastic bag

Box contents of option “Full size input cable connection terminals and PE bus-bar”	
1	Metallic shroud with ground bar
2	Paper fill
3	Input cable connection terminal L3/W1
4	Input cable connection terminal L2/V1
5	Input cable connection terminal L1/U1
6	Cardboard box
7	Screws and insulators in a plastic bag




76 Mechanical installation



Ramp box contents


- | | |
|---|--|
| 1 | Screw package |
| 2 | Telescopic extraction and insertion ramp |
| 3 | Cardboard box |



Accessory box contents: Assembly kit 3AXD50000453900

- | | |
|---|--|
| 1 | Screw package, includes also spacers for FSO module installation |
| 2 | Rubber grommets for control unit cable entry holes in the middle front cover of the drive module |
| 3 | Fastener for Rittal VX25 enclosure |
| 4 | Bracket for attaching the drive module from top (3AUA0000096082). The bracket brings a gap for cooling air flow and prevents the drive module screws from chafing the plate. |
| 5 | Cardboard box |






■ **Examining the delivery**

Examine that all the items are present and there are no signs of damage. Read the data on the type designation label of the drive module to make sure that the module is of the correct type.

■ **Lifting the drive module**

Lift the drive module only by the lifting lugs.



Installation alternatives

You can install the drive module into a cabinet using different procedures depending on the drive configuration. Obey the general power and control cable installation instructions that we give and see the installation example of your drive configuration in the following chapters.



■ **Standard drive module configuration (bookshelf mounting)**

The power cables can be connected directly to the drive module input and output terminals with cable lugs or by busbars. The drive module can also be installed self standing on the floor in an electrical equipment room when the power cable terminals and electrical parts are protected against contact and the drive module is grounded properly. For an installation example, see [Installation example – standard, optional IP20 shrouds and power cable connection terminals](#) (page 141).

■ **Flat mounting**

You can attach the drive module with option "Flat mounting" to the cabinet mounting plate in flat position:

- with bolts through the mounting holes at the top and bottom of the module,
- or you can, first, attach the mounting brackets delivered with the option to the cabinet mounting plate and then attach the drive module to the mounting brackets with screws.

See the dimension drawing for R10 with option "Flat mounting" (page 225) or for R11 with option "Flat mounting" (page 231).

For option +0H354 (no pedestal): Make sure that the cabinet mounting plate and frame are strong enough to carry the weight of the drive module. See [Dimensions, weights and free space requirements](#) (page 201).


For an installation example on how to install the drive module without pedestal in flat position in a Rittal VX25 enclosure, see [Step-by-step drawings for a flat installation example in a Rittal 600 mm wide cabinet](#) (page 277).

■ **Option "Full-size input power cable connection terminals and PE (ground) busbar"**

Connect the input power cable connection terminals as shown in [Step-by-step drawings for an installation example of drive module with optional IP20 shrouds and input and output terminals in Rittal VX25 600 mm wide cabinet](#) (page 269).



Install the metallic shroud with ground bar as shown below.



- **Option “Full power cabling panels to be attached to a cabinet (IP20)”**

For an installation example into a Rittal VX25 enclosure including power cable connection procedure, see *Step-by-step drawings for installing full cabling panels (option) in a Rittal VX25 400 mm wide enclosure (page 273)*.

- **Option “Power cable connection terminals on the right-hand side of the drive module”**


For an installation example into a Rittal VX25 enclosure, see *Step-by-step drawings for option "Power cable connection terminals on the right-hand side of the module" installation example in a Rittal 600 mm wide cabinet (page 279)*. Otherwise, install the drive module as the standard drive module configuration.

- **Attaching the drive module to a mounting plate or wall**

Use the support bracket 3AUA0000096082 (included in the assembly kit 3AXD50000453900) if you attach the drive module directly to a mounting plate or wall. The support bracket prevents the drive module screws from chafing against the plate.




80 Mechanical installation



■ Alternatives for grounding the drive module


You can ground the drive module from its top back to the cabinet frame with these alternatives:

1. from the grounding hole
2. to a Rittal punched section with the fastening bracket.



■ Installing the bottom grille for IP20 degree of protection

If IP20 degree of protection is needed from the bottom side, install the bottom grille as shown below.



■ Attaching the external control unit

The drive control unit can be attached on a mounting plate or onto a DIN rail.

Connect the fiber optic, power supply and BGDR cables from the drive module to the external control unit before you attach the control unit. See section [Connecting the control unit to the drive module](#) (page 117)

See [BCU-02/12/22 control units hardware manual \(3AUA0000113605 \[English\]\)](#).

■ Attaching the type designation label

Attach the drive module package type designation label delivered with the drive modules to the cabinet door.



6

Guidelines for planning the electrical installation

Contents of this chapter

This chapter contains guidelines for planning the electrical installation of the drive.

Limitation of liability

The installation must always be designed and made according to applicable local laws and regulations. ABB does not assume any liability whatsoever for any installation which breaches the local laws and/or other regulations. Furthermore, if the recommendations given by ABB are not followed, the drive may experience problems that the warranty does not cover.

Selecting the main supply disconnecting device

You must equip the drive with a main supply disconnecting device which meets the local safety regulations. You must be able to lock the disconnecting device to the open position for installation and maintenance work.

■ European Union and United Kingdom

To comply with European Union directives and United Kingdom regulations related to standard EN 60204-1, the disconnecting device must be one of these types:

- switch-disconnector of utilization category AC-23B (IEC 60947-3)
 - disconnector that has an auxiliary contact that in all cases causes switching devices to break the load circuit before the opening of the main contacts of the disconnector (EN 60947-3)
 - circuit-breaker suitable for isolation in accordance with IEC 60947-2.
-

■ North America

Installations must be compliant with NFPA 70 (NEC)¹⁾ and/or Canadian Electrical Code (CE) along with state and local codes for your location and application.

¹⁾ National Fire Protection Association 70 (National Electric Code).

■ Other regions

The disconnecting device must conform to the applicable local safety regulations.

Selecting the main contactor

You can equip the drive with a main contactor.

Follow these guidelines when you select a customer-defined main contactor:

- Dimension the contactor according to the nominal voltage and current of the drive. Also consider the environmental conditions such as surrounding air temperature.
- IEC devices only: Select contactor with utilization category AC-1 (number of operations under load) according to IEC 60947-4.
- Consider the application life time requirements.

■ North America

Installations must be compliant with NFPA 70 (NEC)¹⁾ and/or Canadian Electrical Code (CE) along with state and local codes for your location and application.

¹⁾ National Fire Protection Association 70 (National Electric Code).

■ Other regions

The disconnecting device must conform to the applicable local safety regulations.

Examining the compatibility of the motor and drive

Use asynchronous AC induction motors, permanent magnet synchronous motors, AC induction servomotors or ABB synchronous reluctance motors (SynRM motors) with the drive.

Select the motor size and drive type from the rating table on basis of the AC line voltage and motor load. You can find the rating table in the appropriate hardware manual. You can also use the DriveSize PC tool.

Make sure that the motor can be used with an AC drive. See [Requirements tables \(page 85\)](#). For basics of protecting the motor insulation and bearings in drive systems, see [Protecting the motor insulation and bearings \(page 85\)](#).

Note:

- Consult the motor manufacturer before using a motor with nominal voltage that differs from the AC line voltage connected to the drive input.
 - The voltage peaks at the motor terminals are relative to the supply voltage of the drive, not to the drive output voltage.
-

■ Protecting the motor insulation and bearings

The drive employs modern IGBT inverter technology. Regardless of frequency, the drive output comprises pulses of approximately the drive DC bus voltage with a very short rise time. The pulse voltage can almost double at the motor terminals, depending on the attenuation and reflection properties of the motor cable and the terminals. This can cause additional stress on the motor and motor cable insulation.

Modern variable speed drives with their fast rising voltage pulses and high switching frequencies can generate current pulses that flow through the motor bearings. This can gradually erode the bearing races and rolling elements.

du/dt filters protect motor insulation system and reduce bearing currents. Common mode filters mainly reduce bearing currents. Insulated N-end (non-drive end) bearings protect the motor bearings.

■ Requirements tables

These tables show how to select the motor insulation system and when a drive du/dt and common mode filters and insulated N-end (non-drive end) motor bearings are required. Ignoring the requirements or improper installation may shorten motor life or damage the motor bearings and voids the warranty.

Requirements for ABB motors, $P_n < 100$ kW (134 hp)

See also [Abbreviations](#) (page 88).

Motor type	Nominal AC line voltage	Requirement for	
		Motor insulation system	ABB du/dt and common mode filters, insulated N-end motor bearings
			$P_n < 100$ kW and frame size < IEC 315
			$P_n < 134$ hp and frame size < NEMA 500
Random-wound M2_, M3_ and M4_	$U_n \leq 500$ V	Standard	-
	500 V < $U_n \leq 600$ V	Standard	+ du/dt
		Reinforced	-
	600 V < $U_n \leq 690$ V (cable length ≤ 150 m)	Reinforced	+ du/dt
600 V < $U_n \leq 690$ V (cable length > 150 m)	Reinforced	-	
Form-wound HX_ and AM_	380 V < $U_n \leq 690$ V	Standard	n.a.
Old ¹⁾ form-wound HX_ and modular	380 V < $U_n \leq 690$ V	Check with the motor manufacturer.	+ N + du/dt with voltages over 500 V + CMF
Random-wound HX_ and AM_ ²⁾	0 V < $U_n \leq 500$ V	Enamelled wire with fiber glass taping	+ N + CMF
	500 V < $U_n \leq 690$ V		+ N + du/dt + CMF
HDP	Consult the motor manufacturer.		

1) manufactured before 1.1.1998

2) For motors manufactured before 1.1.1998, check for additional instructions with the motor manufacturer.

Requirements for ABB motors, $P_n \geq 100$ kW (134 hp)

See also Abbreviations (page 88).

Motor type	Nominal AC line voltage	Requirement for		
		Motor insulation system	ABB du/dt and common mode filters, insulated N-end motor bearings	
			$100 \text{ kW} \leq P_n < 350 \text{ kW}$ or $\text{IEC } 315 \leq \text{frame size} < \text{IEC } 400$	$P_n \geq 350 \text{ kW}$ or $\text{frame size} \geq \text{IEC } 400$
			$134 \text{ hp} \leq P_n < 469 \text{ hp}$ or $\text{NEMA } 500 \leq \text{frame size} \leq \text{NEMA } 580$	$P_n \geq 469 \text{ hp}$ or $\text{frame size} > \text{NEMA } 580$
Random-wound M2_, M3_ and M4_	$U_n \leq 500 \text{ V}$	Standard	+ N	+ N + CMF
	$500 \text{ V} < U_n \leq 600 \text{ V}$	Standard	+ N + du/dt	+ N + du/dt + CMF
		Reinforced	+ N	+ N + CMF
	$600 \text{ V} < U_n \leq 690 \text{ V}$ (cable length $\leq 150 \text{ m}$)	Reinforced	+ N + du/dt	+ N + du/dt + CMF
$600 \text{ V} < U_n \leq 690 \text{ V}$ (cable length $> 150 \text{ m}$)	Reinforced	+ N	+ N + CMF	
Form-wound HX_ and AM_	$380 \text{ V} < U_n \leq 690 \text{ V}$	Standard	+ N + CMF	$P_n < 500 \text{ kW}$: + N + CMF
				$P_n \geq 500 \text{ kW}$: + N + du/dt + CMF
Old ¹⁾ form-wound HX_ and modular	$380 \text{ V} < U_n \leq 690 \text{ V}$	Check with the motor manufacturer.	+ N + du/dt with voltages over 500 V + CMF	
Random-wound HX_ and AM_ ²⁾	$0 \text{ V} < U_n \leq 500 \text{ V}$	Enamelled wire with fiber glass taping	+ N + CMF	
	$500 \text{ V} < U_n \leq 690 \text{ V}$		+ N + du/dt + CMF	
HDP	Consult the motor manufacturer.			

1) manufactured before 1.1.1998

2) For motors manufactured before 1.1.1998, check for additional instructions with the motor manufacturer.

Requirements for non-ABB motors, $P_n < 100$ kW (134 hp)

See also Abbreviations (page 88).

Motor type	Nominal AC line voltage	Motor insulation system	Requirement for
			ABB du/dt and common mode filters, insulated N-end motor bearings
			$P_n < 100$ kW and frame size < IEC 315
			$P_n < 134$ hp and frame size < NEMA 500
Random-wound and form-wound	$U_n \leq 420$ V	Standard: $\hat{U}_{LL} = 1300$ V	-
	420 V < $U_n \leq 500$ V	Standard: $\hat{U}_{LL} = 1300$ V	+ du/dt
		Reinforced: $\hat{U}_{LL} = 1600$ V, 0.2 μ s rise time	-
	500 V < $U_n \leq 600$ V	Reinforced: $\hat{U}_{LL} = 1600$ V	+ du/dt
		Reinforced: $\hat{U}_{LL} = 1800$ V	-
	600 V < $U_n \leq 690$ V	Reinforced: $\hat{U}_{LL} = 1800$ V	+ du/dt
		Reinforced: $\hat{U}_{LL} = 2000$ V, 0.3 μ s rise time ¹⁾	-

¹⁾ If the intermediate DC circuit voltage of the drive is increased from the nominal level due to long term resistor braking cycles, check with the motor manufacturer if additional output filters are needed.

Requirements for non-ABB motors, $P_n \geq 100$ kW (134 hp)

See also Abbreviations (page 88).

Motor type	Nominal AC line voltage	Motor insulation system	Requirement for	
			ABB du/dt and common mode filters, insulated N-end motor bearings	
			$100 \text{ kW} \leq P_n < 350 \text{ kW}$ or $IEC 315 \leq \text{frame size} < IEC 400$	$P_n \geq 350 \text{ kW}$ or $\text{frame size} \geq IEC 400$
			$134 \text{ hp} \leq P_n < 469 \text{ hp}$ or $NEMA 500 \leq \text{frame size} \leq NEMA 580$	$P_n \geq 469 \text{ hp}$ or $\text{frame size} > NEMA 580$
Random-wound and form-wound	$U_n \leq 420 \text{ V}$	Standard: $\hat{U}_{LL} = 1300 \text{ V}$	+ N or CMF	+ N + CMF
	$420 \text{ V} < U_n \leq 500 \text{ V}$	Standard: $\hat{U}_{LL} = 1300 \text{ V}$	+ du/dt + (N or CMF)	+ N + du/dt + CMF
		Reinforced: $\hat{U}_{LL} = 1600 \text{ V}$, 0.2 μs rise time	+ N or CMF	+ N + CMF
	$500 \text{ V} < U_n \leq 600 \text{ V}$	Reinforced: $\hat{U}_{LL} = 1600 \text{ V}$	+ du/dt + (N or CMF)	+ N + du/dt + CMF
		Reinforced: $\hat{U}_{LL} = 1800 \text{ V}$	+ N or CMF	+ N + CMF
	$600 \text{ V} < U_n \leq 690 \text{ V}$	Reinforced: $\hat{U}_{LL} = 1800 \text{ V}$	+ du/dt + N	+ N + du/dt + CMF
		Reinforced: $\hat{U}_{LL} = 2000 \text{ V}$, 0.3 μs rise time ¹⁾	+ N + CMF	+ N + CMF

¹⁾ If the intermediate DC circuit voltage of the drive is increased from the nominal level due to long term resistor braking cycles, check with the motor manufacturer if additional output filters are needed.

Abbreviations

Abbr.	Definition
U_n	Nominal AC line voltage
\hat{U}_{LL}	Peak line-to-line voltage at motor terminals which the motor insulation must withstand
P_n	Motor nominal power
du/dt	du/dt filter at the output of the drive
CMF	Common mode filter of the drive
N	N-end bearing: insulated motor non-drive end bearing
n.a.	Motors of this power range are not available as standard units. Consult the motor manufacturer.

Availability of du/dt filter and common mode filter by drive type

Product type	Availability of du/dt filter	Availability of common mode filter (CMF)
ACS880-04XT	Ordered separately, see du/dt filters (page 267)	Standard

Additional requirements for explosion-safe (EX) motors

If you use an explosion-safe (EX) motor, obey the rules in the requirements table above. In addition, consult the motor manufacturer for any further requirements.

Additional requirements for ABB motors of types other than M2_, M3_, M4_, HX_ and AM_

Use the selection criteria given for non-ABB motors.

Additional requirements for braking applications

When the motor brakes the machinery, the intermediate circuit DC voltage of the drive increases, the effect being similar to the motor supply voltage increasing by up to 20 percent. Consider this voltage increase when specifying the motor insulation requirements if the motor will be braking a large part of its operation time.

Example: Motor insulation requirement for a 400 V AC line voltage application must be selected as if the drive were supplied with 480 V.

Additional requirements for ABB high-output and IP23 motors

The rated output power of high output motors is higher than what is stated for the particular frame size in EN 50347 (2001).

This table shows the requirements for protecting the motor insulation and bearings in drive systems for ABB random-wound motor series (for example, M3AA, M3AP and M3BP).

Nominal AC supply voltage	Requirement for			
	Motor insulation system	ABB du/dt and common mode filters, insulated N-end motor bearings		
		$P_n < 100$ kW	100 kW $\leq P_n < 200$ kW	$P_n \geq 200$ kW
		$P_n < 140$ hp	140 hp $\leq P_n < 268$ hp	$P_n \geq 268$ hp
$U_n \leq 500$ V	Standard	-	+ N	+ N + CMF
500 V $< U_n \leq 600$ V	Standard	+ du/dt	+ du/dt + N	+ du/dt + N + CMF
	or			
600 V $< U_n \leq 690$ V	Reinforced	-	+ N	+ N + CMF
	Reinforced	+ du/dt	+ du/dt + N	+ du/dt + N + CMF

Additional requirements for non-ABB high-output and IP23 motors

The rated output power of high-output motors is higher than what is stated for the particular frame size in EN 50347 (2001).

If you plan to use a non-ABB high-output motor or an IP23 motor, consider these additional requirements for protecting the motor insulation and bearings in drive systems:

90 Guidelines for planning the electrical installation

- If motor power is below 350 kW: Equip the drive and/or motor with the filters and/or bearings according to the table below.
- If motor power is above 350 kW: Consult the motor manufacturer.


Nominal AC supply voltage U_n	Requirement for		
	Motor insulation system	ABB du/dt and common mode filters, insulated N-end motor bearings	
		$P_n < 100$ kW or frame size < IEC 315	100 kW < $P_n < 350$ kW or IEC 315 < frame size < IEC 400
	$P_n < 134$ hp or frame size < NEMA 500	134 hp < $P_n < 469$ hp or NEMA 500 < frame size < NEMA 580	
$U_n \leq 420$ V	Standard: $\hat{U}_{LL} = 1300$ V	+ N or CMF	+ N or CMF
420 V < $U_n < 500$ V	Standard: $\hat{U}_{LL} = 1300$ V	+ du/dt + (N or CMF)	+ N + du/dt + CMF
	or Reinforced: $\hat{U}_{LL} = 1600$ V, 0.2 microsecond rise time	+ N or CMF	+ N or CMF
500 V < $U_n \leq 600$ V	Reinforced: $\hat{U}_{LL} = 1600$ V	+ du/dt + (N or CMF)	+ N + du/dt + CMF
	or Reinforced: $\hat{U}_{LL} = 1800$ V	+ N or CMF	+ N + CMF
600 V < $U_n \leq 690$ V	Reinforced: $\hat{U}_{LL} = 1800$ V	+ N + du/dt	+ N + du/dt + CMF
	Reinforced: $\hat{U}_{LL} = 2000$ V, 0.3 microsecond rise time ¹⁾	+ N + CMF	+ N + CMF

¹⁾ If the intermediate DC circuit voltage of the drive is increased from the nominal level due to long term resistor braking cycles, check with the motor manufacturer if additional output filters are needed.

Additional data for calculating the rise time and the peak line-to-line voltage

The diagrams below show the relative peak line-to-line voltage and rate of change of voltage as a function of the motor cable length. If you need to calculate the actual peak voltage and voltage rise time considering the actual cable length, proceed as follows:

- Peak line-to line voltage: Read the relative \hat{U}_{LL}/U_n value from the diagram below and multiply it by the nominal supply voltage (U_n).
- Voltage rise time: Read the relative values \hat{U}_{LL}/U_n and $(du/dt)/U_n$ from the diagram below. Multiply the values by the nominal supply voltage (U_n) and substitute into equation $t = 0.8 \cdot \hat{U}_{LL}/(du/dt)$.



Additional note for sine filters

A sine filter also protects the motor insulation system. The peak phase-to-phase voltage with a sine filter is approximately $1.5 \cdot U_N$.

Selecting the power cables

■ General guidelines

Select the input power and motor cables according to local regulations.

- **Current:** Select a cable capable of carrying the maximum load current and suitable for the prospective short-circuit current provided by the supply network. The method of installation and ambient temperature affect the cable current carrying capacity. Obey local regulations and laws.
- **Temperature:** For an IEC installation, select a cable rated for at least 70 °C (158 °F) maximum permissible temperature of conductor in continuous use. For North America, select a cable rated for at least 75 °C (167 °F).
Important: For certain product types or option configurations higher temperature rating may be required. See the technical data for details.
- **Voltage:** 600 V AC cable is accepted for up to 500 V AC. 750 V AC cable is accepted for up to 600 V AC. 1000 V AC cable is accepted for up to 690 V AC.

To comply with the EMC requirements of the CE mark, use one of the preferred cable types. See Preferred power cable types (page 92).

Symmetrical shielded cable reduces electromagnetic emission of the whole drive system as well as the stress on motor insulation, bearing currents and wear.

Metal conduit reduces electromagnetic emission of the whole drive system.




■ **Typical power cable sizes**

See the technical data.

■ **Power cable types**


Preferred power cable types


This section presents the preferred cable types. Make sure that the selected cable type also complies with local/state/country electrical codes.

Cable type	Use as input power cabling	Use as motor cabling and as brake resistor cabling
 <p>Symmetrical shielded (or armored) cable with three phase conductors and concentric PE conductor as shield (or armor)</p>	Yes	Yes
 <p>Symmetrical shielded (or armored) cable with three phase conductors and symmetrically constructed PE conductor and a shield (or armor)</p>	Yes	Yes
 <p>Symmetrical shielded (or armored) cable with three phase conductors and a shield (or armor), and separate PE conductor/cable¹⁾</p>	Yes	Yes

¹⁾ A separate PE conductor is required if the conductivity of the shield (or armor) is not sufficient for the PE use.

Alternate power cable types

Cable type	Use as input power cabling	Use as motor cabling and as brake resistor cabling
 <p>Four-conductor cabling in PVC conduit or jacket (three phase conductors and PE)</p>	Yes with phase conductor smaller than 10 mm ² (8 AWG) Cu.	Yes with phase conductor smaller than 10 mm ² (8 AWG) Cu, or motors up to 30 kW (40 hp). Note: Shielded or armored cable, or cabling in metal conduit is always recommended to minimize radio frequency interference.

Cable type	Use as input power cabling	Use as motor cabling and as brake resistor cabling
 <p>Four-conductor cabling in metal conduit (three phase conductors and PE). For example, EMT, or four-conductor armored cable</p>	Yes	Yes with phase conductor smaller than 10 mm ² (8 AWG) Cu, or motors up to 30 kW (40 hp)
 <p>Shielded (Al/Cu shield or armor)¹⁾ four-conductor cable (three phase conductors and a PE)</p>	Yes	Yes with motors up to 100 kW (135 hp). A potential equalization between the frames of motor and driven equipment is required.

1) Armor may act as an EMC shield, as long as it provides the same performance as a concentric EMC shield of a shielded cable. To be effective at high frequencies, the shield conductivity must be at least 1/10 of the phase conductor conductivity. The effectiveness of the shield can be evaluated based on the shield inductance, which must be low and only slightly dependent on frequency. The requirements are easily met with a copper or aluminum shield/armor. The cross-section of a steel shield must be ample and the shield helix must have a low gradient. A galvanized steel shield has a better high-frequency conductivity than a non-galvanized steel shield.

Not allowed power cable types

Cable type	Use as input power cabling	Use as motor cabling and as brake resistor cabling
 <p>Symmetrical shielded cable with individual shields for each phase conductor</p>	No	No

■ **Additional guidelines, North America**

ABB recommends the use of metallic conduit for power wiring. ABB also recommends the use of symmetrical shielded VFD cable between drive and motor(s).

This table shows examples of methods for wiring the drive. Refer to NFPA 70 (NEC) along with state and local codes for the appropriate methods for your application.

Wiring method	Notes
Conduit - Metallic ^{1) 2)}	
Electrical metallic tubing: Type EMT	Prefer symmetrical shielded VFD cable. Use separate conduit run for each motor. Do not run input power wiring and motor wiring in the same conduit.
Rigid metal conduit: Type RMC	
Liquid-tight flexible metal electrical conduit: Type LFMC	
Conduit - Non-metallic ^{2) 3)}	
Liquid-tight flexible non-metallic conduit: Type LFNC	Prefer symmetrical shielded VFD cable. Use separate conduit run for each motor. Do not run input power wiring and motor wiring in the same conduit.
Wireways ²⁾	
Metallic	Prefer symmetrical shielded VFD cable. Separate motor wiring from input power wiring and other low voltage wiring. Do not run outputs of multiple drives parallel. Bundle each cable (wiring) together and use separators where possible.
Free air ²⁾	
Enclosures, air handlers, etc.	Prefer symmetrical shielded VFD cable. Allowed internally in enclosures when in accordance with UL.

¹⁾ Metallic conduit may be used as an additional ground path, provided this path is a solid path capable of handling ground currents.

²⁾ See NFPA 70 (NEC), UL, and local codes for your application.

³⁾ Non-metallic conduit use underground is allowed; however, these installations inherently have an increased chance for nuisance problems due to the potential for water/moisture in the conduit. Water/moisture in the conduit increases the likelihood of VFD faults or warnings. Proper installation is required to make sure there is no intrusion of water/moisture.


Metal conduit

Couple separate parts of a metal conduit together: bridge the joints with a ground conductor bonded to the conduit on each side of the joint. Also bond the conduits to the drive enclosure and motor frame. Use separate conduits for input power, motor, brake resistor, and control wiring. Do not run motor wiring from more than one drive in the same conduit.

■ Power cable shield

If the cable shield is used as the sole protective earth (PE) conductor, make sure that its conductivity agrees with the PE conductor requirements.

To effectively suppress radiated and conducted radio-frequency emissions, the cable shield conductivity must be at least 1/10 of the phase conductor conductivity. The requirements are easily met with a copper or aluminum shield. The minimum requirement of the motor cable shield of the drive is shown below. It consists of a concentric layer of copper wires with an open helix of copper tape or copper wire. The better and tighter the shield, the lower the emission level and bearing currents.



Grounding requirements

This section gives general requirements for grounding the drive. When you plan the grounding of the drive, obey all the applicable national and local regulations.

The conductivity of the protective earth conductor(s) must be sufficient.

Unless local wiring regulations state otherwise, the cross-sectional area of the protective earth conductor must agree with the conditions that require automatic disconnection of the supply required in 411.3.2 of IEC 60364-4-41:2005 and be capable of withstanding the prospective fault current during the disconnection time of the protective device. The cross-sectional area of the protective earth conductor must be selected from the table below or calculated according to 543.1 of IEC 60364-5-54.

This table shows the minimum cross-sectional area of the protective earth conductor related to the phase conductor size according to IEC/UL 61800-5-1 when the phase conductor(s) and the protective earth conductor are made of the same metal. If this is not so, the cross-sectional area of the protective earth conductor must be determined in a manner which produces a conductance equivalent to that which results from the application of this table.

Cross-sectional area of the phase conductors S (mm ²)	Minimum cross-sectional area of the corresponding protective earth conductor S_p (mm ²)
$S \leq 16$	S ¹⁾
$16 < S \leq 35$	16
$35 < S$	$S/2$

¹⁾ For the minimum conductor size in IEC installations, refer to Additional grounding requirements – IEC.

If the protective earth conductor is not part of the input power cable or input power cable enclosure, the minimum permitted cross-sectional area is:

- 2.5 mm² if the conductor is mechanically protected,
or
- 4 mm² if the conductor is not mechanically protected. If the equipment is cord-connected, the protective earth conductor must be the last conductor to be interrupted if there is a failure in the strain relief mechanism.

■ Additional grounding requirements – IEC

This section gives grounding requirements according to standard IEC/EN 61800-5-1.

Because the normal touch current of the drive is more than 3.5 mA AC or 10 mA DC:

- the minimum size of the protective earth conductor must comply with the local safety regulations for high protective earth conductor current equipment, and
- you must use one of these connection methods:
 1. a fixed connection and:
 - a protective earth conductor with a minimum cross-sectional area of 10 mm² Cu or 16 mm² Al (as an alternative when aluminum cables are permitted),
or
 - a second protective earth conductor of the same cross-sectional area as the original protective earth conductor,
or
 - a device that automatically disconnects the supply if the protective earth conductor is damaged.
 2. a connection with an industrial connector according to IEC 60309 and a minimum protective earth conductor cross-section of 2.5 mm² as part of a multi-conductor power cable. Sufficient strain relief must be provided.

If the protective earth conductor is routed through a plug and socket, or similar means of disconnection, it must not be possible to disconnect it unless power is simultaneously removed.

Note: You can use power cable shields as grounding conductors only when their conductivity is sufficient.

■ Additional grounding requirements – UL (NEC)

This section gives grounding requirements according to standard UL 61800-5-1.

The protective earth conductor must be sized as specified in Article 250.122 and table 250.122 of the National Electric Code, ANSI/NFPA 70.

For cord-connected equipment, it must not be possible to disconnect the protective earth conductor before power is removed.


Selecting the control cables

■ Shielding

Only use shielded control cables.

Use a double-shielded twisted pair cable for analog signals. ABB recommends this type of cable also for the pulse encoder signals. Use one individually shielded pair for each signal. Do not use common return for different analog signals.

A double-shielded cable (a) is the best alternative for low-voltage digital signals, but single-shielded (b) twisted pair cable is also acceptable.



■ Signals in separate cables

Run analog and digital signals in separate, shielded cables. Do not mix 24 V DC and 115/230 V AC signals in the same cable.

■ Signals that can be run in the same cable

If their voltage does not exceed 48 V, relay-controlled signals can be run in the same cables as digital input signals. The relay-controlled signals should be run as twisted pairs.

■ Relay cable

The cable type with braided metallic shield (for example ÖLFLEX by LAPPKABEL, Germany) has been tested and approved by ABB.

■ Control panel to drive cable

Use EIA-485, Cat 5e (or better) cable with male RJ-45 connectors. The maximum length of the cable is 100 m (328 ft).

■ PC tool cable

Connect the Drive Composer PC tool to the drive through the USB port of the control panel. Use a USB Type A (PC) - Type Mini-B (control panel) cable. The maximum length of the cable is 3 m (9.8 ft).


Routing the cables

■ General guidelines – IEC

- Route the motor cable away from other cables. Motor cables of several drives can be run in parallel installed next to each other.
- Install the motor cable, input power cable and control cables on separate trays.
- Avoid long parallel runs of motor cables with other cables.
- Where control cables must cross power cables, make sure that they are arranged at an angle as near to 90 degrees as possible.
- Do not run extra cables through the drive.
- Make sure that the cable trays have good electrical bonding to each other and to the grounding electrodes. Aluminum tray systems can be used to improve local equalizing of potential.

The following figure illustrates the cable routing guidelines with an example drive.

98 Guidelines for planning the electrical installation




■ **General guidelines – North America**

Make sure that the installation is in accordance with national and local codes. Obey these general guidelines:

- Use separate conduits for the input power, motor, brake resistor (optional), and control cabling.
- Use separate conduit for each motor cabling.

The following figure illustrates the cable routing guidelines with an example drive.




■ **Continuous motor cable shield/conduit or enclosure for equipment on the motor cable**

To minimize the emission level when safety switches, contactors, connection boxes or similar equipment are installed on the motor cable between the drive and the motor:

- Install the equipment in a metal enclosure.
- Use either a symmetrical shielded cable, or install the cabling in a metal conduit.
- Make sure that there is a good and continuous galvanic connection in the shield/conduit between drive and motor.
- Connect the shield/conduit to the protective ground terminal of the drive and the motor.

■ **Separate control cable ducts**


Put 24 V DC and 230 V AC (120 V AC) control cables in separate ducts, unless the 24 V DC cable is insulated for 230 V AC (120 V AC) or insulated with an insulation sleeving for 230 V AC (120 V AC).



Protecting the drive, input power cable, motor and motor cable in short circuit situations and against thermal overload

■ Protecting the drive and the input power cable in short-circuits

Protect the drive (1) with fuses (a) and the input cable with fuses (b) or a circuit breaker.



Equip the fuses with blown fuse indicators (microswitches) for stopping the drive. For instructions, see [Wiring the microswitches of the fuses](#) (page 119).

Size the fuses or the circuit breaker according to local regulations for the input cable protection. Select the fuses for the drive according to the instructions given in the technical data. The fuses for the drive protection will restrict drive damage and prevent damage to adjoining equipment in case of a short-circuit inside the drive.

Note: Circuit breakers must not be used without fuses.



WARNING!

Due to the inherent operating principle and construction of circuit breakers, independent of the manufacturer, hot ionized gases can escape from the breaker enclosure in case of a short-circuit. To ensure safe use, pay special attention to the installation and placement of the breakers. Obey the manufacturer's instructions.

■ Tested circuit breakers

You can use the circuit breakers listed in the technical data. Other circuit breakers can be used with the drive if they provide the same electrical characteristics. ABB does not assume any liability whatsoever for the correct function and protection with circuit breakers not listed. Furthermore, if the recommendations given by ABB are not obeyed, the drive can experience problems that the warranty does not cover.

■ Protecting the motor and motor cable in short-circuits

The drive protects the motor cable and motor in a short-circuit situation when:

- the motor cable is sized correctly
- the motor cable type complies with the motor cable selection guidelines by ABB
- the cable length does not exceed the allowed maximum length specified for the drive
- the setting of parameter 99.10 Motor nominal power in the drive is equal with the value given on the motor rating plate.

The electronic power output short-circuit protection circuitry meets the requirements of IEC 60364-4-41 2005/AMD1.

■ Protecting the motor cables against thermal overload

The drive protects the motor cables against thermal overload when the cables are sized according to the nominal output current of the drive. No additional thermal protection devices are needed.



WARNING!

If the drive is connected to multiple motors, use a separate overload protection for each motor cable and motor. The drive overload protection is tuned for the total motor load. It may not detect an overload in one motor circuit only.

North America: The local code (NEC) requires an overload protection and a short-circuit protection for each motor circuit. Use, for example:

- manual motor protector
 - circuit breaker, contactor and overload relay or
 - fuses, contactor and overload relay.
-

■ Protecting the motor against thermal overload

According to regulations, the motor must be protected against thermal overload and the current must be switched off when overload is detected. The drive includes a motor thermal protection function that protects the motor and switches off the current when necessary. Depending on a drive parameter value, the function either monitors a calculated temperature value (based on a motor thermal model) or an actual temperature indication given by motor temperature sensors.

The motor thermal protection model supports thermal memory retention and speed sensitivity. The user can tune the thermal model further by feeding in additional motor and load data.

The most common temperature sensor types are PTC or Pt100.

For more information, see the firmware manual.

■ Protecting the motor against overload without thermal model or temperature sensors

Motor overload protection protects the motor against overload without using motor thermal model or temperature sensors.

Motor overload protection is required and specified by multiple standards including the US National Electric Code (NEC) and the common UL/IEC 61800-5-1 standard in conjunction with UL/IEC 60947-4-1. The standards allow for motor overload protection without external temperature sensors.

The protection feature of the drive allows the user to specify the class of operation in the same manner as the overload relays are specified in standards UL/IEC 60947-4-1 and NEMA ICS 2.

The motor overload protection supports thermal memory retention and speed sensitivity.

For more information, see drive firmware manual.

Protecting the drive against ground faults

The drive is equipped with an internal ground fault protective function to protect the unit against ground faults in the motor and motor cable. This function is not a personnel safety or a fire protection feature. See the firmware manual for more information.

■ Residual current device compatibility

The drive is suitable for use with residual current devices of Type B.

Note: As standard, the drive contains capacitors connected between the main circuit and the frame. These capacitors and long motor cables increase the ground leakage current and may cause nuisance faults in residual current devices.

Connecting drive modules to a common DC system

See ACS880-01 drives and ACS880-04 drive modules common DC systems application guide (3AUA0000127818 [English]).

Implementing a motor temperature sensor connection



WARNING!

IEC 61800-5-1 requires double or reinforced insulation between live parts and accessible parts when:

- the accessible parts are not conductive, or
- the accessible parts are conductive, but not connected to the protective earth.

Obey this requirement when you plan the connection of the motor temperature sensor to the drive.

You have these implementation alternatives:

1. If there is double or reinforced insulation between the sensor and the live parts of the motor: You can connect the sensor directly to the analog/digital input(s) of the drive. See the control cable connection instructions. Make sure that the voltage does not exceed the maximum allowed voltage over the sensor.
 2. If there is basic insulation between the sensor and the live parts of the motor, or if the insulation type is not known, you can connect the sensor to the drive via an option module. The sensor and the module must form a double or reinforced insulation between the motor live parts and the drive control unit. See [Connecting a motor temperature sensor to the drive through an option module \(page 103\)](#). Make sure that the voltage does not exceed the maximum allowed voltage over the sensor.
 3. If there is basic insulation between the sensor and the live parts of the motor, or if the insulation type is not known: You can connect a sensor to a digital input of the drive via an external relay. The sensor and the relay must form a double or reinforced insulation between the motor's live parts and the digital input of the drive. Make sure that the voltage does not exceed the maximum allowed voltage over the sensor.
-

■ **Connecting a motor temperature sensor to the drive through an option module**

This table shows:

- option module types that you can use for the motor temperature sensor connection
- insulation or isolation level that each option module forms between its temperature sensor connector and other connectors
- temperature sensor types that you can connect to each option module
- temperature sensor insulation requirement in order to form, together with the insulation of the option module, a reinforced insulation between the motor live parts and the drive control unit.

Option module		Temperature sensor type			Temperature sensor insulation requirement
Type	Insulation/Isolation	PTC	KTY	Pt100, Pt1000	
FIO-11	Galvanic isolation between sensor connector and drive control unit connector. No isolation between sensor connector and other I/O connectors.	x	x	x	Reinforced insulation
FIO-21	Galvanic isolation between sensor connector and other connectors (including drive control unit connector).	x	x	x	Reinforced insulation
FEN-01	Galvanic isolation between sensor connector and drive control unit connector. No isolation between sensor connector and TTL encoder emulation output.	x	-	-	Reinforced insulation
FEN-11	Galvanic isolation between sensor connector and drive control unit connector. No isolation between sensor connector and TTL encoder emulation output.	x	x	-	Reinforced insulation
FEN-21	Galvanic isolation between sensor connector and drive control unit connector. No isolation between sensor connector and TTL encoder emulation output.	x	x	-	Reinforced insulation
FEN-31	Galvanic isolation between sensor connector and drive control unit connector. No isolation between sensor connector and other connectors.	x	x	-	Reinforced insulation
FAIO-01	Basic insulation between sensor connector and drive control unit connector. No insulation between sensor connector and other I/O connectors.	x	x	x	Reinforced or basic insulation. With basic insulation, the other I/O connectors of the option module must be kept disconnected.

Option module		Temperature sensor type			Temperature sensor insulation requirement
Type	Insulation/Isolation	PTC	KTY	Pt100, Pt1000	
FPTC-01/02 ¹⁾	Reinforced insulation between sensor connector and other connectors (including drive control unit connector).	x	-	-	No special requirement

¹⁾ Suitable for use in safety functions (SIL2 / PL c rated).

For more information, refer to the applicable option module user's manual.

Implementing the emergency stop function

For safety reasons, install the emergency stop devices at each operator control station and at other operating stations where the emergency stop may be needed. Implement the emergency stop according to relevant standards.

Note: You can use the Safe torque off function of the drive to implement the Emergency stop function.

Implementing the Safe torque off function

See [The Safe torque off function \(page 237\)](#).

Implementing the functions provided by the FSO safety functions module

You can order the drive with an FSO-12 safety functions module (option +Q973) or FSO-21 safety functions module (option +Q972). An FSO module enables the implementation of functions such as Safe brake control (SBC), Safe stop 1 (SS1), Safe stop emergency (SSE), Safely limited speed (SLS) and Safe maximum speed (SMS).

The settings of the FSO module have default values when delivered from the factory. The wiring of the external safety circuit and configuration of the FSO module are the responsibility of the user.

The FSO module reserves the standard Safe torque off (STO) connection of the drive control unit. STO can still be utilized by other safety circuits through the FSO module.

See the appropriate manual for more information.

Name	Code
FSO-12 safety functions module user's manual	3AXD50000015612
FSO-21 safety functions module user's manual	3AXD50000015614

Using power factor compensation capacitors with the drive

Power factor compensation is not needed with AC drives. However, if a drive is to be connected in a system with compensation capacitors installed, note the following restrictions.

**WARNING!**

Do not connect power factor compensation capacitors or harmonic filters to the motor cables (between the drive and the motor). They are not meant to be used with AC drives and can cause permanent damage to the drive or themselves.

If there are power factor compensation capacitors in parallel with the input of the drive:

1. Do not connect a high-power capacitor to the power line while the drive is connected. The connection will cause voltage transients that may trip or even damage the drive.
2. If capacitor load is increased/decreased step by step when the AC drive is connected to the power line, make sure that the connection steps are low enough not to cause voltage transients that would trip the drive.
3. Make sure that the power factor compensation unit is suitable for use in systems with AC drives, ie, harmonic generating loads. In such systems, the compensation unit should typically be equipped with a blocking reactor or harmonic filter.

Using a safety switch between the drive and the motor

ABB recommends to install a safety switch between the permanent magnet motor and the drive output. The switch is needed to isolate the motor from the drive during maintenance work on the drive.

Implementing an ATEX-certified motor thermal protection

With option +Q971, the drive provides ATEX-certified safe motor disconnection without contactor using the drive Safe torque off function. To implement the thermal protection of a motor in explosive atmosphere (Ex motor), you must also:

- use an ATEX-certified Ex motor
- order an ATEX-certified thermistor protection module for the drive (option +L537), or acquire and install an ATEX-compliant protection relay
- do the necessary connections.

For more information, see:

User's manual	Manual code (English)
ATEX-certified Safe disconnection function, Ex II (2) GD for ACS880 drives (+Q971) application guide	3AUA0000132231
FPTC-02 ATEX-certified thermistor protection module, Ex II (2) GD (option +L537+Q971) for ACS880 drives user's manual	3AXD50000027782

Implementing the power loss ride-through function

If the incoming supply voltage is cut off, the drive will continue to operate by utilizing the kinetic energy of the rotating motor. The drive will be fully operational as long as the motor rotates and generates energy to the drive.

If you equip the drive with a main contactor or breaker, make sure that it restores the drive input power after a short break. The contactor must either re-connect after the break automatically, or remain closed over the break. Depending on the contactor control circuit design, this can require an additional hold circuit, uninterruptible auxiliary power supply or auxiliary power supply buffering.

Note: If the power loss lasts so long that the drive trips on undervoltage, a fault reset and a fresh start command is required to continue operation.

Implement the power-loss ride-through function as follows:

1. Enable the power-loss ride-through function of the drive (parameter 30.31).
2. If the installation is equipped with a main contactor, prevent its tripping at the input power break. For example, use a time delay relay (hold) in the contactor control circuit.
3. Enable the automatic restart of the motor after a short power supply break:
 - Set the start mode to automatic (parameter 21.01 or 21.19, depending on the motor control mode being used).
 - Define the automatic restart time (parameter 21.18).



WARNING!

Make sure that a flying restart of the motor will not cause any danger. If you are in doubt, do not implement the power loss ride-through function.

Controlling a contactor between drive and motor

The control of the output contactor depends on how you use the drive, that is, which motor control mode and which motor stop mode you select.

If you have the DTC motor control mode and the motor ramp stop mode selected, use this operation sequence to open the contactor:

1. Give a stop command to the drive.
2. Wait until the drive decelerates the motor to zero speed.
3. Open the contactor.

If you have the DTC motor control mode and the motor coast stop, or scalar control mode selected, open the contactor as follows:

1. Give a stop command to the drive.
2. Open the contactor.



WARNING!

When the DTC motor control mode is in use, never open the output contactor while the drive controls the motor. The DTC motor control operates extremely fast, much faster than it takes for the contactor to open its contacts. When the contactor starts opening while the drive controls the motor, the DTC control will try to maintain the load current by immediately increasing the drive output voltage to the maximum. This will damage, or even burn, the contactor completely.

Implementing a bypass connection

If bypassing is required, employ mechanically or electrically interlocked contactors between the motor and the drive and between the motor and the power line. Make sure with interlocking that the contactors cannot be closed simultaneously. The installation must be clearly marked as defined in IEC/EN/UL 61800-5-1, subclause 6.5.3, for example, “THIS MACHINE STARTS AUTOMATICALLY”.




WARNING!

Never connect the drive output to the electrical power network. The connection may damage the drive.

■ **Example bypass connection**

An example bypass connection is shown below.



Q1	Drive main switch
Q4	Bypass circuit breaker
K1	Drive main contactor
K4	Bypass contactor
K5	Drive output contactor
S11	Drive main contactor on/off control
S40	Motor power supply selection (drive or direct-on-line)
S41	Start when motor is connected direct-on-line
S42	Stop when motor is connected direct-on-line

Switching the motor power supply from drive to direct-on-line

1. Stop the drive and the motor with the drive control panel stop key (drive in the local control mode) or the external stop signal (drive in the remote control mode).
2. Open the main contactor of the drive with S11.
3. Switch the motor power supply from the drive to direct-on-line with S40.
4. Wait for 10 seconds to allow the motor magnetization to dissipate.
5. Start the motor with S41.

Switching the motor power supply from direct-on-line to drive


1. Stop the motor with S42.
2. Switch the motor power supply from direct-on-line to the drive with S40.
3. Close the main contactor of the drive with switch S11 (-> turn to position ST for two seconds and leave to position 1).
4. Start the drive and the motor with the drive control panel start key (drive in the local control mode) or the external start signal (drive in the remote control mode).

Protecting the contacts of relay outputs

Inductive loads (relays, contactors, motors) cause voltage transients when switched off.

The relay contacts on the drive control unit are protected with varistors (250 V) against overvoltage peaks. In spite of this, it is highly recommended that inductive loads are equipped with noise attenuating circuits (varistors, RC filters [AC] or diodes [DC]) to minimize the EMC emission at switch-off. If not suppressed, the disturbances may connect capacitively or inductively to other conductors in the control cable and form a risk of malfunction in other parts of the system.

Install the protective component as close to the inductive load as possible. Do not install protective components at the relay outputs.



7

Electrical installation

Contents of this chapter

This chapter contains instructions for electrical installation of the drive module. The chapter refers to installation example chapters which contain instructions that depend on the selected drive configuration.


Safety

**WARNING!**

If you are not a qualified electrical professional, do not do installation or maintenance work. Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

Grounding the motor cable shield at the motor end

For minimum radio-frequency interference, ground the cable shield 360 degrees at the cable entry of the motor terminal box.



Measuring the insulation

■ Measuring the insulation resistance of the drive




WARNING!

Do not do any voltage withstand or insulation resistance tests on any part of the drive as testing can damage the drive. Every drive has been tested for insulation between the main circuit and the chassis at the factory. Also, there are voltage-limiting circuits inside the drive which cut down the testing voltage automatically.

■ Measuring the insulation resistance of the input power cable

Before you connect the input power cable to the drive, measure its insulation resistance according to local regulations.

■ Measuring the insulation resistance of the motor and motor cable




WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur. If you are not a qualified electrical professional, do not do installation, commissioning or maintenance work.

1. Do the steps in section [Electrical safety precautions](#) (page 19) before you start the work.
2. Make sure that the motor cable is disconnected from the drive output terminals.
3. Measure the insulation resistance between each phase conductor and the protective earth conductor. Use a measuring voltage of 1000 V DC. The insulation resistance of an ABB motor must be more than 100 Mohm (reference value at 25 °C [77 °F]). For the insulation resistance of other motors, refer to the manufacturer's instructions.

Note: Moisture inside the motor reduces the insulation resistance. If you think that there is moisture in the motor, dry the motor and do the measurement again.




■ Measuring the insulation resistance of the brake resistor circuit



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur. If you are not a qualified electrical professional, do not do installation, commissioning or maintenance work.

1. Stop the drive and do the steps in section [Electrical safety precautions](#) (page 19) before you start the work.
2. Make sure that the resistor cable is connected to the resistor and disconnected from the drive output terminals.
3. At the drive end, connect the R+ and R- conductors of the resistor cable together. Measure the insulation resistance between the conductors and the PE conductor with a measuring voltage of 1000 V DC. The insulation resistance must be more than 1 Mohm.



Grounding system compatibility check

The standard drive with no EMC filter and the ground-to-phase varistor connected can be installed to a symmetrically grounded TN-S system. If you install the drive to another system, you may need to disconnect the EMC filter and ground-to-phase varistor. See [ACS880 frames R1 to R11 EMC filter and ground-to-phase varistor disconnecting instructions](#) (3AUA0000125152 [English]).



WARNING!

Do not install the drive with EMC filter option +E200 to a system that the filter is not suitable for. This can cause danger, or damage the drive.



WARNING!

Do not install the drive with the ground-to-phase varistor connected to a system that the varistor is not suitable for. If you do, the varistor circuit can be damaged.

■ Corner-grounded and midpoint-grounded 525...690 V delta systems



WARNING!

Do not install the drive on a 525...690 V corner-grounded or midpoint-grounded delta system. Disconnecting the EMC filter and ground-to-phase varistor does not prevent damage to the drive.

Installing the EMC filter (option)

See [ARFI-10 EMC filter installation guide](#) (3AFE68317941 [English]).


Connecting the power cables



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

■ **Power cable connection diagram example (6-pulse)**




1	Use a separate grounding PE cable (1a) or a cable with a separate PE conductor (1b) if the conductivity of the shield does not meet the requirements for the PE conductor (see section <i>Selecting the power cables</i> (page 91)).
2	360-degree grounding is recommended if shielded cable is used. Ground the other end of the input cable shield or PE conductor at the distribution board.
3	360-degree grounding is required
4	Line contactor
5	Common mode filter

6	du/dt filter or sine filter (options)
7	Use a separate grounding cable if the shield does not meet the requirements of IEC 61439-1 (see section Selecting the power cables (page 91)) and there is no symmetrically constructed grounding conductor in the cable (see section Not allowed power cable types (page 93)).
8	External brake resistor
9	Drive module
10	Switch-disconnector and separate fuses or switch fuse
11	Separate fuses for each module
<p>Protect the input cables with additional fuses or circuit breaker against thermal overload.</p> <p>If there is a symmetrically constructed grounding conductor in the motor cable in addition to the conductive shield, connect the grounding conductor to the grounding terminal at the drive and motor ends. Do not use an asymmetrically constructed motor cable. Connecting its fourth conductor at the motor end increases bearing currents and causes extra wear.</p> <p>The minimum permitted motor cable length without optional output filters is 2 m (6.6 ft).</p> <p>Maximum cable length of the DC cables is 4 m (13.1 ft).</p> <p>Motor cables must be installed symmetrically to the common motor.</p>	



■ Power cable connection diagram example (6-pulse and 12-pulse)



- 1 Use a separate grounding PE cable (1a) or a cable with a separate PE conductor (1b) if the conductivity of the shield does not meet the requirements for the PE conductor (see section [Selecting the power cables](#) (page 91)).

2	360-degree grounding is recommended if shielded cable is used. Ground the other end of the input cable shield or PE conductor at the distribution board.
3	360-degree grounding is required
4	Line contactor
5	Common mode filter
6	du/dt filter or sine filter (options)
7	Use a separate grounding cable if the shield does not meet the requirements of IEC 61439-1 (see section Selecting the power cables (page 91)) and there is no symmetrically constructed grounding conductor in the cable (see section Not allowed power cable types (page 93)).
8	External brake resistor
9	Drive module
10	Switch-disconnector and separate fuses or switch fuse


Protect the input cables with additional fuses or circuit breaker against thermal overload.

If there is a symmetrically constructed grounding conductor in the motor cable in addition to the conductive shield, connect the grounding conductor to the grounding terminal at the drive and motor ends. Do not use an asymmetrically constructed motor cable. Connecting its fourth conductor at the motor end increases bearing currents and causes extra wear.


The minimum permitted motor cable length without optional output filters is 2 m (6.6 ft).
Maximum cable length of the DC cables is 4 m (13.1 ft).
Motor cables must be installed symmetrically to the common motor.

■ Preparing the cable ends and making 360-degree grounding at the cable entry

1. Peel off 3...5 cm (1 1/4 ... 2 in) of the outer insulation of the cables at the cable entries with the conductive sleeves for the 360° high-frequency grounding.




2. Prepare the ends of the cables.



WARNING!

Apply grease to stripped aluminum conductors before attaching them to non-coated aluminum cable lugs. Obey the grease manufacturer's instructions. Aluminum-aluminum contact can cause oxidation in the contact surfaces.


3. If fire insulation is used, make an opening in the mineral wool sheet according to the diameter of the cable.
4. Put the cables through the entry plate.
5. If rubber grommets are used, remove them from the entry plate for the cables to be connected. Cut adequate holes into the rubber grommets. Put the grommets onto the cables. Put the cables through the entry plate and attach the grommets to the holes.
6. Attach the conductive sleeves to the cable shields with cable ties. Tie up the unused conductive sleeves with cable ties. An example of bottom entry is shown below. For top entry, put the grommet upwards.



■ Power cable connection procedure

1. Connect the cable shields of the motor cables and any separate ground conductors or cables to the ground terminal of the drive module or to the cabinet ground bar.
2. Connect the phase conductors of the motor cables to terminals T1/U2, T2/V2 and T3/W2 of the drive module. For the tightening torques, see the technical data.
3. Drive modules with option +D150: Connect the brake resistor conductors to the R+ and R- terminals. For the tightening torques, see the technical data.
4. Connect the UDC terminals of the drive modules together. For the tightening torques, see the technical data.

If the DC cables are run outside the cabinet, ground the cable shield 360° at one end only.



5. Connect the cable shields of the input cables and any separate ground conductors or cables to the drive module ground terminal or to the cabinet PE busbar.
6. Connect the phase conductors of the input cables to terminals L1/U1, L2/V1 and L3/W1 of the drive module. For the tightening torques, see the technical data.

Connecting the control unit to the drive module



WARNING!


Handle the fiber optic cables with care. When you unplug the cables, always grab the connector, not the cable itself. Do not touch the ends of the fibers with bare hands as the ends are extremely sensitive to dirt.

■ Routing the control unit cables into the drive module

Route the control unit connection cables to the drive module through the slot in the middle front cover at the front or left side. First, remove the plate which covers the slot. Then, install the rubber grommet (accessories box item 2, see **Accessory box contents:** Assembly kit 3AXD50000453900 (page 76)).

■ **Connections to the drive module**

1. Connect power supply cable of the control unit to the ZPOW connector.
2. Connect the BGDR cable to the BGDR connector.
3. Connect the fiber optic cables to the V20 and V10 connectors.



■ **Connections to the control unit**

Connect the fiber optic, power supply and BGDR cables to the control unit as follows:

ZPOW	BCU control unit
X3:1	XPOW:1 (+24VI)
X3:2	XPOW:2 (GND)
X3:3 (not used)	-
BGDR	BCU control unit
Drive module 1	(connector XSTO OUT)
X7:1	5 (IN1)
X7:2	6 (SGND)
X8:1	7 (IN2)
X8:2	8 (SGND)
Drive module 2	(connector XSTO OUT)
X7:1	5 (IN1)
X7:2	6 (SGND)
X8:1	7 (IN2)
X8:2	8 (SGND)

ZINT/SOIA	BCU control unit
Drive module 1	
ZINT: V1; SOIA: V10	V1T
ZINT: V2; SOIA: V20	V1R
Drive module 2	
ZINT: V1; SOIA: V10	V2T
ZINT: V2; SOIA: V20	V2R

Connecting the control cables to the terminals of the control unit


■ Control cable connection procedure

1. Route the cables to the control unit.
2. Strip the cable ends and conductors. When connecting to the drive I/O, use electrical tape or shrink tubing to contain the strands. Elsewhere, twist the outer shield strands into a bundle, crimp a lug onto it and connect it to the nearest chassis grounding point.
3. Connect the conductors to the appropriate detachable terminals of the control unit, see section [Default I/O diagram of the inverter control unit \(A41\)](#) (page 130).

Note: Keep any signal wire pairs twisted as close to the terminals as possible. Twisting the wire with its return wire reduces disturbances caused by inductive coupling. Keep the shields continuous as close to the terminals of the control unit as possible. Leave the other end of the shield unconnected or ground it indirectly via a few nanofarads high-frequency capacitor, eg, 3.3 nF / 630 V. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points.

Wiring the microswitches of the fuses


Wire the microswitches of the drive input fuses to the DIIL input as shown below or to an external switch for stopping the drive in case of a blown fuse.



Connecting a control panel

With control panel door mounting platform, connect the control panel as follows:

1. Connect an Ethernet cable to the RJ-45 connector of the control panel.
2. Connect the other end of the cable to the X13 connector of the control unit.



Note: When a PC is connected to the control panel, the control panel keypad is disabled. In this case, the control panel acts as a USB-RS485 adapter.

Panel bus (Control of several units from one control panel)

One control panel (or PC) can be used to control several drives (or inverter units, supply units etc.) by constructing a panel bus. This is done by daisy-chaining the panel connections of the drives. Some drives have the necessary (twin) panel connectors in the control panel holder; those that do not require the installation of an FDPI-02 module (available separately). For further information, see the hardware description and FDPI-02 diagnostics and panel interface user's manual (3AUA0000113618 [English]).

The maximum allowed length of the cable chain is 100 m (328 ft).

1. Connect the panel to one drive using an Ethernet (for example Cat 5e) cable.
 - Use Menu - Settings - Edit texts - Drive to give a descriptive name to the drive
 - Use parameter 49.01* to assign the drive with a unique node ID number
 - Set other parameters in group 49* if necessary
 - Use parameter 49.06* to validate any changes.

*The parameter group is 149 with supply (line-side), brake or DC/DC converter units.

Repeat the above for each drive.


2. With the panel connected to one unit, link the units using Ethernet cables.
3. Switch on the bus termination on the drive that is farthest from the control panel in the chain.
 - With drives that have the panel mounted on the front cover, move the terminating switch into the outer position.
 - With an FDPI-02 module, move termination switch S2 into the TERMINATED position.

Make sure that bus termination is off on all other drives.


4. On the control panel, switch on the panel bus functionality (Options - Select drive - Panel bus). The drive to be controlled can now be selected from the list under Options - Select drive.

If a PC is connected to the control panel, the drives on the panel bus are automatically displayed in the Drive Composer PC tool.

With twin connectors in the control panel holder:



With FDPI-02 modules:



Connecting a PC




WARNING!

Do not connect the PC directly to the control panel connector of the control unit as this can cause damage.

A PC (with, for example, the Drive composer PC tool) can be connected as follows:

1. Connect a ACS-AP-... or ACH-AP-... control panel to the unit either
 - by inserting the control panel into the panel holder or platform, or
 - by using an Ethernet (eg, Cat 5e) networking cable.
2. Remove the USB connector cover on the front of the control panel.
3. Connect an USB cable (Type A to Type Mini-B) between the USB connector on the control panel (3a) and a free USB port on the PC (3b).
4. The panel will display an indication whenever the connection is active.
5. See the documentation of the PC tool for setup instructions.



Installing option modules



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

Pay attention to the free space required by the cabling or terminals coming to the option modules.

1. Repeat the steps described in [Electrical safety precautions](#) (page 19).
2. Pull out the lock (a).

Note: The location of the lock depends on the module type.


3. Install the module to a free option module slot on the control unit.
4. Push in the lock (a).
5. Tighten the grounding screw (b) to a torque of 0.8 N·m (7 lbf·in).

Note: The screw tightens the connections and grounds the module. It is essential for fulfilling the EMC requirements and for proper operation of the module.



WARNING!

Do not use excessive force, or leave the screw too loose. Over-tightening can damage the screw or module. A loose screw can cause an operation failure.



6. Connect the wiring to the module. Obey the instructions given in the documentation of the module.

■ Installation of an FSO safety functions module onto BCU




WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

This procedure describes the installation of an FSO safety functions module onto the BCU control unit. As an alternative, the FSO module can be installed adjacent to the control unit, which is the standard method for factory-installed FSO modules. For instructions, refer to the applicable FSO module user's manual.

1. Stop the drive and do the steps in section [Electrical safety precautions](#) (page 19) before you start the work.
2. The FSO module comes with alternative bottom plates for installation onto different control units. For installation onto a BCU control unit, the mounting points should be located at the long edges of the module as shown in the illustration below. If necessary, replace the bottom plate of the FSO module.


3. Attach the FSO module onto slot 3 of the BCU control unit [A41] with four screws.



4. Tighten the FSO module electronics grounding screw.

Note: The screw tightens the connections and grounds the module. It is essential for fulfilling the EMC requirements and for proper operation of the module.

5. Connect the FSO module data cable between FSO connector X110 and BCU connector X12.
6. To complete the installation, refer to the instructions in the applicable FSO module user's manual.




■ **Installation of FSO-xx adjacent to the control unit**

To reserve the slots of the control unit for other modules, you can install the FSO-xx separately from the control unit using mounting kit 3AXD50000025495. The kit contains:

- parts for mounting the FSO-xx onto a DIN rail nearby the control unit
- parts for mounting the FSO-xx onto the grounding/clamping plate of a ZCU-14 control unit in ACS880-104 frames R1i...R4i
- longer cables for connecting the FSO-xx to the control unit
- installation instructions (assembly drawing).

The illustration below shows the FSO module installed onto a DIN rail.






Control unit

Contents of this chapter


This chapter

- describes the connections of the control unit(s) used in the drive,
 - contains the specifications of the inputs and outputs of the control unit(s).
-

BCU-x2 layout



	Description
I/O	I/O terminals (see following diagram)
SLOT 1	I/O extension, encoder interface or fieldbus adapter module connection. (This is the sole location for an FDPI-02 diagnostics and panel interface.)
SLOT 2	I/O extension, encoder interface or fieldbus adapter module connection
SLOT 3	I/O extension, encoder interface, fieldbus adapter or FSO safety functions module connection
SLOT 4	RDCO-0x DDCS communication option module connection
X205	Memory unit connection
BATTERY	Holder for real-time clock battery (BR2032)
AI1	Mode selector for analog input AI1 (I = current, U = voltage)
AI2	Mode selector for analog input AI2 (I = current, U = voltage)
D2D TERM	Termination switch for drive-to-drive link (D2D)
DICOM=DIOGND	Ground selection. Determines whether DICOM is separated from DIOGND (ie. the common reference for the digital inputs floats). See the ground isolation diagram.
7-segment display	
Multicharacter indications are displayed as repeated sequences of characters	
	("U" is indicated briefly before "o".) Control program running
	Control program startup in progress
	(Flashing) Firmware cannot be started. Memory unit missing or corrupted
	Firmware download from PC to control unit in progress
	At power-up, the display may show short indications of eg. "1", "2", "b" or "U". These are normal indications immediately after power-up. If the display ends up showing any other value than those described, it indicates a hardware failure.



	Description
XAI	Analog inputs
XAO	Analog outputs
XDI	Digital inputs, Digital input interlock (DIIL)
XDIO	Digital input/outputs
XD2D	Drive-to-drive link
XD24	+24 V output (for digital inputs)
XETH	Ethernet port – Not in use
XPOW	External power input
XRO1	Relay output RO1
XRO2	Relay output RO2
XRO3	Relay output RO3
XSTO	Safe torque off connection (input signals)
XSTO OUT	Safe torque off connection (to inverter modules)
X12	(On the opposite side) Connection for FSO safety functions module (optional)
X13	Control panel / PC connection
X485	Not in use
V1T/V1R, V2T/V2R	Fiber optic connection to modules 1 and 2 (VxT = transmitter, VxR = receiver)
V3T/V3R ... V7T/V7R	Fiber optic connection to modules 3...7 (BCU-12/22 only) (VxT = transmitter, VxR = receiver)
V8T/V8R ... V12T/V12R	Fiber optic connection to modules 8...12 (BCU-22 only) (VxT = transmitter, VxR = receiver)
SD CARD	Data logger memory card for inverter module communication
BATT OK	Real-time clock battery voltage is higher than 2.8 V. If the LED is off when the control unit is powered, replace the battery.
FAULT	The control program has generated a fault. See the firmware manual of the supply/inverter unit.
PWR OK	Internal voltage supply is OK
WRITE	Writing to memory card in progress. Do not remove the memory card.

Default I/O diagram of the inverter control unit (A41)

The table below describes the use of the connections in the inverter unit.

The wire size accepted by all screw terminals (for both stranded and solid wire) is 0.5 ... 2.5 mm² (22...12 AWG). The tightening torque is 0.45 N·m (4 lbf·in).

Terminal			Description
XD2D			Drive-to-drive link
1	1	B	Drive-to-drive link. Refer to section The XD2D connector (page 135).
2	2	A	
3	3	BGND	
4	4	Shield	
	D2D.TERM		Drive-to-drive link termination switch. Must be set to ON when the inverter unit is the first or last unit in the drive-to-drive (D2D) link. On intermediate units, set termination to OFF.
X485			RS485 connection
5	5	B	Not in use by default
6	6	A	
7	7	BGND	
8	8	Shield	
XRO1, XRO2, XRO3			Relay outputs
	11	NC	Norm. closed
11	12	COM	Common
12	13	NO	Norm. open
13	21	NC	Norm. closed
21	22	COM	Common
22	23	NO	Norm. open
23	31	NC	Norm. closed
31	32	COM	Common
32	33	NO	Norm. open
33			
XSTO, XSTO OUT			Safe torque off
	1	OUT	XSTO: Factory connection. Both circuits must be closed for the drive to start (IN1 and IN2 must be connected to OUT). Refer to chapter The Safe torque off function .
1	2	SGND	
2	3	IN1	
3	4	IN2	
4	5	IN1	XSTO OUT: Safe torque off output to inverter modules.
5	6	SGND	
6	7	IN2	
7	8	SGND	
8			
XDI			Digital inputs


Terminal		Description	
1 2 3 4 5 6 7	1	DI1	Stop (0) / Start (1)
	2	DI2	Forward (0) / Reverse (1)
	3	DI3	Reset
	4	DI4	Acceleration & deceleration select ¹⁾
	5	DI5	Constant speed 1 select (1 = on) ²⁾
	6	DI6	Not in use by default.
	7	DIIL	Run enable ³⁾
XDIO		Digital input/outputs	
1 2 3 4	1	DIO1	Output: Ready
	2	DIO2	Output: Running
	3	DIOGND	Digital input/output ground
	4	DIOGND	Digital input/output ground
XD24		Auxiliary voltage output	
5 6 7 8	5	+24VD	+24 V DC 200 mA ⁴⁾
	6	DICOM	Digital input ground
	7	+24VD	+24 V DC 200 mA ⁴⁾
	8	DIOGND	Digital input/output ground
	DICOM=DIOGND	Ground selection switch. Determines whether DICOM is separated from DIOGND (ie, common reference for digital inputs floats). ON: DICOM connected to DIOGND. OFF: DICOM and DIOGND separate.	
XAI		Analog inputs, reference voltage output	
1 2 3 4 5 6 7	1	+VREF	10 V DC, R_L 1 ... 10 kohm
	2	-VREF	-10 V DC, R_L 1 ... 10 kohm
	3	AGND	Ground
	4	AI1+	Speed reference. 0(2)...10 V, $R_{in} > 200$ kohm ⁵⁾
	5	AI1-	
	6	AI2+	Not in use by default. 0(4)...20 mA, $R_{in} = 100$ ohm ⁶⁾
	7	AI2-	
	AI1	AI1 current/voltage selection switch	
	AI2	AI2 current/voltage selection switch	
XAO		Analog outputs	
1 2 3 4	1	AO1	Motor speed rpm 0 ... 20 mA, $R_L < 500$ ohm
	2	AGND	
	3	AO2	Motor current 0 ... 20 mA, $R_L < 500$ ohm
	4	AGND	
XPOW		External power input	
1 2 3 4	1	+24VI	24 V DC, 2.05 A Two supplies can be connected for redundancy.
	2	GND	
	3	+24VI	
	4	GND	
X12		Safety functions module connection	
X13		Control panel connection	

132 Control unit

Terminal	Description
X205	Memory unit connection

- 1) 0 = Acceleration/deceleration ramps defined by parameters 23.12/23.13 in use.
1 = Acceleration/deceleration ramps defined by parameters 23.14/23.15 in use.
 - 2) Constant speed 1 is defined by parameter 22.26.
 - 3) The DIIL input is configured to stop the unit when the input signal is removed. This input does not have a SIL or PL classification.
 - 4) Total load capacity of these outputs is 4.8 W (200 mA at 24 V) minus the power taken by DIO1 and DIO2.
 - 5) Current [0(4)...20 mA, $R_{in} = 100 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$] input selected by switch AI1. Change of setting requires reboot of control unit.
 - 6) Current [0(4)...20 mA, $R_{in} = 100 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$] input selected by switch AI2. Change of setting requires reboot of control unit.
-

The diagram below shows the default I/O connections on the inverter control unit (A41).



1) Fault

2) If necessary, you can connect an emergency stop button to the XSTO terminal. Refer to chapter The Safe torque off function.

Additional information on the connections

■ External power supply for the control unit (XPOW)


The control unit is powered from a 24 V DC, 2 A supply through terminal block XPOW. With a type BCU control unit, a second supply can be connected to the same terminal block for redundancy.

Using an external supply is recommended if

- the control unit needs to be kept operational during input power breaks, for example, because of continuous fieldbus communication
- immediate restart is needed after a power break (that is, no control unit power-up delay is allowed).

■ DI6 as a PTC sensor input

PTC sensors can be connected to this input for motor temperature measurement as follows. The sensor can alternatively be connected to a FEN encoder interface module. At the sensor end of the cable, leave the shields unconnected or ground them indirectly via a high-frequency capacitor with a few nanofarads, for example 3.3 nF / 630 V. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points. See the firmware manual of the inverter unit for parameter settings.




WARNING!

As the inputs pictured above are not insulated according to IEC 60664, the connection of the motor temperature sensor requires double or reinforced insulation between motor live parts and the sensor. Make sure that the voltage does not exceed the maximum allowed voltage over the PTC sensor.

■ AI1 or AI2 as a Pt100, Pt1000, PTC or KTY84 sensor input

Sensors for motor temperature measurement can be connected between an analog input and output, an example connection is shown below. (Alternatively, you can connect the KTY to an FIO-11 or FAIO-01 analog I/O extension module or a FEN encoder interface module.) At the sensor end of the cable, leave the shields unconnected or ground them indirectly via a high-frequency capacitor with a few nanofarads, for example 3.3 nF / 630 V. The shield can also be grounded directly at both ends if they are in the same ground line with no significant voltage drop between the end points.

**WARNING!**

As the inputs pictured above are not insulated according to IEC/EN 60664, the connection of the motor temperature sensor requires double or reinforced insulation between motor live parts and the sensor. Make sure that the current does not exceed the maximum allowed current through the Pt100/Pt1000 sensor.

■ DIIL input

The DIIL input is used for the connection of safety circuits. The input is parametrized to stop the unit when the input signal is lost.

Note: This input is NOT SIL or PL certified.

■ The XD2D connector

The XD2D connector provides an RS-485 connection that can be used for


- basic master/follower communication with one master drive and multiple followers,
- fieldbus control through the embedded fieldbus interface (EFB), or
- drive-to-drive (D2D) communication implemented by application programming.

See the firmware manual of the drive for the related parameter settings.

Enable bus termination on the units at the ends of the drive-to-drive link. Disable bus termination on the intermediate units.

Use a high-quality shielded twisted-pair cable for the wiring, for example, Belden 9842. The nominal impedance of the cable should be 100 ... 165 ohm. You can use one pair for the data wiring and another pair or a wire for the grounding. Avoid unnecessary loops and parallel runs near power cables.

The following diagram shows the wiring between control units.

BCU-x2

- **Safe torque off (XSTO, XSTO OUT)**

See chapter [The Safe torque off function](#) (page 237).

Note: The XSTO input only acts as a true Safe torque off input on the inverter control unit. De-energizing the IN1 and/or IN2 terminals of other units (supply, DC/DC converter, or brake unit) will stop the unit but not constitute a true safety function.


- **FSO safety functions module connection (X12)**

Refer to the applicable FSO module user's manual.

- **SDHC memory card slot**

The BCU-x2 has an on-board data logger that collects real-time data from the power modules to help fault tracing and analysis. The data is stored onto the SDHC memory card inserted into the SD CARD slot and can be analyzed by ABB service personnel.

Connector data


Power supply (XPOW)	<p>Connector pitch 5 mm, wire size 0.5 ... 2.5 mm² (22...12 AWG) Tightening torque 0.45 N·m (4 lbf·in) 24 V (±10%) DC, 2 A External power input. Two supplies can be connected to the BCU-x2 for redundancy.</p>
Relay outputs RO1...RO3 (XRO1...XRO3)	<p>Connector pitch 5 mm, wire size 0.5 ... 2.5 mm² (22...12 AWG) Tightening torque 0.45 N·m (4 lbf·in) 250 V AC / 30 V DC, 2 A Protected by varistors</p>
+24 V output (XD24:2 and XD24:4)	<p>Connector pitch 5 mm, wire size 0.5 ... 2.5 mm² (22...12 AWG) Tightening torque 0.45 N·m (4 lbf·in) Total load capacity of these outputs is 4.8 W (200 mA / 24 V) minus the power taken by DIO1 and DIO2.</p>
Digital inputs DI1...DI6 (XDI:1...XDI:6)	<p>Connector pitch 5 mm, wire size 0.5 ... 2.5 mm² (22...12 AWG) Tightening torque 0.45 N·m (4 lbf·in) 24 V logic levels: "0" < 5 V, "1" > 15 V R_{in}: 2.0 kohm Input type: NPN/PNP (DI1...DI5), PNP (DI6) Hardware filtering: 0.04 ms, digital filtering up to 8 ms DI6 (XDI:6) can alternatively be used as an input for a PTC sensor. "0" > 4 kohm, "1" < 1.5 kohm. I_{max}: 15 mA (DI1...DI5), 5 mA (DI6)</p>
Start interlock input DIIL (XDI:7)	<p>Connector pitch 5 mm, wire size 0.5 ... 2.5 mm² (22...12 AWG) Tightening torque 0.45 N·m (4 lbf·in) 24 V logic levels: "0" < 5 V, "1" > 15 V R_{in}: 2.0 kohm Input type: NPN/PNP Hardware filtering: 0.04 ms, digital filtering up to 8 ms</p>
<p>Digital inputs/outputs DIO1 and DIO2 (XDIO:1 and XDIO:2)</p> <p>Input/output mode selection by parameters.</p> <p>DIO1 can be configured as a frequency input (0...16 kHz with hardware filtering of 4 microseconds) for 24 V level square wave signal (sinusoidal or other wave form cannot be used). DIO2 can be configured as a 24 V level square wave frequency output. See the firmware manual, parameter group 111/11.</p>	<p>Connector pitch 5 mm, wire size 0.5 ... 2.5 mm² (22...12 AWG) Tightening torque 0.45 N·m (4 lbf·in)</p> <p><u>As inputs:</u> 24 V logic levels: "0" < 5 V, "1" > 15 V. R_{in}: 2.0 kohm. Filtering: 1 ms.</p> <p><u>As outputs:</u> Total output current from +24VD is limited to 200 mA</p> 
Reference voltage for analog inputs +VREF and -VREF (XAI:1 and XAI:2)	<p>Connector pitch 5 mm, wire size 0.5 ... 2.5 mm² (22...12 AWG) Tightening torque 0.45 N·m (4 lbf·in) 10 V ±1% and -10 V ±1%, R_{load} 1...10 kohm Maximum output current: 10 mA</p>

138 Control unit

<p>Analog inputs AI1 and AI2 (XAI:4 ... XAI:7). Current/voltage input mode selection by switches</p>	<p>Connector pitch 5 mm, wire size 0.5 ... 2.5 mm² (22...12 AWG) Tightening torque 0.45 N·m (4 lbf·in) Current input: -20...20 mA, $R_{in} = 100 \text{ ohm}$ Voltage input: -10...10 V, $R_{in} > 200 \text{ kohm}$ Differential inputs, common mode range $\pm 30 \text{ V}$ Sampling interval per channel: 0.25 ms Hardware filtering: 0.25 ms, adjustable digital filtering up to 8 ms Resolution: 11 bit + sign bit Inaccuracy: 1% of full scale range</p>
<p>Analog outputs AO1 and AO2 (XAO)</p>	<p>Connector pitch 5 mm, wire size 0.5 ... 2.5 mm² (22...12 AWG) Tightening torque 0.45 N·m (4 lbf·in) 0...20 mA, $R_{load} < 500 \text{ ohm}$ Frequency range: 0...500 Hz Resolution: 11 bit + sign bit Inaccuracy: 2% of full scale range</p>
<p>XD2D connector</p>	<p>Connector pitch 5 mm, wire size 0.5 ... 2.5 mm² (22...12 AWG) Tightening torque 0.45 N·m (4 lbf·in) Physical layer: RS-485 Transmission rate: 8 Mbit/s Cable type: Shielded twisted-pair cable with a twisted pair for data and a wire or another pair for signal ground (nominal impedance 100 ... 165 ohm, for example Belden 9842) Maximum length of link: 50 m (164 ft) Termination by switch</p>
<p>RS-485 connection (X485)</p>	<p>Connector pitch 5 mm, wire size 0.5 ... 2.5 mm² (22...12 AWG) Tightening torque 0.45 N·m (4 lbf·in) Physical layer: RS-485 Cable type: Shielded twisted-pair cable with a twisted pair for data and a wire or another pair for signal ground (nominal impedance 100 ... 165 ohm, for example Belden 9842) Maximum length of link: 50 m (164 ft)</p>
<p>Safe torque off connection (XSTO)</p>	<p>Connector pitch 5 mm, wire size 0.5 ... 2.5 mm² (22...12 AWG) Tightening torque 0.45 N·m (4 lbf·in) Input voltage range: -3...30 V DC Logic levels: "0" < 5 V, "1" > 17 V. Note: For the unit to start, both connections must be "1". This applies to all control units (including drive, inverter, supply, brake, DC/DC converter etc. control units), but true Safe torque off functionality is only achieved through the XSTO connector of the drive/inverter control unit. Current consumption: 66 mA (continuous) per STO channel EMC (immunity) according to IEC 61326-3-1 and IEC 61800-5-2</p>
<p>Safe torque off output (XSTO OUT)</p>	<p>Connector pitch 5 mm, wire size 0.5 ... 2.5 mm² (22...12 AWG) Tightening torque 0.45 N·m (4 lbf·in) To STO connector of inverter module.</p>
<p>Control panel connection (X13)</p>	<p>Connector: RJ-45 Cable length < 100 m (328 ft)</p>
<p>Ethernet connection (XETH)</p>	<p>Connector: RJ-45 This connection is not supported by the firmware.</p>

SDHC memory card slot (SD CARD)	Memory card type: SDHC Maximum memory size: 4 GB
The terminals of the control unit fulfill the Protective Extra Low Voltage (PELV) requirements. The PELV requirements of a relay output are not fulfilled if a voltage higher than 48 V is connected to the relay output.	

■ **BCU-x2 ground isolation diagram**



***Ground selector (DICOM=DIOGND) settings**

<p>DICOM=DIOGND: ON All digital inputs share a common ground (DICOM connected to DIOGND). This is the default setting.</p>
<p>DICOM=DIOGND: OFF Ground of digital inputs DI1...DI5 and DIIL (DICOM) is isolated from DIO signal ground (DIOGND). Isolation voltage 50 V.</p>

**The maximum common mode voltage between each AI input and AGND is +30 V

9

Installation example – standard, optional IP20 shrouds and power cable connection terminals

Contents of this chapter

In this chapter, the drive module is installed in a 600 mm wide Rittal VX25 enclosure in a bookshelf way of mounting. The module is placed in an upright position on the enclosure bottom with its front facing the enclosure door. Available alternative ABB parts are also given.

Limitation of liability

The installation must always be designed and made according to applicable local laws and regulations. ABB does not assume any liability whatsoever for any installation which breaches the local laws and/or other regulations. Furthermore, if the recommendations given by ABB are not followed, the drive may experience problems that the warranty does not cover.

Safety



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur. If you are not a qualified electrical professional, do not do installation, commissioning or maintenance work.

Required parts

Drive module standard parts		
<ul style="list-style-type: none"> • Drive module • Fastening bracket • Pedestal guide plate • Telescopic extraction and insertion ramp • Fastening screws and insulators in a plastic bag • External control unit 		
Rittal parts / Alternative ABB parts		
Rittal part code	Qty (pcs)	Description
VX 8606.000	1	Enclosure without mounting plate, bottom plates and side panels.
DK 7967.000 (one set = four pieces) ABB 3AUA0000117003 (IP20) ABB 3AUA0000117008 (IP42)	1	Spacers for roof plates. / ABB roof Note: For alternative ABB outlet kits, see section Air outlet kits (page 186).
VX 8617.030	5	Punched section with mounting flange, outer mounting level for 600 mm horizontal
TS 4396.500		Support rails
SK 3243.200 / ABB 3AUA0000117003 (IP20) ABB 3AUA0000117008 (IP42)	4 / 2	Air filter 323 mm × 323 mm. Remove the filter mats. Note: For alternative ABB air filters, see section Air inlet kits (page 184).
Customer-made parts (not ABB or Rittal products)		
Air baffles	2	See Layout example, doors open with IP20 shrouds (option) (page 57).

Required tools

- Set of screw drivers (Torx and Pozidriv)
- Set of metric magnetic-end hexagon sockets
- Torque wrench
- Step drill bit for drilling the holes in the clear plastic shroud for input power cables.

Overall flowchart of the installation process

Step	Task	For instructions, see
1	Install the Rittal parts, drive bottom guide plate and loose drive options in the drive module cubicle	Installing the drive module into the enclosure (page 143) and installation drawings
2	Install the auxiliary components (such as mounting plates, air baffles, switches, busbars etc.)	The component manufacturer's instructions Cabinet design and construction instructions for drive modules (3AUA0000107668 [English])

Step	Task	For instructions, see
3	Attach the drive module to the cabinet	Step-by-step drawings for an installation example of drive module with optional IP20 shrouds and input and output terminals in Rittal VX25 600 mm wide cabinet (page 269) Connecting the power cables and installing the IP20 shrouds (if present) (page 144)
4	<p><u>For the standard drive module configuration:</u> connect the power cables to the drive module output and input busbars.</p> <p><u>For option “Full size output cable connection terminals and PE busbar”:</u> connect the output power cable terminals and motor cables.</p> <p><u>For option “IP20 shrouds for covering the input and motor cabling area”:</u> install the shrouds onto the motor cabling area and while connecting the input cables onto the input cabling area.</p> <p><u>For option “Full size input cable connection terminals and PE busbar”:</u> connect the input power cable terminals and input cables.</p>	
5	Install the external control unit	
6	Connect the control cables	
7	Install the remaining parts, for example cabinet doors, side plates, etc.	The component manufacturer’s instructions Installing the roof and door (Rittal parts) (page 146)

Installing the drive module into the enclosure

See Step-by-step drawings for an installation example of drive module with optional IP20 shrouds and input and output terminals in Rittal VX25 600 mm wide cabinet (page 269) and ACS880-04 quick installation guide (3AXD50000009366 [English]).

- Install the punched section to the back of the enclosure frame.
- Install the bottom grille to the drive module for IP20 degree of protection from bottom if there is no leak-proof bottom plate in the enclosure.
- Install the support rails and pedestal guide plate to the enclosure bottom frame.
- Install the telescopic insertion ramp to the pedestal guide plate.
- Remove the sheeting from the clear plastic shrouds from both sides.
- Install the top metallic shroud to the drive module.
- Install the back shrouds to the drive module.
- To prevent the drive module from falling, attach its lifting lugs with chains to the enclosure frame.
- Push the drive module carefully into the enclosure along the telescopic insertion ramp.
- Remove the ramp.
- Attach the drive module to the pedestal guide plate.
- Attach the drive module from top to the punched section at the enclosure back.

Note: The fastening bracket grounds the drive module to the enclosure frame.

- Install the air baffles.

Connecting the power cables and installing the IP20 shrouds (if present)

Step	Task (motor cables, options “Full size output cable connection terminals” and “IP20 shrouds for covering the motor cabling area” included)
1	Run the motor cables to the enclosure. Ground the cable shields 360 degrees at the cabinet entry.
2	Connect the twisted shields of the motor cables to the grounding terminal of the drive module.
3	Connect the phase T3/W2 conductors to the T3/W2 terminal.
4	Connect the phase T2/V2 conductors to the T2/V2 connection terminal.
5	Connect the phase T1/U2 conductors to the T1/U2 terminal.


Step	Task (DC cables)
1	Connect the UDC+ terminals of the drive modules together. Connect the UDC- terminals of the drive modules together. <u>If the DC cables are run outside the cabinet</u> , ground the cable shield 360° at one end only.

Step	Task (motor cables, options “Full size output cable connection terminals” and “IP20 shrouds for covering the motor cabling area” included)
1	Install the grounding terminal to the drive module base.
2	Run the motor cables to the cabinet. Ground the cable shields 360 degrees at the cabinet entry.
3	Connect the twisted shields of the motor cables to the grounding terminal.
4	<p>Screw in and tighten the insulators to the drive module by hand. Install the T3/W2 connection terminal to the insulators.</p> <p> WARNING! Do not use longer screws or bigger tightening torque than given in the installation drawing. They can damage the insulator and cause dangerous voltage to be present at the module frame.</p> <p></p>
5	Connect the phase T3/W2 conductors to the T3/W2 terminal.
6	Install the T2/V2 connection terminal to the insulators. See the warning in step 4.
7	Connect the phase T2/V2 conductors to the T2/V2 connection terminal.
8	Install the T1/U2 connection terminal to the insulators. See the warning in step 4.
9	Connect the phase T1/U2 conductors to the T1/U2 terminal.
10	Remove the plastic sheeting from the output clear plastic shrouds from both sides.
11	Install the shrouds to the drive module.
12	Install the lower front cover to the drive module.

Step	Task (input cables, options “Full size input cable connection terminals and PE busbar” and IP20 shrouds for covering the input cabling area” included)
1	Ground the input cable shields (if present) 360 degrees at the cabinet entry.
2	Connect the twisted shields of the input cables and separate ground cable (if present) to the cabinet grounding busbar.
3	<p>Step drill carefully sufficiently big holes to the entry clear plastic shroud for the cables to be connected. Align the holes in the vertical direction according to the alignment holes in the shroud. Smooth the hole edges.</p> <p>Remove the plastic sheeting from both sides of the shroud.</p> <p>Attach the cables firmly to the cabinet frame to prevent chafing against the hole edges.</p>
4	Put the conductors of the input cables through the drilled holes in the clear plastic shroud.
5	<p><u>For drive modules without option “Full size input cable connection terminals and PE busbar”:</u> Connect the input cable conductors to the drive module L1/U1, L2/V1 and L3/W1 connection busbars, Go to step 12.</p>
For option “Full size input cable connection terminals and PE busbar”: Do steps 6 to 11.	
6	<p>Screw in and tighten the insulators to the drive module by hand. Install the L1/U1 connection terminal to the insulators.</p> <div style="display: flex; align-items: center;">  <p>WARNING! Do not use longer screws or bigger tightening torque than given in the installation drawing. They can damage the insulator and cause dangerous voltage to be present at the module frame.</p> </div> <div style="text-align: center; margin-top: 10px;">  </div>
7	Connect the L1/U1 conductors to the L1/U1 connection terminal.
8	Install the L2/V1 connection terminal to the insulators. See the warning in step 6.
9	Connect the L2/V1 conductors to the L2/V1 connection terminal.
10	Install the L3/W1 connection terminal to the insulators. See the warning in step 6.
11	Connect the L3/W1 conductors to the L3/W1 connection terminal.
12	Install the entry clear plastic shroud. Install the front clear plastic shroud and upper front cover.
13	Install the side and top clear plastic shrouds to the drive module.


Installing the roof and door (Rittal parts)

This drawing shows a layout tested by ABB.



Installing the roof and door (ABB air filters and roof)

This drawing shows a layout tested by ABB.



Removing the protective covering from the drive module air outlet



WARNING!

Remove the protective covering from the top of the drive module after the installation. If the covering is not removed, the cooling air cannot flow freely through the module and the drive will overheat.



Miscellaneous

■ Input power cable entry from top

If you run the input cables from top to the drive module, drill the entry holes to the top clear plastic shroud.

10

Installation example with option “Full power cabling panels to be attached to a cabinet (IP20)”

Contents of this chapter

In this chapter, the drive module is installed into a 400 mm wide Rittal VX25 enclosure in a bookshelf way of mounting. The module is placed in an upright position on the enclosure bottom with its front facing the enclosure door. Space for the additional components can be made by connecting two or more VX25 enclosures together. Available alternative ABB parts are also given.

Limitation of liability

The installation must always be designed and made according to applicable local laws and regulations. ABB does not assume any liability whatsoever for any installation which breaches the local laws and/or other regulations. Furthermore, if the recommendations given by ABB are not followed, the drive may experience problems that the warranty does not cover.

Safety



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur. If you are not a qualified electrical professional, do not do installation, commissioning or maintenance work.

150 Installation example with option “Full power cabling panels to be attached to a cabinet (IP20)”

Required parts

Drive module standard parts		
<ul style="list-style-type: none"> • Drive module • Top guide plate • Fastening bracket • Grounding busbar • Pedestal guide plate • Telescopic extraction and insertion ramp • Fastening screws in a plastic bag • External control unit 		
Drive module options		
Option code	Qty (pcs)	Description
3AXD50000024520 for frame R10, 3AXD50000024561 for frame R11	1	Full power cabling panels
Rittal parts / Alternative ABB parts		
Rittal part code	Qty (pcs)	Description
VX 8406.000	1	Enclosure without mounting plate, bottom plates and side panels
VX 8106.245	1	Side panels for the enclosure
DK 7967.000 (one set = four pieces) ABB 3AUA0000125201 (IP20) ABB 3AUA0000114967 (IP42)	1	Spacers for roof plate / ABB roof Note: For alternative ABB outlet kits, see section Air outlet kits (page 186).
VX 8617.030	5	Punched section with mounting flange, outer mounting level for 600 mm horizontal
VX 8617.010	3	Punched section with mounting flange, outer mounting level for 400 mm horizontal
SK 3243.200 / ABB 3AUA0000117002 (IP20) ABB 3AUA0000117007 (IP42)	4 / 2	Air filter 323 mm × 323 mm. Remove the filter mat according to the manufacturer’s instructions. Note: For alternative ABB air filters, see section Air inlet kits (page 184).
TS 4396.500	3	Support rail (alternative to a customer-made bottom plate)
Customer-made parts (not ABB or Rittal products)		
Dimension drawing code	Qty (pcs)	Description
3AXD50000437368	2	Air baffles See section Air baffles for option +H381 in Rittal VX25 400 mm wide enclosure installation (page 234) for the dimension drawings of the air baffles required in the cabinet.
3AXD50000433988	1	Cabinet bottom plate (alternative to Rittal support rails) See section Bottom plate for option +H381 in Rittal VX25 400 mm wide enclosure installation (page 232) for the dimension drawing of a customer-made bottom plate.

Required tools

- Set of screw drivers (Torx and Pozidriv)
- Set of metric magnetic-end hexagon sockets
- Torque wrench with a 500 mm (20 in) or 2 × 250 mm (2 × 10 in) long socket extension.

Overall flowchart of the installation process

Step	Task	For instructions, see
1	Install the Rittal parts and drive module mechanical accessories into the enclosure	Installing the mechanical accessories into the enclosure (page 151) and Step-by-step drawings for installing full cabling panels (option) in a Rittal VX25 400 mm wide enclosure (page 273)
2	Connect the power cables to the cabling panels	Connecting the power cables (page 152)
3	Install the drive module into the enclosure	Installing the drive module into the enclosure (page 156)
4	Install the external control unit	BCU-02/12/22 control units hardware manual (3AUA0000113605 [English])
5	Connect the control cables	Connecting the control cables to the terminals of the control unit (page 119)
6	Install the remaining parts, for example enclosure doors, side plates, air baffles, etc.	The component manufacturer’s instructions Air baffles for option +H381 in Rittal VX25 400 mm wide enclosure installation (page 234)

Installing the mechanical accessories into the enclosure


Install the mechanical accessories into the enclosure as shown in Step-by-step drawings for installing full cabling panels (option) in a Rittal VX25 400 mm wide enclosure (page 273)

If you do not use Rittal support rails on the bottom of the enclosure but use a custom bottom plate instead, see the dimension drawings for the correct dimensions of the bottom plate.

If the thickness of the bottom plate is not 2.5 mm (0.1 in), adjust the dimensions accordingly.

Connecting the power cables

- Power cable connection diagram example (6-pulse and 12-pulse)



1	Use a separate grounding PE cable (1a) or a cable with a separate PE conductor (1b) if the conductivity of the shield does not meet the requirements for the PE conductor (see section <i>Selecting the power cables</i> (page 91)).
2	360-degree grounding is recommended if shielded cable is used. Ground the other end of the input cable shield or PE conductor at the distribution board.
3	360-degree grounding is required
4	Line contactor
5	Common mode filter
6	du/dt filter or sine filter (options)
7	Use a separate grounding cable if the shield does not meet the requirements of IEC 61439-1 (see section <i>Selecting the power cables</i> (page 91)) and there is no symmetrically constructed grounding conductor in the cable (see section <i>Not allowed power cable types</i> (page 93)).
8	External brake resistor
9	Drive module
10	Switch-disconnector and separate fuses or switch fuse
11	The drive module frame must be connected to the cabinet frame. See section <i>Alternatives for grounding the drive module</i> (page 80) and <i>Cabinet design and construction instructions for drive modules</i> (3AUA0000107668 [English]).

Note: If there is a symmetrically constructed grounding conductor in the motor cable in addition to the conductive shield, connect the grounding conductor to the grounding terminal at the drive and motor ends. Do not use an asymmetrically constructed motor cable. Connecting its fourth conductor at the motor end increases bearing currents and causes extra wear.

The minimum allowed motor cable length without optional output filters is 2 m.
 Maximum cable length of the DC cables is 4 m.
 Protect the input cables with additional fuses or circuit breaker against thermal overload.
 Motor cables must be installed symmetrically to the common motor.

■ Power cable connection procedure




WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

1. Run the motor cables from the motor to the enclosure. Ground the cable shields 360° at the entry plate.
2. Twist the cable shields of the motor cables into bundles and connect them and any separate ground conductors or cables to the ground terminal of the drive module or to the enclosure ground bar.
3. Connect the phase conductors of the motor cables to terminals T1/U2, T2/V2 and T3/W2 of the drive module. For the tightening torques, see the technical data.
4. Drive modules with option +D150: Run the power cables from the brake resistor to the cabinet. Ground the cable shield (if present) 360° at the entry plate. Connect the conductors to the R+ and R- terminals. For the tightening torques, see the technical data.
5. Connect the UDC terminals of the drive modules together. For the tightening torques, see the technical data.

If you run the DC cables outside the cabinet, ground the cable shield 360° at one end only.


154 Installation example with option “Full power cabling panels to be attached to a cabinet (IP20)”



6. Make sure that all power is disconnected and reconnection is not possible. Use proper safe disconnect procedures according to local codes.
7. Run the input cables from the supply source to the enclosure. Ground the cable shields 360° at the entry plate.
8. Twist the cable shields of the input cables into bundles and connect them and any separate ground conductors or cables to grounding busbar of the input cabling panel.
9. Connect the phase conductors of the input cables to terminals L1/U1, L2/V1 and L3/W1 of the drive module. For the tightening torques, see the technical data.

An example installation without DC cabling is shown below.

Installation example with option “Full power cabling panels to be attached to a cabinet (IP20)” 155



View without cabinet side plate in place.

A	360-degree grounding at the entry plate for the input power cables
B	Grounding busbar of the input power cabling panel
C	360-degree grounding at the entry plate for the output power cables
D	Grounding busbar of the output power cabling panel
E	Allowed space for power cables. The input and output power cables must fit inside the area marked with diagonal lines to prevent chafing of the cables when the drive module is inserted into the cabinet.

Installing the drive module into the enclosure




WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.


Handle the drive module carefully. Make sure that the module does not fall down when moving it on the floor and during installation and maintenance work: To open the support legs, press each leg a little down and turn it aside (1, 2). When possible, also secure the module with chains from top.

Do not tilt the drive module (A). It is heavy and its center of gravity is high. The module will overturn from a sideways tilt of 5 degrees. Do not leave the module unattended on a sloping floor.




■ Installation procedure

1. Attach the mounting bracket to the drive module. The bracket will ground the drive module to the cabinet frame.



2. Install the telescopic extraction and insertion ramp to the cabinet base with two screws.
3. Remove the upper and lower left-hand side front covers of the drive module (M4x8 combi screws, 2 N·m [18 lbf·in]).
4. Attach the drive module lifting lugs to the enclosure frame with chains.
5. Push the drive module carefully into to the enclosure preferably with the help from another person.
6. Attach the grounding busbar that has been previously attached to the input cabling panel to the drive module.

Note: The design of the grounding busbar can be different from what is shown in the figure.









7. Connect the busbars of the drive module to the busbars of the cabling panels (M12 combi screw, 70 N·m [52 lbf·ft]).

158 Installation example with option “Full power cabling panels to be attached to a cabinet (IP20)”


8. Attach the drive module to the enclosure from top and bottom, see Assembly drawing of installing the drive module to the enclosure (frame R10) (page 160) (frame R10) or Assembly drawing of installing the drive module to the enclosure (frame R11) (page 161) (frame R11). The top fastening bracket grounds the drive module to the cabinet frame.
 9. Attach the cabinet roof on the spacers and the side panels, see Assembly drawing of installing the roof and door (page 162).
 10. Remove the filter mats from the air filters according to Rittal’s instructions. Install the filters to the cabinet door, see Assembly drawing of installing the roof and door (page 162).
 11. Put back the removed front covers of the drive module on the power cable sections, and connect the control cables (see Connecting the control cables to the terminals of the control unit (page 119)).
-

Installation example with option "Full power cabling panels to be attached to a cabinet (IP20)" 159




160 Installation example with option "Full power cabling panels to be attached to a cabinet (IP20)"

Assembly drawing of installing the drive module to the enclosure (frame R10)



Installation example with option "Full power cabling panels to be attached to a cabinet (IP20)" 161


Assembly drawing of installing the drive module to the enclosure (frame R11)



162 Installation example with option “Full power cabling panels to be attached to a cabinet (IP20)”

Assembly drawing of installing the roof and door

This drawing shows a layout tested by ABB. If you use ABB air filters, install them vertically in the positions shown in section Installing the roof and door (ABB air filters and roof) (page 147).



■ Removing the protective covering from the drive module air outlet



WARNING!

Remove the protective covering from the top of the drive module after the installation. If the covering is not removed, the cooling air cannot flow freely through the module and the drive will overheat.



Miscellaneous

■ Installations with input and motor cables of size 4 × 240 mm² per phase


If resistor cables are to be connected, the lower side plate of the output cabling panel must be removed and the resistor cables lead from side to the terminals of the output cabling panel.

■ Installing the rubber grommet

To get IP20 degree of protection for the drive module, install the input power cables through the rubber grommet. Install the grommet as follows:

1. Cut adequate holes into the grommet for the input power cables.
2. Put the cables through the grommet.
3. Attach the grommet to the input cabling panel with five M4×8 Torx T20 screws as shown below.

164 Installation example with option "Full power cabling panels to be attached to a cabinet (IP20)"



11

Installation checklist

Contents of this chapter

This chapter contains a checklist for the mechanical and electrical installation of the drive.

Checklist

Examine the mechanical and electrical installation of the drive before start-up. Go through the checklist together with another person.



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur. If you are not a qualified electrical professional, do not do installation, commissioning or maintenance work.



WARNING!

Stop the drive and do the steps in section [Electrical safety precautions \(page 19\)](#) before you start the work.

Make sure that ...	<input checked="" type="checkbox"/>
The ambient operating conditions meet the drive ambient conditions specification and enclosure rating (IP code).	<input type="checkbox"/>
The supply voltage matches the nominal input voltage of the drive. See the type designation label.	<input type="checkbox"/>
The insulation resistance of the input power cable, motor cable and motor is measured according to local regulations and the manuals of the drive.	<input type="checkbox"/>
The drive cabinet is attached to the floor, and if necessary due to vibration etc, also by its top to the wall or roof.	<input type="checkbox"/>

166 Installation checklist

Make sure that ...	<input checked="" type="checkbox"/>
The drive module is fastened properly to the enclosure.	<input type="checkbox"/>
The cooling air flows freely in and out of the drive. Air recirculation inside the cabinet is not possible (air baffle plates are installed, or there is another air guiding solution).	<input type="checkbox"/>
<u>If the drive is connected to a network other than a symmetrically grounded TN-S system:</u> You have done all the required modifications (for example, you may need to disconnect the EMC filter or ground-to-phase varistor). See the electrical installation instructions.	<input type="checkbox"/>
The enclosures of the equipment in the cabinet have proper galvanic connection to the cabinet protective earth (ground) busbar; The connection surfaces at the fastening points are bare (unpainted) and the connections are tight, or separate grounding conductors have been installed.	<input type="checkbox"/>
The main circuit connections inside the drive cabinet correspond to the circuit diagrams.	<input type="checkbox"/>
The control unit has been connected. See the circuit diagrams.	<input type="checkbox"/>
Appropriate AC fuses and main disconnecting device are installed.	<input type="checkbox"/>
There is an adequately sized protective earth (ground) conductor(s) between the drive and the switchboard, the conductor is connected to correct terminal, and the terminal is tightened to the correct torque. Grounding has also been measured according to the regulations.	<input type="checkbox"/>
The input power cable is connected to the correct terminals, the phase order is correct, and the terminals are tightened to the correct torque.	<input type="checkbox"/>
There is an adequately sized protective earth (ground) conductor between the motor and the drive. The conductor is connected to the correct terminal, and the terminal is tightened to the correct torque. Grounding has also been measured according to the regulations.	<input type="checkbox"/>
The motor cable is connected to the correct terminals, the phase order is correct, and the terminals are tightened to the correct torque.	<input type="checkbox"/>
The motor cable is routed away from other cables.	<input type="checkbox"/>
No power factor compensation capacitors are connected to the motor cable.	<input type="checkbox"/>
<u>If an external brake resistor is connected to the drive:</u> There is an adequately sized protective earth (ground) conductor between the brake resistor and the drive, and the conductor is connected to the correct terminal, and the terminals are tightened to the correct torque. Proper grounding has also been measured according to the regulations.	<input type="checkbox"/>
<u>If an external brake resistor is connected to the drive:</u> The brake resistor cable is connected to the correct terminals, and the terminals are tightened to the correct torque.	<input type="checkbox"/>
<u>If an external brake resistor is connected to the drive:</u> The brake resistor cable is routed away from other cables.	<input type="checkbox"/>
The control cables are connected to the correct terminals, and the terminals are tightened to the correct torque.	<input type="checkbox"/>
<u>If a drive bypass connection will be used:</u> The Direct On Line contactor of the motor and the drive output contactor are either mechanically and/or electrically interlocked, that is, they cannot be closed at the same time. A thermal overload device must be used for protection when bypassing the drive. Refer to local codes and regulations.	<input type="checkbox"/>
There are no tools, foreign objects or dust from drilling inside the drive.	<input type="checkbox"/>
The area in front of the drive is clean: the drive cooling fan cannot draw any dust or dirt inside.	<input type="checkbox"/>
The cover(s) of the motor connection box are in place. Cabinet shrouds are in place and doors are closed.	<input type="checkbox"/>
The motor and the driven equipment are ready for power-up.	<input type="checkbox"/>

12

Commissioning

Contents of this chapter

This chapter describes how to do the commissioning of the drive.

Start-up procedure

**WARNING!**

Only qualified electrical professionals are allowed to start-up the drive.

1. Make sure that the installation of the drive module has been done according to the checklist in chapter [Installation checklist \(page 165\)](#), and that the motor and driven equipment are ready for start.
2. Perform the start-up tasks instructed by the cabinet-installer of the drive module.
3. Switch the power on, setup the drive control program, and perform the first start of the drive and motor. See the appropriate start-up guide or firmware manual. If you need more information on the use of the control panel, see [ACS-AP-I, -S, -W and ACH-AP-H, -W Assistant control panels user's manual \(3AUA0000085685 \[English\]\)](#).

In addition to the parameter settings required by the application, make the following settings for the drive module package:

- Set parameter 95.04 Control board supply according to how the drive control unit is powered.
 - Set parameter 95.09 Switch fuse controller to Disable.
 - Select the drive type in parameter 95.31 Parallel type configuration. To filter the list, use parameter 95.30 Parallel type list filter.
 - Reboot the control unit either by cycling the power, or by parameter 96.08 Control board boot.
-



- For drives with resistor braking (option +D150): See also section [Start-up \(page 264\)](#).
 - For drives with ABB du/dt filter: Make sure that bit 13 of parameter 95.20 HW options word 1 is switched on.
 - For drives with sine filter: Make sure that parameter 95.15 Special HW settings is set to ABB sine filter. See also [Sine filters hardware manual \(3AXD50000016814 \[English\]\)](#).
4. For drives with ABB motors in explosive atmospheres: See also [ACS880 drives with ABB motors in explosive atmospheres \(3AXD50000019585 \[English\]\)](#).
 5. For drive modules in which the Safe torque off function is in use: Test and validate the operation of the Safe torque off function. See section [Validation test procedure \(page 245\)](#).



13

Fault tracing

Contents of this chapter

This chapter describes the fault tracing possibilities of the drive.

LEDs

The table below describes the LEDs of the drive module with option DPMP-01.

Where	LED	Color	When the LED is lit
Control panel mounting platform	POWER	Green	Control unit is powered and +15 V is supplied to the control panel
	FAULT	Red	Drive in fault state

Warning and fault messages

See the firmware manual for the descriptions, causes and remedies of the control program warning and fault messages.

14

Maintenance

Contents of this chapter

This chapter contains maintenance instructions of the drive modules.

Maintenance intervals

The tables below show the maintenance tasks which can be done by the end user. The complete maintenance schedule is available on the Internet (<https://new.abb.com/drives/services/maintenance/preventive-maintenance>). For more information, consult your local ABB Service representative (www.abb.com/searchchannels).

■ Description of symbols

Action	Description
I	Inspection (visual inspection and maintenance action if needed)
P	Performance of on/off-site work (commissioning, tests, measurements or other work)
R	Replacement

■ Recommended maintenance intervals after start-up

Recommended annual actions by the user	
Action	Description
P	Quality of supply voltage
I	Spare parts
P	DC circuit capacitors reforming, spare modules and spare capacitors
I	Tightness of terminals

Recommended annual actions by the user	
I	Dustiness, corrosion and temperature
I	Heat sink cleaning

Recommended maintenance actions by the user							
Component	Years from start-up						
	3	6	9	12	15	18	21
Cooling							
Main cooling fan							
Main cooling fan (R10 and R11)			R			R	
Auxiliary cooling fan							
Circuit board compartment cooling fans (R10 and R11) LONG-LIFE			R			R	
Aging							
BCU control unit battery (real-time clock)		R		R		R	
Control panel battery (real-time clock)			R			R	
Functional safety							
Safety function test	I See the maintenance information of the safety function.						
Safety component expiry (Mission time, T _M)	20 years						
4FPS10000239703							

Note:

- Maintenance and component replacement intervals are based on the assumption that the equipment is operated within the specified ratings and ambient conditions. ABB recommends annual drive inspections to ensure the highest reliability and optimum performance.
- Long term operation near the specified maximum ratings or ambient conditions may require shorter maintenance intervals for certain components. Consult your local ABB Service representative for additional maintenance recommendations.

Cabinet

■ Cleaning the interior of the cabinet



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur. If you are not a qualified electrical professional, do not do installation, commissioning or maintenance work.



WARNING!

Use a vacuum cleaner with antistatic hose and nozzle, and wear a grounding wristband. Using a normal vacuum cleaner creates static discharges which can damage circuit boards.

1. Stop the drive and do the steps in section [Electrical safety precautions \(page 19\)](#) before you start the work.
2. Open the cabinet door.
3. Clean the interior of the cabinet. Use a vacuum cleaner and a soft brush.
4. Clean the air inlets of the fans and air outlets of the modules (top).
5. Clean the air inlet gratings (if any) on the door.
6. Close the door.

Heatsink

The drive module heatsink collects dust from the cooling air. If the heatsink is not clean, the drive can generate overtemperature warnings and faults. When necessary, clean the heatsink as described in this section.

■ Cleaning the interior of the heatsink



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.




WARNING!

Use a vacuum cleaner with antistatic hose and nozzle, and wear a grounding wristband. Using a normal vacuum cleaner creates static discharges which can damage circuit boards.

1. Stop the drive and do the steps in section [Electrical safety precautions \(page 19\)](#) before you start the work.
2. Remove the attaching screws of the handle plate of the drive module.
3. Remove the handle plate.
4. Vacuum the interior of the heatsink from the opening.

5. Carefully blow clean compressed air (not humid or oily) upwards from the opening and, at the same time, vacuum from the top of the drive module. Prevent dust from entering adjoining equipment.
6. Reinstall the handle plate.



Fans

The lifespan of the cooling fans of the drive depends on running time, ambient temperature and dust concentration. See the firmware manual for the actual signal which indicates the running time of the cooling fan. Reset the running time signal after fan replacement.


Replacement fans are available from ABB. Do not use other than ABB-specified spare parts.

■ Replacing the circuit board compartment cooling fans

**WARNING!**

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

1. Stop the drive and do the steps in section [Electrical safety precautions \(page 19\)](#) before you start the work.
2. Remove the drive module out of the cabinet as described in module replacement instructions.
3. Undo the fastening screw of the fan enclosure.
4. Unplug the power supply cable of the fan.
5. Install the new fan in reverse order to the above.
6. Reset the counter (if used) in group 5 in the control program.




■ Replacing the main cooling fans



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

1. Stop the drive and do the steps in section [Electrical safety precautions](#) (page 19) before you start the work.
2. Remove the drive module out of the cabinet as described in [module replacement instructions](#).
3. Open the support legs of the pedestal.
4. Remove the two screws that fasten the fan assembly plate.
5. Tilt the fan assembly plate down.
6. Disconnect the power supply wires of the fans.
7. Remove the fan assembly from the drive module.
8. Remove the fastening screws of the fan(s) and remove the fan(s) from the assembly plate.
9. Install the new fan(s) in reverse order to the above.
10. Reset the counter (if used) in parameter group 5 in the control program.



Replacing the standard drive module and drive module with option “IP20 shrouds for covering the input and motor cabling area”




WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

Note: The replacement module must be of the same type as the original module: same type code and same option codes.


Handle the drive module carefully:

- Use safety shoes with a metal toe cap to prevent foot injury.
- Lift the drive module only by the lifting lugs.
- Make sure that the module does not topple over when you move it on the floor: To open the support legs, press each leg a little down and turn it aside (1, 2). Whenever possible secure the module also with chains.
- Do not tilt the drive module. It is heavy and its center of gravity is high. The module overturns from a sideways tilt of 5 degrees. Do not leave the module unattended on a sloping floor.



1. Stop the drive and do the steps in section [Electrical safety precautions](#) (page 19) before you start the work.
2. Remove the clear plastic shrouds on the power cables and parts in front of the drive module (if present).
3. Disconnect the power cables.
4. Disconnect the power supply, BGDR and fiber optic cables from the drive module.
5. Disconnect the power supply cable and the fiber optic cables from the external control unit and coil them on the top of the drive module.

6. Remove the screws that attach the drive module to the cabinet at the top and behind the front support legs.
7. Attach the extraction ramp to the cabinet base with two screws.
8. To prevent the drive module from falling, attach its top lifting lugs with chains to the cabinet frame.
9. Pull the drive module carefully out of the cabinet preferably with help from another person.
10. Install the new module in reverse order.



Replacing the drive module with option “Full power cabling panels to be attached to a cabinet (IP20)”




WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.




Note: The replacement module must be of the same type as the original module: same type code and same option codes.

Handle the drive module carefully:

- Use safety shoes with a metal toe cap to prevent foot injury.
- Lift the drive module only by the lifting lugs.
- Make sure that the module does not topple over when you move it on the floor: To open the support legs, press each leg a little down and turn it aside (1, 2). When possible, secure the module also with chains.
- Do not tilt the drive module. It is heavy and its center of gravity is high. The module overturns from a sideways tilt of 5 degrees. Do not leave the module unattended on a sloping floor.



1. Stop the drive and do the steps in section [Electrical safety precautions](#) (page 19) before you start the work.
2. Undo the fastening screws to remove the left-hand side upper and lower front covers of the drive module. M4×10 combi screws, 2 N·m (18 lbf·in).
3. Disconnect the drive module busbars from the input cabling panel. Combi screw M12, 70 N·m (52 lbf·ft).
4. Disconnect the drive module busbars from the output cabling panel. Combi screw M12, 70 N·m (52 lbf·ft).
5. Undo the screws that attach the drive module to the cabinet at the top (a) and behind the front support legs (b).
6. Remove the front air baffle.
7. Attach the extraction/installation ramp to the cabinet base with two screws.
8. Disconnect the power supply cables, STO cables and the fiber optic cables from the external control unit and wind them on the top of the drive module.
9. To prevent the drive module from falling, attach its top lifting lugs with chains to the cabinet frame.
10. Pull the drive module carefully out of the cabinet, preferably with help from another person.
11. Install the new module in reverse order to the above.



Capacitors

The DC link of the drive contains several electrolytic capacitors. Operating time, load, and surrounding air temperature have an effect on the life of the capacitors. Capacitor life can be extended by decreasing the surrounding air temperature.

Capacitor failure is usually followed by damage to the unit and an input cable fuse failure, or a fault trip. If you think that any capacitors in the drive have failed, contact ABB.

■ Reforming the capacitors

The capacitors must be reformed if the drive has not been powered (either in storage or unused) for a year or more. The manufacturing date is on the type designation label. For information on reforming the capacitors, refer to [Capacitor reforming instructions \(3BFE64059629 \[English\]\)](#).

Control panel

See [ACS-AP-I, -S, -W and ACH-AP-H, -W assistant control panels user's manual \(3AUA0000085685 \[English\]\)](#).

Replacing the memory unit

See [BCU-02/12/22 control units hardware manual \(3AUA0000113605 \[English\]\)](#).

Reduced run

A “reduced run” function makes it possible to continue operation with one drive module if the other module is out of service, for example because of maintenance work. In principle, reduced run is possible with only one module, but the physical requirements of operating the motor still apply; the remaining module in use must be able to provide the motor with enough magnetizing current.

■ Starting reduced run operation



WARNING!

Obey the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

1. Stop the drive and do the steps in section [Electrical safety precautions \(page 19\)](#) before you start the work.
 2. If the control unit is powered from the faulty module, connect the control unit to another 24 V DC power supply. ABB recommends using an external power supply with parallel-connected drive modules.
 3. Disconnect all cables from the module to be serviced and remove it from its bay. See section [Replacing the standard drive module and drive module with option “IP20 shrouds for covering the input and motor cabling area” \(page 177\)](#).
 4. Switch on the power to the remaining drive module.
 5. Enter the number of drive modules present into parameter 95.13 Reduced run mode.
-

6. Reset all faults and start the drive module. The maximum current is now automatically limited according to the new drive module configuration. A mismatch between the number of detected modules (parameter 95.14) and the value set in parameter 95.13 will generate a fault.
7. If the STO function is in use, validate it as described in chapter *The Safe torque off function* (page 237).

■ Resuming normal operation



WARNING!

Repeat the steps described in section *Electrical safety precautions*. If you ignore them, injury or death, or damage to the equipment can occur.

1. Reinstall the module into its bay.
2. Switch on the power to the drive module package.
3. Enter “0” into parameter 95.13 Reduced run mode.
4. If the STO function is in use, validate it as described in chapter *The Safe torque off function*.

Functional safety components

The mission time of functional safety components is 20 years which equals the time during which failure rates of electronic components remain constant. This applies to the components of the standard Safe torque off circuit as well as any modules, relays and, typically, any other components that are part of functional safety circuits.

The expiry of mission time terminates the certification and SIL/PL classification of the safety function. The following options exist:

- Renewal of the whole drive and all optional functional safety module(s) and components.
- Renewal of the components in the safety function circuit. In practice, this is economical only with larger drives that have replaceable circuit boards and other components such as relays.

Note that some of the components may already have been renewed earlier, restarting their mission time. The remaining mission time of the whole circuit is however determined by its oldest component.

Contact your local ABB service representative for more information.

15

Ordering information

Contents of this chapter

This chapter gives ordering information on additional components available from ABB for the drive module installation.

Note: This chapter only lists the installation accessories available from ABB. All other parts must be sourced from a third party by the system integrator.


See the installation examples for Rittal VX25 enclosure tested by ABB in sections [Installing the roof and door \(Rittal parts\) \(page 146\)](#) and [Assembly drawing of installing the roof and door \(page 162\)](#), or dimension your own cabinet.

Control panel

The control panel is not included with the drive module but must be ordered separately. One control panel is required for the commissioning of an ACS880 drive system, even if the Drive composer PC tool is used.

The control panel can be mounted on the cabinet door with the help of a door mounting kit.

Type	Description	Ordering code	Illustration
ACS-AP-W	Control panel with Bluetooth	3AXD50000025965	

Type	Description	Ordering code	Illustration
ACS-AP-I	Control panel	3AUA0000088311	
DPMP-01	Door mounting kit for flush mounting. Includes a control panel mounting platform, an IP54 cover and a 3-meter panel connection cable.	3AUA0000108878	

Brake choppers and resistors

See chapter Resistor braking (page 259).

Output (du/dt) filters

See section du/dt filters (page 267).

Sine filters

See section Sine filters (page 268).




EMC filter ARFI-10

Ordering code: 68241561




Cabinet ventilation


■ Air inlet kits

Mounting screws are included.

Enclosure width / Degree of protection	Kit code	Ordering code	Illustration
800 mm / IP20	A-8-X-023	3AUA0000117005	 <p data-bbox="987 696 1390 723">Instruction code: 3AUA0000116887</p>
800 mm / IP42	A-8-X-026	3AUA0000117009	 <p data-bbox="987 1193 1390 1220">Instruction code: 3AUA0000116875</p>
800 mm / IP54	A-8-X-029	3AXD50000009186	 <p data-bbox="978 1680 1398 1706">Instruction code: 3AXD50000010001</p>

■ Air outlet kits

Enclosure width / Degree of protection	Qty	Kit code	Ordering code	Illustration
800 mm / IP20	2	A-4-X-062	3AUA0000125201	 <p data-bbox="858 651 1270 678">Instruction code: 3AXD50000001982</p> <p data-bbox="858 701 1270 728">Note: Fan to be ordered separately</p>
800 mm / IP42	2	A-4-X-060	3AUA0000114967	 <p data-bbox="858 1016 1270 1043">Instruction code: 3AUA0000115290</p> <p data-bbox="858 1066 1270 1093">Note: Fan to be ordered separately</p>
800 mm / IP54 (IEC)	2	A-4-X-064	3AXD50000009187	 <p data-bbox="858 1641 1270 1668">Instruction code: 3AXD50000010284</p> <p data-bbox="858 1691 1270 1718">Note: Fan to be ordered separately</p>


Enclosure width / Degree of protection	Qty	Kit code	Ordering code	Illustration
800 mm / IP54 (UL)	2	A-4-X-067	3AXD50000010362	 <p>Instruction code: 3AXD50000010284</p> <p>Note: Fan to be ordered separately</p>

Cooling fans

Two cooling fans must be installed inside the air outlet compartment to ensure sufficient cooling of the cabinet.

Enclosure width / Degree of protection	Component		Qty	Ordering code
	Name	Data		
800 mm / IP20, IP42	Fan	R2E225-RA92-17 (230 V)	2	3AXD50000000514
	Capacitor	MSB MKP 3,5/603/E1679	2	3AXD50000000882
	Connector	SPB2,5/7 (2.5 mm ² , 12AWG)	2	3AXD50000000723
	Connector	SC 2,5-RZ/7 (2.5 mm ² , 12AWG)	2	3AXD50000000724
800 mm / IP54	Fan	RB4C-355/170	2	3AXD50000006934
	Capacitor	MSB MKP 6/603/E1679	2	3AXD50000006959
	Connector	SPB2,5/7 (2.5 mm ² , 12AWG)	2	3AXD50000000723
	Connector	SC 2,5-RZ/7 (2.5 mm ² , 12AWG)	2	3AXD50000000724

F50 accessories kit

Kit code	Ordering code	Illustration
A-X-X-279	3AXD50000025495	 <p>Instruction code: 3AXD50000025583</p>

Control panel mounting platforms

Kit	Ordering code
DPMP-02 control panel mounting platform	3AXD50000009374
DPMP-04 control panel mounting platform	3AXD50000217717

Accessory kits

Kit	Ordering code
Full size input cable connection terminals and PE busbar. Not to be used with full power cabling panels which are to be attached to a cabinet.	3AXD50000024518
Full size output cable connection terminals. Not to be used with full power cabling panels which are to be attached to a cabinet.	3AXD50000024519
For frame R10: Full power cabling panels to be attached to a cabinet (IP20)	3AXD50000024520
For frame R11: Full power cabling panels to be attached to a cabinet (IP20)	3AXD50000024561
Power cable connection terminals on the right-hand side of the drive module. Not to be used with full power cabling panels which are to be attached to a cabinet. Not to be used with flat mounting.	3AXD50000026152
Flat mounting. Not to be used with full power cabling panels which are to be attached to a cabinet. Not to be used with power cable connection terminals on the right-hand side of the drive module.	3AXD50000024562
For frame R10: IP20 shrouds for covering the input and motor cabling area. Not to be used with full power cabling panels which are to be attached to a cabinet.	3AXD50000024563
For frame R11: IP20 shrouds for covering the input and motor cabling area. Not to be used with full power cabling panels which are to be attached to a cabinet.	3AXD50000024564
For frame R10: Cover plate kit for right-hand side module.	3AXD50000236206
For frame R11: Cover plate kit for right-hand side module.	3AXD50000235582

16

Technical data

Contents of this chapter

This chapter contains the technical specifications of the drive, for example the ratings, sizes and technical requirements, provisions for fulfilling the requirements for CE and other markings.

Electrical ratings

The ratings of the drive module packages with 50 Hz and 60 Hz supply are given below.

IEC RATINGS											
ACS880-04XT-...	Frame size	Input current	Output ratings								
			Nominal use					Light-duty use		Heavy-duty use	
			I_1	I_{max}	I_{max_start}	I_2	P_n	S_n	I_{Ld}	P_{Ld}	I_{Hd}
A	A	A	A	kW	kVA	A	kW	A	kW		
$U_n = 400\text{ V}$											
1010A-3	2×R10	1010	1270	1441	1010	560	700	997	560	746	400
1190A-3	2×R10	1190	1343	1755	1190	630	824	1167	630	878	500
1330A-3	2×R11	1330	1886	2024	1330	710	921	1316	710	1041	560
1610A-3	2×R11	1610	2024	2024	1610	900	1115	1570	900	1334*	710
$U_n = 500\text{ V}$											
1010A-5	2×R10	1010	1270	1441	1010	710	875	992	710	720	500
1160A-5	2×R10	1160	1343	1755	1160	800	1008	1146	800	878	630
1310A-5	2×R11	1310	1564	2024	1310	900	1134	1297	900	1041	710
1610A-5	2×R11	1610	2024	2024	1610	1000	1394	1570	1000	1282**	900
$U_n = 690\text{ V}$											
0810A-7	2×R10	810	1017	1356	810	810	968	791	710	678***	630

IEC RATINGS												
ACS880-04XT-...	Frame size	Input current	Output ratings									
			Nominal use					Light-duty use		Heavy-duty use		
			I_1	I_{max}	I_{max_start}	I_2	P_n	S_n	I_{Ld}	P_{Ld}	I_{Hd}	P_{Hd}
			A	A	A	A	kW	kVA	A	kW	A	kW
0960A-7	2×R11	960	1260	1674	960	900	1147	929	900	837	800	
1080A-7	2×R11	1080	1472	1858	1080	1000	1291	1051	1000	929	900	
1320A-7	2×R11	1320	1509	2024	1320	1200	1578	1297	1200	1051***	1000	
3AXD10000363510												

UL/NEC RATINGS												
ACS880-04XT-...	Frame size	Input current	Max. current		Output ratings							
					App. power	Light-duty use			Heavy-duty use			
						S_n	I_{Ld}	P_{Ld}		I_{Hd}	P_{Hd}	
						kVA	A	kW	hp	A	kW	hp
$U_n = 480\text{ V}$												
1010A-5	2×R10	1010	1270	1441	875	997	710	900	720	500	600	
1160A-5	2×R10	1160	1343	1755	1005	1146	800	1000	878	630	700	
1310A-5	2×R11	1310	1564	2024	1134	1297	900	1000	1041	710	900	
1610A-5	2×R11	1610	2024	2024	1394	1570	1000	1250	1282**	900	1000	
$U_n = 575\text{ V}$												
0810A-7	2×R10	810	1017	1356	968	791	710	800	678***	630	700	
0960A-7	2×R11	960	1260	1674	1147	929	900	1000	837	800	800	
1080A-7	2×R11	1080	1472	1858	1291	1051	1000	1000	929	900	1000	
1320A-7	2×R11	1320	1509	2024	1578	1297	1200	1250	1051***	1000	1000	
3AXD10000363510												

U_n	Nominal voltage of the drive. For input voltage range, see <i>Type designation key</i> (page 47).
I_1	Nominal input current (rms) at 40 °C (104 °F)
I_{max}	Maximum output current. Available for 10 seconds at start, otherwise as long as allowed by drive temperature. 140% ... 200% of I_{Hd} , depending on power rating.
I_{max_start}	Maximum output current at start. Available for two seconds only at start every seven seconds if start current limit is activated by parameter 30.15 Maximum start current enable.
I_2	Continuous rms output current. No overload capability at 40 °C (104 °F). This is indicated in the type designation label as output current I_2 .
P_n	Typical motor power in no-overload use
S_n	Apparent power (no overload)
I_{Ld}	Continuous rms output current allowing 10% overload for 1 minute every 5 minutes
P_{Ld}	Typical motor power for light-overload use
I_{Hd}	Continuous rms output current allowing 50% overload for 1 minute every 5 minutes * Continuous rms output current allowing 40% overload for 1 minute every 5 minutes ** Continuous rms output current allowing 45% overload for 1 minute every 5 minutes *** Continuous rms output current allowing 44% overload for 1 minute every 5 minutes
P_{Hd}	Typical motor power for heavy-duty use

Note: To achieve the rated motor power given in the table, the rated current of the drive must be higher than or equal to the rated motor current. The power ratings apply to most IEC 34 motors at the nominal voltage of the drive.

ABB recommends to select the drive, motor and gear combination for the required motion profile with the DriveSize dimensioning tool available from ABB.

Output derating

■ When is derating necessary


Derate the continuous output current of the drive if

- ambient temperature exceeds +40 °C (+104 °F) or
- drive is installed higher than 1000 m (3280 ft) above sea level
- switching frequency is other than default
- the minimum requirements of motor cable length are not met (see chapter Filters (page 267)).

Note: The final derating factor is a multiplication of all applicable derating factors.

■ Ambient temperature derating


In the temperature range +40...55 °C (+104...131 °F), the rated output current is derated by 1% for every added 1 °C (1.8 °F) as follows. Calculate the output current by multiplying the current given in the rating table by the derating factor.



■ Altitude derating

At altitudes above 1000 m (3281 ft) above sea level, the output current derating is 1 percentage point for every added 100 m (328 ft). For example, the derating factor for 1500 m (4921 ft) is 0.95. The maximum permitted installation altitude is given in the technical data.

If the surrounding air temperature is less than +40 °C (104 °F), the derating can be reduced by 1.5 percentage points for every 1 °C (1.8 °F) reduction in temperature. A few altitude derating curves are shown below.



For a more accurate derating, use the DriveSize PC tool.

■ **Deratings for special settings in the drive control program**

Enabling special settings in the drive control program can require output current derating.

Ex motor, sine filter, low noise

Table below gives the deratings for these cases:

- drive is used with an ABB motor for explosive atmospheres (Ex) and EX motor in parameter 95.15 Special HW settings is enabled
- sine filter given in the selection table in section Sine filters (page 268) is used and ABB sine filter in parameter 95.15 Special HW settings is enabled
- Low noise optimization is selected in parameter 97.09 Switching freq mode.

With other than recommended sine filters (see [Sine filters \(page 268\)](#)) and non-ABB Ex motors, contact ABB.

ACS880-04XT-...	Output ratings for special settings											
	Ex motor (ABB Ex motor)				ABB sine filter				Low noise mode			
	Nominal use		Light-duty use	Heavy-duty use	Nominal use		Light-duty use	Heavy-duty use	Nominal use		Light-duty use	Heavy-duty use
	I_2	P_n	I_{Ld}	I_{Hd}	I_2	P_n	I_{Ld}	I_{Hd}	I_2	P_n	I_{Ld}	I_{Hd}
A	kW	A	A	A	kW	A	A	A	kW	A	A	
$U_n = 400\text{ V}$												
1010A-3	959	435	677	499	940	435	901	666	760	435	729	541
1190A-3	1128	580	795	587	1104	580	1060	782	892	460	857	637
1330A-3	1227	653	867	646	1190	653	1156	861	955	460	913	718
1610A-3	1489	828	1049	828	1444	828	1398	1104	1159	653	1104	920*
$U_n = 500\text{ V}$												
1010A-5	924	618	886	663	894	618	847	604	696	435	661	519
1160A-5	1065	736	1018	771	1030	736	975	736	754	460	721	548
1310A-5	1209	828	1179	960	1172	828	1141	933	850	580	788	666
1610A-5	1413	920	1374	1093	1343	920	1306	1030	1012	736	938	754
$U_n = 690\text{ V}$												
0810A-7	712	669	693	593	662	653	644	552***	534	460	515	434***
0960A-7	793	736	767	681	736	653	714	629	552	460	534	482
1080A-7	892	828	865	826	828	736	802	708	626	580	607	552
1320A-7	1091	920	1056	883	1012	920	975	828***	828	736	791	644***
3AXD10000363510												

U_n	Nominal voltage of the drive
I_2	Nominal output current (rms) at 40 °C (104 °F)
P_n	Typical motor power in no-overload use
I_{Ld}	Continuous rms output current allowing 10% overload for 1 minute every 5 minutes *Continuous rms output current allowing 40% overload for 1 minute every 5 minutes **Continuous rms output current allowing 45% overload for 1 minute every 5 minutes ***Continuous rms output current allowing 44% overload for 1 minute every 5 minutes
I_{Hd}	Continuous rms output current allowing 50% overload for 1 minute every 5 minutes

Note: To achieve the rated motor power given in the table, the rated current of the drive must be higher than or equal to the rated motor current. The power ratings apply to most IEC 34 motors at the nominal voltage of the drive.

ABB recommends to select the drive, motor and gear combination for the required motion profile with the DriveSize dimensioning tool available from ABB.

■ High speed mode

The selection **High speed mode** of parameter 95.15 Special HW settings improves control performance at high output frequencies. ABB recommends it to be selected with output frequency of 120 Hz and above.

This table gives the drive module ratings for 120 Hz output frequency and the maximum output frequency when **High speed mode** in parameter 95.15 Special HW settings is enabled. With output frequencies lower than the maximum output frequency, the current derating is less than the value given in the table. Contact ABB for operation above the recommended maximum output frequency or for the output current derating with output frequencies above 120 Hz and below the maximum output frequency.

ACS880-04XT-...	Deratings with selection High speed mode of parameter 95.15 Special HW settings									
	120 Hz output frequency					Maximum output frequency				
	Fre- quency	Nominal use		Light- duty use	Heavy- duty use	Maxim- um fre- quency	Nominal use		Light- duty use	Heavy- duty use
	f	I_2	P_n	I_{Ld}	I_{Hd}	f_{max}	I_2	P_n	I_{Ld}	I_{Hd}
Hz	A	kW	A	A	Hz	A	kW	A	A	
$U_n = 400\text{ V}$										
1010A-3	120	1010	544	997	746	500	760	435	729	541
1190A-3	120	1190	650	1167	878	500	892	460	857	637
1330A-3	120	1330	734	1316	1041	500	955	460	913	718
1610A-3	120	1610	915	1570	1334*	500	1159	653	1104	920*
$U_n = 500\text{ V}$										
1010A-5	120	1010	693	997	720	500	696	435	661	519
1160A-5	120	1160	822	1146	878	500	754	460	721	548
1310A-5	120	1310	916	1297	1041	500	850	580	788	666
1610A-5	120	1610	1153	1570	1282**	500	1012	736	938	754
$U_n = 690\text{ V}$										
0810A-7	120	810	753	791	678***	375	546	471	528	445***
0960A-7	120	960	920	929	837	375	552	460	534	482
1080A-7	120	1080	1025	1051	929	375	626	580	607	552
1320A-7	120	1320	1300	1297	1051***	375	828	736	791	644***
3AXD10000363510										

f	Output frequency
f_{max}	Maximum output frequency with High speed mode
U_n	Nominal voltage of the drive
I_2	Continuous rms output current. No overload capability at 40 °C (104 °F).
P_n	Typical motor power in no-overload use
I_{Ld}	Continuous rms output current allowing 10% overload for 1 minute every 5 minutes
I_{Hd}	Continuous rms output current allowing 50% overload for 1 minute every 5 minutes *Continuous rms output current allowing 40% overload for 1 minute every 5 minutes **Continuous rms output current allowing 45% overload for 1 minute every 5 minutes ***Continuous rms output current allowing 44% overload for 1 minute every 5 minutes

Modules used

Drive module package type	Drive module	
	Type	Qty + size
<i>U_n</i> = 400 V		
ACS880-04XT-1010A-3	ACS880-04-585A-3+P943	2×R10
ACS880-04XT-1190A-3	ACS880-04-650A-3+P943	2×R10
ACS880-04XT-1330A-3	ACS880-04-725A-3+P943	2×R11
ACS880-04XT-1610A-3	ACS880-04-880A-3+P943	2×R11
<i>U_n</i> = 500 V		
ACS880-04XT-1010A-5	ACS880-04-583A-5+P943	2×R10
ACS880-04XT-1160A-5	ACS880-04-635A-5+P943	2×R10
ACS880-04XT-1310A-5	ACS880-04-715A-5+P943	2×R11
ACS880-04XT-1610A-5	ACS880-04-880A-5+P943	2×R11
<i>U_n</i> = 690 V		
ACS880-04XT-0810A-7	ACS880-04-430A-7+P943	2×R10
ACS880-04XT-0960A-7	ACS880-04-522A-7+P943	2×R11
ACS880-04XT-1080A-7	ACS880-04-590A-7+P943	2×R11
ACS880-04XT-1320A-7	ACS880-04-721A-7+P943	2×R11
3AXD10000363510		

Fuses (IEC)

aR fuses by Cooper Bussmann for protection against short-circuit in the input power cable of the drive are listed below.

Drive module package type ACS880- 04XT-...	Ultrarapid (aR) fuses per drive module						
	Min. short- circuit cur- rent ¹⁾	Input cur- rent	Fuse				
	A	A	A	A ² s	V	Type DIN 43653 with trip indicator (without trip indic- ator)	Size
$U_n = 400\text{ V}$							
1010A-3	6500	1010	1000	945000	690	170M6064 (170M6014)	3
1190A-3	6500	1190	1000	945000	690	170M6064 (170M6014)	3
1330A-3	9100	1330	1250	1950000	690	170M6066 (170M6016)	3
1610A-3	11000	1610	1600	3900000	690	170M6069 (170M6019)	3
$U_n = 500\text{ V}$							
1010A-5	6500	1010	1000	945000	690	170M6064 (170M6014)	3
1160A-5	6500	1160	1000	945000	690	170M6064 (170M6014)	3
1310A-5	9100	1310	1250	1950000	690	170M6066 (170M6016)	3
1610A-5	11000	1610	1600	3900000	690	170M6069 (170M6019)	3
$U_n = 690\text{ V}$							
0810A-7	6500	810	1000	945000	690	170M6064 (170M6014)	3
0960A-7	9100	960	1250	195000	690	170M6066 (170M6016)	3
1080A-7	10200	1080	1400	2450000	690	170M6067 (170M6017)	3
1320A-7	10500	1320	1500	3100000	690	170M6068 (170M6018)	3
3AXD10000363510							

¹⁾ Minimum short-circuit current of the installation

Note: The fuses per module are the same as for single drive modules, but the fuses must have a trip indicator. If fuses without a built-in trip indicator are used, the user must equip them with external fuse monitoring.

In multicable installations, install only one fuse per phase (not one fuse per conductor).

Fuses with higher current rating than the recommended ones must not be used. Fuses with lower current rating can be used.

Fuses from other manufacturers can be used if they agree with the ratings and the melting curve of the fuse does not exceed the melting curve of the fuse mentioned in the table.

■ Calculating the short-circuit current of the installation

Make sure that the short-circuit current of the installation is at least the value given in the fuse table.

The short-circuit current of the installation can be calculated as follows:

$$I_{k2-ph} = \frac{U}{2 \cdot \sqrt{R_c^2 + (Z_k + X_c)^2}}$$

where

I_{k2-ph}	Short-circuit current in symmetrical two-phase short-circuit
U	Network line-to-line voltage (V)
R_c	Cable resistance (ohm)
Z_k	$Z_k = z_k \cdot U_n^2 / S_n =$ transformer impedance (ohm)
z_k	Transformer impedance (%)
U_n	Transformer rated voltage (V)
S_n	Nominal apparent power of the transformer (kVA)
X_c	Cable reactance (ohm)

Calculation example

Drive module package: ACS880-04XT-1310-5

- Module = ACS880-04-715A-5 (Fuses per drive module, short circuit current calculated per drive module)
- Supply voltage = 500 V

Transformer:

- rated power $S_n = 5000$ kVA
- rated voltage (drive supply voltage) $U_N = 480$ V
- transformer impedance $z_k = 10\%$.

Supply cable:

- length = 170 m
 - resistance/length = 0.125 ohm/km
 - reactance/length = 0.074 ohm/km.
-

$$Z_k = z_k \cdot \frac{U_N^2}{S_N} = 0.1 \cdot \frac{(480 \text{ V})^2}{5000 \text{ kVA}} = 4.61 \text{ mohm}$$

$$R_c = 170 \text{ m} \cdot 0.125 \frac{\text{ohm}}{\text{km}} = 21.25 \text{ mohm}$$

$$X_c = 170 \text{ m} \cdot 0.074 \frac{\text{ohm}}{\text{km}} = 12.58 \text{ mohm}$$

$$I_{k2\text{-ph}} = \frac{500 \text{ V}}{2 \cdot \sqrt{(21.25 \text{ mohm})^2 + (4.61 \text{ mohm} + 12.58 \text{ mohm})^2}} = 9.15 \text{ kA}$$

The calculated short-circuit current 9.15 kA is higher than the minimum short-circuit current of the drive aR fuse type 1706066 (9100 A). -> The 690 V aR fuse (170M6066) can be used.

Fuses (UL)

UL fuses for branch circuit protection per NEC per drive module are listed below. Obey the local regulations. The listed fuses do not include trip indicators by default.

Drive module package type	UL fuses per drive module					
	Input current (A)	Fuse				
		A	V	Manufacturer	UL class	Type
$U_n = 480 \text{ V}$						
ACS880-04XT-1010A-5	1010	800	600	Ferraz	L	A4BY800
ACS880-04XT-1160A-5	1160	800	600	Ferraz	L	A4BY800
ACS880-04XT-1310A-5	1310	800	600	Ferraz	L	A4BY800
ACS880-04XT-1610A-5	1610	1000	600	Ferraz	L	A4BY1000
$U_n = 575 \text{ V}$						
ACS880-04XT-0810A-7	810	500	600	Bussmann	T	JJS-500
ACS880-04XT-0960A-7	960	600	600	Bussmann	T	JJS-600
ACS880-04XT-1080A-7	1080	800	600	Ferraz	L	A4BY800
ACS880-04XT-1320A-7	1320	800	600	Ferraz	L	A4BY800
3AXD10000363510						

1. Fuses are required as part of the installation, are not included in the base drive configuration and must be provided by others.
2. Fuses with a higher current rating than specified must not be used.
3. The UL listed fuses recommended by ABB are the required branch circuit protection per NEC. Circuit breakers listed in section Circuit breakers (UL) are also acceptable as branch circuit protection.
4. The recommended size or smaller UL listed 248 fast acting, time delay, or high speed fuses must be used to maintain the UL listing of the drive. Additional protection can be used. Refer to local codes and regulations.
5. A fuse of a different class can be used at the high fault rating where the I_{peak} and I^2t of the new fuse is not greater than that of the specified fuse.
6. UL listed 248 fast acting, time delay, or high speed fuses from other manufacturers can be used if they meet the same class and rating requirements specified in the rules above.
7. When installing a drive, always follow ABB installation instructions, NEC requirements and local codes.
8. Alternative fuses can be used if they meet certain characteristics. For acceptable fuses, see the manual supplement (3AXD50000645015).

In multicable installations, install only one fuse per phase (not one fuse per conductor).

Circuit breakers

The protective characteristics of circuit breakers depend on the type, construction and settings of the breakers. There are also limitations pertaining to the short-circuit capacity of the supply network. Your local ABB representative can help you in selecting the breaker type when the supply network characteristics are known.

You can use the circuit breakers listed below. Other circuit breakers can be used with the drive if they provide the same electrical characteristics. ABB does not assume any liability whatsoever for the correct function and protection with circuit breakers not listed below. Furthermore, if the recommendations given by ABB are not obeyed, the drive can experience problems that the warranty does not cover.

Drive module type	Frame size	ABB molded case circuit breaker (Tmax)	kA ¹⁾
		Product ID (Type)	
$U_n = 400\text{ V}$			
ACS880-04-585A-3	R10	1SDA069428R1 (T6V 800 PR221DS-LS/I In=800 3p F F)	30
ACS880-04-650A-3	R10	1SDA069428R1 (T6V 800 PR221DS-LS/I In=800 3p F F)	30
ACS880-04-725A-3	R11	1SDA062770R1 (T7H 1000 PR231/P LS/I In=1000A 3p F F)	50
ACS880-04-880A-3	R11	1SDA062770R1 (T7H 1000 PR231/P LS/I In=1000A 3p F F)	50
$U_n = 500\text{ V}$			
ACS880-04-583A-5	R10	1SDA054412R1 (T5H 630 PR221DS-LS/I In=630 3p F F)	30
ACS880-04-635A-5	R10	1SDA069428R1 (T6V 800 PR221DS-LS/I In=800 3p F F)	30
ACS880-04-715A-5	R11	1SDA062770R1 (T7H 1000 PR231/P LS/I In=1000A 3p F F)	50
ACS880-04-880A-5	R11	1SDA062770R1 (T7H 1000 PR231/P LS/I In=1000A 3p F F)	50
$U_n = 690\text{ V}$			
ACS880-04-430A-7	R10	1SDA054412R1 (T5H 630 PR221DS-LS/I In=630 3p F F)	30
ACS880-04-522A-7	R11	1SDA069428R1 (T6V 800 PR221DS-LS/I In=800 3p F F)	40
ACS880-04-590A-7	R11	1SDA069428R1 (T6V 800 PR221DS-LS/I In=800 3p F F)	40
ACS880-04-721A-7	R11	²⁾	²⁾
¹⁾ Maximum allowed rated conditional short-circuit current (IEC 61439-1) of the electrical power network			
²⁾ Contact your local ABB representative			

**WARNING!**

Due to the inherent operating principle and construction of circuit breakers, independent of the manufacturer, hot ionized gases can escape from the breaker enclosure in case of a short-circuit. To ensure safe use, pay special attention to the installation and placement of the breakers. Obey the manufacturer's instructions.

Dimensions, weights and free space requirements

Drive module with option "IP20 shrouds for covering the input and motor cabling area"								
Frame size	Height		Width		Depth		Weight*	
	mm	in	mm	in	mm	in	kg	lb
R10	1541	60.67	350	14.82	505	19.88	161	355
R11	1741	68.54	350	14.82	505	19.88	199	439

Standard drive module configuration								
Frame size	Height		Width		Depth		Weight*	
	mm	in	mm	in	mm	in	kg	lb
R10	1462	57.56	305	12.01	506	19.92	156	345
R11	1662	65.43	305	12.01	506	19.92	156	345

Option "Full power cabling panels to be attached to a cabinet (IP20)"								
Frame size	Height		Width		Depth		Weight*	
	mm	in	mm	in	mm	in	kg	lb
R10	1590	62.62	329	12.95	516	20.31	196	432
R11	1740	68.52	329	12.95	516	20.31	233	514

* approximate (depends on the selected options)

The weight of the cabling panels of option "Full power cabling panels to be attached to a cabinet (IP20)" is 30 kg (66 lb).

Additional depth with option "Flat mounting" when the mounting brackets are used: 18.5 mm (0.73 in.)

For the free space requirements, refer to section [Free space requirements \(page 65\)](#).

Losses, cooling data and noise

ACS880-04XT-...	Frame size	Air flow per drive module		Heat dissipation per drive module ¹⁾	Noise	
		m ³ /h	ft ³ /min		Drive module	Drive
				W	dB(A)	dB(A)
U_n = 400 V						
1010A-3	2×R10	1200	707	6409	72	75
1190A-3	2×R10	1200	707	8122	72	75
1330A-3	2×R11	1200	707	8764	72	75
1610A-3	2×R11	1420	848	10578	71	74
U_n = 500 V						
1010A-5	2×R10	1200	707	6409	72	75
1160A-5	2×R10	1200	707	8122	72	75
1310A-5	2×R11	1200	707	8764	72	75
1610A-5	2×R11	1420	848	10578	71	74
U_n = 690 V						
0810A-7	2×R10	1200	707	7070	72	75
0960A-7	2×R11	1200	707	6888	72	75
1080A-7	2×R11	1200	707	8471	72	75
1320A-7	2×R11	1420	848	10677	71	74
3AXD10000363510						

¹⁾ Typical drive losses when it operates at 90% of the motor nominal frequency and 100% of the drive nominal output current (calculated according to IEC61800-9-2).

The cooling air temperature rises 30 degrees Celsius when it goes through the drive module if the temperature of the input cooling air is 40 degrees Celsius.

Typical power cable sizes

The tables below give typical copper and aluminum cable types with concentric copper shield for the drive modules with nominal current. See also section [Terminal and entry data](#) for the power cables (page 206).

ACS880-04XT-...	IEC ¹⁾ input and motor cabling			
	Cabling per drive module ²⁾		Common cabling for the drive modules ³⁾	
	Cu cable type	Al cable type	Cu cable type	Al cable type
	mm ²	mm ²	mm ²	mm ²
U_n = 400 V				
1010A-3	3×(3×120)	3×(3×185)	4×(3×185)	5×(3×240)
1190A-3	3×(3×150)	3×(3×240)	4×(3×240)	6×(3×240)
1330A-3	3×(3×185)	4×(3×185)	5×(3×240)	6×(3×240)
1610A-3	3×(3×240)	4×(3×240)	6×(3×240)	7×(3×240)
U_n = 500 V				
1010A-5	3×(3×120)	3×(3×185)	4×(3×185)	5×(3×240)
1130A-5	3×(3×150)	3×(3×240)	4×(3×240)	6×(3×240)
1310A-5	3×(3×185)	4×(3×185)	5×(3×240)	6×(3×240)
1610A-5	3×(3×240)	4×(3×240)	6×(3×240)	7×(3×240)
U_n = 690 V				
0810A-7	3×(3×95)	3×(3×120)	4×(3×150)	4×(3×240)
0960A-7	3×(3×120)	3×(3×185)	4×(3×185)	5×(3×185)
1080A-7	3×(3×150)	3×(3×185)	4×(3×240)	5×(3×240)
1320A-7	3×(3×185)	4×(3×185)	5×(3×240)	6×(3×240)

¹⁾ The cable sizing is based on max. 9 cables laid on a cable ladder side by side, three ladder type trays one on top of the other, ambient temperature 30 °C (86 °F) PVC insulation, surface temperature 70 °C (158 °F) (EN 60204-1 and IEC 60364-5-52). For other conditions, dimension the cables according to local safety regulations, appropriate input voltage and the load current of the drive.

²⁾ See section [Drive connection examples](#) (page 33)

³⁾ The supply cables are connected to a common switch or breaker, see section [Drive connection examples](#) (page 33). The whole input current flows through common cabling and you can use the recommended cables for that. The connection from the switch to the drive modules inside the cabinet can be made with busbars. Note that common output cables require the use of du/dt filters.

Temperature: Select a cable rated for at least 70 °C maximum permissible temperature of conductor in continuous use.

Voltage: 600 V AC cable is accepted for up to 500 V AC. 750 V AC cable is accepted for up to 600 V AC. 1000 V AC cable is accepted for up to 690 V AC.

ACS880-04XT-...	IEC ¹⁾ external ^{*)} DC cabling between drive modules	
	Cu cable type**	Al cable type**
	mm ²	mm ²
U_n = 400 V		
1010A-3	2×(3×120)	2×(3×185)
1190A-3	2×(3×150)	2×(3×185)
1330A-3	2×(3×185)	2×(3×185)
1610A-3	2×(3×240)	2×(3×240)
U_n = 500 V		
1010A-5	2×(3×120)	2×(3×185)
1160A-5	2×(3×150)	2×(3×185)
1310A-5	2×(3×185)	2×(3×185)
1610A-5	2×(3×240)	2×(3×240)
U_n = 690 V		
0810A-7	2×(3×95)	2×(3×120)
0960A-7	2×(3×120)	2×(3×185)
1080A-7	2×(3×150)	2×(3×185)
1320A-7	2×(3×185)	2×(3×185)

- ¹⁾ The cable sizing is based on max. 9 cables laid on a cable ladder side by side, three ladder type trays one on top of the other, ambient temperature 30 °C (86 °F) PVC insulation, surface temperature 70 °C (158 °F) (EN 60204-1 and IEC 60364-5-52). For other conditions, dimension the cables according to local safety regulations, appropriate input voltage and the load current of the drive.
- ^{*)} The table gives DC cable types when the cables are outside the cabinet. For DC cables inside the cabinet, select a cable capable of carrying 2/3 of the continuous output current of one drive module.
- ^{**) Connection (2 × (3 × xxx)):} two phase conductors of one three-phase cable between the DC+ terminals of the drive modules and two phase conductors of the second three-phase cable between the DC- terminals of the drive modules. The third phase conductors unconnected.

ACS880-04XT-...	UL/NEC ¹⁾ input and motor cabling			
	Cabling per drive module ²⁾		Common cabling for the drive modules ³⁾	
	Cu cable type	Al cable type	Cu cable type	Al cable type
	AWG/kcmil	AWG/kcmil	AWG/kcmil	AWG/kcmil
$U_n = 400\text{ V}$				
1010A-3	2×600 or 3×300	3×400 or 4×250	3×600 or 4×300	4×700 or 6×250
1190A-3	2×700 or 3×350	3×400 or 4×250	3×700 or 5×350	4×700 or 6×350
1330A-3	3×500 or 4×300	3×500 or 4×300	4×500 or 6×300	6×500
1610A-3	3×600 or 4×400	4×500	5×600 or 6×400	6×500
$U_n = 500\text{ V}$				
1010A-5	2×600 or 3×300	3×500 or 4×300	3×600 or 4×300	4×700 or 6×250
1160A-5	2×700 or 3×350	3×600 or 4×400	3×700 or 5×350	4×700 or 6×350
1310A-5	3×500 or 4×300	3×600 or 4×400	4×500 or 6×300	4×700 or 6×350
1610A-5	3×600 or 4×400	4×500	5×600 or 6×400	6×500
$U_n = 690\text{ V}$				
0810A-7	2×350 or 3×4/0	2×500 or 3×250	3×350 or 5×4/0	3×500 or 5×250
0960A-7	2×500 or 3×250	2×700 or 3×350	3×500 or 5×250	3×700 or 5×350
1080A-7	2×600 or 3×300	3×500 or 4×300	3×600 or 4×350	4×500 or 6×300
1320A-7	3×500 or 4×300	3×600 or 4×400	4×500 or 6×300	5×600 or 6×400

¹⁾ The cable sizing is based on NEC Table 310-16 for copper wires, 75 °C (167 °F) wire insulation at 40 °C (104 °F) ambient temperature. Not more than three current-carrying conductors in raceway or cable or earth (directly buried). For other conditions, dimension the cables according to local safety regulations, appropriate input voltage and the load current of the drive.

²⁾ See section [Drive connection examples \(page 33\)](#)

³⁾ The supply cables are connected to a common switch or breaker, see section [Drive connection examples \(page 33\)](#). The whole input current flows through common cabling and you can use the recommended cables for that. The connection from the switch to the drive modules inside the cabinet can be made with busbars. Note that common output cables require the use of du/dt filters.

Temperature: Select a cable rated for at least 75 °C (167 °F) maximum permissible temperature of conductor in continuous use.

Voltage: 600 V AC cable is accepted for up to 500 V AC. 750 V AC cable is accepted for up to 600 V AC. 1000 V AC cable is accepted for up to 690 V AC.

ACS880-04XT-...	UL/NEC ¹⁾ external ^{*)} DC cabling between drive modules	
	Cu cable type**	Al cable type**
	mm ²	mm ²
U_n = 400 V		
1010A-3	2×400	2×400
1190A-3	2×400	2×400
1330A-3	2×400	2×500
1610A-3	2×400	2×500
U_n = 500 V		
1010A-5	2×400	2×400
1160A-5	2×400	2×400
1310A-5	2×400	2×500
1610A-5	2×400	2×500
U_n = 690 V		
0810A-7	1×350	1×500
0960A-7	2×300	2×300
1080A-7	2×300	2×300
1320A-7	2×300	2×400

¹⁾ The cable sizing is based on NEC Table 310-16 for copper wires, 75 °C (167 °F) wire insulation at 40 °C (104 °F) ambient temperature. Not more than three current-carrying conductors in raceway or cable or earth (directly buried). For other conditions, dimension the cables according to local safety regulations, appropriate input voltage and the load current of the drive.

^{*)} The table gives DC cable types when the cables are outside the cabinet. For DC cables inside the cabinet, select a cable capable of carrying 2/3 of the continuous output current of one drive module.

^{*)} **Connection (1× xxx):** One phase conductor of the three-phase cable between the DC+ terminals of the drive modules and another phase conductor of the three-phase cable between the DC- terminals of the drive modules. The third phase conductor unconnected.

Connection (2 × (3 × xxx)): two phase conductors of one three-phase cable between the DC+ terminals of the drive modules and two phase conductors of the second three-phase cable between the DC- terminals of the drive modules. The third phase conductors unconnected.

Terminal and entry data for the power cables

■ Standard drive module configuration

It is possible to use the maximum cable size (4×[3×240] mm² or 4×[3×500 MCM]) only with special cable lugs and additional insulation. For more information, contact your local ABB representative.

■ Drive modules with full-size cable connection terminals (option)

The maximum accepted cable size is 4×(3×240) mm² or 4×(3×500 MCM). Screw size for connecting busbars to the drive module input and output busbars: M12, tightening torque 50...75 N·m (37...55 lbf·ft).

■ Drive modules with option “Full power cabling panels to be attached to a cabinet (IP20)”

The maximum accepted cable size is $4 \times (3 \times 240) \text{ mm}^2$ or $4 \times (3 \times 500 \text{ MCM})$. The cabling panels are connected to the drive module busbars with M12 serpress nuts, tightening torque 30 N·m (20 lbf·ft).

Input, motor and brake resistor cable terminal sizes and tightening torques are given below.

L1/U1, L2/V1, L3/W1, T1/U2, T2/V2, T3/W2, UDC+, UDC-				Grounding busbar			
Screw		Tightening torque		Screw		Tightening torque	
		N·m	lbf·ft			N·m	lbf·ft
M12	1/2	50...75	37...55	M10	3/8	30...44	22...32

Two-hole 1/2 inch diameter cable lugs can be used.

Terminal data for the control cables

See section Default I/O diagram of the inverter control unit (A41) (page 130)

Electrical power network specification

Voltage (U_1)	<p><u>ACS880-04XT-xxxx-3 drives</u>: 380...415 VAC 3-phase +10%...-15%. This is indicated in the type designation label as typical input voltage level 3~400 V AC.</p> <p><u>ACS880-04XT-xxxx-5 drives</u>: 380...500 V AC 3-phase +10%...-15%. This is indicated in the type designation label as typical input voltage levels 3~400/480/500 V AC.</p> <p><u>ACS880-04XT-xxxx-7 drives</u>: 525...690 V AC 3-phase +10%...-15%. This is indicated in the type designation label as typical input voltage levels 3~525/600/690 V AC.</p>
Network type	TN (grounded) and IT (ungrounded) systems
Rated conditional short-circuit current I_{cc} (IEC 61439-1)	Maximum allowable prospective short-circuit current is 65 kA when protected by the fuses given in the fuse table.
Short-circuit current protection (UL 61800-5-1, CSA C22.2 No. 274-17)	The drive is suitable for use on a circuit capable of delivering not more than 100 kA rms symmetrical amperes at 600 V maximum when protected by the fuses given in the fuse table.
Frequency (f_1)	50/60 Hz. Variation $\pm 5\%$ of nominal frequency.
Imbalance	Max. $\pm 3\%$ of nominal phase to phase input voltage
Fundamental power factor ($\cos \phi_1$)	0.98 (at nominal load)
Transformer for 12-pulse supply	<p>According to IEC60076-1:2011</p> <p>Connection: Dy 11 d0 or Dyn 11 d0</p> <p>Phase shift between secondaries: 30° electrical</p> <p>Voltage difference between secondaries: < 0.5%</p> <p>Short-circuit impedance of secondaries: > 5%</p> <p>Short-circuit impedance difference between secondaries: <10% of the percentage impedance</p> <p>No grounding of the secondaries allowed. Static shield recommended.</p>

Motor connection data

Motor types	Asynchronous AC induction motors, permanent magnet motors and AC induction servomotors.
Voltage (U_2)	This is indicated in the type designation label as typical output voltage level 3~0... U_1 .
Frequency (f_2)	0...500 Hz <u>For drives with du/dt filter:</u> 200 Hz <u>For drives with sine filter:</u> 120 Hz
Frequency resolution	0.01 Hz
Current	See section Electrical ratings (page 189).
Switching frequency	3 kHz (typically)
Maximum recommended motor cable length	<u>DTC control:</u> 500 m (1640 ft) <u>Scalar control:</u> 500 m (1640 ft) Note: With motor cables longer than 100 m (328 ft), the EMC Directive requirements may not be fulfilled. Note: Long cables cause a motor voltage decrease which limits the available motor power. The decrease depends on the motor cable length and characteristics. Contact ABB for more information. Note that a sine filter (optional) at the drive output also causes a voltage decrease.
Minimum recommended motor cable length	<u>For drive modules without du/dt filter:</u> 2 m (7 ft) from each drive module to the motor or 4 m (13 ft) between the drive modules, possible only with special precautions, see section du/dt filters (page 267). The motor cabling must be symmetrical.

Brake resistor data

See section Ratings (page 265).

du/dt and sine filters

See section Filters (page 267).

Control panel type

ACS-AP-I assistant control panel (to be ordered separately).

Efficiency

Approximately 98% at nominal power level.

The efficiency is not calculated according to the ecodesign standard IEC 61800-9-2.

Energy efficiency data (ecodesign)

See ACS880-04XT drives energy efficiency data (ecodesign) supplement (3AXD50000790098 [English]).

Protection classes for module

Degrees of protection (IEC/EN 60529)	IP00 (standard) IP20 (with option "IP20 shrouds for covering the input and motor cabling area") IP20 (with option "Full power cabling panels to be attached to a cabinet (IP20)") Heatsink: IP55
Enclosure types (UL 50/50E)	UL Open Type Heatsink: UL Type 12
Overvoltage category (IEC/EN 60664-1)	III
Protective class (IEC/EN 61800-5-1)	I

Ambient conditions

Environmental limits for the drive are given below. The drive is to be used in a heated, indoor, controlled environment.

	Operation (installed for stationary use)	Storage (in the protective package)	Transportation (in the protective package)
Installation site altitude	<p><u>For TN and TT neutral-grounded network systems and IT non-corner-grounded network systems:</u> 0 to 4000 m (13123 ft) above sea level</p> <p><u>For corner-grounded network systems:</u> 0 to 2000 m (6561 ft) above sea level</p> <p><u>Above 1000 m (3281 ft):</u> see section <i>When is derating necessary</i> (page 191)</p>	-	-
Surrounding air temperature	-15...+55 °C (5...131 °F). No frost allowed. See section <i>When is derating necessary</i> (page 191)	-40... 70 °C (-40...+158 °F)	-40...+70 °C (-40...+158 °F)
Relative humidity	5...95%	Max. 95%	Max. 95%
	No condensation allowed. Maximum allowed relative humidity is 60% in the presence of corrosive gases.		
Contamination levels	IEC/EN 60721-3-3:2002	IEC 60721-3-1:1997	IEC 60721-3-2:1997
Chemical gases	Class 3C2	Class 1C2	Class 2C2
Solid particles	Class 3S2. No conductive dust allowed.	Class 1S3. (packing must support this, otherwise 1S2)	Class 2S2
Pollution degree IEC/EN 60664-1	2		
Atmospheric pressure	70...106 kPa (0.7 ... 1.05 atmospheres)	70...106 kPa (0.7 ... 1.05 atmospheres)	60...106 kPa (0.6 ... 1.05 atmospheres)
Vibration IEC 60068-2-6:2007, EN 60068-2-6:2008	Max. 0.1 mm (0.004 in) (10...57 Hz), max. 10 m/s ² (33 ft/s ²) (57...150 Hz) sinusoidal	Max. 1 mm (0.04 in) (5 ... 13.2 Hz), max. 7 m/s ² (23 ft/s ²) (13.2...100 Hz) sinusoidal	Max. 3.5 mm (0.14 in) (2...9 Hz), max. 15 m/s ² (49 ft/s ²) (9...200 Hz) sinusoidal
Shock IEC 60068-2-27:2008, EN 60068-2-27:2009	Not allowed	With packing max. 100 m/s ² (330 ft/s ²), 11 ms	With packing max. 100 m/s ² (330 ft/s ²), 11 ms
Free fall	Not allowed	100 mm (4 in) for weight over 100 kg (220 lb)	100 mm (4 in) for weight over 100 kg (220 lb)

Colors

RAL 9002

Materials

■ Drive

See Recycling instructions and environmental information for ACS880-04, ACS880-04F, ACS880-14, ACS880-34, ACS580-04, ACH580-04, ACH580-34, ACQ580-04 and ACQ580-34 drives (3AXD50000137688 [English]).

■ Package materials for module products

This is a complete list of the package materials. The materials vary depending on the frame size (packages do not contain all materials listed below).

- Cardboard¹⁾
- Molded pulp
- Plywood
- Wood
- PP (strapping)
- EPP (foam)
- PE (plastic bag and/or VCI foil)
- Metal (fixing clamps, screws).

¹⁾ Cardboard heavy duty quality with wet strength glue in large modules.

■ Package materials for options, accessories and spare parts

- Cardboard
- Kraft paper
- PP (straps)
- PE (foil, bubble wrap)
- Plywood, wood (only for heavy components).

Materials vary according to the item type, size and shape. Typical package consists of a cardboard box with paper filling or bubble wrap. ESD-safe packing materials are used for printed circuit boards and similar items.

■ Materials of manuals

Printed product manuals are recyclable paper. Product manuals are available on the Internet.

Disposal

The main parts of the drive can be recycled to preserve natural resources and energy. Product parts and materials should be dismantled and separated.

Generally all metals, such as steel, aluminum, copper and its alloys, and precious metals can be recycled as material. Plastics, rubber, cardboard and other packaging material can be used in energy recovery. Printed circuit boards and large electrolytic capacitors

need selective treatment according to IEC 62635 guidelines. To aid recycling, plastic parts are marked with an appropriate identification code.

Contact your local ABB distributor for further information on environmental aspects and recycling instructions for professional recyclers. End of life treatment must follow international and local regulations.

Applicable standards

The drive complies with the following standards.

IEC/EN 61800-5-1:2007	Adjustable speed electrical power drive systems. Part 5-1: Safety requirements – electrical, thermal and energy
EN 60204-1:2006 + A1:2010	Safety of machinery. Electrical equipment of machines. Part 1: General requirements. Provisions for compliance: The final assembler of the machine is responsible for installing <ul style="list-style-type: none"> • emergency-stop device • supply disconnecting device • IP00 drive module into a cabinet.
IEC 60529:1989 + A1:1999 + A2:2013 EN 60529:1991 + A1:2000 + A2:2013	Degrees of protection provided by enclosures (IP code)
IEC 61800-3:2004 + A1:2011 EN 61800-3:2004 + A1:2012	Adjustable speed electrical power drive systems. Part 3: EMC requirements and specific test methods
UL 61800-5-1 First edition	Standard for Adjustable Speed Electrical Power Drive Systems – Part 5-1: Safety Requirements – Electrical, Thermal and Energy
CSA C22.2 No. 0-10	General Requirements - Canadian Electrical Code, Part II
CSA C22.2 No. 274-17	Adjustable speed drives

Markings

These markings are attached to the drive:

	CE mark Product complies with the applicable European Union legislation. For fulfilling the EMC requirements, see the additional information concerning the drive EMC compliance (IEC/EN 61800-3).
	UL Listed mark for USA and Canada Product has been tested and evaluated against the relevant North American standards by the Underwriters Laboratories. Valid with rated voltages up to 600 V.
	TÜV Safety Approved mark (functional safety) Product contains Safe torque off and possibly other (optional) safety functions which are certified by TÜV according to the relevant functional safety standards. Applicable to drives and inverters; not applicable to supply, brake or DC/DC converter units or modules.

	<p>CSA certification mark for USA and Canada Product has been tested and evaluated against the relevant North American standards by the CSA Group. Valid with rated voltages up to 600 V.</p>
	<p>EAC (Eurasian Conformity) mark Product complies with the technical regulations of the Eurasian Customs Union. EAC mark is required in Russia, Belarus and Kazakhstan.</p>
	<p>Electronic Information Products (EIP) symbol including an Environment Friendly Use Period (EFUP). Product is compliant with the People's Republic of China Electronic Industry Standard (SJ/T 11364-2014) about hazardous substances. The EFUP is 20 years. China RoHS II Declaration of Conformity is available from https://library.abb.com.</p>
	<p>KC mark Product complies with Korean Registration of Broadcasting and Communications Equipment Clause 3, Article 58-2 of Radio Waves Act.</p>
	<p>WEEE mark At the end of life the product should enter the recycling system at an appropriate collection point and not placed in the normal waste stream.</p>
	<p>UKCA (UK Conformity Assessed) mark Product complies with the applicable United Kingdom's legislation (Statutory Instruments). Marking is required for products being placed on the market in Great Britain (England, Wales and Scotland).</p>

EMC compliance (IEC/EN 61800-3)

■ Definitions

EMC stands for Electromagnetic Compatibility. It is the ability of electrical/electronic equipment to operate without problems within an electromagnetic environment. Likewise, the equipment must not disturb or interfere with any other product or system within its locality.

First environment includes establishments connected to a low-voltage network which supplies buildings used for domestic purposes.

Second environment includes establishments connected to a network not supplying domestic premises.

Drive of category C1: drive of rated voltage less than 1000 V and intended for use in the first environment.

Drive of category C2: drive of rated voltage less than 1000 V and intended to be installed and started up only by a professional when used in the first environment.

Note: A professional is a person or organization having necessary skills in installing and/or starting up power drive systems, including their EMC aspects.

Drive of category C3: drive of rated voltage less than 1000 V and intended for use in the second environment and not intended for use in the first environment.

Drive of category C4: drive of rated voltage equal to or above 1000 V, or rated current equal to or above 400 A, or intended for use in complex systems in the second environment.

■ **Category C3**

The drive complies with the standard with the following provisions:

1. The drive is equipped with EMC filter +E200 or +E201.
2. The motor and control cables are selected as specified in the hardware manual.
3. The drive is installed according to the instructions given in the hardware manual.
4. Maximum motor cable length is 100 meters.




WARNING!

A drive of category C3 is not intended to be used on a low-voltage public network which supplies domestic premises. Radio frequency interference is expected if the drive is used on such a network.

■ **Category C4**

The drive complies with the C4 category with these provisions:

1. It is made sure that no excessive emission is propagated to neighboring low-voltage networks. In some cases, the natural suppression in transformers and cables is sufficient. If in doubt, a supply transformer with static screening between the primary and secondary windings can be used.
-



2. An EMC plan for preventing disturbances is drawn up for the installation. A template is available in [Technical guide No. 3 EMC compliant installation and configuration for a power drive system \(3AFE61348280 \[English\]\)](#).
3. The motor and control cables are selected, and routed according to the electrical planning guidelines of the drive. The EMC recommendations are obeyed.
4. The drive is installed according to its installation instructions. The EMC recommendations are obeyed.



WARNING!

A drive of category C4 is not intended to be used on a low-voltage public network which supplies domestic premises. Radio frequency interference is expected if the drive is used on such a network.

Compliance with the European Machinery Directive

See chapter [The Safe torque off function \(page 237\)](#).

UL checklist



WARNING!

Operation of this drive requires detailed installation and operation instructions provided in the hardware and software manuals. The manuals are provided in electronic format in the drive package or on the Internet. Keep the manuals with the drive at all times. Hard copies of the manuals can be ordered through the manufacturer.

- Make sure that the drive type designation label includes the applicable marking.
 - **DANGER - Risk of electric shock.** After disconnecting the input power, always wait for 5 minutes to let the intermediate circuit capacitors discharge before you start working on the drive, motor or motor cable.
 - The drive is to be used in a heated, indoor controlled environment. The drive must be installed in clean air according to the enclosure classification. Cooling air must be clean, free from corrosive materials and electrically conductive dust.
 - The maximum surrounding air temperature is 40 °C at rated output current. The output current is derated for 40...55 °C.
 - The drive is suitable for use in a circuit capable of delivering not more than 100 kA rms symmetrical amperes, 600 V maximum when protected by the UL fuses given elsewhere in this chapter.
 - The cables located within the motor circuit must be rated for at least 75 °C in UL-compliant installations.
 - The input cable must be protected with fuses or circuit breakers. These protective devices provide branch circuit protection in accordance with the national regulations (National Electrical Code (NEC) or Canadian Electrical Code). Obey also any other applicable local or provincial codes.
-



WARNING!

The opening of the branch-circuit protective device may be an indication that a fault current has been interrupted. To reduce the risk of fire or electric shock, current-carrying parts and other components of the device should be examined and replaced if damaged.

- The drive provides motor overload protection. The protection is not enabled when the drive leaves the ABB factory. For enabling the protection, see the firmware manual.
- The drive overvoltage category according to IEC 60664-1 is III.

Disclaimers

■ Generic disclaimer

The manufacturer shall have no obligation with respect to any product which (i) has been improperly repaired or altered; (ii) has been subjected to misuse, negligence or accident; (iii) has been used in a manner contrary to the manufacturer's instructions; or (iv) has failed as a result of ordinary wear and tear.

■ **Cybersecurity disclaimer**

This product can be connected to and communicate information and data via a network interface. The HTTP protocol, which is used between the commissioning tool (Drive Composer) and the product, is an unsecured protocol. For independent and continuous operation of product such connection via network to commissioning tool is not necessary. However it is Customer's sole responsibility to provide and continuously ensure a secure connection between the product and Customer network or any other network (as the case may be). Customer shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, prevention of physical access, application of authentication measures, encryption of data, installation of anti-virus programs, etc.) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information.

Notwithstanding any other provision to the contrary and regardless of whether the contract is terminated or not, ABB and its affiliates are under no circumstances liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.




Dimension drawings


Contents of this chapter

This chapter contains dimension drawings of the drive modules with optional parts for Rittal VX25 cabinet assembly.

R10 with option +D150




R10 with option "Full power cabling panels"




1) Shim plate (3AXD50000546336) for Rittal VX25 enclosure. There are 8 shim plates attached to the drive module. If the drive module is installed into a Rittal TS8 enclosure, remove the shim plates.


R10 with option “Full power cabling panels to be attached to a cabinet (IP20)” installed into a Rittal VX25 cabinet




R10 with option "Flat mounting"




R11 with options “Full size input and output cable connection terminals and PE busbar” and “IP20 shrouds for covering the input and motor cabling area”



R11 with options “Full size input and output cable connection terminals and PE busbar” and “Power cable connection terminals on the right-hand side of the drive module”




R11 with option “Full power cabling panels”




1) Shim plate (3AXD50000546336) for Rittal VX25 enclosure. There are 8 shim plates attached to the drive module. If the drive module is installed into a Rittal TS8 enclosure, remove the shim plates.

R11 with option “Full power cabling panels to be attached to a cabinet (IP20) installed into a Rittal VX25 cabinet”




R11 with option "Flat mounting"

FLAT MOUNTING R10-R11
MRP CODE 3AXD50000024562




WALL MOUNTING
HOLE PATTERN



3AXD50000025591


Bottom plate for option +H381 in Rittal VX25 400 mm wide enclosure installation

Note: The bottom plate is not an ABB part.




Air baffles for the drive module with options “IP20 shrouds for covering the input and motor cabling area” and “Flat mounting”

This drawing shows the dimensions of the hole in the air baffle around the standard drive module and flat mounting option +C173. The drawing also shows the correct vertical location area of the air baffle as measured from the top grille.



Air baffles for option +H381 in Rittal VX25 400 mm wide enclosure installation

Note: These air baffles are not ABB parts.



Material of the air baffles

0.75 mm polycarbonate (PC) film LEXAN® FR60 (GE) with UL94 V-0 listing, UV stability. Unmarked bend radii 0.6 mm.

18

Example circuit diagram


Contents of this chapter

This chapter shows an example circuit diagram for a cabinet-installed drive module package.

Example circuit diagram

This diagram is an example for the main wiring of a drive cabinet. Note that the diagram includes components which are not included in a basic delivery (* option, ** to be acquired by the customer).

236 Example circuit diagram



1	Cabinet
2	*ACS-AP-W control panel
3	24 V DC supply
4	**Main contactor
5	**Motor temperature supervision
6	**Switch fuse disconnect
7	Common mode filter
8	*du/dt filter or sine filter
9	Drive module
10	Alarm
11	Supply
12	360 degree grounding recommended
13	**Brake resistor

For BCU input and output signals, see the Default I/O diagram of the inverter control unit (A41) (page 130).

19

The Safe torque off function

Contents of this chapter

This chapter describes the Safe torque off (STO) function of the drive and gives instructions for its use.

Description



WARNING!

In case of parallel-connected drives or dual-winding motors, the STO must be activated on each drive to remove the torque from the motor.

The Safe torque off function can be used, for example, as the final actuator device of safety circuits (such as an emergency stop circuit) that stop the drive in case of danger. Another typical application is a prevention of unexpected start-up function that enables short-time maintenance operations like cleaning or work on non-electrical parts of the machinery without switching off the power supply to the drive.

When activated, the Safe torque off function disables the control voltage for the power semiconductors of the drive output stage, thus preventing the drive from generating the torque required to rotate the motor. If the motor is running when Safe torque off is activated, it coasts to a stop.

The Safe torque off function has a redundant architecture, that is, both channels must be used in the safety function implementation. The safety data given in this manual is calculated for redundant use, and does not apply if both channels are not used.

The Safe torque off function complies with these standards:

Standard	Name
IEC 60204-1:2016 EN 60204-1:2018	Safety of machinery – Electrical equipment of machines – Part 1: General requirements

Standard	Name
IEC 61000-6-7:2014	Electromagnetic compatibility (EMC) – Part 6-7: Generic standards – Immunity requirements for equipment intended to perform functions in a safety-related system (functional safety) in industrial locations
IEC 61326-3-1:2017	Electrical equipment for measurement, control and laboratory use – EMC requirements – Part 3-1: Immunity requirements for safety-related systems and for equipment intended to perform safety-related functions (functional safety) – General industrial applications
IEC 61508-1:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems – Part 1: General requirements
IEC 61508-2:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems – Part 2: Requirements for electrical/electronic/programmable electronic safety-related systems
IEC 61511-1:2017	Functional safety – Safety instrumented systems for the process industry sector
IEC 61800-5-2:2016 EN 61800-5-2:2007	Adjustable speed electrical power drive systems – Part 5-2: Safety requirements – Functional
IEC 62061:2021 EN 62061:2021	Safety of machinery – Functional safety of safety-related electrical, electronic and programmable electronic control systems
EN ISO 13849-1:2015	Safety of machinery – Safety-related parts of control systems – Part 1: General principles for design
EN ISO 13849-2:2012	Safety of machinery – Safety-related parts of control systems – Part 2: Validation

The function also corresponds to Prevention of unexpected start-up as specified by EN ISO 14118:2018 (ISO 14118:2017), and Uncontrolled stop (stop category 0) as specified in EN/IEC 60204-1.

■ Compliance with the European Machinery Directive and the UK Supply of Machinery (Safety) Regulations

The Declarations of conformity are shown at the end of this chapter.

Wiring

For the electrical specifications of the STO connection, see [BCU-02/12/22 control units hardware manual \(3AUA0000113605 \[English\]\)](#).

■ Activation switch

In the wiring diagrams, the activation switch has the designation [K]. This represents a component such as a manually operated switch, an emergency stop push button switch, or the contacts of a safety relay or safety PLC.

- In case a manually operated activation switch is used, the switch must be of a type that can be locked out to the open position.
- The contacts of the switch or relay must open/close within 200 ms of each other.
- An FSO safety functions module, an FSPS safety functions module or an FPTC thermistor protection module can also be used. For more information, see the module documentation.

■ Cable types and lengths

- ABB recommends double-shielded twisted-pair cable.
- Maximum cable lengths:
 - 300 m (1000 ft) between activation switch [K] and drive control unit
 - 60 m (200 ft) between multiple drives
 - 60 m (200 ft) between external power supply and first control unit

Note: A short-circuit in the wiring between the switch and an STO terminal causes a dangerous fault. Therefore, it is recommended to use a safety relay (including wiring diagnostics) or a wiring method (shield grounding, channel separation) which reduces or eliminates the risk caused by the short-circuit.

Note: The voltage at the STO input terminals of the control unit must be at least 17 V DC to be interpreted as “1”.


The pulse tolerance of the input channels is 1 ms.

■ Grounding of protective shields


- Ground the shield in the cabling between the activation switch and the control unit at the control unit only.
 - Ground the shield in the cabling between two control units at one control unit only.
-

■ With internal power supply

Dual-channel connection



Single-channel connection of activation switch




Note:

- Both STO inputs (IN1, IN2) must be connected to the activation switch. Otherwise, no SIL/PL classification is given.
- Pay special attention to avoiding any potential failure modes for the wiring. For example, use shielded cable. For measures for fault exclusion of wiring, see eg. EN ISO 13849-2:2012, table D.4.


1	Drive
2	Control unit
K	Activation switch
	Note: A single-channel activation switch can limit the SIL/PL capability of the safety function to a lower level than the SIL/PL capability of the STO function of the drive.

■ With external power supply



■ **Safe torque off function not in use**

If STO is not in use, close the circuit as shown. Otherwise the drive will not start.



Operation principle

1. The Safe torque off activates (the activation switch is opened, or safety relay contacts open).
2. The STO inputs of the drive control unit de-energize.
3. The control unit cuts off the control voltage from the output IGBTs.
4. The control program generates an indication as defined by parameter 31.22 (see the firmware manual of the drive).

The parameter selects which indications are given when one or both STO signals are switched off or lost. The indications also depend on whether the drive is running or stopped when this occurs.

Note: This parameter does not affect the operation of the STO function itself. The STO function will operate regardless of the setting of this parameter: a running drive will stop upon removal of one or both STO signals, and will not start until both STO signals are restored and all faults reset.

Note: The loss of only one STO signal always generates a fault as it is interpreted as a malfunction of STO hardware or wiring.

5. The motor coasts to a stop (if running). The drive cannot restart while the activation switch or safety relay contacts are open. After the contacts close, a reset may be needed (depending on the setting of parameter 31.22). A new start command is required to start the drive.
-

Start-up including validation test

To ensure the safe operation of a safety function, validation is required. The final assembler of the machine must validate the function by performing a validation test. The test must be performed

1. at initial start-up of the safety function
2. after any changes related to the safety function (circuit boards, wiring, components, settings, replacement of inverter module, etc.)
3. after any maintenance work related to the safety function
4. after a drive firmware update
5. at the proof test of the safety function.

■ Competence

The validation test of the safety function must be carried out by a competent person with adequate expertise and knowledge of the safety function as well as functional safety, as required by IEC 61508-1 clause 6. The test procedures and report must be documented and signed by this person.

■ Validation test reports

Signed validation test reports must be stored in the logbook of the machine. The report shall include documentation of start-up activities and test results, references to failure reports and resolution of failures. Any new validation tests performed due to changes or maintenance shall be logged into the logbook.

■ Validation test procedure

After wiring the Safe torque off function, validate its operation as follows.

Note: If an FSO safety functions module, FSPS-21 or FPTC module is installed, refer to its documentation.

Action	<input checked="" type="checkbox"/>
 WARNING! Obey the safety instructions. If you ignore them, injury or death, or damage to the equipment can occur.	<input type="checkbox"/>
Make sure that the motor can be run and stopped freely during start-up.	<input type="checkbox"/>
Stop the drive (if running), switch the input power off and isolate the drive from the power line using a disconnecter.	<input type="checkbox"/>
Check the STO circuit connections against the wiring diagram.	<input type="checkbox"/>
Close the disconnecter and switch the power on.	<input type="checkbox"/>

246 The Safe torque off function

Action	<input checked="" type="checkbox"/>
<p>Test the operation of the STO function when the motor is stopped.</p> <ul style="list-style-type: none"> • Give a stop command for the drive (if running) and wait until the motor shaft is at a standstill. <p>Make sure that the drive operates as follows:</p> <ul style="list-style-type: none"> • Open the STO circuit. The drive generates an indication if one is defined for the 'stopped' state in parameter 31.22 (see the firmware manual). • Give a start command to verify that the STO function blocks the drive's operation. The motor should not start. • Close the STO circuit. • Reset any active faults. Restart the drive and check that the motor runs normally. 	<input type="checkbox"/>
<p>Test the operation of the STO function when the motor is running.</p> <ul style="list-style-type: none"> • Start the drive and make sure the motor is running. • Open the STO circuit. The motor should stop. The drive generates an indication if one is defined for the 'running' state in parameter 31.22 (see the firmware manual). • Reset any active faults and try to start the drive. • Make sure that the motor stays at a standstill and the drive operates as described above in testing the operation when the motor is stopped. • Close the STO circuit. • Reset any active faults. Restart the drive and check that the motor runs normally. 	<input type="checkbox"/>
<p>Test the operation of the failure detection of the drive. The motor can be stopped or running.</p> <ul style="list-style-type: none"> • Open the 1st input channel of the STO circuit. If the motor was running, it should coast to a stop. The drive generates an FA81 fault indication (see the firmware manual). • Give a start command to verify that the STO function blocks the drive's operation. The motor should not start. • Close the STO circuit. • Reset any active faults. Restart the drive and check that the motor runs normally. • Open the 2nd input channel of the STO circuit. If the motor was running, it should coast to a stop. The drive generates an FA82 fault indication (see the firmware manual). • Give a start command to verify that the STO function blocks the drive's operation. The motor should not start. • Close the STO circuit. • Reset any active faults. Restart the drive and check that the motor runs normally. 	<input type="checkbox"/>
<p>Document and sign the validation test report which verifies that the safety function is safe and accepted for operation.</p>	<input type="checkbox"/>

Use

1. Open the activation switch, or activate the safety functionality that is wired to the STO connection.
2. The STO inputs on the drive control unit de-energize, and the control unit cuts off the control voltage from the output IGBTs.
3. The control program generates an indication as defined by parameter 31.22 (see the firmware manual of the drive).
4. The motor coasts to a stop (if running). The drive will not restart while the activation switch or safety relay contacts are open.
5. Deactivate the STO by closing the activation switch, or resetting the safety functionality that is wired to the STO connection.
6. Reset any faults before restarting.



WARNING!

The Safe torque off function does not disconnect the voltage of the main and auxiliary circuits from the drive. Therefore maintenance work on electrical parts of the drive or the motor can only be carried out after isolating the drive from the supply and all other voltage sources.



WARNING!

The drive cannot detect or memorize any changes in the STO circuitry when the drive control unit is not powered. If both STO circuits are closed and a level-type start signal is active when the power is restored, it is possible that the drive starts without a fresh start command. Take this into account in the risk assessment of the system.



WARNING!

Permanent magnet or synchronous reluctance [SynRM] motors only:

In case of a multiple IGBT power semiconductor failure, the drive can produce an alignment torque which maximally rotates the motor shaft by $180/p$ degrees (with permanent magnet motors) or $180/2p$ degrees (with synchronous reluctance [SynRM] motors) regardless of the activation of the Safe torque off function. p denotes the number of pole pairs.

Notes:

- If a running drive is stopped by using the Safe torque off function, the drive will cut off the motor supply voltage and the motor will coast to a stop. If this causes danger or is not otherwise acceptable, stop the drive and machinery using the appropriate stop mode before activating the Safe torque off function.
 - The Safe torque off function overrides all other functions of the drive.
 - The Safe torque off function is ineffective against deliberate sabotage or misuse.
 - The Safe torque off function has been designed to reduce the recognized hazardous conditions. In spite of this, it is not always possible to eliminate all potential hazards. The assembler of the machine must inform the final user about the residual risks.
-

Maintenance

After the operation of the circuit is validated at start-up, the STO function shall be maintained by periodic proof testing. In high demand mode of operation, the maximum proof test interval is 20 years. In low demand mode of operation, the maximum proof test interval is 10 years; see section [Safety data \(page 251\)](#).

There are two alternative procedures for proof testing:

1. Perfect proof testing. It is assumed that all dangerous failures of the STO circuit are detected during the test. PFD_{avg} values for STO with the perfect proof testing procedure are given in the safety data section.
2. Simplified proof testing. This procedure is faster and simpler than perfect proof testing. Not all dangerous failures of the STO circuit are detected during the test. The PFD_{avg} value for STO with the simplified proof testing procedure is given in the safety data section.

Note: The proof testing procedures are only valid for proof testing (periodic test, item 5 under section [Start-up including validation test](#)) but not for re-validation after changes made in the circuit. Re-validation (items 1..4 under [Start-up including validation test](#)) must be done according to the initial validation procedure.

Note: See also the Recommendation of Use CNB/M/11.050 (published by the European co-ordination of Notified Bodies) concerning dual-channel safety-related systems with electromechanical outputs:

- When the safety integrity requirement for the safety function is SIL 3 or PL e (cat. 3 or 4), the proof test for the function must be performed at least every month.
- When the safety integrity requirement for the safety function is SIL 2 (HFT = 1) or PL d (cat. 3), the proof test for the function must be performed at least every 12 months.

The STO function of the drive does not contain any electromechanical components.

In addition to proof testing, it is a good practice to check the operation of the function when other maintenance procedures are carried out on the machinery.

Include the Safe torque off operation test described above in the routine maintenance program of the machinery that the drive runs.

If any wiring or component change is needed after start-up, or the parameters are restored, do the test given in section [Validation test procedure \(page 245\)](#).

Use only spare parts approved by ABB.

Record all maintenance and proof test activities in the machine logbook.

■ Competence

The maintenance and proof test activities of the safety function must be carried out by a competent person with adequate expertise and knowledge of the safety function as well as functional safety, as required by IEC 61508-1 clause 6.

■ **Perfect proof test procedure**

Action	<input checked="" type="checkbox"/>
 WARNING! Obey the safety instructions. If you ignore them, injury or death, or damage to the equipment can occur.	<input type="checkbox"/>
Test the operation of the STO function. If the motor is running, it will stop during the test. <ul style="list-style-type: none"> • Give a stop command for the drive (if running) and wait until the motor shaft is at a standstill. Make sure that the drive operates as follows: • Open the STO circuit. The drive generates an indication if one is defined for the 'stopped' state in parameter 31.22 (see the firmware manual). • Close the STO circuit. • Reset any active faults. Restart the drive and check that the motor runs normally. 	<input type="checkbox"/>
Test the operation of the failure detection of the drive. The motor can be stopped or running. <ul style="list-style-type: none"> • Open the 1st input channel of the STO circuit. If the motor was running, it should coast to a stop. The drive generates an FA81 fault indication (see the firmware manual). • Close the STO circuit. • Reset any active faults. • Open the 2nd input channel of the STO circuit. If the motor was running, it should coast to a stop. The drive generates an FA82 fault indication (see the firmware manual). • Close the STO circuit. • Reset any active faults. Restart the drive and check that the motor runs normally. 	<input type="checkbox"/>
Document and sign the test report to verify that the safety function has been tested according to the procedure.	<input type="checkbox"/>

■ **Simplified proof test procedure**

Action	<input checked="" type="checkbox"/>
 WARNING! Obey the safety instructions. If you ignore them, injury or death, or damage to the equipment can occur.	<input type="checkbox"/>
Test the operation of the STO function. If the motor is running, it will stop during the test. <ul style="list-style-type: none"> • Give a stop command for the drive (if running) and wait until the motor shaft is at a standstill. Make sure that the drive operates as follows: • Open the STO circuit. The drive generates an indication if one is defined for the 'stopped' state in parameter 31.22 (see the firmware manual). • Close the STO circuit. • Reset any active faults. Restart the drive and check that the motor runs normally. 	<input type="checkbox"/>
Document and sign the test report to verify that the safety function has been tested according to the procedure.	<input type="checkbox"/>

Fault tracing

The indications given during the normal operation of the Safe torque off function are selected by drive control program parameter 31.22.

The diagnostics of the Safe torque off function cross-compare the status of the two STO channels. In case the channels are not in the same state, a fault reaction function is performed and the drive trips on an FA81 or FA82 fault. An attempt to use the STO in a non-redundant manner, for example activating only one channel, will trigger the same reaction.

See the firmware manual of the drive control program for the indications generated by the drive, and for details on directing fault and warning indications to an output on the control unit for external diagnostics.

Any failures of the Safe torque off function must be reported to ABB.

Safety data

The safety data for the Safe torque off function is given below.

Note: The safety data is calculated for redundant use, and applies only if both STO channels are used.

Frame size	SIL	SC	PL	PFH (1/h)	PFD _{avg}			MTTF _D (a)	DC SFF (%)	SFF (%)	Cat.	HFT	CCF	T _M (a)	PFH _{diag} (1/h)	λ _{Diag_s} (1/h)	λ _{Diag_d} (1/h)
					Perfect proof test T ₁ = 5 a	Perfect proof test T ₁ = 10 a	Simplified proof test T ₁ = 5 or 10 a										
2xR10, 2xR11	3	3	e	1.25E-10	2.76E-06	5.51E-06	1.10E-05	16330	≥90	>99	3	1	80	20	1.47E-09	1.10E-06	1.48E-07
3AXD10000414074 E																	

- The following temperature profile is used in safety value calculations:
 - 670 on/off cycles per year with $\Delta T = 71.66\text{ }^{\circ}\text{C}$
 - 1340 on/off cycles per year with $\Delta T = 61.66\text{ }^{\circ}\text{C}$
 - 30 on/off cycles per year with $\Delta T = 10.0\text{ }^{\circ}\text{C}$
 - $32\text{ }^{\circ}\text{C}$ board temperature at 2.0% of time
 - $60\text{ }^{\circ}\text{C}$ board temperature at 1.5% of time
 - $85\text{ }^{\circ}\text{C}$ board temperature at 2.3% of time.
- The STO is a type B safety component as defined in IEC 61508-2.
- Relevant failure modes:
 - The STO trips spuriously (safe failure)
 - The STO does not activate when requested
 - A fault exclusion on the failure mode “short circuit on printed circuit board” has been made (EN 13849-2, table D.5). The analysis is based on an assumption that one failure occurs at one time. No accumulated failures have been analyzed.
- STO response times:
 - STO reaction time (shortest detectable break): 1 ms
 - STO response time: 2 ms (typical), 25 ms (maximum)
 - Fault detection time: Channels in different states for longer than 200 ms
 - Fault reaction time: Fault detection time + 10 ms.
- Indication delays:
 - STO fault indication (parameter 31.22) delay: < 500 ms
 - STO warning indication (parameter 31.22) delay: < 1000 ms.

■ Terms and abbreviations

Term or abbreviation	Reference	Description
Cat.	EN ISO 13849-1	Classification of the safety-related parts of a control system in respect of their resistance to faults and their subsequent behavior in the fault condition, and which is achieved by the structural arrangement of the parts, fault detection and/or by their reliability. The categories are: B, 1, 2, 3 and 4.
CCF	EN ISO 13849-1	Common cause failure (%)
DC	EN ISO 13849-1	Diagnostic coverage (%)
HFT	IEC 61508	Hardware fault tolerance
$MTTF_D$	EN ISO 13849-1	Mean time to dangerous failure: (Total number of life units) / (Number of dangerous, undetected failures) during a particular measurement interval under stated conditions
PFD_{avg}	IEC 61508	Average probability of dangerous failure on demand, that is, mean unavailability of a safety-related system to perform the specified safety function when a demand occurs
PFH	IEC 61508	Average frequency of dangerous failures per hour, that is, average frequency of a dangerous failure of a safety related system to perform the specified safety function over a given period of time
PFH_{diag}	IEC/EN 62061	Average frequency of dangerous failures per hour for the diagnostic function of STO
PL	EN ISO 13849-1	Performance level. Levels a...e correspond to SIL
Proof test	IEC 61508, IEC 62061	Periodic test performed to detect failures in a safety-related system so that, if necessary, a repair can restore the system to an "as new" condition or as close as practical to this condition

Term or abbreviation	Reference	Description
SC	IEC 61508	Systematic capability (1...3)
SFF	IEC 61508	Safe failure fraction (%)
SIL	IEC 61508	Safety integrity level (1...3)
STO	IEC/EN 61800-5-2	Safe torque off
T_1	IEC 61508-6	Proof test interval. T_1 is a parameter used to define the probabilistic failure rate (PFH or PFD) for the safety function or subsystem. Performing a proof test at a maximum interval of T_1 is required to keep the SIL capability valid. The same interval must be followed to keep the PL capability (EN ISO 13849) valid. See also section Maintenance.
T_M	EN ISO 13849-1	Mission time: the period of time covering the intended use of the safety function/device. After the mission time elapses, the safety device must be replaced. Note that any T_M values given cannot be regarded as a guarantee or warranty.
λ_{Diag_d}	IEC 61508-6	Dangerous failure rate (per hour) of the diagnostics function of STO
λ_{Diag_s}	IEC 61508-6	Safe failure rate (per hour) of the diagnostics function of STO

■ TÜV certificate

The TÜV certificate is available on the Internet at www.abb.com/drives/documents.

■ **Declarations of conformity**



EU Declaration of Conformity

Machinery Directive 2006/42/EC

We

Manufacturer: ABB Oy

Address: Hiomotie 13, 00380 Helsinki, Finland.

Phone: +358 10 22 11

declare under our sole responsibility that the following products:

Frequency converters and frequency converter components

ACS880-04, -14, -34 (frames nxR8i)

ACS880-04XT, -04FXT

ACS880-07, -17, -37, -107

ACS880-104

ACS880 multidrives

ACS880-104LC (690V, frames nxR7i and nxR8i)

ACS880-07CLC, -07LC, -17LC, -37LC, -107LC (690V, frames nxR7i and nxR8i)

ACS880 liquid-cooled multidrives

identified with serial numbers beginning with 1 or 8

with regard to the safety functions

Safe torque off

Safe motor temperature with FPTC-01 module (option code +L536)

Safe Stop 1 (SS1-t) with FSPS-21 module (+Q986)

Safe stop 1 (SS1-t and SS1-r), Safe stop emergency, Safely-limited speed, Safe maximum speed, Safe brake control, Prevention of unexpected start-up, with FSO-12 module (option code +Q973)

Safe stop 1 (SS1-t and SS1-r), Safe stop emergency, Safely-limited speed, Safe maximum speed, Safe brake control, Safe Speed monitor, Safe direction, Prevention of unexpected start-up, with FSO-21 and FSE-31 modules (option codes +Q972 and +L521)



ACS880-07, -17, -37, -07CLC, -07LC, -17LC, -37LC, ACS880 multidrives and ACS880 liquid-cooled multidrives: Prevention of unexpected start-up (option codes +Q950; +Q957), **Emergency stop** (option codes +Q951; +Q952; +Q963; +Q964; +Q978; +Q979), **Safely-limited speed** (option codes +Q965; Q966)

are in conformity with all the relevant safety component requirements of EU Machinery Directive 2006/42/EC, when the listed safety functions are used for safety component functionality.

The following harmonized standards have been applied:

EN 61800-5-2:2007	Adjustable speed electrical power drive systems – Part 5-2: Safety requirements - Functional
EN 62061:2021	Safety of machinery – Functional safety of safety-related control systems
EN ISO 13849-1:2015	Safety of machinery – Safety-related parts of control systems. Part 1: General principles for design
EN ISO 13849-2:2012	Safety of machinery – Safety-related parts of the control systems. Part 2: Validation
EN 60204-1:2018	Safety of machinery – Electrical equipment of machines – Part 1: General requirements

The following other standard has been applied:

IEC 61508:2010, parts 1-3	Functional safety of electrical / electronic / programmable electronic safety-related systems
IEC 61800-5-2:2016	Adjustable speed electrical power drive systems – Part 5-2: Safety requirements - Functional

The products referred in this Declaration of conformity fulfil the relevant provisions of other European Union Directives which are notified in Single EU Declaration of conformity 3AXD10000497305.

Authorized to compile the technical file: ABB Oy, Hiomotie 13, 00380 Helsinki, Finland

Helsinki, 23 Jun 2022

Signed for and on behalf of:

Peter Lindgren
Peter Lindgren
Vice President, ABB Oy

Vesa Tiihonen
Vesa Tiihonen
Manager, Reliability and Quality, ABB Oy



Declaration of Conformity

Supply of Machinery (Safety) Regulations 2008

We

Manufacturer: ABB Oy

Address: Hiomotie 13, 00380 Helsinki, Finland.

Phone: +358 10 22 11

declare under our sole responsibility that the following products:

Frequency converters and frequency converter components

ACS880-04, -14, -34 (frames nxR8i)

ACS880-04XT, -04FXT

ACS880-07, -17, -37, -107

ACS880-104

ACS880 multidrives

ACS880-104LC (690V, frames nxR7i and nxR8i)

ACS880-07CLC, -07LC, -17LC, -37LC, -107LC (690V, frames nxR7i and nxR8i)

ACS880 liquid-cooled multidrives

identified with serial numbers beginning with 1 or 8

with regard to the safety functions

Safe torque off

Safe motor temperature with FPTC-01 module (option code +L536)

Safe Stop 1 (SS1-t) with FSPS-21 module (+Q986)

Safe stop 1 (SS1-t and SS1-r), Safe stop emergency, Safely-limited speed, Safe maximum speed, Safe brake control, Prevention of unexpected start-up, with FSO-12 module (option code +Q973)

Safe stop 1 (SS1-t and SS1-r), Safe stop emergency, Safely-limited speed, Safe maximum speed, Safe brake control, Safe Speed monitor, Safe direction, Prevention of unexpected start-up, with FSO-21 and FSE-31 modules (option codes +Q972 and +L521)



ACS880-07, -17, -37, -07CLC, -07LC, -17LC, -37LC, ACS880 multidrives and ACS880 liquid-cooled multidrives: Prevention of unexpected start-up (option codes +Q950; +Q957), **Emergency stop** (option codes +Q951; +Q952; +Q963; +Q964; +Q978; +Q979), **Safely-limited speed** (option codes +Q965; Q966)

are in conformity with all the relevant safety component requirements of the Supply of Machinery (Safety) Regulations 2008, when the listed safety functions are used for safety component functionality.

The following designated standards have been applied:

EN 61800-5-2:2007	Adjustable speed electrical power drive systems – Part 5-2: Safety requirements - Functional
EN 62061:2005 + AC:2010 + A1:2013 + A2:2015	Safety of machinery – Functional safety of safety-related electrical, electronic and programmable electronic control systems
EN ISO 13849-1:2015	Safety of machinery – Safety-related parts of control systems. Part 1: General principles for design
EN ISO 13849-2:2012	Safety of machinery – Safety-related parts of the control systems. Part 2: Validation
EN 60204-1:2018	Safety of machinery – Electrical equipment of machines – Part 1: General requirements

The following other standards have been applied:

EN 61508:2010, parts 1-3	Functional safety of electrical / electronic / programmable electronic safety-related systems
EN 61800-5-2:2017	Adjustable speed electrical power drive systems – Part 5-2: Safety requirements - Functional

The products referred in this declaration of conformity fulfil the relevant provisions of other UK statutory requirements, which are notified in a single declaration of conformity 3AXD10001346556.

Authorized to compile the technical file:
ABB Limited, Daresbury Park, Cheshire, United Kingdom, WA4 4BT

Helsinki, 23 Jun 2022

Signed for and on behalf of:

Peter Lindgren
Peter Lindgren
Vice President, ABB Oy

Vesa Tiihonen
Vesa Tiihonen
Manager, Reliability and Quality, ABB Oy

20

Resistor braking

Contents of this chapter

This chapter describes how to select, protect and wire brake choppers and resistors. The chapter also contains the technical data.

When is resistor braking necessary?

Resistor braking is necessary for high capacity braking if a regenerative drive cannot be used.

Operation principle and hardware description

The drive can be equipped with optional built-in brake chopper (+D150). Brake resistors are available as add-on kits.

The brake chopper handles the energy generated by a decelerating motor. The extra energy increases the DC link voltage. The chopper connects the brake resistor to the intermediate DC circuit whenever the voltage in the circuit exceeds the limit defined by the control program. Energy consumption by the resistor losses lowers the voltage until the resistor can be disconnected.

Planning the braking system

■ Generic guidelines

This section contains generic brake cable type, length and placing instructions, rules on how to minimize electromagnetic interference and descriptions and requirements for protections.

Resistor cables

Cable type

Use the same cable type for the resistor cabling as for the drive input cabling or, alternatively, a two conductor shielded cable with the same cross-sectional area.

Maximum cable length

The maximum length of the resistor cable(s) is 10 m (33 ft).

Minimizing electromagnetic interference

Obey these rules in order to minimize electromagnetic interference caused by the rapid current changes in the resistor cables:

- Shield the braking power line completely, either by using shielded cable or a metallic enclosure. Unshielded single-core cable can only be used if it is routed inside a cabinet that efficiently suppresses the radiated emissions.
- Install the cables away from other cable routes.
- Avoid long parallel runs with other cables. The minimum parallel cabling separation distance is 0.3 meters (1 ft).
- Cross the other cables at 90 degree angles.
- Keep the cable as short as possible in order to minimize the radiated emissions and stress on chopper IGBTs. The longer the cable the greater the radiated emissions, inductive load and voltage peaks over the IGBT semiconductors of the brake chopper.

Note: ABB has not verified that the EMC requirements are fulfilled with custom brake resistors and cabling. The customer must consider the EMC compliance of the complete installation.

Protecting the resistor cable against short-circuits

The input fuses of the drive will also protect the resistor cable when it is identical with the input cable.

Resistor thermal switch

Use a resistor with a thermal switch (standard in ABB resistors).

Make sure that the cable in the resistor thermal switch circuit meets the following requirements:

- shielded cable
- rated operating voltage between a core and ground $> 750 (U_0)$
- insulation test voltage > 2.5 kV
- jacket material for at least 90 °C (194 °F). Take into account further requirements due to resistor construction and temperature.

Protecting the system against thermal overload

The brake chopper protects itself and the resistor cables against thermal overload when the cables are dimensioned according to the nominal current of the drive. The drive control program includes a resistor overload protection function which can be tuned by the user. See the firmware manual.

EMC compliance of the complete installation

ABB cannot test that the EMC requirements are fulfilled with custom brake resistors and cabling. The customer must consider the EMC compliance of the complete installation.

Placing the brake resistors

Install the resistor assembly outside the drive in a place where it is able to cool effectively.

Arrange the cooling of the resistor so that:

- no danger of overheating is caused to the resistor or nearby materials, and
- the temperature of the room the resistor is located in does not exceed the allowed maximum.

Supply the resistor with cooling air or coolant according to the resistor manufacturer's instructions.



WARNING!

The materials near the brake resistor must be non-flammable. The surface temperature of the resistor is high. Air flowing from the resistor is of hundreds of degrees Celsius. If the exhaust vents are connected to a ventilation system, make sure that the material withstands high temperatures. Protect the resistor against contact.

■ Protecting the system in fault situations

A main contactor is not required for protecting against resistor overheating when the resistor is dimensioned according to the instructions and the internal brake chopper is in use. The drive will disable power flow through the input bridge if the chopper remains conductive in a fault situation but the charging resistor may fail.

Note: If an external brake chopper (outside the drive module) is used, ABB always requires a main contactor.

■ Selecting the default brake system components

1. Calculate the maximum power generated by the motor during braking.
2. Select a suitable drive, brake chopper and brake resistor combination for the application from the brake ratings table in the technical data. The braking power of the chopper must be greater than or equal to the maximum power generated by the motor during the braking.
3. Make sure that the resistor selection is correct: The energy generated by the motor during a 400-second period must not exceed the resistor heat dissipation capacity E_R .

Note: If the E_R value is not sufficient, it is possible to use a four-resistor assembly in which two standard resistors are connected in parallel, two in series. The E_R value of the four-resistor assembly is four times the value specified for the standard resistor.

■ Calculation example

Drive: ACS880-04-583A-5. Maximum continuous braking power (P_{brcont}) of the internal brake chopper = 315 kW. Preselected ABB resistor = 2×SAFUR200F50. Braking power

of the motor is 300 kW. The duration of a braking cycle (T) is three minutes -> number of braking pulses in 400 seconds = 2.2. The braking time (t_{br}) is 20 seconds.

$P_{br} = 300 \text{ kW} < P_{brcont} = 315 \text{ kW}$. This is ok.

The energy generated by the motor during a 400-second period = $2.2 \times 300 \text{ kW} \times 20 \text{ s} = 13200 \text{ kJ}$. The brake resistor withstands an energy pulse of 10800 kJ in every 400 seconds period. $13200 \text{ kJ} > 10800 \text{ kJ}$. -> The resistor is too small. -> Decrease the braking power or braking time or select a custom brake resistor as described in section [Selecting a custom brake resistor \(page 262\)](#).

■ Selecting a custom brake resistor

If you use other than ABB resistor,

1. make sure that the resistance of the custom resistor is greater than or equal to the resistance of the default ABB resistor.

$$R \geq R_{min}$$

where

R Resistance of the custom resistor

R_{min} Resistance of the default resistor



WARNING!

Never use a brake resistor with a resistance smaller than R_{min} . This will cause overcurrent that will damage the brake chopper and the drive.

2. make sure that the resistance of the custom resistor does not restrict the braking capability needed, ie.

$$P_{max} < \frac{U_{DC}^2}{R}$$

where

P_{max} Maximum power generated by the motor during braking

U_{DC} Drive intermediate DC circuit voltage.

1.35 · 1.2 · 415 V DC (when supply voltage is 380 ... 415 V AC)

1.35 · 1.2 · 500 V DC (when supply voltage is 440 ... 500 V AC) or

1.35 · 1.2 · 690 V DC (when supply voltage is 525 ... 690 AC)

R Resistance of the custom resistor

3. make sure that the resistor can dissipate the energy transferred to it during the braking:
 - Braking energy is not greater than the resistor heat dissipation capacity (E_r) during the period specified. See the custom resistor specification.
 - The resistor is installed in a correctly ventilated and cooled space. Otherwise the resistor cannot meet its heat dissipation capacity and overheats.
4. make sure that the instantaneous load capacity of the custom resistor is greater than the maximum power taken by the resistor when it is connected to the drive intermediate DC circuit by the chopper:

$$P_{R,inst} > \frac{U_{DC}^2}{R}$$

where

$P_{R, \text{inst}}$	Instantaneous load capacity of the custom resistor
U_{DC}	Drive intermediate DC circuit voltage: $1.35 \cdot 1.2 \cdot 415 \text{ V DC}$ (when supply voltage is 380 ... 415 V AC) $1.35 \cdot 1.2 \cdot 500 \text{ V DC}$ (when supply voltage is 440 ... 500 V AC) or $1.35 \cdot 1.2 \cdot 690 \text{ V DC}$ (when supply voltage is 525 ... 690 AC)
R	Resistance of the custom resistor

Mechanical installation of resistors

All brake resistors must be installed outside the drive. Obey the resistor manufacturer's instructions.

Electrical installation

■ Measuring the insulation of the assembly

Obey the instructions given in section Measuring the insulation resistance of the brake resistor circuit (page 110).

■ Connection diagram


See section Power cable connection diagram example (6-pulse) (page 112).

■ Connection procedure

- Connect the resistor cables to the R+ and R- terminals in the same way as the other power cables. If a shielded three-conductor cable is used, cut the third conductor and ground the twisted shield of the cable (protective earth conductor of the resistor assembly) at both ends.
- Connect resistor cables to the R+ and R- terminals of both drive modules in the same way as the other power cables. If a shielded three-conductor cable is used, cut the third conductor and ground the twisted shield of the cable (protective earth conductor of the resistor assembly) at both ends.

Note: It is not possible to use only one brake chopper in the drive module package, brake resistors must be connected to both drive modules.

- Wire the thermal switch to a digital input on the drive control unit as shown below.



Start-up

Note: New brake resistors may be coated with storage grease. As the brake chopper operates for the first time, the grease burns off and may produce some smoke. Make sure there is sufficient ventilation.

■ Parameter settings

Set the following parameters:

- Disable the overvoltage control of the drive with parameter 30.30 Overvoltage control.
- If the thermal switch is wired to the DIIL input, an overheating resistor will, by default, remove the Run enable signal from the drive. See also parameters 20.11 Run enable stop mode, 20.12 Run enable 1 source and 95.20 HW options word 1.
- If the thermal switch is wired to another digital input input, set the following parameters.
 1. Set the source of parameter 31.01 External event 1 source to point to the digital input where the thermal switch of the brake resistor is wired.
 2. Enable the brake chopper by parameter 43.06 Brake chopper enable. If Enabled with thermal model is selected, set also the brake resistor overload protection parameters 43.08 and 43.09 according to the application.
 3. Set parameter 31.02 External event 1 type to Fault.
 4. Set parameter 43.07 Brake chopper run enable to Other [bit] and select from parameter 10.01 DI status the digital input where the thermal switch of the brake resistor is wired.
 5. Set the resistance value of the resistor to parameter 43.10 Brake resistance.With these parameter settings, the drive generates a fault and coasts to a stop on brake resistor overtemperature.



WARNING!

If the drive is equipped with a brake chopper but the chopper is not enabled by the parameter setting, the internal thermal protection of the drive against resistor overheating is not in use. In this case, the brake resistor must be disconnected.

Technical data

■ Ratings

The table below gives the ratings for resistor braking.

ACS880-04XT-...	Drive module type ACS880-04-...	Frame size	Internal brake chopper per drive module		Example brake resistor(s) per drive module			
			P_{brcont}	R_{min}	Type	R	E_R	P_{Rcont}
			kW	ohm		ohm	kJ	kW
$U_n = 400\text{ V}$								
1010A-3	585A-3+P943	2×R10	315	1.3	2×SAFUR200F500	1.35	10800	27
1190A-3	650A-3+P943	2×R10	315	1.3	2×SAFUR200F500	1.35	10800	27
1330A-3	725A-3+P943	2×R11	400	0.7	3×SAFUR200F500	0.90	16200	40
1610A-3	880A-3+P943	2×R11	400	0.7	3×SAFUR200F500	0.90	16200	40
$U_n = 500\text{ V}$								
1010A-5	583A-5+P943	2×R10	315	1.3	2×SAFUR200F500	1.35	10800	27
1160A-5	635A-5+P943	2×R10	315	1.3	2×SAFUR200F500	1.35	10800	27
1310A-5	715A-5+P943	2×R11	400	0.7	3×SAFUR200F500	0.90	16200	40
1610A-5	880A-5+P943	2×R11	400	0.7	3×SAFUR200F500	0.90	16200	40
$U_n = 690\text{ V}$								
0810A-7	430A-7+P943	2×R10	285	2.2	SAFUR200F500	2.7	3600	13
0960A-7	522A-7+P943	2×R11	350	2.0	2×SAFUR125F500	2.0	7200	18
1080A-7	590A-7+P943	2×R11	400	1.8	2×SAFUR125F500	2.0	7200	18
1320A-7	721A-7+P943	2×R11	400	1.8	2×SAFUR125F500	2.0	7200	18
3AXD10000363510, 3AXD00000588487								

P_{brcont} Maximum continuous braking power. The braking is considered continuous if the braking time exceeds 30 seconds.

R_{min} The minimum allowed resistance value of the brake resistor

R Resistance value for the listed resistor assembly

E_R Short energy pulse that the resistor assembly withstands every 400 seconds


P_{Rcont} Continuous power (heat) dissipation of the resistor when placed correctly

The ratings apply at an ambient temperature of 40 °C (104 °F).

■ SAFUR resistors

The degree of protection of SAFUR resistors is IP00. The resistors are not UL listed. The thermal time constant of the resistors is 555 seconds.

Dimensions, weights and ordering codes



■ **Terminals and cable entry data**

See section Terminal and entry data for the power cables (page 206).

21

Filters

Contents of this chapter

This chapter describes how to select du/dt and sine filters for the drive.

du/dt filters

■ When is a du/dt filter necessary?

See Examining the compatibility of the motor and drive (page 84).

Note for drive modules with motor cable length less than 20 m (65 ft) from each drive module before connecting them together: In addition to the requirements given in Examining the compatibility of the motor and drive (page 84), ABB requires du/dt filters or sine filters at the outputs of the drive modules for equalization of drive module currents. See also section Motor connection data (page 208) for the minimum motor cable length. If there is no du/dt filter and the motor cable length from each drive module is less than 20 m (65 ft), the nominal values of the drive must be derated by 15%.

■ Selection table

du/dt filter types for the drive modules are given below.

Drive module type ACS880-04-...	du/dt filter type	Drive module type ACS880-04-...	du/dt filter type	Drive module type ACS880-04-...	du/dt filter type
$U_n = 400\text{ V}$		$U_n = 500\text{ V}$		$U_n = 690\text{ V}$	
585A-3	FOCH0610-70	583A-5	FOCH0610-70	430A-7	FOCH0610-70
650A-3	FOCH0610-70	635A-5	FOCH0610-70	522A-7	FOCH0610-70
725A-3	FOCH0875-70	715A-5	FOCH0875-70	590A-7	FOCH0610-70

Drive module type ACS880-04-...	du/dt filter type	Drive module type ACS880-04-...	du/dt filter type	Drive module type ACS880-04-...	du/dt filter type
880A-3	FOCH0875-70	880A-5	FOCH0875-70	721A-7	FOCH0875-70
3AXD10000363510					

■ Ordering codes

Filter type	ABB ordering code
FOCH0610-70	68550505
FOCH0875-70	3AUA0000129544

■ Description, installation and technical data of the FOCH filters

See FOCH du/dt filters hardware manual (3AFE68577519 [English]).

Sine filters

■ When is a sine filter necessary?

See section Examining the compatibility of the motor and drive (page 84).

■ Selection table

Sine filter types for the drive modules are given below.

Drive module type ACS880-04-...	Sine filter type	Drive module type ACS880-04-...	Sine filter type	Drive module type ACS880-04-...	Sine filter type
$U_n = 400 \text{ V}$		$U_n = 500 \text{ V}$		$U_n = 690 \text{ V}$	
585A-3	NSIN0900-6	583A-5	NSIN0900-6	430A-7	NSIN0485-6
650A-3	NSIN0900-6	635A-5	NSIN0900-6	522A-7	NSIN0900-6
725A-3	NSIN0900-6	715A-5	NSIN0900-6	590A-7	NSIN0900-6
880A-3	NSIN0900-6	880A-5	NSIN0900-6	721A-7	NSIN0900-6
3AXD10000363510					

■ Ordering codes

Filter type	ABB ordering code
NSIN0485-6	64254936
NSIN0900-6	64254961

■ Derating


See section Deratings for special settings in the drive control program (page 192).

■ Description, installation and technical data of the sine filters


See Sine filters hardware manual (3AXD50000016814 [English]). For more information, contact ABB.


Step-by-step drawings for an installation example of drive module with optional IP20 shrouds and input and output terminals in Rittal VX25 600 mm wide cabinet 269

22. Step-by-step drawings for an installation example of drive module with optional IP20 shrouds and input and output terminals in Rittal VX25 600 mm wide cabinet




270 Step-by-step drawings for an installation example of drive module with optional IP20 shrouds and input and output terminals in Rittal VX25 600 mm wide cabinet





272 Step-by-step drawings for an installation example of drive module with optional IP20 shrouds and input and output terminals in Rittal VX25 600 mm wide cabinet



23. Step-by-step drawings for installing full cabling panels (option) in a Rittal VX25 400 mm wide enclosure




ABB parts	
2	Pedestal guide plate
6	Top guide plate
Customer-made parts (not ABB or Rittal product)	
5	Air baffles


Installation procedure

1. Install three Rittal support rails (4396.500) on the bottom of the enclosure.
2. Install the pedestal guide onto the support rails.
3. Install the Rittal punched sections 8617.030 (5 pcs).
4. Install the Rittal punched sections 8617.010 (3 pcs).

274 Step-by-step drawings for installing full cabling panels (option) in a Rittal VX25 400 mm wide enclosure

5. Install the air baffles.

6. Install the top guide plate.



Installation procedure (continued)




7. Install the output cabling panel.

8. Install the side guides to the output cabling panel (2 screws for each side guide).


9. Attach the grounding busbar to the input cabling panel. Back view is shown above.

10. Attach the input cabling panel to the punched section.

11. Install the telescopic extraction and insertion ramp.




TOP MOUNTING
3:25










BOTTOM MOUNTING
3:25

BOTTOM MOUNTING



3AXD50000439317


276 Step-by-step drawings for installing full cabling panels (option) in a Rittal VX25 400 mm wide enclosure



A
3:25

LEAD THROUGH AREA

SCREWS
RITTAL 2486.600
10 pcs




BOTTOM PLATE
3AXD50000433988

B
3:25

C
3:10

3AXD50000439317

24. Step-by-step drawings for a flat installation example in a Rittal 600 mm wide cabinet



3AXD50000440559

278 Step-by-step drawings for a flat installation example in a Rittal 600 mm wide cabinet

25. Step-by-step drawings for option "Power cable connection terminals on the right-hand side of the module" installation example in a Rittal 600 mm wide cabinet




ABB parts for option "Power cable connection terminals on the right-hand side of the drive module"	
1	Support for back top mounting bracket
2	Handle
3	Bottom mounting bracket
ABB standard parts	
4	Lowest back cover plate
5	Back top mounting bracket

280 Step-by-step drawings for option "Power cable connection terminals on the right-hand side of the module" installation example in a Rittal 600 mm wide cabinet

Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to www.abb.com/searchchannels.

Product training

For information on ABB product training, navigate to new.abb.com/service/training.

Providing feedback on ABB manuals

Your comments on our manuals are welcome. Navigate to new.abb.com/drives/manuals-feedback-form.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at www.abb.com/drives/documents.



www.abb.com/drives



3AXD50000025169F