


Quick Start Guide


Relion® 611 series














1	Display	Use navigation buttons for entering to submenus
2	Self-supervision and protection indicator LEDs	Ready-LED steady: OK, Ready-LED flashing: Internal Relay Fault (IRF), Start-LED steady: protection started, Start-LED flashing: protection function blocked, Trip-LED: protection operated
3	Programmable LEDs	Can be programmed for alarming and indication with latching and/or flashing features
4	Control Circuit Breaker (CB)	Press open/close and confirm by pressing enter. Note: control has to be in Local mode.
5	Escape / Cancel	Used for canceling actions and leaving setting mode without saving the values. Returns back to menu.
6	Navigation	Left = go back, Right = go further, Up = scroll up, Down = scroll down. Are also used for changing setting values.
7	Enter / Select	Entering to parameter setting mode and confirming new values
8	Local / Remote	Changes the control between Local/Remote
9	Help	View help menu
10	Front communication port	RJ-45 port can be used for connecting the IED to a PC

Using the local HMI


Accessing main menu and changing parameters

Press  to navigate to the main menu from the measurements view.


From the main menu, go to **Settings** and press . Then press  or  to select the setting value you want to change. Press  to change it with  or  buttons. If there is a “#” mark on the same line as the parameter value, you have to first select which setting group parameter you want to change. If there is no “#” mark then you can change the value directly by pressing  and then with  or  or  or  buttons.

You can change all parameters in the same way. The most common function block names are described at the end of this document.

Storing settings

Parameters have to be stored before taken into use. Store the settings by going back to the main menu by pressing the  button. The IED will ask for confirmation to commit changes, answer “Yes”. Some changes require the IED to reboot before the changes are taken into use. Reboot the IED by going to main menu **Configuration** → **General** → **Software reset** or by switching the auxiliary power off and back on.

Changing the overcurrent start value

From the main menu, go to **Settings** → **Settings** → select setting group, default 1 and press  → **Current Protection** → **PHLPTOC1** → **Start value**.

Changing function block naming from IEC 61850 names to IEC 60617

From the main menu, go to **Configuration** → **HMI** → **FB Naming convention**.




Checking binary input value

From the main menu, go to **Monitoring** → **I/O Status** → **Binary input values** → select correct BIO card.

Checking fault records and measurement values of the latest faults

From the main menu, go to **Monitoring** → **Recorded data** → **Fault record**.

Clearing events, indications and programmable LEDs

From the main menu, go to **Clear**. Select the item you want to clear and press  and select **Clear** by pressing  (Cancel will disappear). Confirm by pressing .

Checking IED order code, serial number, HW revision and software version

From the main menu, go to **Information** → **Product Identifiers**.

Display header area

The icon area at the upper right corner of the display shows the current action or user level. These are described below:

S = Parameters are being stored

! = Warning and/or indication

V = Viewer

O = Operator

E = Engineer

A = Administrator

Checking the input and output status of a function block

From the main menu, go to **Monitoring** → **I/O status**.




Checking the IP address

The address of the front communication port is fixed: 192.168.0.254. If the IED is equipped with a communication card you can check the IP address of the rear communication port from the main menu **Configuration** → **Communication** → **Ethernet** → **Rear port(s)**.

Activating the Web HMI

To activate the Web HMI from the main menu go to **Configuration** → **HMI** → **Web HMI mode**. Activation requires rebooting the IED.

Changing the display contrast

Hold  and press  or  to change the display contrast. The display contrast setting is automatically stored when A (Administrator) is visible in the icon area at the upper right corner of the display.

Using the Web HMI

Connect PC to the IED front communication port with a Ethernet cable. Enter the IP address 192.168.0.254 in a web browser. For full access, login with administrator username and password. The username is “ADMINISTRATOR” and the default password is “remote0004”.

Changing the overcurrent start value via WebHMI

It is important to enable writing to the IED. If write is disabled it is not possible to change settings.

Click settings in the left menu bar, then go to **Settings** → **Settings** → **Current Protection** → **PHLPTOC1** → **Start value**.

After you have changed the **start value** parameter, click **“Write to IED”** and click **“Commit”** in the notification bar that opens.

Input and output signal configuration

Click the corresponding area to view a specific logical group, and then the switch groups included in the logical group are listed in the Function View page. Click **“Overview”** to go back to the overview page.

REF611, A1
 24.04.2012, 14:01

General
Events
Programmable LEDs
Phasor Diagrams
Disturbance records
Signal configuration
Logout

REF611 > Settings > Settings > Current protection > PHLPTOC1 (Three phase non-directional OC, low stage)

IED

- REF611
- Control
- Events
- Measurements
- Disturbance records
- Settings**
- Setting group
- Settings
 - Current protection**
 - INRPHAR1
 - EFIPTOC1
 - EFHPTOC1
 - EFLPTOC1
 - EPLPTOC1
 - PHIPTOC1
 - PHHPTOC1
 - PHHPTOC2**
 - PHLPTOC1**
 - T1PTTR1
 - NSPTOC1
 - NSPTOC2
 - PDNSPTOC1
- Other protection
- Configuration
- Monitoring

Parameter Setting

Parameter Name	IED Value	New Value	Unit	Min.	Max.	Step
Operation	on	<input type="text" value="on"/>				
Num of start phases	1 out of 3	<input type="text" value="1 out of 3"/>				
Start value #	0.05	<input type="text" value="1.25"/>	xIn	0.05	5.00	0.01
Start value Mult #	1.0	<input type="text" value="1.0"/>		0.8	10.0	0.1
Time multiplier #	1.00	<input type="text" value="1.00"/>		0.05	15.00	0.05
Operate delay time #	40	<input type="text" value="40"/>	ms	40	200000	10
Minimum operate time	20	<input type="text" value="20"/>	ms	20	60000	1
Reset delay time	20	<input type="text" value="20"/>	ms	0	60000	1
Operating curve type #	IEC Def. Time	<input type="text" value="IEC Def. Time"/>				
Type of reset curve #	Immediate	<input type="text" value="Immediate"/>				
Measurement mode	DFT	<input type="text" value="DFT"/>				
Curve parameter A	28.2000	<input type="text" value="28.2000"/>		0.0086	120.0000	0.0001
Curve parameter B	0.1217	<input type="text" value="0.1217"/>		0.0000	0.7120	0.0001

Changing the overcurrent start value via WebHMI

Input and output signal configuration

Most common function blocks

The most common function blocks are listed below, see the full list from the operators manual. Available function blocks varies depending on the selected IED and standard configuration.

Function	IEC 61850	IEC 60617
Three-phase non-directional overcurrent protection, low stage	PHLPTOC	3I>
Three-phase non-directional overcurrent protection, high stage	PHHPTOC	3I>>
Three-phase non-directional overcurrent protection, instantaneous stage	PHIPTOC	3I>>>
Non-directional earth-fault protection, low stage	EFLPTOC	Io>
Non-directional earth-fault protection, high stage	EFHPTOC	Io>>
Non-directional earth-fault protection, instantaneous stage	EFIPTOC	Io>>>
Directional earth-fault protection, low stage	DEFLPDEF	Io> →
Directional earth-fault protection, high stage	DEFHPDEF	Io>> →
Transient / intermittent earth-fault protection	INTRPTEF	Io> → IEF
Negative-sequence overcurrent protection	NSPTOC	I2>
Phase discontinuity protection	PDNSPTOC	I2/I1>
Residual overvoltage protection	ROVPTOV	Uo>
Three-phase thermal protection for feeders	T1PTTR	3Ith>F
Loss of load supervision	LOFLPTUC	3I<
Motor load jam protection	JAMPTOC	Ist>
Motor start-up supervision	STTPMSU	Is2t n<
Phase reversal protection	PREVPTOC	I2>>
Thermal overload protection for motors	MPTR	3Ith>M
Circuit breaker failure protection	CCBRBRF	3I>/Io>BF
Three-phase inrush detector	INRPHAR	3I2f>
High-impedance differential protection	HIPDIF	dHi>
Phase segregated CT supervision function	HZCCRDIF	MCS 1I
Circuit-breaker control	CBXCBR	I ↔ O CB
Emergency startup	ESMGAPC	ESTART
Trip circuit supervision	TCSSCBR	TCS
Runtime counter for machines and devices	MDSOPT	OPTS
Disturbance recorder	RDRE	DR
Optional		
Auto-reclosing	DARREC	O → I

Complete customer documentation is available in the product pages that can be accessed through abb.com/reliion.

For more information, please contact

ABB Distribution Solutions

P.O. Box 699
FI-65101 Vaasa, Finland
Phone: + 358 10 22 11

abb.com/substationautomation

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB.
Copyright© 2019 ABB. All rights reserved.