

ABB DISTRIBUTION SOLUTIONS

Operation and Maintenance Manual MNS-SG Low Voltage Metal-Enclosed Drawout Switchgear



Table of Contents

•••	.po. tu.		
		Safety notices	
_		Warning	
1.		al information and system description	
	1.1.	System overview	
	1.2.	Component names	
	1.3.	Technical data table	
	1.4.	MNS-SG standard configuration	
	1.4.1.	Structure description	
	1.5.	Labels and markings	
	1.5.1.	Switchgear lineup label	
	1.5.2.	Cubicle/device label	
	1.6.	Mechanical design	
	1.6.1.	Section arrangement	
	1.7.	Busbar compartments	
	1.7.1.	Bus phases	
	1.7.2.	Horizontal neutral bus (optional feature)	
	1.7.3.	Ground bar	
	1.7.4.	Vertical distribution busbar	
	1.8.	Device compartment	
	1.8.1.	Section and location numbering	
	1.9.	Wireways	
	1.9.1.	Cable compartment	12
	1.9.2.	Top horizontal wireway	12
	1.9.3.	Bottom horizontal wireway	12
	1.9.4.	Vertical wireway	13
	1.10.	Seismic structure Frame	13
2.	Exhau	st plenum (optional)	14
	2.1.	Install side-exhaust plenum	15
	2.2.	Install rear-exhaust plenum	16
	2.3.	Seismic installation for plenum	18
	2.4.	Positioning arc-resistant switchgear	18
3.	Packa	ging and handling	19
	3.1.	Standard packaging	19
	3.2.	Section weight	20
	3.3.	Receiving	
	3.4.	Unload and move switchgear components	21
	3.4.1.	Loading and transport	
	3.4.2.	Ground transport	
	3.4.3.	Transport by crane	
	3.4.4.	Temporary storage	
4.		e and connect the switchgear	
	4.1.	Installation location requirements	
	4.2.	Installation guidelines	
	4.3.	Section installation sequence	
	4.4.	Install and connect shipping splits	
	rr.	motan and connect simpling spires	٠ د

	4.4.2.	Connect sections	26
	4.5.	Splice horizontal busbars	.27
	4.6.	Splicing Ground Busbar	29
	4.7.	Attach switchgear to the floor	30
	4.8.	Attach overhead lifting device	30
	4.8.1.	Operating overhead lifting device	.32
	4.9.	Connect cable and wiring	.32
	4.9.1.	Install connections – general information	32
	4.9.2.	Direct connections to main sections	35
	4.9.3.	Connect between horizontal and vertical wireways	35
	4.9.4.	Connect control wiring between sections	35
	4.9.5.	Connection to external control source (If required)	35
	4.10.	Other installation information	35
	4.10.1.	Interruption of installation	35
	4.10.2.	Surface damage	35
	4.11.	Commission the switchgear	
		Physical equipment check	
		Prepare to energize switchgear	
		Testing and final inspection	
		Energize the switchgear	
	4.11.5.	Energize the main bus	39
		Final testing	
		onent operation documents	
6.	Mainte	enance	
	6.1.	Lockout/tagout	
	6.2.	Tighten unit control and power terminals	
	6.3.	Remove/insert withdrawable breaker	
	6.4.	Inspect units	
	6.5.	Inspect busbars	
	6.6.	Exterior metal damage repair	
	6.7	Maintenance schedule	
	6.7.1	Semi-annual inspection	
	6.7.2	Annual inspection	
	6.7.3	18-to-36 month inspection	
	6.7.4	10-year maximum inspection	
	6.7.5	Eslok® fasteners	
	6.8	Arc flash protection	
		onal resources	
8.	Torque	e fasteners	
	8.1.	Torque table	
9.	Disclai	imer of warranties and limitation of liability	47

4.4.1. Position shipping splits......26

Important user information

ABB shall not assume any liability for any of the following:

- Negligent handling of the MNS-SG (Switchgear) system.
- Insufficient maintenance or non-compliance with the recommendations presented in this manual and other documents related to the MNS-SG and its components.
- Inappropriate repairs or modifications to the equipment.
- Operation, installation or maintenance of the equipment by personnel who lack appropriate training and/or authorization.
- Failure to follow appropriate safety procedures or use of the proper personal protective equipment, including arc flash, insulating, shielding materials, and use of insulated tools and test equipment per the National Electrical Safety Code (ANSI C2) and Electrical Equipment Maintenance (NFPA 70E).

The examples and diagrams in this manual are included exclusively for illustrative purposes. Because many variables and requirements are associated with each particular installation, ABB, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

Reproduction of the contents of this manual, in whole or in part, without written permission of ABB, Inc., is prohibited.

Safety notices

READ THIS MANUAL CAREFULLY BEFORE ATTEMPTING TO INSTALL, OPERATE OR MAINTAIN THIS EQUIPMENT.

Keep this manual available for the installation, operation and maintenance of this equipment. After installing the equipment, file these instructions with other instruction books, drawings and descriptive data for this equipment. Using these instructions will facilitate proper equipment maintenance and prolong its useful life.

Install the switchgear within the design limitations described in this manual. This equipment is designed to operate within the current and voltage limitations on the main nameplate. Do not use or install this equipment in applications or systems using current and/or voltages that exceed its limits.

Follow your company's safety procedures.

Do not remove covers, open doors or work on equipment unless power has been turned off and all circuits deenergized. All components should be electrically disconnected by means of a visible break, securely grounded and locked out, and tagged in accordance with precautions stated in ANSI Standard Z244.1 Control of Hazardous Energy – Lockout/Tagout and Alternative Methods and ISO Standards.

Personnel performing installation, operation or maintenance work on the equipment should wear the appropriate personal protective equipment.

Personnel installing, operating or maintaining this equipment must have thorough knowledge of all applicable local, regional, industry, governmental, ISO and OSHA safety procedures. They must also follow commonly accepted safe working practices based on the potential hazards involved. Personnel working in or around this equipment must use common sense and good judgment regarding the potential hazards to themselves and other personnel in the area.

These instructions are intended for use by fully qualified personnel and are not a substitute for adequate training, experience and supervision. This manual is not intended to be a substitute for adequate training and experience in the safety procedures related to this device. If you require clarification or additional information, contact your ABB representative. Please reference the Project Number shown on the equipment main nameplate. See Lineup Nameplate section of this manual.

Warning

Detailed descriptions of standard repair procedures, safety principles and service operations are not included. It is important to note this document contains some warnings and cautions against some specific service methods that could cause personal injury to service personnel, damage equipment, or render it unsafe. These warnings do not cover all conceivable ways in which service, whether or not recommended by ABB, might be performed, or the possible hazardous consequences of each conceivable way, nor could ABB investigate all such ways.

Anyone using service procedures or tools, whether or not recommended by ABB, must satisfy himself or herself thoroughly that neither personal safety nor equipment safety will be jeopardized by the service method or tools selected.

Should further information be required or specific problems arise that are not sufficiently covered, refer the matter to an ABB service representative.

The purchaser, installer or ultimate user is responsible for ensuring that warning signs are attached and all access doors and operating handles are securely locked when the gear is left unattended, even momentarily.

All information contained in this manual is based on the latest product information available at the time of printing. The manufacturer reserves the right to make changes at any time without notice.

Safety notations alert personnel to possible death, injury, or property damage situations. The following four safety notations and words are used in the manual to indicate the degree of hazard that may be encountered by the user. These words and safety notations are as follows:

⚠ DANGER

"Danger" – Indicates an imminently hazardous situation which is not avoided and has a high probably of death or serious injury and substantial property damage.

"Warning" – Indicates a potential hazardous situation which is not avoided and has some probably of death or serious injury and substantial property damage.

! CAUTION

"Caution" – Indicates a potential hazardous situation which is not avoided and has a minor or moderate probably of death or serious injury and substantial property damage.

№ NOTICE

"Notice" – Indicates a statement of company policy as it relates directly to the safety of personnel or protection of property.

General information and system description

1. General information and system description

1.1. System overview

The MNS-SG switchgear consists of one or more vertical metal cabinets referred to as "sections." Each section includes three separate compartments: device, busbar and cable compartment.

Each section contains up to four compartment locations that may contain breakers, instruments and/or empty compartments that are used to control, protect and isolate electrical equipment.

All sections include a top and a bottom horizontal wireway for control wiring.

Units feature front, hinged doors held closed by one or more latches.

The rear door is secured by a swing handle with a door- lock mechanism that secures the door at four points of contact.

The unit door is interlocked with the disconnecting means, preventing the door from being opened when the breaker is in the ON position. The unit door can only be opened when the breaker is in the OFF position.



A continuous horizontal bus, rated 1,600 to 5,000 amps, distributes incoming power to all switchgear sections. The horizontal bus is located in the bottom half of each section, and for tie applications a similar assembly is used at the top of the section. Each section may contain a system of vertical bus, rated 1,600A up to 5,000A. The vertical bus is located in the busbar compartment, segregated from the device compartment.

1.2. Component names

This manual uses the following naming conventions:

Blank unit: An empty compartment.

Compartment: Sections are typically divided into three compartments: Device, busbar and cable.

See Mechanical Design - Section Arrangement.

Cubicle: See section.

Device: An instrument compartment, breaker compartment, empty compartment or an equipped space feeder.

Equipped space feeder: An empty compartment with the cradle and pilot light, control and other wiring already in place, ready for the addition of a breaker.

Lineup: The arrangement of several vertical sections, joined side-by-side, to create a complete switchgear with a continuous horizontal bus.

Mimic bus: Consists of a series of electrical symbols and designations used on the exterior of large switchgear panels that mimic the wiring scheme within the panel.

Module: The equipment compartment within a section is sometimes divided into smaller modules to accommodate devices of different heights. One section may be divided into as many as four modules.

Section: An enclosed, vertical metal cabinet that contains devices, wireways and other internal constructions. Several sections are typically combined next to one another to form a switchgear lineup.

Shipping split: Up to three vertical sections are arranged and joined side-by-side at the factory. This facilitates shipping, handling and installation. A lineup may include more than one shipping split depending on the configuration.

Vertical Section: See Section.

1.3. Technical data table

Standards		Type-tested switchgear assemblies (TTA)*	ANSI C37.20.1, ANSI C37.20.7, ANSI C37.50, ANSI C37.51, ASCE/SEI 7-05, CSA C22.2 No. 31, IEEE 1584, UL 50 E, UL1558, UL508	
Test certificates		The MNS-SG is designed, tested and constructed in accordance with the following industry standards and guidelines:	UL file E235182	
		Rated insulation voltage Vi	2.2 kV	
	Part deselven	Rated operating voltage Ve	240, 480 or 600 VAC	
	Rated voltages =	System types	3 phase-3 wire, 3 phase-4 wire	
Electrical data	-	Rated Frequency	50/60 Hz	
	Rated ampacities main and	Rated current	1,600A up to 5,000A	
	distribution busbars	Rated short circuit current	Up to 100kA @ 600V	
		Height: in (mm)	90.6 (2,300) [without chimney, plenum or top hat]	
	Dimensions	Width: in (mm)	23.6 (600) 27.6 (700) 31.5 (800) 39.4 (1,000) 19.7 (500) transition section	
		Depth: in (mm)	72.9 (1,852) 80.8 (2052)	
	-	Basic unit (grid) size	E = approximately 1.0 inch (25 mm)	
		Frame	Alu-zinc coated/galvanized/stainless steel	
	-	Internal subdivision	Alu-zinc coated/galvanized/stainless steel	
Mechanical features	Surface protection =	Transverse section	Galvanized	
		Enclosure	Paint color gray ANSI 61 hammered tone	
	Enclosure type	NEMA 1 (arc-resistant) NEMA 1 with gasketing (non arc-resistant)		
	Plastic components	Self-extinguishing, flame retardant		
		Standard - silver plated, tin-plated (copper available)		
	Busbars =	Bus bracing	Up to 100kA @ 600V	
	Paint finish	Enclosure	Standard - textured ANSI 61 Special colors available)	

^{*} TTA: Switchgear assembly corresponding to the original type or system of switchgear assembly type tested in accordance with these standards.

1.4. MNS-SG standard configuration

1.4.1. Structure description

The switchgear assembly consists of one or more metalenclosed vertical sections. Each vertical section is divided into several areas: The instrumentation/ device compartment in the front of the section, the bus compartment in the middle and the cable compartment for the end terminal connections at the back.

A continuous horizontal ground bus, running from the front to the back of the section, is located at the bottom of all sections.

End sections are designed to allow for the addition of future sections.


The switchgear may accept power cable entry from the top, bottom or both. Bus duct or closed-couple connections are also an option.

The base channel is an optional feature to use to install the SG in its final location. It will raise the units by 1.5 inches. It is an alternate method to weld the base channel to a metal structure.

The channel shall get the equipment off the ground so the doors can open properly without hitting the floor.

When the base channel option is selected there are rodent barriers attached to the side of the SG. All openings in the enclosure are limited by the IP20 rating; this will be enough protection to prevent vermin, rodents and snakes from entering the switchgear from the top, bottom and sides of the equipment.

Lifting angles are provided to allow lifting by crane.



1.5. Labels and markings

The switchgear is provided with several nameplates and labels that display data related to the equipment's electrical ratings and the specific application or installation.


1.5.1. Switchgear lineup label

Sections are organized side-by-side in a lineup that has a metallic master label. This master nameplate is attached to Section 1.



1.5.2. Cubicle/device label

Each cubicle and device has a label located on a visible area, which displays the approval agency marking.



1.6. Mechanical design


1.6.1. Section arrangement

Vertical sections are composed of the following three main compartments:


Device compartment: Composed of up to four vertical locations that house the installed devices, which are the main functional elements of the switchgear.

Busbar compartment: The compartment where main and distribution busbar systems are installed.

Cable compartment: Location where power connections are made to the rear of the device.




MNS-SG standard compartments



MNS-SG standard compartments

1.7. Busbar compartments

The main horizontal busbar is installed in the busbar compartment located at the middle of the section. The main horizontal bus may be supplied in various configurations depending on the current rating.




Horizontal busbars

1.7.1. Bus phases

The horizontal busbar is located at the bottom of each section. The phase arrangement of 3-phase horizontal busbar and vertical busbars is A, B, C from top to bottom, or left to right, as viewed from the front.

The busbar systems are installed in the lower level busbar compartment. The tie busing will be installed at the upper level.



Bus Phases

Bus ratings and sizes

The number of installed bars per phase depends on the current ratings. Up to five bars per phase may be installed.

Only sections with the same horizontal bus configuration can be coupled (or spliced) together except for tie main sections.


Busbars systems are 3-phase 3-wire or 3-phase 4-wire. See Horizontal Neutral Bus for details.

There is the option of only having 3-phase 4-wire in the incoming section and the rest of the lineup will be 3-phase 3-wire.

Sections in the same shipping split will be connected at the factory. For lineups that combine multiple shipping splits, each shipping split must be connected together during installation using the splice kits provided on each split. The splice kits' bolts must be tightened to the specified torque. See the Torque Table provided in this manual.

Horizontal bus is available in silver-plated copper or optional tin-plated copper.






Bus ratings and sizes

1.7.2. Horizontal neutral bus (optional feature)

When required, a 100% rated neutral horizontal busbar is provided in the busbar compartment above the lower A-phase horizontal busbar. For four-wire systems that have no line-to-neutral load requirements, an incoming neutral connection point can be provided to facilitate the power system grounding connection, but without neutral horizontal or distribution busbars are provided.

1.7.3. Ground bar

A continuous, sectionalized, bare-copper ground bus, rated 1,000A, is provided at the bottom-rear side of each section running from side-to-side on the cable compartment of all sections. In the cable compartment, the ground bar is linked to the ground bar in other sections by a splice link.




The copper bus bars have a size of 9.52 mm (3/8") of thickness and a width of 50.80 mm (2"). The ground system can be silver or tin plated and also bare copper.

The lateral ground bus is machined with a series of holes spaced 2.0 in (50 mm) apart for attaching ground lugs and other conductors. Ground the switchgear ground bus using equipment-grounding conductors sized according to NEC 250-94, or by bonding the ground bus to the raceway enclosing the main supply conductors according to NEC 250-92(B).

1.7.4. Vertical distribution busbar

There are three standard vertical busbar types: full, threequarters and half distribution busbars. Both are located inside the busbar compartment. These busbars are arranged in A-B-C order from left to right.



Vertical bottom/full distribution busbar

1.8. Device compartment

Each device compartment is divided vertically into four locations, A through D. Locations A, B and D may contain feeders, equipped space, control or blank. Location C may contain main, tie, feeders or equipped space feeders.


Breaker unit instruments installed on the doors may include only pilot lights, push buttons, control switches and maintenance switches.

In addition to the items listed above, instrument compartments may also include ammeters, voltmeters, high-resistance grounds (HRGs), potential transformers and relays. These instruments can be installed inside the devices or on the front of the device door.


1.8.1. Section and location numbering

Each section is sequentially numbered as the general arrangement drawings are prepared. The left-most section is usually section 1, the next section to the right is 2, etc. This numbering scheme ensures the correct sequencing of vertical sections during installation.

The combination of the numeric section code (1, 2, 3, etc.) with the vertical level designation (A, B, C, and D) uniquely describes each device's location in the switchgear. For example, the device mounted in the top of the first section of a lineup would be coded 1-A.



Device location numbering (C and D locations can be combined)



1.9. Wireways

1.9.1. Cable compartment

A cable compartment is provided in each section. The compartment is located on the back of the section, extending the full height of the structure. It is used to route top or bottom incoming conductors to the individual devices within the section. The overall depth of a standard cable compartment is 27.5 in (700 mm).

The overall depth of the SG is 1852 or 2052 mm having two cable compartment depths.

For 1800 SG the cable compartment is 27.5 in (700 mm) and for 2000 mm SG the cable compartment is 35.4 in (900 mm).

Cable compartments may be equipped with three 12 gauge [0.1 in (2.5 mm) thick] steel covers or single/ double full-height, hinged doors. The doors swing open 120° for maximum accessibility.

Cable compartment may have an optional cable support structure which is adjustable in vertical and horizontal position.

1.9.2. Top horizontal wireway

The MNS-SG has a 3.9 in (100 mm) high, 17.7 in (450 mm) deep top-horizontal wireway. This wireway provides the space for interconnection wiring. It is covered by a steel door secured by two quarter-turn latch.



Top horizontal wireway

1.9.3. Bottom horizontal wireway

The bottom horizontal wireway is 6.0 in (150 mm) high and 17.7 in (450 mm) deep, covered by a steel door secured by two quarter-turn latch. The bottom of the bottom horizontal wireway includes a cutout for control conduit entry. See Install Connections – General Information section in this manual for more information.



Bottom horizontal wireway



Control conduit entry cutout

1.9.4. Vertical wireway


The vertical wireway is formed by the segregation walls on either side of the device and is directly connected to the top and bottom with the horizontal wireways.




Vertical wireway

1.10. Seismic structure Frame

When a seismic structure is required there is a specific frame available. Basically, in this frame the transverse channels are required in cold roll steel without painting or plating. This frame allow to have the structure welded when is installed.






Switchgear frame for seismic structure

This frame includes stainless steel parts also in some cases and purpose is to minimize generation of magnetic fields in the structure.

When a seismic structure is required a specific sub-frame is available. Basically additional plates are included to give stiffness to the structure.

This assembly includes also two side walls which are mounted in the device compartment; these are used to segregate the device compartment in a single unit lineup or multi-section lineup. These side walls are manufactured in sheet metal 2.0 mm thickness.




Basic sub-frame for seismic structure

Exhaust plenum (optional)

2. Exhaust plenum (optional)

The optional plenum will be shipped separately from the switchgear. It must be assembled and installed onsite. The switchgear will be shipped with temporary covers over the busbar compartment of sections of the lineup to prevent the entry of dirt or debris.

Following an arc flash, the equipment must be inspected by a qualified service technician prior to putting the switchgear back in service. Contact your local ABB representative for assistance.




Temporary covers

Side and rear exhaust plenum configurations are available. These two configurations may be converted if required. Contact an ABB representative for additional parts needed to convert the plenum.

NOTE: The rear-exhaust plenum is not available with top-cable-entry switchgear.

Before beginning the installation, identify the location where the plenum will vent outside of the switchgear room. The exhaust must be directed to a location where it will not cause injury or damage. See Positioning Arc-Resistant Switchgear.

Create the necessary opening in the wall.



Wall-opening dimensions


After installing the plenum, reseal the gap according to NEC and local regulations.

Calculate the number of extensions that will be required to connect the switchgear to the wall opening. Extensions are available length sections of 9.8, 19.7, 31.5 and 39.4 in (250, 500, 800 and 1000 mm). Use as many extensions as necessary between the switchgear and the wall. However, there can be no corners or turns in the extensions; they must be installed in a straight line to the exterior of the electric room. Support the extensions at 47.2 in (1200 mm) intervals using any secure supporting method.

Verify the correct extensions and other necessary parts to complete the installation.


Remove the temporary cover from all sections of the switchgear.

2.1. Install side-exhaust plenum



Extension and end flaps


- 1. Install the top cover above the busbar compartment, securing it with the six M6 x 16 screws supplied with each section. Torque to 3.5 ft/lbs (4.7 Nm).
- 2. Connect each top cover to the adjacent cover with 10 M6 x 16 bolts, using the supplied washer and nuts for each bolt. Torque to 3.5 ft/lbs (4.7 Nm).



3. Place the L-profile rail at the edge of the section that will be closed (opposite from the edge on the side of the section where the plenum will vent). Attach the L-profile using four M6 x 16 screws.


Torque to 3.5 ft/lbs (4.7 Nm).

4. Install the end cover by inserting the rivet screws through the L-profile and into the end cover, then securing the cover in place with 10 M6-1 x 16 bolts, using the supplied washer and nuts for each bolt.



Attach end cover

- 5. After installing the top and end covers, install the extension connection on the plenum. Attach the extension to the switchgear section frame using four M6 x 16 screws. Torque to 3.5 ft/lbs (4.7 Nm).
- 6. Attach the extension connection to switchgear frame with 4 M6 x 16 screws, and to the top cover with 10 M61 x 16 bolts, using the supplied washers and nuts for each $\frac{1}{2}$




Extension connector

7. Once the extension connection is in place, attach additional extensions as needed to create the needed plenum length. Connect each extension using 14 M61 x 16 bolts, washers and nuts. Torque to 3.5 ft/lbs (4.7 Nm).

8. Attach the end flaps to extension on the opposite side of the wall from the switchgear, outside the vent hole. Connect the end flaps using 14 M6-1x16 bolts, washers and nuts. Torque to 3.5 ft/lbs (4.7 Nm).


2.2. Install rear-exhaust plenum



Rear exhaust plenum


The preferred location for the rear-exhaust plenum is the middle of the lineup, but it can be placed in any part of the lineup.

- 1. Remove the top covers of busbar and cable compartments where the plenum will be attached.
- 2. Install the top cover on the section where the rear exhaust will vent from the lineup. This cover is the same as the others, but the back side is removed to allow the gas to flow out of the lineup.



Top cover - Rear exhaust


3. Install the top covers over each cable compartment of the lineup securing them with the six M6 x 16 screws supplied with each section. Torque to 3.5 ft/ lbs (4.7Nm).



Install top covers

4. Connect each top cover to the adjacent cover with 10 M61 x 16 bolts, using the supplied washer and nuts for each bolt. Torque to 3.5 ft/lbs (4.7 Nm).

5. Place the L-profile rail at the side-edge of the section that will be closed. Attach the L-profile using four M6 x 16 screws. Torque to 3.5 ft/lbs (4.7 Nm).



Top cover - rear exhaust


- 6. Install the rear cover on top of the cable compartment using 10 M6-1 x16 bolts, washers and nuts. Torque to 3.5 ft/lbs (4.7 Nm).
- 7. If the lifting angles are still in place, remove the angles that interfere with the cover(s) and replace the bolts.

№ WARNING

DO NOT remove the top cover of cable compartment section that has the rear cover attached to it.


NOTE: For 31.5 in (800 mm) or 39.4 in (1,000 mm) wide sections, install a rear-plenum transition to compensate for the width difference to the rear extension.

8. Attach the extension connection to switchgear frame with four M6 x 16 screws, and to the top cover with 10 M6 x 16 bolts, using the supplied washers and nuts for each bolt. Torque all to $3.5 \, \text{ft/lbs}$ ($4.7 \, \text{Nm}$).




Top cover – rear exhaust

9. Attach the end flaps to connect the plenum to the exterior vent hole. Connect the end flaps using 14 M61 x 16 bolts, washers and nuts. [Torque to 3.5 ft/lbs (4.7 Nm)].



2.3. Seismic installation for plenum

When the MNS-SG is arc resistant with plenum and rated for seismic, the seismic supports (not included by ABB) for the plenum installation must to be placed after the plenum extending at least 9 in (225 mm) minimum and maximum 40 in (1000 mm) from the side/back of the switchgear (see image).



The plenum should be installed by the end user according to local regulations for a seismic resistance installation.


2.4. Positioning arc-resistant switchgear

When installing this switchgear, you must provide the following clearances:


- The switchgear must be at least three feet from the walls to either side and behind the switchgear.
- There must be at least 4.0 in (100 mm) clearance around the plenum and extensions.
- The plenum must direct the exhaust outside of the building.
- Designate a safe area adjacent to the outlet from the plenum. This safe area must be 6.0 X 6.0 ft (1.8 X 1.8 m), clearly marked as a Keep Out or restricted area. Do not store equipment or materials in this area that could be damaged by a blast force or heat.
- Allow at least 15.0 in (400 mm) between nearest objects or adjacent wall and the end flaps of the plenum.



Safe area - front view



Safe area-interior - front view



Safe area – top view

Packaging and handling

3. Packaging and handling

3.1. Standard packaging

MNS-products are shipped either in single cubicles or in shipping units not exceeding 1.8 m for MNS UL switchgear in length depending on the type of equipment installed and on the space available for handing the unit at the erection site.

If no special instructions are given by the customer, packing is carried out based on this document and a suitable method of shipping is selected.

Maximum size of a shipping unit (length x width x height) in mm:

Packed in crate for one section from 600 mm up to 1000 mm

- 83 in x 51 in x 101 in (2107 mm x 1292 mm x 2576 mm) for 1852 mm depth
- 90 in x 51 in x 101 in (2307 mm x 1292 mm x 2576 mm) for 2052 mm depth Packed in crate for two sections up to 1400 mm
 - 83 in x 63 in x 101 in (2107 mm x 1608 mm x 2576 mm) for 1852 mm depth
- 90 in x 63 in x 101 in (2307 mm x 1608 mm x 2576 mm) for 2052 mm depth Packed in crate for three sections up to 1800 mm
 - 83 in x 79 in x 101 in (2107 mm x 2000 mm x 2576 mm) for 1852 mm depth
 - 90 in x 79 in x 101 in (2307 mm x 2000 mm x 2576 mm) for 2052 mm depth


Maximum size of a shipping unit (length x width):

Pallet dimensions for 1852 depth:

- 83 in x 51 in (2107 mm x 1292 mm)
- 83 in x 63 in (2107 mm x 1608 mm)
- 83 in x 79 in (2107 mm x 2000 mm)

Pallet dimensions for 2052 depth:

- 90 in x 51 in (2307 mm x 1292 mm)
- 90 in x 63 in (2307 mm x 1608 mm)
- 90 in x 79 in (2307 mm x 2000 mm)



Shipping pallet dimensions
Approximate values for weights per cubicle

3.2. Section weight

Some heavy devices or sensitive parts may be shipped separately. Weights listed in the following table are approximate. Consult equipment shipping documents for actual weights and dimensions.

			losure tructure					Coppe	r busbars				
Width	Units	De	epth	1	1600	2	000	3	3200	4	1000	5	000
		1852 mm (72.9 in)	2000 mm (80.7 in)	3P-3W	3P-4W	3P-3W	3P-4W	3P-3W	3P-4W	3P-3W	3P-4W	3P-3W	3P-4W
500 mm*	kg	269.9	283.3	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
(19.6 in)	lbs	595.0	624.6	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
600	kg	326.0	339.9	174.1	183.0	222.8	233.9	N/A	N/A	N/A	N/A	N/A	N/A
(23.6 in)	lbs	718.6	749.4	383.8	403.4	491.2	515.7	N/A	N/A	N/A	N/A	N/A	N/A
700	kg	345.5	360.2	182.0	191.9	230.8	243.4	N/A	N/A	N/A	N/A	N/A	N/A
(27.5 in)	lbs	761.7	794.0	401.1	423.1	508.8	536.6	N/A	N/A	N/A	N/A	N/A	N/A
800	kg	374.8	390.1	N/A	N/A	N/A	N/A	412.6	434.2	N/A	N/A	N/A	N/A
(31.5 in)	lbs	826.3	860.0	N/A	N/A	N/A	N/A	909.6	957.2	N/A	N/A	N/A	N/A
1000	kg	413.1	429.7	N/A	N/A	N/A	N/A	N/A	N/A	615.8	649.2	810.6	850.6
(39.4 in)	lbs	910.7	947.2	N/A	N/A	N/A	N/A	N/A	N/A	1357.6	1431.2	1787.1	1875.3

 $\begin{tabular}{ll} \textbf{NOTE:} Breaker compartment and breakers weight shall be multiplied times the quantity in each section $$ *Fortransition section only $$$

Breaker/cradle							
E2.2	E4.2 (up to 2500A)	E4.2 (3200A)	E6.2				
128 lbs	261 lbs	300 lbs	486 lbs				
58 kg	118 kg	136 kg	220 kg				
30 kg	110 kg	150 kg	LLO Kg				

NOTE: Hardware and control factor adds 4% to total

Breaker/instrument/empty compartment
63.1 lbs (28.6 kg)
73.3 lbs (33.25 kg)
83.8 lbs (38 kg)
94.1 lbs (42.7 kg)
114.6 lbs (52 kg)

Accessories	
Overhead lifting device	118 lbs
Overnedd menig derice	54 kg
CTs (set of three up to 2200A)	33 lbs
CTs (set of three up to 3200A)	15 kg
CT- (+ -f+h 4000A)	77 lbs
CTs (set of three, 4000A)	35 kg
UDG	132 lbs
HRG	60 kg
DT- (reals)	11 lbs
PTs (each)	5 kg
	441 lbs
Close coupling or bus duct raisers (3200A)	200 kg
Class as well as a select death as is see (5000A)	661 lbs
Close coupling or bus duct raisers (5000A)	300 kg

3.3. Receiving

Before shipment, each vertical section was inspected and marked with its assembly number and location within the lineup. See Section and Device Numbering. Check the equipment received against the packing list to ensure that all components were received. Notify your ABB representative and the carrier at once if there are any discrepancies between what was ordered and what was received.

Before accepting your switchgear, inspect each shipping split and its packaging for evidence of damage during shipment. If there is any evidence the equipment has been damaged or mishandled, a qualified technician should perform a complete inspection of both the interior and exterior of the equipment. If there is damage from improper handling, file a claim for damages at once with the carrier and notify an ABB representative.

Retain all of the packing material until you are confident that you have all components and that they are suitable for installation.

If there will be a delay in installing the switchgear, retain the necessary packing materials to store it safely. See Temporary Storage.

3.4. Unload and move switchgear components

Unload the sections or shipping splits as close to the installation site as possible to minimize additional transportation. Place the shipping splits on a flat surface. When moving the sections or shipping splits, keep them vertical at all times.

Sections and shipping splits usually have a high center of gravity. To improve stability while moving them to the installation site, leave the sections or shipping splits secured to the shipping skid or base.

Be sure to balance your loads carefully when moving them and use safety straps when using material-handling equipment.

The switchgear includes very heavy components. To prevent equipment damage and serious injury or death, only use material-handling equipment with sufficient capacity for the loads involved.

Components should be unloaded and transported only by qualified operators and/or installers.

NOTE: Never set the switchgear sections on edge. To prevent deformation, sections should always rest flat on the floor or supporting structure.

3.4.1. Loading and transport


The truck can be unloaded by crane or fork-lift truck. The loads must be lowered onto a flat surface.

3.4.2. Ground transport


- By fork-lift truck
- By lifting and conveying devices
- In an emergency, with rollers (min. 3 pieces)
- Switchgear cubicles have to be transported only in the vertical position.
- Tilting and canting must be avoided



Cubicles may easily tip over when transported with a handpulled truck. Therefore the distance between the wooden cross beam or the pallet and the underground should not be more than 3 mm.




Transport with a hand-pulled truck




Roller transport



Crane transport, transport unit unpacked



Fork-lift transport



Crane transport, transport unit in box


3.4.3. Transport by crane

Sections are equipped with lifting angles to enable unloading and positioning using a crane. Do not fasten any lifting device directly to the vertical sections. Lift only using the lifting angles located on the outer corners of each section. If lifting angles can be removed after the section is in position. If you remove the lifting angles, replace the bolts; do not leave the bolt holes open.


Transportation by crane must comply with the ASME B30 Safety Standards Committee for Cableways, Cranes, Derricks, Hoists, Hooks, Jacks, and Slings.

For transport by crane, the shipping units are equipped with lifting angles.

Shipping units with one, two or three sections are equipped with single angles on each corner of every shipping section.



Arrangement of lifting angles



Frame corner joint with lifting angle


Tilting danger signs must not be removed before all cubicles have been secured to the foundation.

Do not put the switchgear down on one edge, because of the danger of considerable mechanical damage.



Sling placement on SG

- Lift units from the four outside corners
- Fastening of any lifting device directly to the frame sections is not permitted.



Sling minimum angle
Sling leg angle should not be more than 120°



Correct hook engagement on lifting eye

- When installing the sling hooks, the hook should always be pointing to the outside of the load and not to the center of the load.
- The lifting angles may be removed after the switchgear has been erected.

3.4.4. Temporary storage

If the switchgear will not be immediately installed upon receipt, it should be stored under the following conditions to avoid damage:

- Unpack immediately upon delivery and inspect for damage. See Receiving.
- Open all section doors and allow the equipment to adjust to room temperature and humidity for several hours.
- Store the equipment in an area where the ambient temperature remains above 16°C (60°F) but will not exceed 65°C (149°F). The air must be dry (50% moisture maximum).
- Before energizing the space heaters remove all packing materials from the SG.
- Connect external power to space heaters (and temporarily disconnect from internal circuitry, if so connected) adjusting the thermostat between 35°C (95°F) and 40°C (104°F) to help drive off condensation.
- Do not omit the use of appropriate personal protective equipment (PPE) necessary to do the connections of the power supply of the heaters.
- If the switchgear will not be installed soon after arrival, cover the sections to protect them.
- During the operation of the heaters, these must be monitored to avoid any damage that may cause a fire.
- Check once per week for condensation on the components. If condensation is detected, dry the equipment and move it to a different storage area.

TIP: You can use heaters or hang a 100 watt incandescent light bulb inside the section to reduce condensation.

If your delivery includes spare parts:

- Store the components indoors in a condensation- free environment, with no more than 50% humidity, with ambient temperature above freezing but not exceeding 104°F (40°C).
- Store them with the boxes top-side up.
- Store circuit breakers upright in their original shipping carton. Do not stack.

Locate and connect the switchgear

4. Locate and connect the switchgear


- 1. Before beginning the installation, ensure that you have all of the needed components:
- Switchgear sections
- Fastener hardware to connect sections
- Shipping split connection hardware
- 2. Make a final check that all components are in good condition. If there is any evidence of damage to the equipment, contact an ABB representative to evaluate the condition of the equipment before proceeding with installation.
- 3. Carefully review all supplied project drawings and notes to familiarize yourself with the layout and construction of the switchgear.
- 4. Based on the footprint shown on the general arrangement drawings, mark the floor for all drill holes necessary to fasten the switchgear or base frame to the floor, and for cable conduits (if applicable). See Fastening Sections to a Base Frame.
- 5. Install power and secondary (control) conduits before moving the switchgear to the site. The available space for conduits appears on the floor plans supplied with the switchgear. Conduits should not extend more than 1.0 in (25mm) above floor level.

4.1. Installation location requirements


The installation must meet the following requirements:

- Indoor location protected from moisture and dramatic temperature changes. For longest equipment life, install the switchgear in an enclosed room with temperature and humidity control and filtered, and forced air ventilation.
- Level the site, preferably including a base frame that is either embedded in the concrete floor or rests on a false floor on supports. The floor must be straight and level to +/-1/4 inches (6 mm) over the entire length of the lineup.
- Prepare proper openings in the floor, wall and ceiling for cables, conductors, pipes, bars and ventilation in accordance with the construction drawings provided.
- At least 2.5 ft (750 mm) from the top of the highest section to the ceiling, and at least 3.0 ft (920 mm) between the left and right end sections to the walls.
- At least 3.5 ft (1066 mm) between the unit and the rear wall.

 See Positioning Arc-Resistant Switchgear for special restrictions regarding distances around the switchgear and other positioning requirements.



Clearances - front view



Clearances - side view

- For sections with left-mounted doors, provide at least 3.0 ft (920 mm) between the left wall and the left-end section so the doors can be opened more than 120°.
- Ambient temperature is to be above -13° F (-25° C) but not exceeding 104°F (40°C) at 85% non-condensing humidity.
- Supply sufficient space for future expansions, if required.

- Supporting brackets, beams, enclosures and foundation frames should be painted or treated with corrosion-resistant coating. To facilitate installation and maintenance, the site should also have:
- Convenient alignment with other equipment.
- Accessibility for maintenance.
- Adequate lighting.
- Free access to the electrical equipment rooms.

4.2. Installation guidelines

№ WARNING

Follow all instructions related to the installation of the switchgear to avoid potentially hazardous situations that could result in serious injury or death.

If the installation is being done near operational equipment, it may be appropriate to erect temporary barriers between that equipment and the switchgear.

If you are adding sections to existing switchgear, turn off all power supplying this equipment before working on or inside it.

Always use an appropriate voltage-sensing device to confirm that the power is off prior to installing or working with the switchgear.

Follow appropriate lockout/tagout procedures.

4.3. Section installation sequence

Sections can be installed or added in any order, and new sections may be added between existing sections. If the sequential order designated during manufacturing is altered onsite by adding sections to an existing lineup, the main bussing must match; and the related drawings must be updated.

When adding, removing or rearranging sections, do not exceed the maximum amperage available on the horizontal bussing.

4.4. Install and connect shipping splits

NOTE: Diagrams showing the location of fasteners and the appropriate torque values can be found in the Torque Table section of this manual.

4.4.1. Position shipping splits

Remove the shipping splits from their pallets or skids. If you need to support a multiple- section shipping split at the base after removing it from the pallet, use supports at the corner of each section. Don't support the shipping split only at the four outer corners.


Position the shipping splits in their final arrangement and location. Connecting the sections together before attaching them to the floor and/or wall will simplify splicing the horizontal bus.

If doors won't close easily or panels are twisted or stressed, this may indicate that the site is not leveled. You may be able to shim the sections to level them.

4.4.2. Connect sections

NOTE: Use only the provided fasteners to assemble the switchgear.

 Begin the installation at either the left or the right end of the lineup by connecting the frames of the sections together. The left side of each frame is fitted with threaded inserts. Sections are fitted on the right side with the necessary rivet nuts. Insert the bolts from the left side of one frame to the inserts in the adjoining section to the right.



Frame connection using spacer bolts



Section Frame Connections

- 2. Connect the sections using the provided hardware, consisting of 12 M8-1.25 x 20. Torque to 15 ft/lbs (20 Nm). The hardware bag is typically affixed to the front of the switchgear shipping split.
- 3. After connecting the sections, you can attach the lineup to the floor (see section 4.7).

NOTE: Install the spacer bolts only in the front C profiles and rear C profiles as shown on the frame connection drawing. The bolts in the middle section are not necessary to install because in the field it is no longer possible to join the frames in certain areas.

4.5. Splice horizontal busbars

NOTE: The fasteners provided with the switchgear include an integrated thread coating that ensures they will remain at the torque valued. See Eslok® Fasteners in this manual for more.

The bus in each section is designed to allow splicing with the bus of the adjacent sections to create a continuous horizontal bus. The splice links are located on the right-hand side for the neutral and phase A and on the left-hand side for phase B and C of each section. They are slid to the right or left to connect the bus to the adjacent section.

1. After installing and connecting the shipping splits, connect the main horizontal bus splice links and tighten the hardware to the specified torque. Splice kits are supplied from the factory, installed on the right-hand side for neutral and phase A, and left-hand for phase B and C of each shipping split. They are slid to the right or left to connect the bus to the adjacent section.


Follow the next steps to connect the Main Bus Bar:

- a) Remove the Cable support if provided.
- b) If the Main Bus is insulated you must remove the insulation boots.





Splice Kits



Splice Links locations



Insulation Boots and Cable Supports to be removed

- Remove the Copper bars for field cable connections if applicable.
- d) Remove the rear cover (GPO3 or metal sheet) to access the Main Bus bar area.




Copper bars and cover to be removed

The only space for access to the connections and put the hand and the torque wrench is between Phase B & Phase C, also between Phase A and Neutral bus bar.




Access for connect the links of Bus Bars



The maximum gap between the left and right busbar is 0.9 in +/- 0.1 (25 mm +/- 3)

2. Tighten the four (4) M12 bolts. For easiest installation, use a long ratchet extension that extends outside the back of the bus bar compartment and an 18mm socket with a universal joint to easily access and tighten all of the bolts. Torque to 52 ft/lbs (70 Nm). Use only the fasteners provided for busbar connections. Do not use additional locking fluid. See Eslok® Fasteners in this manual for more information about the fasteners.




Main horizontal busbar splice kit

3. Once torqued to the proper value, draw a line across each fastener head and the surrounding metal surface so you can visually check whether the fastener has been properly torqued.



4. Frame Connection Torque Marks


NOTE: To connect the Neutral Bus Bar if provided, remove the black support & the red spacers of GPO3 at the end of the Bus Bar, those pieces sometimes are installed additionally but they are not necessary.



Repeat this process for all of the splice kits, including the neutral bus if provided. Splice links are provided on the right-hand side of each section for neutral and Phase A, and on the left-hand side for Phases B, C and the ground. The links may be loosened and bridged to the adjacent section.

NOTE: Splice Kits for 3200 A to 5000 A runs on the outside of the BusBar as described in the table and figure below.

CURRENT	BARS QTY.	SPLICE KIT BAR
3200 A.	3	2 X 5" X 3/8"
4000 A.	4	2 V E!! V 1 /2!!
5000 A.	5	2 X 5" X 1/2"



3200-5000 Amp Splice Kit



Insulated Busbar

The insulated bus option is available for non-arc resistant and for arc-resistant MNS-SG.


Boot insulation should be installed after the splice kit is installed; the flexible boot is wrapped around the splice connection and is secured with plastic tights.

NOTE: The holes at the ends of all busbars ensure adequate adjustment within the required tolerances (±20 mils [0.5 mm] in any direction). If the lineup has been installed properly, the busbars in adjacent sections will line up. Never drill or modify busbars if alignment is poor. Ensure that the adjacent sections are properly and completely connected together mechanically before connecting the horizontal bus splices.

Do not clean the contact surfaces on a new SG. For connections to existing SGs with heavy oxidation, you may need to clean the contact surfaces by sanding lightly with a fine grain aluminum oxide paper.

4.6. Splicing Ground busbar

The horizontal ground bus must be spliced between adjacent sections. Splice links are also provided on the right-hand side of each shipping section and may be loosened and bridged to the adjacent section.



Ground Bus Bar

The ground bus bar is designed to use one single bar across the sections or the shipping pallet, this bus bar is provided at the bottom-rear side of each section running from side-to-side on the cable compartment of all sections.



Ground Bus Bar Splice link

The lateral ground bus is machined with a series of holes spaced 2.0 in (50 mm) apart for attaching ground lugs and other conductors.

Loosen and remove the bolts holding the ground splice link(s) in place and put the link(s) to the right to straddle the ground bus in the adjacent (right-hand) section.

Tighten the two (2) M12 bolts using an 18mm socket wrench. Torque the bolts to 60 +/- 2 N-m. It is recommended to use an 18mm socket with an integral universal joint, to easily access and tighten all of the bolts.



Place the Link to join with the next section

The Switchgear must be grounded to the ground system designed by either a star or delta connection and the resistance must be a minimum of 0,001 Ω to ensure a good residual energy drain.

Refer to the Torque Table for all tightening torques for horizontal buss bolted connections.

Ground the Switchgear ground bus using equipment-grounding conductors sized according to NEC 250-94, or by bonding the ground bus to the raceway enclosing the main supply conductors according to NEC 250-92(B).

NOTE: Do not use abrasive cleaners on the bus joints. Failure to follow this instruction can result in high resistance connections.

Additional connections to the central ground system and the Switchgear ground bus can be made at any point on the perforated ground bus. Ground cables should not be run in conduit and should take the most direct path to the site ground.


4.7. Attach switchgear to floor

After completing the internal connections, attach the switchgear to its location. Switchgear may be:

- Attached to a base frame that has been secured to the floor (preferred method).
- Bolted directly to a concrete floor by setting vertical mounting bolts in the floor.
- Bolted to floor channels.

 Bolted to a false floor. A minimum floor height of 20.0 in (500 mm) is recommended to accommodate the bending radius of the cables and provide adequate accessibility.
 The false floor must have a carrying capacity of 20 kN/m2 (2.9 PSI) compression load from top to bottom.

Attach the sections using four bolts through the holes in the section base to the floor or base frame. Use M8 (5/16 in) or larger hardware. Torque to 14 ft/lbs (20 Nm).



Floor mounting anchor plan

The SG with seismic structure or with base channels can be welded to the floor. However, it is recommended that the customer follow appropriate welding techniques and treat the welded area with a corrosion-resistant coating.

4.8. Attach overhead lifting device


A traveling, overhead lifting device is available to assist with handling breakers. The front section of the switchgear provides support for the lifting device. The device travels the full width of the switchgear.

The breaker lifts from the floor or from a completely withdrawn circuit breaker cradle with a lifting yoke. A wormgear-driven mechanism and wire rope, operated by a removable hand crank, provide lifting power.

Although the driving mechanism allows for easy hand operation, the weight of the circuit breaker cannot accidentally move the mechanism. See the corresponding ABB drawing for detailed operating instructions.


To attach the lifting device:

1. Remove the carriage stop from one end of the lineup.



Remove carriage stop


- 2. Loosen all rails for the overhead lift device and mount the locator plates. Note that the plates have round bosses that mate with holes in the rails.
- 3. Adjust the rails as required to loosely secure the locator plates in place with the bosses in their mating holes.



Adjust the rails


- 4. After mating all locator plates in place with the rails, secure the locator plates and the rails.
- 5. Position overhead lift device on the tines of forklift.

Raise the overhead lift device up to the rails on the frame.




Raise lift device

Align wheels on the front rail and behind the rear rail. Adjust the upper-rear wheel to minimize vertical movement.



Align wheels

Push the overhead lift device off the forklift onto the rails.



Push device off the forklift

Push the overhead lift device off the forklift onto the rails.

Test the continuous movement of the overhead lift device. If the movement is correct, reinstall the carriage stop bracket.

4.8.1. Operating the overhead lifting device

Observe the following requirements when operating the circuit breaker lifting device:

- The wheels must be properly set on track.
- Do not depend upon the drum attachment to support the full breaker weight. Allow 4-5 wraps of wire rope to remain on the drum.
- Prevent snarling, kinking or knotting the wire rope.
- Lift only circuit breakers.
- Do not alter the lifting device or the circuit breaker lifting yoke.
- Never walk or stand under a circuit breaker suspended by wire rope.
- Do not leave a circuit breaker suspended on the wire rope.

4.9. Connect cable and wiring



Verify that all cables are de-energized prior to installing.

4.9.1. Install connections - general information

All conduit installations should conform to local codes and be compatible with the NEMA environmental rating of the switchgear. Install conduit away from the ground busbar to avoid possible damage. Position the cable connection to minimize bending and maintain relative vertical alignment to incoming connections.

When installing cable, make sure the temperature is above 32°F (0°C) unless the cable is appropriate for installation at lower temperatures.

On every connection, verify the compatibility of wire size, type and stranding for the type of power terminations (lugs or terminals).

Use correct lugs in all applications. Crimp compression lugs with the manufacturer- recommended tools. Properly connect all line and load cables to avoid bolted-fault and equipment damage (see chart p.32).

Cable support is a metal structure designed to help to support the filed cables connections. These structures are designed to be adjustable in height and depth to the end user preferences.

Use the switchgear electrical schematics provided to verify field wiring connection points.

Tighten any unused bolts.

The SG has the option for top incoming, bottom incoming, bus duct (top or bottom), and connection to dry transformers (closed couple connection).

Closed couple connection are available for 3-phase 3-wire and 3-phase 4-wire and designed for dry transformer only. It can be on either side of the SG.

For the neutral there are three options:

- UL service entrance.
- Bonded neutral to ground.
- Neutral separated from ground.

If your installation has top incoming connections:

Refer to the elevation drawings shipped with the switchgear to check space availability for incoming cables.

Make the connections only after the switchgear is in place, leveled, anchored and the sections joined and spliced. Bring the conduit into the top of the incoming section.

If the top plate has to be modified for the incoming conduit, remove the lifting angle and top plate to perform the modifications. Do not drill or cut the top plate while still attached to the section. This prevents metal chips from falling into the section, which can cause serious damage to the equipment.

After modification, replace the top plate and lifting angle bolts to guard against dust or dirt from entering from the top. The lifting angle bolts can also be removed and the holes plugged. See Crane Handling in this manual.

Optional bottom plates can be removed for modification. For approximate section base dimensions and ground bus locations, refer to the elevation and floor plan drawings shipped with the switchgear.

Lug assemblies

E2.2 breaker connection table

Section width	Contt current	Vertical runback coupling	Number of lugs	Size of lug connector
600				
700	•	2 x 1/4" x 3" 4		2 1 / 4 2
800	1200		4	2 x 1/4" x 3"
1000	•			
600	1600	2×1/4"×4" 5		
700			_	
800			5	2 x 1/4" x 4"
1000	•			

E4.2 breaker connection table (1600A and 2500A)

Section width	Contt current	Vertical runback coupling	Number of lugs	Size of lug connector
700				
800	1600	2 x 1/4" x 4" 5	5	2 x 1/4" x 4"
1000				
700				
800	= 2500	4 x 1/4" x 4"	7	4 x 1/4" x 4"
1000				

E2.2 & E4.2 breaker connection table (2000A)


Section width	Vertical runback coupling	Number of lugs	Size of lug connector
600			
700	2 x 3/8" x 4"	6	2 2 (01 41
800		0	2 x 3/8" x 4"
1000	•		

E4.2 breaker connection table (3200A)

Section width	Vertical runback coupling	Number of lugs	Size of lug connector	
800	6 x 1/4" x 4"	9	6 x 1/4" x 4"	

E6.2 breaker connection table

	tion dth	Vertical runback coupling	Number of lugs	Size of lug connector
10	00	4 x 3/8" x 5"	11	4 x 3/8" x 5"



Top and floor cable cutouts

4.9.2. Direct connections to main sections

For main sections, entry spaces for connections are provided at the top or bottom of the sections. The top plates (and bottom plates, if present) are removable to facilitate installing conduit or making other modifications.

The top and bottom horizontal wireway are dedicated to control wires. The horizontal wireway enables running control wiring between sections.

4.9.3. Connect between horizontal and vertical wireways

There are openings available between the vertical locations (A, B, C, D) for control wiring. Openings are 8.6 in (219 mm) X 0.9 in (22 mm).


4.9.4. Connect control wiring between sections

The device compartment segregation walls have knockouts that can be used to create openings to connect the horizontal wireway between sections.

Run interconnecting wiring between sections in a shipping split through the horizontal wireway in the top and bottom of each section.

To make connections between shipping splits, a pull-apart terminal block usually will be provided.

- Locate and uncoil removable shipping split terminals, refer to SG connection drawings provided in the Quality Dossier.
- Once the wiring is uncoiled, locate the terminals according to the number marked on them.
- Connect the removable terminal block to the fixed terminal block according to the marked numbering.



KIOCK-OUT IOCATIONS

- To make the communication connection, refer to connection drawings in the communication section and locate the plug in connectors in the shipping section.
- Connect the male and female communication connectors following their guide

4.9.5. Connection to external control source (if required)

If an external control source is used, it should be stable and not subject to variations. Consult your ABB representative for minimum VA requirements. Terminals for external control sources will usually be provided in the top or bottom wireway of the first or last section of the lineup. See the switchgear drawings for more details.

4.10. Other installation information

4.10.1. Interruption of installation

If work is interrupted during installation or connection, take appropriate measures to ensure that dust, moisture and foreign objects are not allowed to enter the switchgear enclosures.

Close the section doors whenever installation work stops or is delayed. For interruptions lasting more than one day, you should cover the sections.

In damp or humid environments, use heaters to prevent condensation. See Temporary Storage in this manual for more information.

4.10.2. Surface damage

To extend the life and ensure the safe operation of your switchgear, keep the exterior clean and in good condition.

To remove grease or oil on the exterior, use a cleaning solvent and a cloth or disposable wipe.

See Exterior Metal Damage Repair in this manual for repair instructions.

4.11. Commission the switchgear

4.11.1. Physical equipment check

Check all of the following items related to the installation and site before energizing the switchgear:

- Are the shipping splits connected properly and the lineup firmly attached to the foundation or false floor?
- Are shipping split bus splices at all bars tightened to the proper torque? Refer to the Torque Table in this manual.
- Are all factory-installed splice connections still at the proper torque as indicated by the alignment?


- Are all barriers, plates, doors and locks in place?
- Are the bottom plates (if used) properly installed?
- Are all tools, dirt/debris, shipping/packing materials or other foreign objects removed from inside the switchgear?
- Is the equipment properly grounded?
- Are the phase sequence and marking correct?
- Have all withdrawable breakers been inserted and removed to test interlock?

4.11.2. Prepare to energize switchgear


For arc-resistant switchgear:

Ensure that the flaps on the chimney are closed.

These flaps are hinged and can be pushed closed by hand.




Flaps in open position



Flaps in closed position


Ensure that the flaps on the rear covers/doors are open. To open the covers, push the flap stopper until it contacts the cover/door.



If the switchgear is equipped with a plenum, ensure that the end flaps are closed position. Push the flaps closed by hand or, if too high to reach, using a pole.







End flaps in closed position

/ DANGER

Always use properly insulated tools and instruments during commissioning. Short circuit currents in low-voltage switchgear are typically very high. Depending on trip settings, high short circuit currents with long durations can occur.

↑ DANGER

Follow all codes and regulations related to servicing and installing electrical equipment. Failure to follow these instructions can result in short circuits and electrical arcing.

Check all of the following items related to the electrical connections and systems before energizing the switchgear.

- Ensure the electrical characteristics of the switchgear (e.g., rated voltage, short circuit current rating, grounding system, etc.) are compatible with the site conditions.
- Inspect the withdrawable breaker, following the instructions in the Inspect Units section of this manual.
- Inspect the unit contacts, following the instructions in the Inspect Units section of this manual.
- Using the proper tool for each connection, verify the tightness of all control and power terminals within the units.
- Insert all necessary fuses in the main and auxiliary circuits, verifying that they match the apparatus list and the circuit diagram.
- Set to its lowest value the main circuit protective device feeding the switchgear.
- Set the units' protective devices to the specified values.
- If present, verify that current transformers are properly connected or short- circuited.
- If an external control voltage is present, verify that it is OFF.

- Close and latch all doors.
- Test electrical insulation resistance. Conduct the test phase-to-phase, phase-to- ground, and when applicable, phase-to-neutral. Conduct the test with all unit disconnects in the OFF position. If the switchgear is equipped with potential transformers (for metering, etc.) remove the primary fuses prior to performing the test.

NOTE: When conducting an electrical insulation resistance test, isolate equipment sensitive to high test voltages – such as meters, solid state devices, motor winding heaters and capacitor units. Following successful completion of the test, reconnect all relays, operating voltages, circuits and fuses.

4.11.3. Testing and final inspection

MANGER

Disconnect the primary power source during testing.

Do not exceed the listed voltages for the voltage class of the equipment under testing. Disconnect the shuntconnected coils such as potential transformers.

Do not test solid-state sensors or relays with high voltage. Disconnect solid-state sensors and relays before applying voltage.

With the switchgear erected, assembled, and connected, do the following:

- 1. Remove packing and shipping materials.
- 2. Make sure that all internal parts are clean and dry. If moisture is present, dry with moving air and heat.
- 3. To check for damaged insulation, apply potential tests to the primary bus. Potential tests should be conducted phase-to-phase and phase-to-ground.

60 HZ. RMS WITHSTAND VOLTAGES (PRIMARY CIRCUITS) (1 MINUTE)			DC WITHSTAND*
Rated voltage 240 V, 480 V, 600 V	Factory test 2200 volts	Field test 1650 volts	Field test 2300 volts

*The column heading DC WITHSTAND is a reference for those using DC tests to verify the integrity of connected switchgear. It represents values believed to be appropriate and approximately equivalent to the corresponding power frequency withstand test values specified for each voltage class of switchgear. The presence of this column in no way implies any requirements for a DC withstand test on AC equipment. Also, it does not imply that a DC withstand test is an acceptable alternative to ANSI C37.20 for design, production or conformance tests. When making DC tests, raise the voltage to the test value in discrete steps and hold for one (1) minute.

4. With the main circuit dead, check the continuity of all circuits after installing the circuit breakers.
Energize the control source and operate the equipment.
Indicating instruments verify the continuity of current transformer circuits after energizing the main circuit.

Test the control circuit by following these steps.

⚠ DANGER

The breaker or cutout device of the local control power circuit must remain open when using a separate control power source.

The preferred method for checking the control circuit is to furnish a separate temporary source of control power of the required control voltage rating. The temporary source must have a properly coordinated backup protective device in the circuit. Set the device to clear faults that might occur. Initially all circuit breakers should be in the DISCONNECT position, and the main circuit de-energized. When AC control power is from control power transformers in the switchgear, remove all fuses in the transformer circuits. On electrically operated circuit breakers, discharge the springs; and the motor-disconnect-switch should be in the OFF position.

⚠ DANGER

OPEN the circuit breaker before racking.

- 5. Rack drawout breakers to the DISCONNECT position.
- Open all normal control power source disconnects, if supplied.
- Check each control switch or push-button.
 Make sure that they are in the OPEN position.
- 8. Connect a temporary control power source to the circuit load terminals in the switchgear. Energize the control circuit from the temporary control power source.
- Rack one circuit breaker into the TEST position. When the on-off switch is in the ON position, the charging of the closing springs of an electrically operated circuit breaker indicates connection to the control power.
- 10. Rack the remaining circuit breakers into the TEST position, one at a time.
- Test all electrically and manually operated breakers for closing and tripping, while they are in the TEST position.
 Use the optional test set available with the trip unit for testing solid state tripping.
- 12. De-energize the control circuit. If AC control power is from transformers in the switchgear, remove the temporary separate source of control power.

 Reinstall all fuses in the transformer circuit.
- 13. Set all relays, regulators, and other devices for the proper operation of loads. The factory does not set the relays.
- 14. Remove shorting screws from the terminal blocks in the current transformer circuits. See Figure 22 on page 33. Store screws in the tapped holes in the corners of the blocks.

NOTE: Verify the proper phasing of all main circuits according to diagram.

To open the short circuiting device:

- 1. Make sure that the current transformer secondary circuits are complete. Do not open circuit the secondary of an energized breaker.
- 2. a) Single Ratio Remove and store the shorting screw. Do not remove the ground screw.
- 2. b) Multi Ratio Remove the shorting screw.

 Insert shorting screw according to connection diagram. Do not remove the ground screw.

4.11.4. Energize the switchgear

After completing all of the previous steps related to installation and commissioning, energize the switchgear following these steps:

- 1. Apply power on the main incoming.
- 2. Verify that the incoming phase sequence is correct.
- 3. Switch on the main disconnect.
- 4. Check the phase sequence of each unit.
- 5. If existing, switch on any external power sources.

4.11.5. Energize the main bus

After completing the control circuit checkout, energize the switchgear main bus.

- 1. Energize the incoming bus to the switchgear main circuit breaker. Observe if operation of instruments and relays is correct.
- Energize the separate control power source, if furnished.
- 3. Energize the switchgear main bus by closing the main circuit breaker. Observe if operation of relays and instruments is correct.
- 4. If applicable, close feeders and tie circuit breakers.
- 5. Verify that all door panel screws are tight.
- 6. Rack all drawout-type circuit breakers to the CONNECTED position.

4.11.6. Final testing

Check that all instrumentation is working properly and the readings are within specifications or reasonable levels.

Check that all instantaneous protections that were turned down during previous testing are reset to their operating positions.

5. Component operation documents

Circuit breakers, relays and other components may have documentation that describes operating instructions that are not included in this manual. Review any documentation provided with those components prior to operating the switchgear.

Review the final project documents, manuals and other documents that accompanied your switchgear regarding operating procedures.

6. Maintenance

A well-planned and executed maintenance program will ensure uptime, extend equipment life and reduce overall costs. Routine maintenance is typically less costly than the emergency repairs and parts typically required in order to correct unexpected equipment failures.

For information on the mechanical and electrical life of components included in the switchgear, refer to the individual product documentation.

ABB offers a range of preventive maintenance services and programs. ABB can also provide ABB-trained expert technicians and give you fast access to OEM parts.

Contact your ABB representative for more information.

⚠ WARNING

Always use an appropriate voltage-sensing device to confirm that the power is off prior to installing or working with the switchgear.

⚠ DANGER

Maintenance work on this equipment should be performed only by qualified personnel wearing proper personal protective equipment.

6.1. Lockout/Tagout

The switchgear's breakers provide the ability to padlock it in the OFF position to prevent changing the status or position. Follow your local authority having jurisdiction and/or facility's procedures for properly locking out / tagging out equipment during maintenance.

6.2. Tighten unit control and power terminals

Recommended Interval: Perform annually or based on your local maintenance schedule. Using the proper tool for each connection, verify the tightness of all control and power terminals within the units. While tightening the terminals, be alert for any signs of heat damage, which indicates potential problems or loose connections. Heat generated by inadequate terminal torque is one of the leading causes of equipment malfunction and failure. When heat damage is observed, it typically indicates damage to the component. Repair or replacement may be required.

6.3. Remove/insert withdrawable breaker

For information on how to remove or insert a breaker, reference the specific instructions regarding breakers in document 1SDH001000R0002, Emax 2 UL Listed Breaker Installation, Service and Maintenance Instructions.

You may need to withdraw or remove a breaker for repair, update or testing. The switchgear allows breaker units to be easily replaced with breakers of the same rating.

You may continue to operate the switchgear with a unit removed. However, if the breaker will be removed for an extended period of time, it is advisable to replace it with another breaker or to temporarily cover the hole where it was with a blank cover.

While equipment is energized, always cover live parts to avoid unintentional contact.

6.4. Inspect units

Inspect each unit prior to first installation and periodically according to your local maintenance schedule.

Visually inspect the contacts for damage. Look for excessive wear or damage (e.g., worn silver or tin layer, signs of excessive heat, etc.) on all contact surfaces, including distribution bars, withdrawable breakers, power cable connection unit, etc.

See breaker user manual for proper inspection.

Using the proper tool for each connection, verify the tightness of all control and power terminals within the units.

Be sure that the contacts are properly greased. If they appear dry, use a brush to apply the appropriate amount of contact grease. Each unit will require approximately 3.5g of lubricant. Grease both the incoming and outgoing contacts.

∴ CAUTION

Never grease the contacts while the unit is energized.

If you detect contact damage, we recommend replacing the entire withdrawable unit chassis or the entire contact system. Contact your ABB representative for assistance with repair or replacement.

Maintenance

For equipment that is arc-resistant, ensure that flaps on the rear doors or covers are open and chimney flaps are closed. See Prepare to Energize Switchgear in this manual.

6.5. Inspect busbars

Changes in environmental conditions can cause the busbar mounting components to loosen over time.

During scheduled inspections, check the condition of the busbar system in locations where it is possible to access them. The components that can be removed to provide busbar access include the rear panels, side walls, segregation barrier between the cable compartment and main busbar compartment, and the roof plates.

6.6. Exterior metal damage repair

Any scratches or damage to the surface of the vertical sections must be repaired in order to avoid oxidation, which can reduce the life of the equipment.

6.7. Maintenance schedule

It is highly recommended that you establish a periodic maintenance program for the switchgear. The frequency of maintenance activities depends on equipment usage and the operating environment.

Perform a visual inspection, front and rear, to see that there is no evidence of loose parts, warping or undue vibration. Take steps to remedy any deficiencies of this nature that may appear. Keep the assembly dry. Cover to prevent moisture from dripping on the equipment. Do not block vents.

↑ DANGER

There are hazards of electrical shocks and/or burns whenever working in or around electrical equipment. Turn off power ahead of the switchgear before performing any maintenance operations.

Check incoming line terminals to verify that the equipment is de- energized. Check the out-going terminals to make sure that no feedback conditions exist.

/ DANGER

Limit the use of solvents to removing grease and contamination from primary conductors, insulation, and from unpainted metallic surfaces. Do not use alcohol or Freon. Use OSHA-approved solvents in accordance with local regulations. Use a non- flammable solvent with a threshold limit of 300 PPM or higher. Use solvents in well-ventilated areas.

6.7.1. Semi-annual inspection

At least twice yearly, perform a thorough inspection of the switchgear. Emphasize the following checks:

- Perform an overall visual inspection.
- Check all indicators, meters and instruments for proper operation.
- Make sure all bolted panels are secure.
- Verify operation of heaters and thermostats, if used.
- Check for undue noise or vibration that might loosen bolted connections.
- Look for evidence of moisture in the switchgear.

6.7.2. Annual inspection

- Bolted connections should be tight. Discoloration, excessive corrosion, embrittled or discolored insulation may indicate an overheated connection.
- Inspect all cables for tight connections and ample support.
- Inspect control wiring for signs of wear and damage.
 Replace wires wherever doubtful.
- Examine resistors and other devices prone to overheating.
- Open all hinged panels and remove all bolted panels.
- Clean insulation thoroughly.
- Withdraw and clean all drawout components.
- Clean the stationary portion of the switchgear by wiping with a clean cloth.
 - Compressed dry-air is useful with inaccessible areas.
- Remove covers of all panel devices where possible. Check wiring for secure connections. Clean contacts on relays and switches wherever necessary.
 Replace covers.
- Inspect the gearing of the overhead lifting device when used. Keep well lubricated. In very dirty or gritty conditions, use a dry lubricant.
- Follow the recommendations of any individual device instructions furnished for maintenance of the device.

6.7.3. 18-to-36 month inspection

Perform the following at 18-to-36 month intervals or sooner if required by local conditions or regulations.

- Clean the circuit breaker stationary primary contacts.
 See document 1SDH001000R0002 Emax 2 UL Listed Breaker Installation, Service and Maintenance Instructions. Inspect for evidence of excessive heat, arcing, or corrosion.
- Inspect secondary wiring bundles for signs of discoloration because of heat or chafing. Check for cracked or embrittled insulation. Replace wire whenever doubtful.
- Inspect primary insulation system for accumulated contamination. Clean insulation with a dry cloth, dry-air, vacuum or, if necessary, with an OSHA- approved solvent.
- Check the calibration of protective relays approximately every two years.

6.7.4. 10-year maximum inspection

- Disassemble, inspect, clean, lubricate, adjust, and calibrate circuit breaker mechanisms.
- Tighten all secondary control wire connections. Check for loose lug crimps and broken wire strands.

6.7.5. Eslok® fasteners

The Eslok® fasteners provided with the switchgear include an integrated, dry, polyamide- based, securing- varnish, thread-coating that ensures they will remain at the torqued valued. Any other polyamide product of same quality characteristic can be used. Do not use additional locking fluid.

Bus connections are maintenance-free and do not require routine inspections. The fasteners can be re-torqued as many as 10 times and still offering sufficient thread locking effect.

. ₩ARNING

Defects or deficiencies in any electrical equipment should be remedied immediately. If immediate repair is not possible, lockout/tagout the equipment until after repairs have been made or the components replaced.

6.8. Arc flash protection

The National Fire Protection Association (NFPA 70E) flash protection marking requirement¹ applies to personnel who install, maintain, or repair electrical systems.

(1 Standard for Electrical Safety Requirements for Employee Workplaces.)

NEC Article 110.16 Flash Protection: Switchboards,

panelboards, industrial control panels, and switchgears that are in other than dwelling occupancies and are likely to require examination, adjustment, servicing, or maintenance while energized shall be field marked to warn qualified persons of potential electric arc flash hazards. The marking shall be located so as to be clearly visible to qualified persons before examination, adjustment, servicing, or maintenance of the equipment.

FPN No. 1: NFPA 70E-2000, Electrical Safety Requirements for Employee Workplaces, provides assistance in determining severity of potential exposure, planning safe work practices, and selecting personal protective equipment.

FPN No. 2: ANSI Z535.4-1998, Product Safety Signs and Labels, provides guidelines for the design of safety signs and labels for application to products.

The flash criteria are regularly updated as the technology changes. The latest editions of the NEC and NFPA 70E should be used in establishing potential electric arc flash hazards and arc flash marking.

The required flash protection marking is to be applied by the switchgear end-user for each installation. It is similar to other NEC marking requirements such as voltage, voltage hazard labels, and circuits. Flash protection markings, however, must be based on application information and calculations from the installation site. This information helps to identify the presence of a potential flash hazard and provides guidance in determining necessary personal protective equipment (PPE) to be worn by installation and maintenance personnel.

You must establish field marking requirements based upon:

- Level of onsite personnel safety training.
- Level of required clothing and required PPE.
- Consistency for the level of marking for various equipment types, for example: switchboards, panelboards, industrial control panels and MCCs.
- Available flash energy on each piece of equipment as determined by available fault current and arc flash duration based on the type and degree of short circuit protection equipment.

7. Additional resources

In addition to this manual, refer to the job-specific literature, manuals and drawings that will provide useful information as you install, operate and maintain the switchgear.

8. Torque fasteners

⚠ WARNING

Heat generated by improper terminal torque is a leading cause of equipment failure. Torque terminals to the values shown in the following table.

The Eslok® fasteners provided include an integrated thread coating that ensures they will remain at the torqued valued.

Once torqued to the proper value, draw a line across the fastener head and the surrounding metal surface so you can visually check whether the fastener has changed position and may require attention. Bolts torqued at the factory will be marked in the same way.

The following torque tables apply to horizontal and vertical busbar screw connections, electrical component screw connections, terminal connections and structural components of the MNS-SG system.


NOTE: For equipment connections and mountings, see the manufacturers' technical data sheets.

Torque fasteners


8.1. Torque table

Torque fasteners as specified below when assembling the switchgear. The Eslok® fasteners provided are maintenance free. See Eslok® fasteners in this manual for more information.

MNS-SG torque table						
UNION DESCRIPTION	SCREW	Metric (Nm)	English (ft/lbs)			
Splice kit connections						
Copper-copper, other connectors (splice kit)	M12	70	52			
Breaker connections						
Breaker stabs	M12	70	52			
Breaker grounding stab	M12	70	52			
Busbar ground connections						
Copper-copper for grounding	M12	60	44			
Copper-copper for grounding	M10	50	37			
Copper support for grounding	M10	40	30			
Copper support for grounding	М8	30	22			
Insulating barrier and support connections						
GPO3 glastic inserts	M6	20	15			
GPO3 glastic-Iron	М6	20	15			
GPO3 glastic-Iron	М8	25	18			
GPO3 glastic-brass	М8	25	18			
GPO3 glastic-copper	M12	50	37			
Exterior metal panels and enclosures						
Iron-iron	M8	20	15			
Iron-iron	M6 Self- tapping	4.7	35			
Insulators-iron	M12	60	44			
Insulators-copper	M12	50	37			




Busbar torque values (copper-to-copper)




Ground bars

Initial tightening torque values



Main busbar to insulation supports torque

Frame and enclosure fasteners torque



Main busbar coper-to-coper torque

9. Disclaimer of warranties and limitation of liability

There are no understandings, agreements, representations or warranties, expressed or implied, including warranties of merchantability or fitness for a particular purpose, other than those specifically set out by an existing contract between the parties.

Any such contract states the entire obligation of seller. The contents of this document shall not become part of or modify any prior or existing agreement, commitment or relationship.

The information, recommendations, descriptions and safety notations in this document are based on ABB experience and judgment with respect to MNS-SG switchgear. This information should not be considered to be all inclusive or covering all contingencies.

No warranties, expressed or implied, including warranties of fitness for a particular purpose or merchantability, or warranties of fitness for a particular purpose or merchantability, or warranties arising from course of dealing or usage of trade are made regarding the information, recommendations, descriptions and safety notations contained herein.

In no event will ABB be responsible to the user in contract, in tort (including negligence), strict liability or otherwise for any special, indirect, incidental or consequential damage or loss whatsoever including but not limited to damage to or loss of use of equipment, plant or power system, cost of capital, loss of profits or revenue, cost of replacement power, additional expenses in the use of existing power facilities, or claims against the user by its customers resulting from the use of information, recommendations, descriptions and safety notations contained herein.



USA

ABB, Inc. Distribution Solutions ANSI 3700 W Sam Houston Parkway S Houston, TX 77042

Tel.: 1713 587-8000 Toll Free: 1888 385-1221

Canada

ABB, Inc.
Distribution Solutions ANSI
800 Hymus Boulevard
St-Laurent, Quebec H4S-0B5
Tel.: 1 514 856-6266

Toll Free: 1 800 905-0222

México

ABB México, S.A. de CV.
Distribution Solutions ANSI
Av. Central No. 405, Parque WTC Industrial
C.P. 78395, San Luis Potosí, SLP

Tel.: +52 444 870 8000

While all care has been taken to ensure that the information contained in this publication is correct, no responsibility can be accepted for any inaccuracy. The Company reserves the right to alter or modify the information contained herein at any time in the light of technical or other developments.

Technical specifications are valid under normal operating conditions only. The Company does not accept any responsibility for any misuse of the product and cannot be held liable for indirect or consequential damages.

©Copyright 2019 ABB Inc. All rights reserved