

User's Manual

ACQ550-CC Packaged Drive with Bypass Supplement for ACQ550-U1 Drives User's Manual



ACQ550 Drive Manuals

GENERAL MANUALS

ACQ550-U1 Drives User's Manual (1...550 HP)

- Safety
- Installation
- Start-Up
- Embedded Fieldbus
- Fieldbus Adapter
- Diagnostics
- Maintenance
- Technical Data

ACQ550-PC/PD Drive with Disconnect Supplement to ACQ550-U1 User's Manual

- Safety
- Installation
- Start-Up
- Technical Data

ACQ550-CC Packaged Drive with Bypass Supplement for ACQ550-U1 User's Manual

- Safety
- Installation
- Start-Up
- Maintenance
- Technical Data

Safety



WARNING! The ACQ550 adjustable speed AC drive with Bypass should **ONLY** be installed by a qualified electrician.



WARNING! Even when the motor is stopped, dangerous voltage is present at the Power Circuit terminals U1, V1, W1 and U2, V2, W2 and, depending on the frame size, UDC+ and UDC-, or BRK+ and BRK-.



WARNING! Dangerous voltage is present when input power is connected. After disconnecting the supply, wait at least 5 minutes (to let the intermediate circuit capacitors discharge) before removing the cover.



WARNING! Even when power is removed from the input terminals of the ACQ550, there may be dangerous voltage (from external sources) on the terminals of the relay outputs.



WARNING! When the control terminals of two or more drive units are connected in parallel, the auxiliary voltage for these control connections must be taken from a single source which can either be one of the units or an external supply.



WARNING! The ACQ550 will start up automatically after an input voltage interruption if the external run command is on.



WARNING! When the ACQ550 with Bypass is connected to the line power, the Motor Terminals T1, T2, and T3 are live even if the motor is not running. Do not make any connections when the ACQ550 with Bypass is connected to the line. Disconnect and lock out power to the drive before servicing the drive. Failure to disconnect power may cause serious injury or death.

Note! For more technical information, contact the factory or your local ABB sales representative.

Use of Warnings and Notes

There are two types of safety instructions throughout this manual:

- Notes draw attention to a particular condition or fact, or give information on a subject.
- Warnings caution you about conditions which can result in serious injury or death and/or damage to the equipment. They also tell you how to avoid the danger. The warning symbols are used as follows:



Dangerous voltage warning warns of high voltage which can cause physical injury and/or damage to the equipment.



General warning warns about conditions, other than those caused by electricity, which can result in physical injury and/or damage to the equipment.

Table of Contents

Safety

 Use of Warnings and Notes 2

Table of Contents

Installation

 Application 4

 Bypass Features and Functions 4

 Installation Flow Chart 6

 Preparing for Installation 7

 Preparing for Installation 8

 Installing the Drive 9

 Installing the Wiring 10

Maintenance

 Maintenance Interval 17

Technical Data

 Ratings 18

 Input Power Connections 18

 Power Connection Terminals 22

 Motor Connections 25

 Motor Connection Specifications – R8 26

 Cooling – R8 26

 Dimensions and Weights 27

 Applicable Standards 32

Index

Installation

Study these installation instructions carefully before proceeding. **Failure to observe the warnings and instructions may cause a malfunction or personal hazard.**



WARNING! Before you begin read “Safety” on page 1.



WARNING! When the ACQ550 with Bypass is connected to the line power, the Motor Terminals T1, T2, and T3 are live even if the motor is not running. Do not make any connections when the ACQ550 with Bypass is connected to the line. Disconnect and lock out power to the drive before servicing the drive. Failure to disconnect power may cause serious injury or death.

Application


This manual is a supplement to the ACQ550-U1 User's Manual and documents Bypass configurations.

Bypass Features and Functions


The ACQ550 with Bypass is an ACQ550 AC adjustable frequency drive in an integrated UL Type/NEMA 1, UL Type/NEMA 12, or UL Type/NEMA 3R package with a bypass function configured entirely of standard industrial control components. The ACQ550 with Bypass provides:

- Main circuit breaker with door mounted control lever. The lever can be padlocked in the OFF position (padlock not supplied).
- Electrically interlocked Bypass and drive output contactors
- Class 20 motor overload protection.
- ACQ-CP-AQ drive control panel
 - Cover mounted - UL Type/NEMA 1 and 12 enclosures
 - Drive mounted - UL Type/NEMA 3R enclosures
- Bypass cover mounted control
 - Drive-Off-Bypass selector switch
- Provisions for external control connections.
- Optional drive service switch (drive input disconnect), the functional equivalent of a three-contactor bypass arrangement.


The following shows the front view of a typical ACQ550 Bypass wall mount configuration, and identifies the major components.



The following shows the front view of a typical ACQ550 Bypass floor mount configuration, and identifies the major components.



The following is a typical power diagram.



Installation Flow Chart

The installation of Bypass Configurations for ACQ550 drives follows the outline below. The steps must be carried out in the order shown. At the right of each step are references to the detailed information needed for the correct installation of the unit.

Task	Reference in ACQ550-U1 User's Manual "Installation" section	Reference in this Manual
PREPARE for installation	"Preparing for Installation"	Floor Mounted: "Lifting the Drive" on page 7. "Drive Identification" on page 8. "Suitable Mounting Location (Supplement to ACQ550-U1 User's Manual)" on page 8.
PREPARE the Mounting Location	"Prepare the Mounting Location"	"Prepare the Mounting Location – Floor Mounted Enclosures" on page 9. "Dimensions and Weights" on page 27.
REMOVE the front cover	"Remove Front Cover"	--
MOUNT the drive	"Mount the Drive"	--
INSTALL wiring	"Wiring Overview" and "Install the Wiring"	"Installing the Wiring" starting on page 10.
CHECK installation	"Check Installation"	--
RE-INSTALL the cover	"Re-install Cover"	--
APPLY power	"Apply Power"	--
START-UP	"Start-Up"	--

Preparing for Installation

Lifting the Drive

Floor Mounting



Warning! Handle and ship floor mounted enclosures only in the upright position. These units are not designed to be laid on their backs.

1. Use a pallet truck to move the package/enclosure to the installation site.
2. Remove any bolts that secure the cabinet to the shipping pallet.



PC00005



Warning! Use the lifting lugs/bars at the top of the unit to lift floor mounted drives.

3. Use a hoist to lift the drive. (Do not place drive in final position until mounting site is prepared.)



PC00003

Preparing for Installation

Drive Identification

To identify the type of device you are installing, refer to the type code number on the device identification label.

- Wall mounting base drives – label attached on the side surface of the heat sink.
- Packaged drive with screw cover – label attached to outside surface on the left side of the enclosure.
- Enclosure with hinged cover/door – label on inside surface of the cover/door.

Type Code Number

Use the following to interpret the type code found on the identification label.

	ACQ550-U1-015A-4 +...+...
AC Drive = 550 Product Series	
Construction	
U1 = Base Drive	
CC = Bypass with circuit breaker	
PC = Drive with circuit breaker	
PD = Drive with disconnect switch	
Output current rating (See ratings chart for details)	
Voltage rating	
2 = 208...240 VAC	
4 = 380...480 VAC	
6 = 500...600 VAC	
Enclosure protection class	
No specification = UL Type/NEMA 1	
+B055 = UL Type/NEMA 12	
+B058 = UL Type/NEMA 3R	
Power options	
+F267 = Service switch	
Input/Output option modules	
+L511 = Relay output extension	
+L512 = 115/230 V digital input interface	
Fieldbus adaptors	
+K451 = DeviceNet Adapter	
+K457 = CANopen Adapter	
+K462 = ControlNet Adapter	
+K466 = Ethernet Adapter	
+K467 = PROFINET IO Adapter	
Miscellaneous Options	
+P191 = Bypass Cover Control Option	

Suitable Mounting Location (Supplement to ACQ550-U1 User's Manual)

For selecting a suitable mounting location for Drive with Bypass units, refer to:

- Preparing for installation in the ACQ550-U1 User's Manual, and
- The Technical Data section of this manual for information on dimensions and weights.

Installing the Drive



Warning! Metal shavings or debris in the enclosure can damage electrical equipment and create a hazardous condition. Where parts, such as conduit plates require cutting or drilling, first remove the part. If that is not practical, cover nearby electrical components to protect them from all shavings or debris.

Prepare the Mounting Location – Floor Mounted Enclosures

The ACQ550 should only be mounted where all of the requirements defined in “Preparing for Installation” are met.

Installing the Wiring



WARNING!

- **Metal shavings or debris in the enclosure can damage electrical equipment and create a hazardous condition. Where parts, such as conduit plates require cutting or drilling, first remove the part. If that is not practical, cover nearby electrical components to protect them from all shavings or debris.**
 - **Do not connect or disconnect input or output power wiring, or control wires, when power is applied.**
 - **Never connect line voltage to drive output Terminals T1, T2, and T3.**
 - **Do not make any voltage tolerance tests (Hi Pot or Megger) on any part of the unit. Disconnect motor wires before taking any measurements in the motor or motor wires.**
 - **Make sure that power factor correction capacitors are not connected between the drive and the motor.**
-

Wiring Requirements


Refer to the “Wiring Requirements” Section in the ACQ550-U1 User’s Manual. The requirements apply to all ACQ550 drives. In particular:

- Use separate, metal conduit runs for the following different classes of wiring:
 - Input power wiring.
 - Motor wiring.
 - Control/communications wiring.
- Properly and individually ground the drive, the motor and cable shields.

Wiring Overview

Connection Diagrams —

ACQ550-CC units are configured for wiring access from the top or the bottom. The following figures show the wiring connection points. Refer to the ACQ550-U1 User's Manual for control connections to the drive.




Install the Line Input Wiring


Line Input Connections – Bypass Configurations

Connect input power to the terminals of the circuit breaker. Connect the equipment grounding conductor to the ground lug at the top of the enclosure. The figures below show the connection points for typical configurations. Units are configured for wiring access from the top or the bottom.

Typical Wall Mount



Typical Floor Mount




WARNING! Check the motor and motor wiring insulation before connecting the ACQ550 to line power. Follow the procedure in the ACQ550-U1 User's Manual. Before proceeding with the insulation resistance measurements, check that the ACQ550 is disconnected from incoming line power. Failure to disconnect line power could result in death or serious injury.

Install the Motor Wiring


Motor Connections – Bypass Configurations

Connect the motor cables to the motor overload relay output terminals; see the figures below. The motor grounding conductor can be connected to the ground lug near the motor overload relay.

Typical Wall Mount



Typical Floor Mount



Install the Control Wiring (Supplement to ACQ550-U1 User's Manual)

Connect control wiring to the terminal block 1TB located on the back panel toward the bottom of the enclosure and terminal block x1 inside the drive.


Control Wiring

The control wiring includes connections to an analog speed command signal and start/stop relay contact for controlling the drive in the AUTO mode. There may also be connections to external run enable interlock contacts and a connection from the Motor Run contact to an external status indicating circuit.

Wiring Practices

The external control wiring must not be run in the same conduit or raceway with any high power wiring. The external speed reference signal must be wired using a shielded, twisted pair cable. The shield connection must be terminated at the ground terminal provided (x1:3). The other end of the shield should be cut and taped back at the signal source.

Terminal Block 1TB



Connection Points

Basic control connections are made to 1TB, which is a din-rail terminal block on the back panel at the bottom of the enclosure. 1TB includes screw clamp terminals rated for #22-10 AWG stranded or solid wire. Recommended tightening torque is 4.4 - 7.1 in-lbs.

Terminals 1TB:7 and 1TB:8 are 120 VAC control circuit terminals connected to 120 VAC control power supplied by the control circuit transformer provided. Terminals 1TB:9 and 1TB:10 are powered at 24VDC to accept an external contact closure to start the drive. Terminals 1TB:13 and 1TB:14 are connected to un-powered relay contacts provided for use with externally powered customer control circuits.

Additional Connections

The low voltage speed reference signal input, analog outputs, additional relay outputs, and additional digital input connections are available on Terminal Block X1 inside the ACQ550. Note that the Bypass control circuitry uses inputs and outputs DI1, DI4 and R02. These inputs are not available for any other purpose and must not be reconfigured. Output R02 is wired to the terminal block, 1TB. AI1, AI2, DI3, DI5, DI6, RO1, and R03 are available for use. Refer to the *ACQ550-U1 User's Manual* for information about control connections on Terminal Block X1. When making connections to Terminal Block X1, be careful not to disturb the factory installed wiring between X1 and the Bypass control circuitry.

Analog Input

The external "Auto" speed reference is to be connected to ACQ550 analog input AI1. The analog input can accept a voltage signal (0 – 10 VDC) or a current signal (0 – 20 mA). Jumper J1, located on the Control Board in the ACQ550, determines the signal type. J1 can be set in either the voltage or current position according to the type of external signal that will be connected. Refer to the *ACQ550-U1 User's Manual*.

Run Enable Interlocks

Run Enable interlocks are normally closed un-powered contacts connected in series between 1TB:7 and 1TB:8. When any of these contacts opens, the motor will stop, whether in DRIVE or BYPASS. The unit is shipped with a jumper installed from 1TB:7 to 1TB:8. This jumper must be removed before connecting external contacts.

Auto Start Contact

To start the ACQ550 by means of an external un-powered contact (maintained), connect the contact to 1TB:9 and 1TB:10. Closing this contact will start the motor when the drive is in the AUTO mode.

Relay Contact Output

A “Motor Running” relay contact output is provided at terminals 1TB:13 and 1TB:14 for external indication of the motor status. The output consists of a normally open auxiliary contact on the bypass contactor and a normally open “Drive Running” contact from the ACQ550. The two contacts are connected in parallel so that a contact closure is provided whenever the motor is running.

Refer to “Control Connections” in the *ACQ550-U1 User’s Manual* Technical Data where relay contacts are used to control inductive loads.

Motor Overload Relay

The ACQ550 with Bypass includes a motor overload relay to provide thermal motor protection. It is connected in both drive and bypass modes of operation. For motor full load currents up to 80 amperes, the Motor Overload Relay is an adjustable trip, bimetallic overload relay with a class 20 trip characteristic. Above 80 amperes, the Motor Overload Relay is an adjustable trip, electronic overload relay with selectable class 10, 20 or 30 trip characteristic.

Suggested Settings

Current

Set the current adjustment to the value of the full load current shown on the motor nameplate.

Auto/Man

It is recommended the overload relay be set to the Manual Reset mode of operation. In the Auto Reset mode, the Overload Relay contacts re-close automatically when the bi-metals of bi-metallic versions cool or when the timer function within the electronic versions times out. If power is applied and the switches and contacts in the control circuit are commanding the motor to run, the motor will start as soon as the overload relay resets.

Class

The class 20 setting on the electronic overload relays would be the appropriate choice for the majority of the motors used in North America.

Resetting the Overload Relay

In the event an overload relay set in the Manual Reset mode trips, it is necessary to open the door of the enclosure and push the Reset button on the front of the overload relay to reset it.



WARNING! If power is applied and the switches and contacts in the control circuit are commanding the motor to run, the motor will start as soon as the overload relay resets. Use caution when manually resetting the overload relay to make sure it is safe to start the motor.

Maintenance

Maintenance Interval

If installed in an appropriate environment, the drive requires very little maintenance. The table lists the routine maintenance intervals recommended by ABB. The information shown below is supplemental and in addition to that shown in the ACQ550-U1 User's Manual.

Maintenance	Configuration	Interval
Check/replace enclosure inlet air filter	UL Type/NEMA 12 and 3R enclosures	Check every 3 months. Replace as needed.
Check/replace enclosure exhaust air filter	UL Type/NEMA 12 and 3R enclosures	Check every 6 months. Replace as needed.
Replace enclosure vent fan(s)	UL Type/NEMA 12 and 3R enclosures	Every three years.
Replace enclosure air circulation fan	Frames R4 through R6 in UL Type/NEMA 1 enclosures	Every three years.

Technical Data

Ratings

Note! The ratings listed below are exceptions to the ratings listed in the ACQ550-U1 User's Manual.

Ratings, 380...480 Volt Drives

Type Code	Valid up to 40°C (104 °F)				Frame Size
	Normal Use		Heavy-Duty Use		
ACQ550-Cx- see below	I_{2N} A	P_N HP	I_{2hd} A	P_{hd} HP	
-316A-4	316	250	240	200	R8
-368A-4	368	300	302	250	R8
-414A-4	414	350	368	300	R8
-486A-4	486	400	414	350	R8

Input Power Connections

Branch Circuit Protection

Input power is connected to the ACQ550 with Bypass through a circuit breaker that provides the branch circuit short circuit and ground fault protection for the motor operating in the bypass mode.

Fuses

Drive input fuses are provided to disconnect the drive from power in the event that a component fails in the drive's input power circuitry. The drive's electronic protection circuitry is designed to clear drive output short circuits and ground faults without blowing the drive input fuses. Drive input fuses are shown in the following tables.

Note! Although fuses listed are similar in functional characteristics to fuses listed in the ACQ550-U1 User's Manual, physical characteristics may differ. Fuses from other manufacturers can be used if they meet the functional characteristics of those shown in the tables.

208...240 Volt Fuses

208/240 Volt		Frame Size	Drive Input Fuse Ratings	
HP	Identification		Amps (600V)	Bussmann Type
1	ACQ550-CC-04A6-2	R1	15	KTK-R-15
1.5	ACQ550-CC-06A6-2	R1	15	KTK-R-15
2	ACQ550-CC-07A5-2	R1	15	KTK-R-15
3	ACQ550-CC-012A-2	R1	15	KTK-R-15
5	ACQ550-CC-017A-2	R1	30	KTK-R-30
7.5	ACQ550-CC-024A-2	R2	30	KTK-R-30
10	ACQ550-CC-031A-2	R2	50	JJS-50
15	ACQ550-CC-046A-2	R3	80	JJS-80
20	ACQ550-CC-059A-2	R3	80	JJS-80
25	ACQ550-CC-075A-2	R4	100	JJS-100
30	ACQ550-CC-088A-2	R4	110	JJS-110
40	ACQ550-CC-114A-2	R4	150	JJS-150
50	ACQ550-CC-143A-2	R6	200	JJS-200
60	ACQ550-CC-178A-2	R6	250	JJS-250
75	ACQ550-CC-221A-2	R6	300	JJS-300
100	ACQ550-CC-248A-2	R6	350	JJS-350

380...480 Volt Fuses

380...480 Volt		Frame Size	Drive Input Fuse Ratings	
HP	Identification		Amps (600V)	Bussmann Type
1/1.5	ACQ550-CC-03A3-4	R1	15	KTK-R-15
2	ACQ550-CC-04A1-4	R1	15	KTK-R-15
3	ACQ550-CC-06A9-4	R1	15	KTK-R-15
5	ACQ550-CC-08A8-4	R1	15	KTK-R-15
7.5	ACQ550-CC-012A-4	R1	15	KTK-R-15
10	ACQ550-CC-015A-4	R2	30	KTK-R-30
15	ACQ550-CC-023A-4	R2	30	KTK-R-30
20	ACQ550-CC-031A-4	R3	50	JJS-50
25	ACQ550-CC-038A-4	R3	50	JJS-50
30	ACQ550-CC-045A-4	R3	100	JJS-100
40	ACQ550-CC-059A-4	R4	100	JJS-100
50	ACQ550-CC-072A-4	R4	100	JJS-100
60	ACQ550-CC-078A-4	R4	100	JJS-100
75	ACQ550-CC-097A-4	R4	125	JJS-125
100	ACQ550-CC-125A-4	R5	175	JJS-175
125	ACQ550-CC-157A-4	R6	200	JJS-200
150	ACQ550-CC-180A-4	R6	250	JJS-250
200	ACQ550-CC-246A-4	R6	400	JJS-400
250	ACQ550-CC-316A-4	R8	400	JJS-400
300	ACQ550-CC-368A-4	R8	400	JJS-400
350	ACQ550-CC-414A-4	R8	600	JJS-600
400	ACQ550-CC-486A-4	R8	600	JJS-600

Fuses, 500...600 Volt, Fuses

500...600 Volt		Frame Size	Drive Input Fuse Ratings	
HP	Identification		Amps (600V)	Bussmann Type
2	ACQ550-CC-02A7-6	R2	15	KTK-R-15
3	ACQ550-CC-03A9-6	R2	15	KTK-R-15
5	ACQ550-CC-06A1-6	R2	15	KTK-R-15
7.5	ACQ550-CC-09A0-6	R2	15	KTK-R-15
10	ACQ550-CC-011A-6	R2	30	KTK-R-30
15	ACQ550-CC-017A-6	R2	30	KTK-R-30
20	ACQ550-CC-022A-6	R3	50	JJS-50
25	ACQ550-CC-027A-6	R3	50	JJS-50
30	ACQ550-CC-032A-6	R4	100	JJS-100
40	ACQ550-CC-041A-6	R4	100	JJS-100
50	ACQ550-CC-052A-6	R4	100	JJS-100
60	ACQ550-CC-062A-6	R4	100	JJS-100
75	ACQ550-CC-077A-6	R6	100	JJS-100
100	ACQ550-CC-099A-6	R6	150	JJS-150
125	ACQ550-CC-125A-6	R6	175	JJS-175
150	ACQ550-CC-144A-6	R6	200	JJS-200

Power Connection Terminals

The following tables show maximum wire size and required tightening torque for incoming power, motor, and grounding terminals.

208...240 Volt, Terminals

208...240 Volt, Power Connection Terminal Data					
208/240 Volt		Base Drive Frame Size	Power Wiring Size		
HP	Type Code		Circuit Breaker	Overload Relay	Ground Lugs
1	ACQ550-CC-04A6-2	R1	#10 62 in-lbs	#10 22 in-lbs	#2 15 in-lbs (#14 - #12) 40 in-lbs (#10 - #6) 50 in-lbs (#4 - #2)
1.5	ACQ550-CC-06A6-2	R1			
2	ACQ550-CC-07A5-2	R1			
3	ACQ550-CC-012A-2	R1			
5	ACQ550-CC-017A-2	R1			
7.5	ACQ550-CC-024A-2	R2	#6 62 in-lbs	#8 22 in-lbs	
10	ACQ550-CC-031A-2	R2			
15	ACQ550-CC-046A-2	R3	#3 62 in-lbs	#3 40 in-lbs	
20	ACQ550-CC-059A-2	R3			
25	ACQ550-CC-075A-2	R4	#1 62 in-lbs	#1 80 in-lbs	
30	ACQ550-CC-088A-2	R4	#2/0 195 in-lbs	#6-2/0 88 in-lbs	
40	ACQ550-CC-114A-2	R4			
50	ACQ550-CC-143A-2	R6	300 MCM 274 in-lbs	250 MCM 160 in-lbs	#2/0 275 in-lbs (#6 - #2) 375 in-lbs (#1 - #2/0)
60	ACQ550-CC-178A-2	R6			
75	ACQ550-CC-221A-2	R6	2 x 250 MCM 275 in-lbs	500 MCM 247 in-lbs	350 MCM 100 in-lbs
100	ACQ550-CC-248A-2	R6			

340...480 Volt, Terminals

340...480 Volt, Power Connection Terminal Data						
340...480 Volt		Base Drive Frame Size	Power Wiring Size			
HP	Type Code		Circuit Breaker	Overload Relay	Ground Lugs	
1/1.5	ACQ550-CC-03A3-4	R1	#10 62 in-lbs	#10 22 in-lbs	#2 15 in-lbs (#14 - #12) 40 in-lbs (#10 - #6) 50 in-lbs (#4 - #2)	
2	ACQ550-CC-04A1-4	R1				
3	ACQ550-CC-06A9-4	R1				
5	ACQ550-CC-08A8-4	R1				
7.5	ACQ550-CC-012A-4	R1				
10	ACQ550-CC-015A-4	R2				
15	ACQ550-CC-023A-4	R2				
20	ACQ550-CC-031A-4	R3	#8 62 in-lbs	#8 22 in-lbs		
25	ACQ550-CC-038A-4	R3		#3 40 in-lbs		
30	ACQ550-CC-045A-4	R3	#4 62 in-lbs			
40	ACQ550-CC-059A-4	R4				
50	ACQ550-CC-072A-4	R4	#3 62 in-lbs	#1 80 in-lbs		
60	ACQ550-CC-078A-4	R4				
75	ACQ550-CC-097A-4	R4	#2/0 195 in-lbs	#6-2/0 88 in-lbs		
100	ACQ550-CC-125A-4	R5				
125	ACQ550-CC-157A-4	R6	2 x 250 MCM 275 in-lbs	300 MCM 274 in-lbs	#2/0 275 in-lbs (#6 - #2)	
150	ACQ550-CC-180A-4	R6		2 x 250 MCM 275 in-lbs		
200	ACQ550-CC-246A-4	R6			2 x 250 MCM 275 in-lbs	350 MCM 100 in-lbs
250	ACQ550-CC-316A-4	R8				
300	ACQ550-CC-368A-4	R8				
350	ACQ550-CC-414A-4	R8			2 x 500 MCM 375 in-lbs	
400	ACQ550-CC-486A-4	R8				

500...600 Volt, Terminals

500...600 Volt, Power Connection Terminal Data									
500...600 Volt		Base Drive Frame Size	Power Wiring Size						
HP	Type Code		Circuit Breaker	Overload Relay	Ground Lugs				
2	ACQ550-CC-02A7-6	R2	#10 62 in-lbs	#10 22 in-lbs	#2 15 in-lbs (#14 - #12) 40 in-lbs (#10 - #6) 50 in-lbs (#4 - #2)				
3	ACQ550-CC-03A9-6	R2							
5	ACQ550-CC-06A1-6	R2							
7.5	ACQ550-CC-09A0-6	R2							
10	ACQ550-CC-011A-6	R2							
15	ACQ550-CC-017A-6	R2							
20	ACQ550-CC-022A-6	R3	#8 62 in-lbs	#8 22 in-lbs		#2 15 in-lbs (#14 - #12) 40 in-lbs (#10 - #6) 50 in-lbs (#4 - #2)			
25	ACQ550-CC-027A-6	R3							
30	ACQ550-CC-032A-6	R4	#3 62 in-lbs	#4 40 in-lbs			#2 15 in-lbs (#14 - #12) 40 in-lbs (#10 - #6) 50 in-lbs (#4 - #2)		
40	ACQ550-CC-041A-6	R4							
50	ACQ550-CC-052A-6	R4							
60	ACQ550-CC-062A-6	R4		#6-2/0 88 in-lbs				#2 15 in-lbs (#14 - #12) 40 in-lbs (#10 - #6) 50 in-lbs (#4 - #2)	
75	ACQ550-CC-077A-6	R6							
100	ACQ550-CC-099A-6	R6	#2/0 195 in-lbs	#2 15 in-lbs (#14 - #12) 40 in-lbs (#10 - #6) 50 in-lbs (#4 - #2)					
125	ACQ550-CC-125A-6	R6							
150	ACQ550-CC-144A-6	R6	250 MCM 275 in-lbs		250 MCM 275 in-lbs				275 in-lbs (#6 - #2) 375 in-lbs (#1 - #2/0)

Motor Connections

Motor Terminals

See preceding “Power Connection Terminal Data” tables.

Bypass Contactors

The bypass circuit in the ACQ550 Bypass includes two contactors. One contactor is the bypass contactor (2M) that can be used to connect the motor directly to the incoming power line in the event that the ACQ550 is out of service. The other contactor is the ACQ550 output contactor (1M) that disconnects the ACQ550 from the motor when the motor is operating in the Bypass mode. The drive output contactor and the bypass contactor are electrically interlocked to prevent “back feeding,” applying line voltage to the ACQ550 output terminals.

Motor Overload Protection

The ACQ550 with Bypass includes a motor overload relay to provide thermal motor protection. It is connected in both drive and bypass modes of operation. For motor full load currents through 80 amperes, the Motor Overload Relay is an adjustable trip, bimetallic overload relay with a class 20 trip characteristic. Above 80 amperes, the Motor Overload Relay is an adjustable trip, electronic overload relay with selectable class 10, 20 or 30 trip characteristic. The class 20 setting on the electronic overload relays is the appropriate choice for the majority of the motors used in North America.



WARNING! If power is applied and the switches and contacts in the control circuit are commanding the motor to run, the motor will start as soon as the overload relay is reset.

Use caution when resetting the overload relay to make sure it is safe to start the motor.

Motor Connection Specifications – R8

Motor Connection Specifications				
Maximum Motor Cable Length	Frame Size	Max. Motor Cable Length*		
		$f_{sw} = 1 \text{ or } 4 \text{ kHz}$		$f_{sw} = 8 \text{ kHz or } 12 \text{ kHz}$
	R8	300 m	980 ft	Does not apply



* Warning! Using a motor cable longer than specified in the chart above may cause permanent damage to the drive.

Cooling – R8

Cooling Specifications	
Method	Internal fan, flow direction from bottom to top.
Requirement	Allow 4 to 6 inches at the sides of enclosure for venting.

Air Flow, 380...480 Volt Drives – R8

The following table lists heat loss and air flow data for 380...480 Volt drives.

Drive		Heat Loss		Air Flow	
ACQ550-xx-	Frame Size	W	BTU/Hr	m ³ /h	ft ³ /min
-316A-4	R8	5300	18000	700	1220
-368A-4	R8	6850	23000	700	1220
-414A-4	R8	7000	24000	700	1220
-486A-4	R8	7600	26000	700	1220

Dimensions and Weights

Dimensional References

The following tables contain dimensional references that will be needed to identify the dimensional information applying to a given type code.

208/230V Bypass Packages


HP	Type Code	AMP	Frame	UL Type / NEMA 1 Dim. Ref. Page 29	UL Type / NEMA 12 Dim. Ref. Page 30	UL Type / NEMA 3R Dim. Ref. Page 31
1	ACQ550-CC-04A6-2	4.6	R1	CX1-1	CX12-1	CX3R-1
1.5	ACQ550-CC-06A6-2	6.6	R1	CX1-1	CX12-1	CX3R-1
2	ACQ550-CC-07A5-2	7.5	R1	CX1-1	CX12-1	CX3R-1
3	ACQ550-CC-012A-4	12	R1	CX1-1	CX12-1	CX3R-1
5	ACQ550-CC-017A-2	17	R1	CX1-1	CX12-1	CX3R-1
7.5	ACQ550-CC-024A-2	24	R2	CX1-3	CX12-3	CX3R-3
10	ACQ550-CC-031A-2	31	R2	CX1-3	CX12-3	CX3R-3
15	ACQ550-CC-046A-2	46	R3	CX1-4	CX12-5	CX3R-5
20	ACQ550-CC-059A-2	59	R3	CX1-4	CX12-5	CX3R-5
25	ACQ550-CC-075A-2	75	R4	CX1-6	CX12-6	CX3R-6
30	ACQ550-CC-088A-2	88	R4	CX1-9	CX12-7	CX3R-7
40	ACQ550-CC-114A-2	114	R4	CX1-9	CX12-7	CX3R-7
50	ACQ550-CC-143A-2	143	R6	CX1-10	CX12-10	CX3R-10
60	ACQ550-CC-178A-2	178	R6	CX1-10	CX12-10	CX3R-10
75	ACQ550-CC-221A-2	221	R6	CX1-11	CX12-10	CX3R-10
100	ACQ550-CC-248A-2	248	R6	CX1-11	CX12-10	CX3R-10

480V Bypass Packages

HP	Type Code	AMP	Frame	UL Type / NEMA 1 Dim. Ref. Page 29	UL Type / NEMA 12 Dim. Ref. Page 30	UL Type / NEMA 3R Dim. Ref. Page 31
1	ACQ550-CC-03A3-4	3.3	R1	CX1-1	CX12-1	CX3R-1
1.5	ACQ550-CC-03A3-4	3.3	R1	CX1-1	CX12-1	CX3R-1
2	ACQ550-CC-04A1-4	4.1	R1	CX1-1	CX12-1	CX3R-1
3	ACQ550-CC-06A9-4	6.9	R1	CX1-1	CX12-1	CX3R-1
5	ACQ550-CC-08A8-4	8.8	R1	CX1-1	CX12-1	CX3R-1
7.5	ACQ550-CC-012A-4	12	R1	CX1-1	CX12-1	CX3R-1
10	ACQ550-CC-015A-4	15	R2	CX1-2	CX12-2	CX3R-2
15	ACQ550-CC-023A-4	23	R2	CX1-2	CX12-2	CX3R-2
20	ACQ550-CC-031A-4	31	R3	CX1-4	CX12-4	CX3R-4
25	ACQ550-CC-038A-4	38	R3	CX1-4	CX12-4	CX3R-4
30	ACQ550-CC-045A-4	44	R3	CX1-4	CX12-5	CX3R-5
40	ACQ550-CC-059A-4	59	R4	CX1-5	CX12-6	CX3R-6
50	ACQ550-CC-072A-4	72	R4	CX1-5	CX12-6	CX3R-6
60	ACQ550-CC-078A-4	78	R4	CX1-5	CX12-6	CX3R-6
75	ACQ550-CC-097A-4	96	R4	CX1-6	CX12-7	CX3R-7
100	ACQ550-CC-125A-4	124	R5	CX1-7	CX12-8	CX3R-8
125	ACQ550-CC-157A-4	157	R6	CX1-10	CX12-9	CX3R-9
150	ACQ550-CC-180A-4	180	R6	CX1-10	CX12-9	CX3R-9
200	ACQ550-CC-246A-4	245	R6	CX1-11	CX12-10	CX3R-10
250	ACQ550-CC-316A-4	316	R8	CX1-12	CX12-11	Consult Factory
300	ACQ550-CC-368A-4	368	R8	CX1-13	CX12-12	
350	ACQ550-CC-414A-4	414	R8	CX1-13	CX12-12	
400	ACQ550-CC-486A-4	486	R8	CX1-13	CX12-12	

600V Bypass Packages

HP	Type Code	AMP	Frame	UL Type / NEMA 1 Dim. Ref. Page 29	UL Type / NEMA 12 Dim. Ref. Page 30	UL Type / NEMA 3R Dim. Ref. Page 31
2	ACQ550-CC-02A7-6	2.7	R2	CX1-2	CX12-2	CX3R-2
3	ACQ550-CC-03A9-6	3.9	R2	CX1-2	CX12-2	CX3R-2
5	ACQ550-CC-06A1-6	6.1	R2	CX1-2	CX12-2	CX3R-2
7.5	ACQ550-CC-09A0-6	9	R2	CX1-2	CX12-2	CX3R-2
10	ACQ550-CC-011A-6	11	R2	CX1-2	CX12-2	CX3R-2
15	ACQ550-CC-017A-6	17	R2	CX1-2	CX12-2	CX3R-2
20	ACQ550-CC-022A-6	22	R3	CX1-4	CX12-4	CX3R-4
25	ACQ550-CC-027A-6	27	R3	CX1-4	CX12-4	CX3R-4
30	ACQ550-CC-032A-6	32	R4	CX1-5	CX12-6	CX3R-6
40	ACQ550-CC-041A-6	41	R4	CX1-5	CX12-6	CX3R-6
50	ACQ550-CC-052A-6	52	R4	CX1-5	CX12-6	CX3R-6
60	ACQ550-CC-062A-6	62	R4	CX1-5	CX12-6	CX3R-6
75	ACQ550-CC-077A-6	77	R6	CX1-8	CX12-9	CX3R-9
100	ACQ550-CC-099A-6	99	R6	CX1-8	CX12-9	CX3R-9
125	ACQ550-CC-125A-6	125	R6	CX1-10	CX12-9	CX3R-9
150	ACQ550-CC-144A-6	144	R6	CX1-10	CX12-9	CX3R-9


Dimensions: ACQ550-CC NEMA 1 R1 through R8 Frame Size

	H1	W1	Height (H)	Width (W)	Depth (D)	Weight
CX1-1	920 [36.2]	208 [8.2]	948 [37.3]	348 [13.7]	349 [13.7]	35 [76]
CX1-2	920 [36.2]	208 [8.2]	948 [37.3]	348 [13.7]	349 [13.7]	37 [82]
CX1-3	1352 [53.2]	254 [10]	1380 [54.3]	414 [16.3]	371 [14.6]	49 [107]
CX1-4	1352 [53.2]	254 [10]	1380 [54.3]	414 [16.3]	371 [14.6]	61 [135]
CX1-5	1352 [53.2]	254 [10]	1380 [54.3]	414 [16.3]	371 [14.6]	76 [168]
CX1-6	1568 [61.7]	330 [13]	1596 [62.8]	491 [19.3]	489 [19.2]	90 [198]
CX1-7	1568 [61.7]	330 [13]	1596 [62.8]	491 [19.3]	489 [19.2]	119 [262]
CX1-8	1568 [61.7]	330 [13]	1596 [62.8]	491 [19.3]	489 [19.2]	154 [339]
CX1-9	Free Standing	Free Standing	1883 [74.1]	889 [35]	527 [20.7]	126 [277]
CX1-10	Free Standing	Free Standing	1883 [74.1]	889 [35]	527 [20.7]	190 [418]
CX1-11	Free Standing	Free Standing	1829 [72]	914 [36]	584 [23]	247 [543]
CX1-12	Free Standing	Free Standing	2134 [84]	914 [36]	847 [33.4]	579 [1273]
CX1-13	Free Standing	Free Standing	2134 [84]	1524 [60]	847 [33.4]	662 [1456]

CX1-9 through CX1-11 are a wall mount configuration with 12 inch high mounting feet.

Feet are removable.

Allow 4-6 inches between enclosures for venting.

Dimensions: ACQ550-CC NEMA 12 R1 through R8 Frame Size*CX12-1 to CX12-10 Wall Mounted**CX12-11 to CX12-12 Free Standing*



	H1	W1	Height (H)	Width (W)	Depth (D)	Weight
CX12-1	648 [25.5]	419 [16.5]	686 [27]	457 [18]	369 [14.5]	36 [78]
CX12-2	648 [25.5]	419 [16.5]	686 [27]	457 [18]	369 [14.5]	38 [84]
CX12-3	800 [31.5]	572 [22.5]	838 [33]	610 [24]	369 [14.3]	51 [113]
CX12-4	800 [31.5]	572 [22.5]	838 [33]	610 [24]	369 [14.3]	64 [141]
CX12-5	953 [37.5]	724 [28.5]	991 [39]	762 [30]	369 [14.3]	78 [172]
CX12-6	953 [37.5]	724 [28.5]	991 [39]	762 [30]	369 [14.3]	93 [205]
CX12-7	1257 [49.5]	724 [28.5]	1304 [51.4]	914 [36]	572 [22.5]	118 [259]
CX12-8	1257 [49.5]	724 [28.5]	1304 [51.4]	914 [36]	572 [22.5]	147 [323]
CX12-9	1257 [49.5]	724 [28.5]	1304 [51.4]	914 [36]	572 [22.5]	182 [400]
CX12-10	Free Standing	Free Standing	1829 [72]	914 [36]	584 [23]	247 [543]
CX12-11	Free Standing	Free Standing	2134 [84]	914 [36]	847 [33.4]	579 [1273]
CX12-12	Free Standing	Free Standing	2134 [84]	1524 [60]	847 [33.4]	662 [1456]

CX3R-10 is a wall mount configuration with 12 inch high mounting feet.

Feet are removable.

CX3R-12 enclosure is double door construction.

Allow 4-6 inches between enclosures for venting.




Dimensions: ACQ550-CC NEMA 3R R1 through R6 Frame Size*CX3R-1 to CX3R-9 Wall Mounted**CX3R-10 Free Standing*

	H1	W1	Height (H)	Width (W)	Width (W2)	Width (W3)	Depth (D)	Weight
CX3R-1	572 [22.5]	419 [16.5]	610 [24]	457 [18]	89 [3.5]	N/A N/A	359 [14.1]	37 [82]
CX3R-2	572 [22.5]	419 [16.5]	610 [24]	457 [18]	89 [3.5]	N/A N/A	359 [14.1]	40 [88]
CX3R-3	724 [28.5]	572 [22.5]	762 [30]	610 [24]	89 [3.5]	N/A N/A	359 [14.1]	53 [117]
CX3R-4	724 [28.5]	572 [22.5]	762 [30]	610 [24]	89 [3.5]	N/A N/A	359 [14.1]	66 [145]
CX3R-5	876 [34.5]	725 [28.5]	914 [36]	762 [30]	89 [3.5]	89 [3.5]	359 [14.1]	82 [180]
CX3R-6	876 [34.5]	725 [28.5]	914 [36]	762 [30]	89 [3.5]	89 [3.5]	359 [14.1]	97 [213]
CX3R-7	1181 [46.5]	876 [34.5]	1219 [48]	914 [36]	89 [3.5]	89 [3.5]	562 [22.1]	121 [267]
CX3R-8	1181 [46.5]	876 [34.5]	1219 [48]	914 [36]	89 [3.5]	89 [3.5]	562 [22.1]	151 [331]
CX3R-9	1181 [46.5]	876 [34.5]	1219 [48]	914 [36]	89 [3.5]	89 [3.5]	562 [22.1]	186 [408]
CX3R-10	Free Standing	Free Standing	1829 [72]	914 [36]	89 [3.5]	89 [3.5]	584 [23]	251 [553]

CX3R-10 is a wall mount configuration with 12 inch high mounting feet.
Feet are removable.

Applicable Standards

Drive compliance with the following standards is identified by the standards “marks” on the type code label.

Mark	Applicable Standards	
	UL 508C and C22.2 No. 14	UL Standard for Safety, Power Conversion Equipment, and CSA Standard for Industrial Control Equipment
	UL 508A	UL Standard for Safety, Industrial Control Panels
	C22.2 No. 14	CSA Standard for Industrial Control Equipment

Compliance is valid with the following provisions:

- The motor and control cables are chosen as specified in this manual.
- The installation rules of this manual are followed.

Index

Numerics		F	
208...230V bypass packages	27	Floor mount	
380...480V bypass packages	28	installing the line input wiring	12
500...600V bypass packages	28	typical configuration, front view	5
A		wiring overview	11
Air flow	26	Fuses, drive	
Analog inputs	14	208...240 volt drives	19
Auto start contact	15	380...480 volt drives	20
Automatic startup warning	1	500...600 volt drives	21
Auto/Man setting	16	G	
Auto/Man setting, overload relay	16	Grounding requirements	10
B		H	
Branch circuit protection	18	Heat loss	26
Bypass		I	
contactors, description	25	Identifying the drive type	8
diagram	6	Input power	
features and functions	4	branch circuit protection	18
C		Installation	
Cable requirements, input power	18	control wiring	13
Class setting, overload relay	16	flow chart	6
Connection points	14	line input wiring	12
Contactor bypass, description	25	motor wiring	13
Contacts, auto start	15	preparation	7, 8
Control wiring	13	wiring requirements	10
Cooling	26	Installer warning	1
Current settings	16	Interlocks, run enable	14
D		L	
Dangerous voltage warning	1	Line connection warning	1
Dimensional references	27–28	Location, mounting	8
208/230V bypass packages	27	M	
480V bypass packages	28	Maintenance schedule	17
600V bypass packages	28	Manuals for ACQ550 drive	ii
Dimensions		Metal conduit runs	10
NEMA 1 R1-R8 frame size	27	Motor	
NEMA 12 R1-R8 frame size	27	cable, maximum length	26
NEMA 3R R1-R6 frame size	27	connection specifications	26
Drive		connections	25
identification	8	protection, overload relay	25
proper lifting	7	runing, relay contact output	15
standards, compliance to	32	wiring	13
E		Mounting locations	8
Enclosure protection class code	8	Mounting locations, preparing	9

N

NEMA 1	
code	8
R1-R8 frame size dimensions	27
NEMA 12	
code	8
R1-R8 frame size dimensions	27
NEMA 3R	
code	8
R1-R6 frame size dimensions	27

O

Overload relay	
motor protection	25
resetting	16

P

Parallel control connectinos warning	1
Power connection terminals	22
Protection	
branch circuit	18
motor overload	25

Q

Qualified installer requirement	1
---------------------------------------	---

R

R8	
cooling	26
motor connection specifications	26
Relay	
motor running contact output	15
overload	16
Requirements	
grounding	10
input power cables	18
metal conduit runs	10
wiring	10
wiring, input power	18
Resetting the overload relay	16
Run enable interlocks	14
Running, relay contact output	15

S

Safety warnings	1
Specifications	
208...240 Volt power connection	22
340...480 Volt power connection	23
500...600 Volt power connection	24
cooling	26
input power connetions	18
motor connections	25
power connection terminals	22
Standards	
C22.2 No. 14	32
UL 508C	32

T

Technical data	18–32
Terminal block 1TB	14
Terminals, power, wire sizes	22

W

Wall mount	
installing the line input wiring	12
installing the motor wiring	13
typical configuration, front view	5
wiring overview	11
Warning	
automatic start up	1
dangerous voltages	1
parallel control connections	1
qualified installer	1
Wiring	
conduits	13
control	13
line input	12
motor	13
requirements	10
shielded cable	13
wall and floor mount overviews	11



3AUA0000150964B



3AUA0000150964 REV B / EN
EFFECTIVE: 12/01/2017
Supersedes: 10/01/2013

ABB Inc.
Automation Products
Low Voltage Drives
16250 West Glendale Drive
New Berlin, WI 53151
Telephone 800-752-0696