

# CoriolisMaster FCB400, FCH400

## Coriolis mass flowmeter



Device firmware version: 01.11.00

Measurement made easy

—  
CoriolisMaster FCB430 / 450  
CoriolisMaster FCH430 / 450

### Introduction

With no up or downstream piping requirements the compact Coriolis flowmeters can be installed in the tightest spaces, enabling applications not possible before.

#### CoriolisMaster FCB400

The compact Coriolis mass flowmeters from the CoriolisMaster FCB400 series offer low pressure drop, high capacity, an intuitive ABB display featuring a standardized design and cross-product compatibility, five modular inputs and outputs as well as HART communication.

#### CoriolisMaster FCH400

The compact Coriolis mass flowmeters for hygienic applications from the CoriolisMaster FCH400 series additionally offer EHEDG certified cleanability; all wetted materials are polished.

### Additional Information

Additional documentation on CoriolisMaster FCB400, FCH400 is available for download free of charge at [www.abb.com/flow](http://www.abb.com/flow). Alternatively simply scan this code:



## Table of contents

<b>1 Safety</b> .....	<b>4</b>	<b>3 Use in hazardous areas in accordance with EAC TR-CU-012</b> .....	<b>27</b>
General information and instructions.....	4		
Warnings.....	4	<b>4 Product identification</b> .....	<b>28</b>
Intended use.....	5	Name plate.....	28
Improper use.....	5	<b>5 Transport and storage</b> .....	<b>29</b>
Cyber security disclaimer.....	5	Inspection.....	29
Software downloads.....	5	Transporting the device.....	29
Manufacturer's address.....	5	Storing the device.....	30
Service address.....	5	Ambient conditions.....	30
<b>2 Use in potentially explosive atmospheres</b> .....	<b>6</b>	Returning devices.....	30
Device overview.....	6	<b>6 Installation</b> .....	<b>30</b>
ATEX, IECEx and UKEX.....	6	General installation conditions.....	30
cFMus.....	7	Installation location and assembly.....	30
Ex marking.....	8	Liquid measuring media.....	31
Description of model numbers.....	8	Gaseous measuring media.....	32
ATEX, IECEx and UKEX.....	11	Turn-off devices for the zero point adjustment.....	33
cFMus.....	12	Sensor insulation.....	33
Temperature data.....	13	Installation in EHEDG-compliant installations.....	33
Temperature resistance for the connecting cable.....	13	Devices for legal metrology.....	34
Environmental and process conditions for model FCx4xx.....	13	Process conditions.....	34
Measuring medium temperature for sensors in integral mount design with dual-compartment housing.....	14	Temperature limits °C (°F).....	34
Measuring medium temperature for sensors in integral mount design with single-compartment housing.....	15	Temperature Data.....	34
Measuring medium temperature for sensors in remote mount design.....	16	Pressure ratings.....	35
Electrical data.....	17	Housing as a protective device (optional).....	35
Overview.....	17	Material load for process connections.....	35
Zone 2, 21 and Division 2 – Model: FCx4xx-A2..., FCx4xx-U2... and FCx4xx-F2.....	18	Material load curves for flange devices.....	36
Zone 1, 21 and Division 1 – Model: FCx4xx-A1..., FCx4xx-U1... and FCx4xx-F1.....	20	Installing the sensor.....	37
Special connection conditions.....	22	Installing the transmitter in the remote mount design.....	37
Installation instructions.....	23	Opening and closing the housing.....	39
ATEX, IECEx and UKEX.....	23	Dual-compartment housing.....	39
cFMus.....	23	Single-compartment housing.....	40
Use in areas exposed to combustible dust.....	23	Adjusting the transmitter position.....	40
Sensor insulation.....	23	Installing the plug-in cards.....	42
Opening and closing the housing.....	23	Optional plug-in cards.....	42
Cable entries in accordance with ATEX/IECEx and UKEX.....	24	Dual-compartment housing.....	44
Cable entries in accordance with cFMus.....	24	Single-compartment housing.....	45
Specific Conditions of Use.....	24	Ethernet card.....	46
Electrical connections.....	25	<b>7 Electrical connections</b> .....	<b>47</b>
Process sealing.....	25	Safety instructions.....	47
Operating instructions.....	26	Power supply.....	47
Protection against electrostatic discharges.....	26	Installing the connection cables.....	48
Repair.....	26	Recommended cables.....	48
Changing the type of protection.....	26	Terminal assignment.....	49
		Electrical data for inputs and outputs.....	50
		Connection examples.....	55
		Connection on the device.....	58
		Connection to integral mount design.....	58
		Connection to remote mount design.....	60

<b>8 Digital communication ..... 63</b>	<b>11 Maintenance / Repair ..... 90</b>
HART® Communication.....63	Safety instructions .....90
Modbus® communication.....63	<b>12 Dismounting and disposal ..... 90</b>
Cable specification ..... 64	Dismounting.....90
PROFIBUS DP® communication ..... 64	Disposal ..... 91
EtherNet/IP™ and PROFINET® communication .....65	<b>13 Specification .....91</b>
EtherNet/IP™ and PROFINET® protocol ..... 66	<b>14 Additional documents .....91</b>
Wiring with different network topologies .....67	<b>15 Appendix ..... 92</b>
Preparing the EtherNet Cat5e cable ..... 69	Return form..... 92
Ground the Ethernet connection cable ..... 69	
M12 connector (optional)..... 69	
RJ45 connector (optional) .....70	
Ethernet card status LEDs..... 72	
<b>9 Commissioning ..... 74</b>	
Safety instructions.....74	
Hardware settings .....74	
Dual- compartment housing .....74	
Single-compartment housing .....75	
Configuration of digital outputs V1 / V2 or V3 / V4....75	
Checks prior to commissioning .....76	
Switching on the power supply .....76	
Parameterization of the device .....76	
Installation of the ABB Field Information Manager (FIM)..... 77	
Parameterization via the infrared service port adapter .....78	
Parameterization via HART®.....78	
Basic Setup.....79	
Menu: Easy Setup .....79	
<b>10 Operation ..... 83</b>	
Safety instructions.....83	
Menu navigation.....83	
Menu levels ..... 84	
Process display .....85	
Switching to the information level.....85	
Error messages on the LCD display..... 86	
Switching to the configuration level (parameterization) 86	
Resetting the customer password.....87	
Selecting and changing parameters..... 88	
Entry from table..... 88	
Numerical entry ..... 88	
Alphanumeric entry..... 88	

# 1 Safety

## General information and instructions

These instructions are an important part of the product and must be retained for future reference.

Installation, commissioning, and maintenance of the product may only be performed by trained specialist personnel who have been authorized by the plant operator accordingly. The specialist personnel must have read and understood the manual and must comply with its instructions.

For additional information or if specific problems occur that are not discussed in these instructions, contact the manufacturer.

The content of these instructions is neither part of nor an amendment to any previous or existing agreement, promise or legal relationship.

Modifications and repairs to the product may only be performed if expressly permitted by these instructions.

Information and symbols on the product must be observed.

These may not be removed and must be fully legible at all times.

The operating company must strictly observe the applicable national regulations relating to the installation, function testing, repair and maintenance of electrical products.

## Warnings

The warnings in these instructions are structured as follows:

### **DANGER**

The signal word '**DANGER**' indicates an imminent danger. Failure to observe this information will result in death or severe injury.

### **WARNING**

The signal word '**WARNING**' indicates an imminent danger. Failure to observe this information may result in death or severe injury.

### **CAUTION**

The signal word '**CAUTION**' indicates an imminent danger. Failure to observe this information may result in minor or moderate injury.

### **NOTICE**

The signal word '**NOTICE**' indicates possible material damage.

### **Note**

'**Note**' indicates useful or important information about the product.

## Intended use

This device is intended for the following uses:

- To convey liquids and gases (including unstable measuring media).
- To meter mass flow directly.
- To meter volumetric flow (indirectly via mass flow and density).
- To measure the density of the measuring medium.
- To measure the temperature of the measuring medium.

The device has been designed for use exclusively within the technical limit values indicated on the identification plate and in the data sheets.

When using measuring media, the following points must be observed:

- Measuring media may only be used if, based on the state of the art or the operating experience of the user, it can be assured that the chemical and physical properties necessary for operational security of the materials of the wetted parts of the flowmeter sensor will not be adversely affected during the operating time.
- Media containing chloride in particular can cause corrosion damage to stainless steels which, although not visible externally, can damage wetted parts beyond repair and lead to the measuring medium escaping. It is the operator's responsibility to check the suitability of these materials for the respective application.
- Measuring media with unknown properties or abrasive measuring media may only be used if the operator is able to perform regular and suitable tests to ensure the safe condition of the device

## Improper use

The following are considered to be instances of especially improper use of the device:

- Operation as a flexible compensating adapter in piping, for example for compensating pipe offsets, pipe vibrations, pipe expansions, etc.
- For use as a climbing aid, for example for mounting purposes.
- For use as a bracket for external loads, for example as a support for piping, etc.
- Material application, for example by painting over the housing, name plate or welding/soldering on parts.
- Material removal, for example by spot drilling the housing.

## Cyber security disclaimer

This product is designed to be connected to and to communicate information and data via a network interface. It is operator's sole responsibility to provide and continuously ensure a secure connection between the product and your network or any other network (as the case may be).

Operator shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc.) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information.

ABB and its affiliates are not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.

## Software downloads

By visiting the web pages indicated below, you will find notifications about newly found software vulnerabilities and options to download the latest software. It is recommended that you visit this web pages regularly:

[www.abb.com/cybersecurity](http://www.abb.com/cybersecurity)

[ABB-Library – CoriolisMaster FCx400 – Software Downloads](#)



## Manufacturer's address

### ABB AG

#### Measurement & Analytics

Schillerstr. 72  
32425 Minden  
Germany

Tel: +49 571 830-0

Fax: +49 571 830-1806

## Service address

### Customer service center

Tel: 0180 5 222 580

Email: [automation.service@de.abb.com](mailto:automation.service@de.abb.com)

## 2 Use in potentially explosive atmospheres

### Note

Further information on the Ex-Approval of devices can be found in the type examination certificates or the relevant certificates at [www.abb.com/flow](http://www.abb.com/flow).

### Device overview

#### ATEX, IECEx and UKEX

	Standard / No explosion protection		Zone 2, 21, 22		Zone 1, 21 (Zone 0)	
Model number	FCx4xx Y0		FCx4xx A2, U2		FCx4xx A1, U1	
Integral mount design						
<ul style="list-style-type: none"> <li>Standard</li> <li>Zone 2, 21, 22</li> <li>Zone 1, 21</li> <li>Zone 0</li> </ul>						
Model number	FCT4xx Y0	FCx4xx Y0	FCT4xx A2	FCx4xx A2	FCT4xx A1	FCx4xx A1
Remote mount design						
Transmitter and flowmeter sensor						
<ul style="list-style-type: none"> <li>Standard</li> <li>Zone 2, 21, 22</li> <li>Zone 1, 21</li> <li>Zone 0</li> </ul>						
Model number	FCT4xx Y0		FCT4xx A2		FCx4xx A1	
Remote mount design						
Transmitter						
<ul style="list-style-type: none"> <li>Standard</li> <li>Zone 2, 21, 22</li> </ul>						
Sensor						
<ul style="list-style-type: none"> <li>Zone 1, 21</li> <li>Zone 0</li> </ul>						
Model number	—		FCT4xx A2		FCx4xx A1	
Remote mount design						
Transmitter						
<ul style="list-style-type: none"> <li>Zone 2, 21, 22</li> </ul>						
Sensor						
<ul style="list-style-type: none"> <li>Zone 1, 21</li> </ul>						

- ① Single-compartment housing
- ② Dual-compartment housing
- ③ Zone 0 within the meter tube

**cFMus**

	Standard / No explosion protection		Class I Div. 2 / Zone 2		Class I Div. 1 / Zone 1 (Zone 0)	
<b>Model number</b>	FCx4xx Y0		FCx4xx F2		FCx4xx F1	
Integral mount design						
<ul style="list-style-type: none"> <li>Standard</li> <li>Div. 2 / Zone 2</li> <li>Div. 1 / Zone 1 (Zone 0)</li> </ul>						
<b>Model number</b>	FCT4xx Y0	FCx4xx Y0	FCT4xx F2	FCx4xx F2	FCT4xx F1	FCx4xx F1
Remote mount design						
Transmitter and flowmeter sensor <ul style="list-style-type: none"> <li>Div. 2 / Zone 2</li> <li>Div. 1 / Zone 1 (Zone 0)</li> </ul>						
<b>Model number</b>	FCT4xx Y0		FCT4xx F2		FCx4xx F1	
Remote mount design						
Transmitter <ul style="list-style-type: none"> <li>Standard</li> </ul> Sensor <ul style="list-style-type: none"> <li>Div. 2 / Zone 2</li> <li>Div. 1 / Zone 1 (Zone 0)</li> </ul>						
<b>Model number</b>	—		FCT4xx F2		FCx4xx F1	
Remote mount design	—					
Transmitter <ul style="list-style-type: none"> <li>Div. 2 / Zone 2</li> </ul> Sensor <ul style="list-style-type: none"> <li>Div. 1 / Zone 1 (Zone 0)</li> </ul>	—					

- ① Single-compartment housing
- ② Dual-compartment housing
- ③ Zone 0 within the meter tube

## ... 2 Use in potentially explosive atmospheres

### Ex marking

#### Description of model numbers

Each device design has a specific model number. The parts of the model number relating to explosion protection are listed in the following table. The complete key to model numbers is described in the device data sheet.

Basic model	FCa4c	d	m	f	g	h	i	j	k	l	m
<b>Explosion protection</b>											
Without		Y0									
ATEX / IECEx (Zone 2 / 22)		A2									
ATEX / IECEx (Zone 1 / 21)		A1									
cFMus version Class 1 Div. 2		F2									
cFMus version, Class 1, Div. 1 (Zone 1 / 21)		F1									
NEPSI (Zone 2 / 22)		S2									
NEPSI (Zone 1 / 21)		S1									
UKEX (Zone 2 / 22)		U2									
UKEX (Zone 1 / 21)		U1									
<b>Design / terminal box material / cable glands</b>											
Integral mount - see transmitter housing			Y0								
Remote mount / aluminum / 1 × M20 × 1.5			U1								
Remote mount / aluminum / 1 × NPT ½ in			U2								
Remote mount / stainless steel / 1 × M20 × 1.5			A1								
Remote mount / stainless steel / 1 × NPT ½ in			A2								
<b>Nominal diameter / nominal connection diameter</b>				xxxxx							
<b>Process connection</b>						xx					
<b>Material for wetted parts</b>											
Stainless steel						A1					
Polished stainless steel						H1					
Nickel alloy						C1					
<b>Flow rate calibration</b>								x			
<b>Density calibration</b>								x			

Basic model	FCa4c	d	m	f	g	h	i	j	k	l	m
<b>Connection Design / Transmitter Housing Type / Transmitter Housing Type / Cable</b>											
<b>Glands</b>											
Integral mount / dual-compartment housing / aluminum / 3 × M20 × 1.5										D1	
Integral mount / dual-compartment housing / aluminum / 3 × NPT ½ in										D2	
Integral mount / dual-compartment housing / aluminum / 3 × M20 × 1.5 (Ex d / XP)										D5	
Integral mount / dual-compartment housing / aluminum / 3 × NPT ½ in (Ex d / XP)										D6	
Integral mount / dual-compartment housing / stainless steel / 3 × M20 × 1.5										D3	
Integral mount / dual-compartment housing / stainless steel / 3 × NPT ½ in										D4	
Integral mount / dual-compartment housing / stainless steel / 3 × M20 × 1.5 (Ex d / XP)										D7	
Integral mount / dual-compartment housing / stainless steel / 3 × NPT ½ in (Ex d / XP)										D8	
Integral mount / single-compartment housing / aluminum / 3 × M20 × 1.5										S1	
Integral mount / single-compartment housing / aluminum / 3 × NPT ½ in										S2	
Remote mount / dual-compartment housing / aluminum / 3 × M20 × 1.5										R1	
Remote mount / dual-compartment housing / aluminum / 3 × NPT ½ in										R2	
Remote mount / dual-compartment housing / aluminum / 3 × M20 × 1.5 (Ex d / XP)										R5	
Remote mount / dual-compartment housing / aluminum / 3 × NPT ½ in (Ex d / XP)										R6	
Remote mount / dual-compartment housing / stainless steel / 3 × M20 × 1.5										R3	
Remote mount / dual-compartment housing / stainless steel / 3 × NPT ½ in										R4	
Remote mount / dual-compartment housing / stainless steel / 3 × M20 × 1.5 (Ex d / XP)										R7	
Remote mount / dual-compartment housing / stainless steel / 3 × NPT ½ in (Ex d / XP)										R8	
Remote mount / single-compartment housing, wall mounting / aluminum / 4 × M20 × 1.5										W1	
Remote / Single compartment, wall mounted / Aluminium / 4 × NPT ½ in										W2	
Remote mount / not specified										Y0	
<b>Outputs</b>											
Current output 1 (active or passive), digital output 1 & 2 (passive), HART®, PROFIBUS DP®										D1	
Current output 1 (active), digital output 1 & 2 (passive), HART®, Modbus®										M1	
Current output 1 (active / passive), digital output 1 & 2 (passive), digital output 3 (active), HART, Modbus										M6	
Current output 1 (active / passive), digital output 1 & 2 (passive), HART®, 1 Port Ethernet										E2*	
Current output 1 (active / passive), digital output 1 & 2 (passive), HART®, 2 Port Ethernet										E3*	
Current output 1 (active / passive), digital output 1 & 2 (passive), HART®, 1 Port Ethernet + POE										E4*	
Current output 1 (active / passive), digital output 1 & 2 (passive), HART										G0	
Current output 1 (active / passive), digital output 1 & 2 (passive), 24 V DC transmitter loop power supply, HART®										G1	
Current output 1 (active / passive), digital output 1 & 2 (passive), current output 2 (passive), HART®										G2	
Current output 1 (active / passive), digital output 1 & 2 (passive), current output 2 (passive), current output 3 (passive), HART®										G3	
Current output 1 (active / passive), digital output 1 & 2 (passive), current output 2 (passive), 24 V DC transmitter loop power supply, HART®										G4	
Without										Y0	
<b>Power supply</b>											
100 to 230 V AC											A
11 to 30 V DC											C
Without											Y

\* Available with single-compartment housing only in 'Not Ex' or 'Zone 2' or 'Div 2' execution.

## ... 2 Use in potentially explosive atmospheres

### ... Ex marking

Additional ordering information	FCa4cdefghijklm	XXX	XXX	XX
<b>Option card 1</b>				
2 port Ethernet (various protocols)		DR6*		
1 × active digital output		DRH		
<b>Option card 2</b>				
Power over Ethernet module / Modbus			DS8*	
1 × active digital output			DSH	
<b>Connection type</b>				
Without				U0
1 × M 12 plug connector for Ethernet 1 Port (4 signal lines)				UE*
2 × M 12 plug connector for Ethernet 2 Port (4 signal lines)				UF*
1 × M 12 plug connector for Ethernet 1 Port (8 signal lines)				UG*
1 × RJ45 connector with 5 m cable length attached (4 signal lines)				U5*
2 × RJ45 connector with 5 m cable length attached (4 signal lines)				UB*
1 × RJ45 connector with 5 m cable length attached (8 signal lines)				UC*
1 × RJ45 connector with 10 m cable length attached (4 signal lines)				U6*
2 × RJ45 connector with 10 m cable length attached (4 signal lines)				DU*
1 × RJ45 connector with 10 m cable length attached (8 signal lines)				UH*
1 × RJ45 connector with 15 m cable length attached (4 signal lines)				U7*
2 × RJ45 connector with 15 m cable length attached (4 signal lines)				UJ*
1 × RJ45 connector with 15 m cable length attached (8 signal lines)				UK*
1 × RJ45 connector with 20 m cable length attached (4 signal lines)				U8*
2 × RJ45 connector with 20 m cable length attached (4 signal lines)				UN*
1 × RJ45 connector with 20 m cable length attached (8 signal lines)				UP*

\* Only available with single-compartment housing and Ethernet

### DANGER

#### Risk of injury caused by live parts!

When using the outputs of the M6 option digital output or the DRH/DSH option active digital output option cards, all the option cards used and all pre-installed output circuits must use the 'Increased safety' (Ex-e) IP rating.

- The 'Intrinsic safety' (Ex i) IP rating is not permitted.

**ATEX, IECEx and UKEX****Note**

- A specific marking applies, depending on the design.
- ABB reserves the right to modify the Ex-marking. Refer to the name plate for the exact marking.

Model number for use in Zone 2, 21	Ex marking	Certificate
<b>FCa4c – A2Y0fghijD; FCa4c – U2Y0fghijD</b> Integral mount design with dual-compartment housing	II3G Ex ec IIC T6...T1 Gc II2D Ex tb IIIC T80°C...Tmedium Db	<b>ATEX:</b> FM15ATEX0014X, FM15ATEX0016X
<b>FCa4c – A2efghijY; FCa4c – U2efghijY</b> Sensor in remote mount design with dual-compartment housing		<b>IECEx:</b> IECEx FME 15.0005X
<b>FCT4c – A2R; FCT4c – U2R</b> Transmitter in remote mount design with dual-compartment housing	II3G Ex ec IIC T6 Gc II2D Ex tb IIIC T80°C Db	<b>UKEX:</b> FM22UKEX0095X, FM22UKEX0097X

Model number for use in Zone 1, 21	Ex marking	Certificate
<b>FCa4c – A1Y0fghijDx; FCa4c – U1Y0fghijDx (x = 1 to 4)</b> Integral mount design with dual-compartment housing	II 1/2 (1) G Ex db eb ia mb [ia Ga] IIC T6...T1 Gb II 2 (1) D Ex ia tb [ia Da] IIIC T80°C Db	<b>ATEX:</b> FM15ATEX0015X
<b>FCa4c – A1Y0fghijDx; FCa4c – U1Y0fghijDx (x = 5 to 8)</b> Integral mount design with dual-compartment housing (flameproof enclosure 'Ex d')	II 1/2 (1) G Ex db ia mb [ia Ga] IIB+H2 T6...T1 Gb II 2 (1) D Ex ia tb [ia Da] IIIC T80°C Db	<b>IECEx:</b> IECEx FME 15.0005X
<b>FCa4cA1Y0fghM6jDx; FCa4cU1Y0fghM6jDx (x = 1 to 4) or DRH or DSH option card</b> Integral mount design with dual-compartment housing and active digital output option card	II 1/2 G Ex db eb mb ia IIC T6...T1 Gb II 2 D Ex ia tb IIIC T80°C Db	<b>UKEX:</b> FM22UKEX0096X
<b>FCa4c – A1efghijY; FCa4c – U1efghijY</b> Sensor in remote mount design with dual-compartment housing	II 1/2 G Ex eb ia mb IIB+H2 T6...T1 Ga/Gb II 2 D Ex ia tb IIIC T80°C Db	
<b>FCa4cA1Y0fghM6jDx; FCa4cU1Y0fghM6jDx (x = 5 to 8) or DRH or DSH option card</b> Integral mount design with dual-compartment housing (flameproof enclosure 'Ex d') and active digital output option card	II 1/2 G Ex db mb ia IIB+H2 T6...T1 Gb II 2 D Ex ia tb IIIC T80°C Db	
<b>FCT4c – A1R; FCT4c – U1R (x = 1 to 4)</b> Transmitter in remote mount design with dual-compartment housing	II 2 (1) G Ex db e ia mb [ia Ga] IIC T6...T1 Gb II 2 (1) D Ex ia mb tb [ia Da] IIIC T80°C Db	
<b>FCT4c – A1R; FCT4c – U1R (x = 5 to 8)</b> Transmitter in remote mount design with dual-compartment housing (flameproof enclosure 'Ex d')	II 2 (1) G Ex db ia mb [ia Ga] IIB+H2 T6...T1 Gb II 2 (1) D Ex ia tb [ia Da] IIIC T80°C Db	
<b>FCT4c – A1R; FCT4c – U1R (x = 1 to 4) fghM6 or DRH or DSH option card</b> Transmitter in remote mount design with dual-compartment housing and active digital output option card	II 2 G Ex db eb mb IIC T6...T1 Gb II 2 D Ex mb tb IIIC T80°C Db	
<b>FCT4c – A1R; FCT4c – U1R (x = 5 to 8) fghM6 or DRH or DSH option card</b> Transmitter in remote mount design with dual-compartment housing (flameproof enclosure 'Ex d') and active digital output option card	II 2 G Ex db mb IIB+H2 T6...T1 Gb II 2 D Ex tb IIIC T80°C Db	

## ... 2 Use in potentially explosive atmospheres

### ... Ex marking

#### cFMus

##### Note

- A specific marking applies, depending on the design.
- ABB reserves the right to modify the Ex-marking. Refer to the name plate for the exact marking.

Model number for use in Division 2	Ex marking	
	Certificate: FM18US0160X	Certificate: FM18CA0073X
<b>FCa4c – F2Y0fghjD</b> Integral mount design with dual-compartment housing	NI: CL I,II,III Div 2, GPS ABCDEFG, T6...T1 CL I, ZN 2, AEx ec IIC T6...T1	DIP: CL II,III, Div 1, GPS EFG, T6 ZN 21, AEx ia tb IIIC T80°C
<b>FCa4c – F2efghjY</b> Sensor in remote mount design with dual-compartment housing Design in accordance with ANSI / ISA 12.27.01 as 'Single Seal Device' or as 'Dual Seal Device' (option TE2)	CL I, ZN 2, Ex ec IIC T6...T1	ZN21,Ex ia tb IIIC T80°C
<b>FCT4c – F2R</b> Transmitter in remote mount design with dual-compartment housing	See handbook for temperature class information	
<b>FCT4c – F2W</b> Sensor in remote mount design with single-compartment housing	NI: CL I,II,III Div 2, GPS ABCDEFG, T6...T1	DIP: CL II,III, Div 1, GPS EFG, T6
	See handbook for temperature class information	
Model number for use in Division 1	Ex marking	
	Certificate: FM18US0160X	Certificate: FM18CA0073X
<b>FCa4c – F1Y0fghjDx (x = 1 to 4)</b> Integral mount design with dual-compartment housing	XP-IS: CL I, Div 1, GPS ABCD,T6...T1 (USA) DIP: CL II,III, Div 1, GPS EFG,T6	XP-IS: CL I, Div 1, GPS BCD,T6...T1 (CAN) ZN21, AEx ia tb IIIC T80°C
<b>FCa4c – F1Y0fghjDx (x = 5 to 8)</b> Integral mount design with dual-compartment housing (Explosionproof 'XP'). Design in accordance with ANSI / ISA 12.27.01 as 'Single Seal Device' or as 'Dual Seal Device' (option TE2).	CL I, ZN 1, AEx db ia IIB+H2 T6...T1 CL I, ZN 1, Ex db ia IIB+H2 T6...T1	ZN21, Ex ia tb IIIC T80°C
<b>FCa4c – F1Y0fghM6jDx (x = 1 to 4) or DRH or DSH option card</b> Integral mount design with dual-compartment housing	XP-IS: CL I, Div 1, GPS ABCD,T6...T1 (USA) DIP: CL II,III, Div 1, GPS EFG,T6	XP-IS: CL I, Div 1, GPS BCD,T6...T1 (CAN) ZN21, AEx ia tb IIIC T80°C
<b>FCa4c – F1Y0fghM6jDx (5 to 8) or DRH or DSH option card</b> Integral mount design with dual-compartment housing (Explosionproof „XP“).	CL I, ZN 1, AEx db ia IIB+H2 T6...T1 CL I, ZN 1, Ex db ia IIB+H2 T6...T1	ZN21, Ex ia tb IIIC T80°C
	See handbook for temperature class information and installation drawing 3KXF000028G0009	
<b>FCa4c – F1efghjY</b> Sensor in remote mount design with dual-compartment housing Design in accordance with ANSI / ISA 12.27.01 as 'Single Seal Device' or as 'Dual Seal Device' (option TE2).	XP-IS: CL I, Div 1, GPS BCD T6...T1 CL I, ZN 1, AEx db ia IIB+H2 T6...T1 CL I, ZN 1, Ex db ia IIB+H2 T6...T1	DIP: CL II,III, Div 1, GPS EFG,T6 ZN 21, AEx ia tb IIIC T80°C ZN21, Ex ia tb IIIC T80°C
	See handbook for temperature class information and installation drawing 3KXF000028G0009	
<b>FCT4c – F1Rx (x = 1 to 4)</b> Transmitter in remote mount design with dual-compartment housing	XP-IS: CL I, Div 1, GPS BCD,T6...T1 (USA) DIP: CL II,III, Div 1, GPS EFG, T6	XP-IS: CL I, Div 1, GPS BCD,T6...T1 (CAN) ZN 21, AEx ia tb IIIC T80°C
<b>FCT4c – F1Rx (x = 5 to 8)</b> Sensor in remote mount design with dual-compartment housing (Explosionproof 'XP').	CL I, ZN 1, AEx db ia IIB+H2 T6...T1 CL I, ZN 1, Ex db ia IIB+H2 T6...T1	ZN21,Ex ia tb IIIC T80°C
	See handbook for temperature class information and installation drawing 3KXF000028G0009	
<b>FCT4c – F1Rx (x = 1 to 4) fghM6 or DRH or DSH option card</b> Transmitter in remote mount design with dual-compartment housing	XP-IS: CL I, Div 1, GPS BCD,T6...T1 (USA) DIP: CL II,III, Div 1, GPS EFG, T6	XP-IS: CL I, Div 1, GPS BCD,T6...T1 (CAN) ZN 21, AEx tb IIIC T80°C
<b>FCT4c – F1Rx (x = 5 to 8) fghM6 or DRH or DSH option card</b> Sensor in remote mount design with dual-compartment housing (Explosionproof 'XP').	CL I, ZN 1, AEx db IIB+H2 T6...T1 CL I, ZN 1, Ex db IIB+H2 T6...T1	ZN21,Ex tb IIIC T80°C
	See handbook for temperature class information and installation drawing 3KXF000028G0009	


## Temperature data

### Temperature resistance for the connecting cable

The temperature at the cable entries of the device depends on the design, the measuring medium temperature  $T_{\text{medium}}$  and the ambient temperature  $T_{\text{amb.}}$ .


For the electric connection of the device, use only cables with sufficient temperature resistance in accordance with the following table.

### Devices in integral mount design with dual-compartment housing




$T_{\text{amb.}}$	Temperature resistance
$\leq 50\text{ °C}$ ( $\leq 122\text{ °F}$ )	$\geq 70\text{ °C}$ ( $\geq 158\text{ °F}$ )
$\leq 60\text{ °C}$ ( $\leq 140\text{ °F}$ )	$\geq 80\text{ °C}$ ( $\geq 176\text{ °F}$ )
$\leq 70\text{ °C}$ ( $\leq 158\text{ °F}$ )	$\geq 90\text{ °C}$ ( $\geq 194\text{ °F}$ )

### Devices in integral mount design with single-compartment housing



$T_{\text{amb.}}$	Temperature resistance
$\leq 50\text{ °C}$ ( $\leq 122\text{ °F}$ )	$\geq 75\text{ °C}$ ( $\geq 167\text{ °F}$ )
$\leq 60\text{ °C}$ ( $\leq 140\text{ °F}$ )	$\geq 85\text{ °C}$ ( $\geq 185\text{ °F}$ )
$\leq 70\text{ °C}$ ( $\leq 158\text{ °F}$ )	$\geq 95\text{ °C}$ ( $\geq 203\text{ °F}$ )

### Sensor in remote mount design



$T_{\text{amb.}}$	Temperature resistance
$\leq 50\text{ °C}$ ( $\leq 122\text{ °F}$ )	$\geq 105\text{ °C}$ ( $\geq 221\text{ °F}$ )
$\leq 60\text{ °C}$ ( $\leq 140\text{ °F}$ )	$\geq 110\text{ °C}$ ( $\geq 230\text{ °F}$ )
$\leq 70\text{ °C}$ ( $\leq 158\text{ °F}$ )	$\geq 120\text{ °C}$ ( $\geq 248\text{ °F}$ )

For sensors in remote mount design, the wires in the connection box must be additionally insulated with the enclosed silicone hoses starting from ambient temperatures of  $T_{\text{amb.}} \geq 60\text{ °C}$  ( $\geq 140\text{ °F}$ ).

### Environmental and process conditions for model FCx4xx...


Ambient temperature $T_{\text{amb.}}$	-20 to 70 °C (-4 to 158 °F)
	-40 to 70 °C* (-40 to 158 °F)*
Measuring medium temperature	-40 to 205 °C (-40 to 400 °F)
$T_{\text{medium}}$	(-40 to 400 °F)
IP rating / NEMA rating	IP 65, IP 67 / NEMA 4X, Type 4X

\* Optional, with order code 'Ambient temperature range – TA9'

## ... 2 Use in potentially explosive atmospheres

### ... Temperature data

Measuring medium temperature for sensors in integral mount design with dual-compartment housing



#### Model FCx4xx-A1..., Model FCx4xx-U1... and FCx4xx-F1... in Zone 1, Division 1

The table shows the maximum permissible measuring medium temperature as a function of ambient temperature and temperature class.

Ambient temperature $T_{amb}$	Temperature class					
	T1	T2	T3	T4	T5	T6
$\leq 30\text{ °C}$ ( $\leq 86\text{ °F}$ )	205 °C (400 °F)*	205 °C (400 °F)*	195 °C (383 °F)*	130 °C (266 °F)	95 °C (203 °F)	80 °C (176 °F)
	130 °C (266 °F)	130 °C (266 °F)	130 °C (266 °F)			
$\leq 40\text{ °C}$ ( $\leq 104\text{ °F}$ )	205 °C (400 °F)*	205 °C (400 °F)*	195 °C (383 °F)*	130 °C (266 °F)	95 °C (203 °F)	80 °C (176 °F)
	130 °C (266 °F)	130 °C (266 °F)	130 °C (266 °F)			
$\leq 50\text{ °C}$ ( $\leq 122\text{ °F}$ )	205 °C (400 °F)*	205 °C (400 °F)*	195 °C (383 °F)*	130 °C (266 °F)	95 °C (203 °F)	80 °C (176 °F)
	130 °C (266 °F)	130 °C (266 °F)	130 °C (266 °F)			
$\leq 60\text{ °C}$ ( $\leq 140\text{ °F}$ )	205 °C (400 °F)*	205 °C (400 °F)*	195 °C (383 °F)*	130 °C (266 °F)	95 °C (203 °F)	80 °C (176 °F)
	130 °C (266 °F)	130 °C (266 °F)	130 °C (266 °F)			
$\leq 70\text{ °C}$ ( $\leq 158\text{ °F}$ )	205 °C (400 °F)*	205 °C (400 °F)*	195 °C (383 °F)*	130 °C (266 °F)	95 °C (203 °F)	80 °C (176 °F)
	130 °C (266 °F)	130 °C (266 °F)	130 °C (266 °F)			

\* Only with the 'Extended tower length – TE1, TE2 or TE3' order option


#### Model FCx4xx-A2..., Model FCx4xx-U2... and FCx4xx-F2... in Zone 2, Division 2

The table shows the maximum permissible measuring medium temperature as a function of ambient temperature and temperature class.

Ambient temperature $T_{amb}$	Temperature class					
	T1	T2	T3	T4	T5	T6
$\leq 30\text{ °C}$ ( $\leq 86\text{ °F}$ )	205 °C (400 °F)	205 °C (400 °F)	195 °C (383 °F)*	130 °C (266 °F)	95 °C (203 °F)	80 °C (176 °F)* 50 °C (122 °F)
$\leq 40\text{ °C}$ ( $\leq 104\text{ °F}$ )	205 °C (400 °F)	205 °C (400 °F)	195 °C (383 °F)*	130 °C (266 °F)	95 °C (203 °F)	—
$\leq 50\text{ °C}$ ( $\leq 122\text{ °F}$ )	205 °C (400 °F)	205 °C (400 °F)	195 °C (383 °F)*	130 °C (266 °F)	—	—
$\leq 60\text{ °C}$ ( $\leq 140\text{ °F}$ )	205 °C (400 °F)	205 °C (400 °F)	195 °C (383 °F)*	130 °C (266 °F)	—	—
$\leq 70\text{ °C}$ ( $\leq 158\text{ °F}$ )	205 °C (400 °F)*	205 °C (400 °F)*	195 °C (383 °F)*	130 °C (266 °F)	—	—
	130 °C (266 °F)	130 °C (266 °F)	130 °C (266 °F)			

\* Only with the 'Extended tower length – TE1, TE2 or TE3' order option

### Measuring medium temperature for sensors in integral mount design with single-compartment housing



#### Model FCx4xx-A2..., Model FCx4xx-U2... and FCx4xx-F2... in Zone 2, Division 2

The table shows the maximum permissible measuring medium temperature as a function of ambient temperature and temperature class.


Ambient temperature $T_{amb}$	Temperature class					
	T1	T2	T3	T4	T5	T6
$\leq 30\text{ °C}$ ( $\leq 86\text{ °F}$ )	205 °C (400 °F)	205 °C (400 °F)	195 °C (383 °F)	130 °C (266 °F)	95 °C (203 °F)	80 °C (176 °F)
$\leq 40\text{ °C}$ ( $\leq 104\text{ °F}$ )	205 °C (400 °F)	205 °C (400 °F)	195 °C (383 °F)	130 °C (266 °F)	95 °C (203 °F)	—
$\leq 50\text{ °C}$ ( $\leq 122\text{ °F}$ )	205 °C (400 °F)	205 °C (400 °F)	195 °C (383 °F)	130 °C (266 °F)	95 °C (203 °F)	—
$\leq 60\text{ °C}$ ( $\leq 140\text{ °F}$ )	205 °C (400 °F)	205 °C (400 °F)	195 °C (383 °F)	130 °C (266 °F)	—	—
$\leq 70\text{ °C}$ ( $\leq 158\text{ °F}$ )	205 °C (400 °F)	205 °C (400 °F)	195 °C (383 °F)	130 °C (266 °F)	—	—

\* Only with the 'Extended tower length – TE1, TE2 or TE3' order option

## ... 2 Use in potentially explosive atmospheres

### ... Temperature data

#### Measuring medium temperature for sensors in remote mount design



#### Model FCx4xx-A1..., Model FCx4xx-U1... and FCx4xx-F1... in Zone 1

The table shows the maximum permissible measuring medium temperature as a function of ambient temperature and temperature class.

Ambient temperature $T_{amb}$	Temperature class					
	T1	T2	T3	T4	T5	T6
$\leq 30\text{ °C}$ ( $\leq 86\text{ °F}$ )	205 °C (400 °F)	205 °C (400 °F)	195 °C (383 °F)	130 °C (266 °F)	95 °C (203 °F)	80 °C (176 °F)
$\leq 40\text{ °C}$ ( $\leq 104\text{ °F}$ )	205 °C (400 °F)	205 °C (400 °F)	195 °C (383 °F)	130 °C (266 °F)	95 °C (203 °F)	80 °C (176 °F)
$\leq 50\text{ °C}$ ( $\leq 122\text{ °F}$ )	205 °C (400 °F)	205 °C (400 °F)	195 °C (383 °F)	130 °C (266 °F)	95 °C (203 °F)	80 °C (176 °F)
$\leq 60\text{ °C}$ ( $\leq 140\text{ °F}$ )	205 °C (400 °F)	205 °C (400 °F)	195 °C (383 °F)	130 °C (266 °F)	95 °C (203 °F)	80 °C (176 °F)
$\leq 70\text{ °C}$ ( $\leq 158\text{ °F}$ )	205 °C (400 °F)	205 °C (400 °F)	195 °C (383 °F)	130 °C (266 °F)	95 °C (203 °F)	80 °C (176 °F)

#### Model FCx4xx-A2..., Model FCx4xx-U2... and FCx4xx-F2... in Zone 2, Division 2

The table shows the maximum permissible measuring medium temperature as a function of ambient temperature and temperature class.



Ambient temperature $T_{amb}$	Temperature class					
	T1	T2	T3	T4	T5	T6
$\leq 30\text{ °C}$ ( $\leq 86\text{ °F}$ )	205 °C (400 °F)*	205 °C (400 °F)*	195 °C (383 °F)*	130 °C (266 °F)*	95 °C (203 °F)*	80 °C (176 °F)
	195 °C (383 °F)	195 °C (383 °F)	130 °C (266 °F)	95 °C (203 °F)	80 °C (176 °F)	
$\leq 40\text{ °C}$ ( $\leq 104\text{ °F}$ )	205 °C (400 °F)*	205 °C (400 °F)*	195 °C (383 °F)*	130 °C (266 °F)*	95 °C (203 °F)*	—
	180 °C (356 °F)	180 °C (356 °F)	130 °C (266 °F)	95 °C (203 °F)	80 °C (176 °F)	
$\leq 50\text{ °C}$ ( $\leq 122\text{ °F}$ )	205 °C (400 °F)*	205 °C (400 °F)*	130 °C (266 °F)*	130 °C (266 °F)*	80 °C (176 °F)*	—
	140 °C (284 °F)	140 °C (284 °F)	130 °C (266 °F)	95 °C (203 °F)	60 °C (140 °F)	
$\leq 60\text{ °C}$ ( $\leq 140\text{ °F}$ )	205 °C (400 °F)*	205 °C (400 °F)*	130 °C (266 °F)*	130 °C (266 °F)*	—	—
	120 °C (248 °F)	120 °C (248 °F)	120 °C (248 °F)	95 °C (203 °F)		
$\leq 70\text{ °C}$ ( $\leq 158\text{ °F}$ )	180 °C (356 °F)*	180 °C (356 °F)*	130 °C (266 °F)*	130 °C (266 °F)*	—	—
	80 °C (176 °F)	80 °C (176 °F)	80 °C (176 °F)	80 °C (176 °F)		

\* Only with the 'Extended tower length – TE1, TE2 or TE3' order option

## Electrical data

### Overview

Standard / No explosion protection	Zone 2, 21 Division 2 and Zone 2, 21	Zone 1, 21 (Zone 0) Division 2 and Zone 1, 21
<b>ATEX:</b> –	<b>ATEX / UKEX:</b> II 3 G & II 2 D	<b>ATEX / UKEX:</b> II 1/2 (1) G & II 2 (1) D
<b>IECEX:</b> –	<b>IECEX:</b> Gc & Db	<b>IECEX:</b> (Ga) Gb & (Da) Db Ga/Gb & Db (Ga) Gb & (Da) Db
<b>USA:</b> –	<b>USA:</b> NI & DIP	<b>USA:</b> XP-IS & DIP
<b>Canada:</b> –	<b>Canada:</b> AEx ec & AEx tb Non-Incendive & Dust Ignition Proof Ex ec & Ex tb	<b>Canada:</b> AEx db ia & AEx ia tb XP-IS & DIP Ex db ia & Ex ia tb



#### (A) Power supply

- Type of protection ATEX / UKEX / IECEX: Increased safety 'Ex e'
- Type of protection USA / Canada: 'non IS'
- Maximum 250 Vrms
- Terminals: 1+, 2-, L, N, 

#### (B) Inputs / outputs, communication

- Type of protection ATEX / UKEX / IECEX: Either increased safety 'Ex e' or intrinsically safe 'Ex ia'
- Type of protection USA / Canada: Either 'non IS' or 'intrinsically safe IS'.
- When installing in 'Ex ia' or 'IS', suitable intrinsically safe isolation amplifiers must be used for the connection.
- Terminals: 31, 32, Uco, V1, V2, V3, V4, 41, 42, 51, 52

#### (C) Signal cable (remote mount design only)

- Terminals: A, B, UFE, GRN
- Type of protection ATEX / UKEX / IECEX: Increased safety 'Ex e'
- Type of protection USA / Canada: 'non IS'

### Note

When installing in 'Ex ia' or 'IS' type of protection, the type of protection is determined by the type of electrical connection. The information in **Changing the type of protection** on page 26 must be observed when changing the type of protection!

## ... 2 Use in potentially explosive atmospheres

### ... Electrical data

Zone 2, 21 and Division 2 – Model: FCx4xx-A2..., FCx4xx-U2... and FCx4xx-F2...

Outputs on basic device	Operating values (general)		Type of protection – 'nA' / 'NI'	
	U <sub>N</sub>	I <sub>N</sub>	U <sub>N</sub>	I <sub>N</sub>
<b>Current / HART output 31 / U<sub>CO</sub>, active</b> Terminals 31 / U <sub>CO</sub>	30 V	30 mA	30 V	30 mA
<b>Current / HART output 31 / 32, passive</b> Terminals 31 / 32	30 V	30 mA	30 V	30 mA
<b>Digital output 41 / 42, active*</b> Terminals 41 / 42 and V1 / V2*	30 V	30 mA	30 V	30 mA
<b>Digital output 41 / 42, active**</b> Terminals 41 / 42 and U <sub>CO</sub> / 32**	30 V	30 mA	30 V	30 mA
<b>Digital output 41 / 42, passive</b> Terminals 41 / 42	30 V	25 mA	30 V	25 mA
<b>Digital output 51 / 52, active*</b> Terminals 51 / 52 and V1 / V2*	30 V	30 mA	30 V	30 mA
<b>Digital output 51 / 52, passive</b> Terminals 51 / 52	30 V	30 mA	30 V	30 mA

All outputs are electrically isolated from each other and from the power supply.

Digital outputs 41 / 42 and 51 / 52 are not electrically isolated from each other. Terminals 42 / 52 have the same potential.

\* Only in conjunction with additional '24 V DC loop power supply (blue)' plug-in card in slot OC1.

\*\* Only in conjunction with current output U<sub>CO</sub> / 32 in 'Powermode', see **Current output U<sub>CO</sub> / 32 as loop power supply for digital output 41 / 42 or 51 / 52** on page 51.

Inputs and outputs with optional plug-in cards	Operating values (general)		Type of protection – 'nA' / 'NI'	
	U <sub>N</sub>	I <sub>N</sub>	U <sub>N</sub>	I <sub>N</sub>
<b>Current output V3 / V4, active*</b> Terminals V3 / V4 and V1 / V2*	30 V	30 mA	30 V	30 mA
<b>Current output V1 / V2, passive**</b> <b>Current output V3 / V4, passive**</b> Terminals V1 / V2** or V3 / V4**	30 V	30 mA	30 V	30 mA
<b>Digital output V3 / V4, active*</b> Terminals V3 / V4 and V1 / V2*	30 V	25 mA	30 V	25 mA
<b>Digital output V1 / V2, passive**</b> <b>Digital output V3 / V4, passive**</b> Terminals V1 / V2** or V3 / V4**	30 V	30 mA	30 V	30 mA
<b>Digital input V3 / V4, active*</b> Terminals V3 / V4 and V1 / V2	30 V	3,45 mA	30 V	3,45 mA
<b>Digital input V1 / V2, passive**</b> <b>Digital input V3 / V4, passive**</b> Terminals V1 / V2** or V3 / V4**	30 V	3,45 mA	30 V	3,45 mA
<b>Digital output V1 / V2, active*</b> <b>Digital output V3 / V4, active*</b> Terminals V1 / V2** or V3 / V4**	24 V	22,5 mA	30 V	30 mA
<b>Modbus® / PROFIBUS DP®</b> Terminals V1 / V2	30 V	30 mA	30 V	30 mA
<b>Ethernet card</b> Ethernet (various protocols) Port 1 / Port 2	57 V	417 mA	57 V	417 mA
<b>Ethernet card in connection with Power over Ethernet (POE card)</b> Ethernet (various protocols) Port 1 / Port 2	57 V	417 mA	57 V	417 mA

\* Only in conjunction with additional '24 V DC loop power supply (blue)' plug-in card in slot OC1.

\*\* The terminal assignment depends on the model number or the slot assignments. For connection examples, see **Connection examples** on page 55.

## ... 2 Use in potentially explosive atmospheres

### ... Electrical data

Zone 1 ,21 and Division 1 – Model: FCx4xx-A1..., FCx4xx-U1... and FCx4xx-F1...

Type of protection	'e' / 'XP'		'ia' / 'IS'											
	$U_M$ [V]	$I_M$ [A]	$U_O$ [V]	$U_I$ [V]	$I_O$ [mA]	$I_I$ [mA]	$P_O$ [mW]	$P_I$ [mW]	$C_O$ [nF]	$C_I$ [nF]	$C_{OPA}$ [nF]	$C_{IPA}$ [nF]	$L_O$ [mH]	$L_I$ [mH]
<b>Outputs on basic device</b>														
<b>Current / HART output 31 / <math>U_{CO}</math>, active</b> Terminals 31 / $U_{CO}$	30	0.2	30	30	115	115	815	815	10	10	5	5	0.08	0.08
<b>Current / HART output 31 / 32, passive</b> Terminals 31 / 32	30	0.2	—	30	—	115	—	815	—	27	—	5	0.08	0.08
<b>Digital output 41 / 42, active*</b> Terminals 41 / 42 and V1 / V2*	30	0.1	27.8	30	119	30	826	225	20	20	29	29	0.22	0.22
<b>Digital output 41 / 42, active**</b> Terminals 41 / 42 and $U_{CO}$ / 32**	30	0.1	30	30	115	115	826	225	16	16	10	10	0.08	0.08
<b>Digital output 41 / 42, passive</b> Terminals 41 / 42	30	0.1	—	30	—	30	—	225	—	27	—	5	—	0.08
<b>Digital output 51 / 52, active*</b> Terminals 51 / 52 and V1 / V2*	30	0.1	27.8	30	119	30	826	225	20	20	29	29	0.22	0.22
<b>Digital output 51 / 52, passive</b> Terminals 51 / 52	30	0.1	—	30	—	30	—	225	—	27	—	5	—	0.08

All outputs are electrically isolated from each other and from the power supply.

Digital outputs 41 / 42 and 51 / 52 are not electrically isolated from each other. Terminals 42 / 52 have the same potential.

\* Only in conjunction with additional '24 V DC loop power supply (blue)' plug-in card in slot OC1.

\*\* Only in conjunction with current output  $U_{CO}$  / 32 in 'power mode', see **Current output  $U_{CO}$  / 32 as loop power supply for digital output 41 / 42 or 51 / 52** on page 51.

Type of protection	'e' / 'XP'		'ia' / 'IS'											
	U <sub>M</sub> [V]	I <sub>M</sub> [A]	U <sub>O</sub> [V]	U <sub>I</sub> [V]	I <sub>O</sub> [mA]	I <sub>I</sub> [mA]	P <sub>O</sub> [mW]	P <sub>I</sub> [mW]	C <sub>O</sub> [nF]	C <sub>I</sub> [nF]	C <sub>OPA</sub> [nF]	C <sub>IPA</sub> [nF]	L <sub>O</sub> [mH]	L <sub>I</sub> [mH]
<b>Inputs and outputs with optional plug-in cards</b>														
<b>Current output V3 / V4, active*</b> Terminals V3 / V4 and V1 / V2*	30	0.1	27.8	30	119	30	826	225	29	29	117	117	0.4	0.4
<b>Current output V1 / V2, passive**</b> <b>Current output V3 / V4, passive**</b> Terminals V1 / V2** or V3 / V4**	30	0.1	—	30	—	68	—	510	—	45	—	59	—	0.27
<b>Digital output V3 / V4, active*</b> Terminals V3 / V4 and V1 / V2*	30	0.1	27.8	30	119	68	826	225	17	17	31	31	0.4	0.4
<b>Digital output V1 / V2, passive**</b> <b>Digital output V3 / V4, passive**</b> Terminals V1 / V2** or V3 / V4**	30	0.1	—	30	—	30	—	225	—	13	—	16	—	0.27
<b>Digital input V3 / V4, active*</b> Terminals V3 / V4 and V1 / V2	30	0.1	27.8	30	119	3.45	826	25.8	17	17	31	31	0.4	0.4
<b>Digital output V1 / V2, active***</b> <b>Digital output V3 / V4, active***</b> Terminals V1 / V2** or V3 / V4	30	0.7	—	—	—	—	—	—	—	—	—	—	—	—
<b>Digital input V1 / V2, passive*</b> <b>Digital input V3 / V4, passive*</b> Terminals V1 / V2** or V3 / V4**	30	0.1	—	30	—	3.45	—	25.8	—	13	—	16	—	0.27
<b>Modbus® / PROFIBUS DP®</b> Terminals V1 / V2	30	0.1	4.2	4.2	150	150	150	150	5300	5300	0.06	0.06	0.14	0.14

\* Only in conjunction with additional '24 V DC loop power supply (blue)' plug-in card in slot OC1.

\*\* The terminal assignment depends on the model number or the slot assignments. For connection examples, see **Connection examples** on page 55.

\*\*\* Not available as intrinsically safe version.

## ... 2 Use in potentially explosive atmospheres

### ... Electrical data

#### Special connection conditions

##### Note

The AS plug-in card (24 V DC loop power supply) may only be used to power the internal inputs and outputs on the device. It must not be used to power external circuits!

##### Note

If the protective earth (PE) is connected in the flowmeter's terminal box, you must ensure that no dangerous potential difference can arise between the protective earth (PE) and the potential equalization (PA) in areas with explosion risk.

##### Note

- For devices with a power supply of 11 to 30 V DC, on-site external overvoltage protection must be provided.
- You must make sure that the overvoltage is limited to 140 % (= 42 V DC) of the maximum operating voltage.

##### Note

The safety requirements for intrinsically safe circuits in the EC type examination certificate of the device must be complied with.

The output circuits are designed so that they can be connected to both intrinsically-safe and non-intrinsically-safe circuits.

- Combining intrinsically safe and non-intrinsically safe circuits is not permitted.
- On intrinsically safe circuits, potential equalization should be established along the entire length of the cable used for the signal outputs.
- The rated voltage of the non-intrinsically safe circuits is  $U_M = 30 \text{ V}$ .
- Intrinsic safety is preserved If the rated voltage  $U_M = 30 \text{ V}$  is not up-scaled when connections are established to non-intrinsically safe external circuits.
- The information in **Changing the type of protection** on page 26 must be observed when changing the type of protection.

Devices connected to the relevant equipment must not be operated at over 250  $V_{\text{rms}}$  AC or 250 V DC to ground.

Installation in accordance with ATEX/IECEX or UKEX must comply with the applicable national and international standards and directives.

Installation in the USA or Canada must comply with ANSI / ISA RP 12.6, 'Installation of intrinsically safe systems for hazardous (classified) locations', the 'National Electrical Code (ANSI / NFPA 70), sections 504, 505' and the 'Canadian electrical code (C22.1-02)'.

Apparatus connected to the flowmeter must have appropriate explosion protection approval in accordance with the Entity concept.

The apparatus must have intrinsically safe circuits.

The apparatus must be installed and connected in accordance with the relevant manufacturer documentation.

The electrical specifications in **Electrical data** on page 17 must be observed.

#### Active digital output

### DANGER

#### Risk of injury caused by live parts!

Option cards for the active digital output are intended only for use in potentially explosive atmospheres as the 'increased safety' (Ex-e) IP rating and therefore may not be used as an intrinsically safe circuit.

If these optional active plug-in cards are used in combination with other option cards, all the option cards used and all pre-installed output current circuits must also use the 'Increased safety' (Ex-e) IP rating.

The option of changing of IP rating is not permitted in connection with Active Pulse option cards.

## Ethernet communication

### **DANGER**

#### **Explosion hazard due to improper installation!**

Ethernet Option Cards are designed only for use in hazardous applications Zone 2 / Division 2.

The output circuits are designed so that different topologies such as daisy chain or point to point can be connected. See Installation diagram for detailed information.

- It is not permitted to combine both topologies.
- Ethernet communication is only available for installations in Zone 2/Division 2.
- The rated voltage of these non-intrinsically safe circuits are UM = 57 V.

## Installation instructions

### **ATEX, IECEx and UKEX**

The installation, commissioning, maintenance and repair of devices in potentially explosive atmospheres must only be carried out by appropriately trained personnel. Works may be carried out only by persons, whose training has included instructions on different types of protection and installation techniques, concerned rules and regulations as well as general principles of zoning.

The person must possess the appropriate competences for the type of work to be conducted.

The safety instructions for electrical apparatus in potentially explosive areas must be in accordance with Directive 2014/34/EU (ATEX) or British Regulations (UKEX) and IEC 60079-14 (Installation of electrical equipment in potentially explosive areas).

Comply with the applicable regulations for the protection of employees to ensure safe operation.

### **cFMus**

The installation, commissioning, maintenance and repair of devices in areas with explosion hazard must only be carried out by appropriately trained personnel.

The operator must strictly observe the applicable national regulations with regard to installation, function tests, repairs, and maintenance of electrical devices. (e. g. NEC, CEC).

### **Use in areas exposed to combustible dust**

When using the device in areas exposed to combustible dusts (dust ignition), EN 60079-31 as well as the following points must be observed:

- The maximum surface temperature of the device may not up-scale 85 °C (185 °F).
- The process temperature of the attached piping may up-scale 85 °C (185 °F).
- Approved dust-proof cable glands must be used when operating in Zone 21, 22 or in Class II, Class III.

### **Sensor insulation**

Observe the notes in **Sensor insulation** on page 33 if the sensor should be insulated.

Observe the information in **Temperature data** on page 13 regarding temperature class and cable specification.

### **Opening and closing the housing**

#### **DANGER**

#### **Danger of explosion if the device is operated with the transmitter housing or terminal box open!**

Before opening the transmitter housing or the terminal box, note the following points:

- A valid fire permit must be present.
- Make sure that there is no explosion hazard.
- Switch off the power supply and wait for  $t > 20$  minutes before opening.

#### **WARNING**

#### **Risk of injury due to live parts!**

When the housing is open, contact protection is not provided and EMC protection is limited.

- Before opening the housing, switch off the power supply.

See also **Opening and closing the housing** on page 39.

Only original spare parts must be used to seal the housing.

### **Note**

Spare parts can be ordered from ABB Service.

[www.abb.com/contacts](http://www.abb.com/contacts)

## ... 2 Use in potentially explosive atmospheres

### ... Installation instructions

#### Cable entries in accordance with ATEX/IECEX and UKEX


The devices are supplied with cable glands installed (certified in accordance with ATEX or IECEx).

- The use of standard cable glands and closures is prohibited.
- The black plugs in the cable glands are intended to provide protection during transport.
- The outside diameter of the connection cable must measure between 6 mm (0.24 in) and 12 mm (0.47 in) to guarantee the required tightness.
- Black cable glands are installed by default when the device is supplied. If signal outputs are connected to intrinsically safe circuits, replace the black cap on the corresponding cable gland with the blue one supplied.
- Any unused cable entries must be sealed before commissioning in accordance with the applicable standards.

#### Note

Low-temperature version devices (optional, up to  $-40\text{ }^{\circ}\text{C}$  ( $-40\text{ }^{\circ}\text{F}$ ) ambient temperature) are supplied with metal cable glands due to the required temperature resistance.

#### Cable entries in accordance with cFMus



① Transport protection plugs

Figure 1: Cable entry

The devices are delivered with  $\frac{1}{2}$  in NPT threads with transport protection plugs.

- Unused cable entries must be sealed off prior to commissioning using either approved pipe fittings or cable glands in accordance with national regulations (NEC, CEC).
- Make sure that the pipe fittings, cable glands and, if applicable, sealing plugs are installed properly and are leak-tight.
- If the device is to be operated in areas with combustible dusts, a threaded pipe connection or cable gland with suitable approval must be used.
- The use of standard cable glands and closures is prohibited.

#### Note

Devices which are certified for use in North America are supplied with a  $\frac{1}{2}$  in NPT thread only and without cable glands.

#### Specific Conditions of Use

### ⚠ WARNING

#### Special conditions for safe use!

The painted surface of the CoriolisMaster Flowmeters may store electrostatic charge and become a source of ignition in applications with a low relative humidity ( $< \sim 30\%$  relative humidity) even where the painted surface is relatively free of surface contamination such as dirt, dust, or oil.

- Guidance on protection against the risk of ignition due to electrostatic discharge can be found in PD CLC/TR 60079-32-1 and IEC TS 60079-32-1.
- Cleaning of the painted surface should only be done with a damp cloth.
- The instruction manual for the CoriolisMaster details the permitted Temperature Classification and Ambient Temperature ratings as influenced by the Process Medium temperature.
- Contact the manufacturer for specific flamepath joint details during repair of flameproof Ex d apparatus.
- For models with option m = C provision shall be made external to the equipment, to provide the transient protection device to be set at a level not exceeding 140% of the peak rated voltage value of 42V.

## Electrical connections

### Note

The temperature at the cable entries of the device depends on the design, the measuring medium temperature  $T_{\text{medium}}$  and the ambient temperature  $T_{\text{amb}}$ .

For the electric connection of the device, use only cables with sufficient temperature resistance in accordance with the tables at **Temperature resistance for the connecting cable** on page 13.

### Grounding

The sensor must be grounded in accordance with the applicable international standards.

For remote mount design, the sensor and the transmitter housing must be connected via potential equalization.

Perform grounding of the device in accordance with **Terminal assignment** on page 49.

In accordance with NEC standards, an internal ground connection is present in the device between the sensor and the transmitter.

Perform grounding of the device in accordance with **Terminal assignment** on page 49.

### Power supply terminal cover

Make sure that the power supply terminal cover is closed tightly, see also **Connection on the device** on page 58.

## Process sealing

In accordance with 'North American Requirements for Process Sealing between Electrical Systems and Flammable or Combustible Process Fluids'.

### Note

The device is suitable for use in Canada.

- For use in Class II, Groups E, F and G, a maximum surface temperature of 165 °C (329 °F) may not be up-scaled.
- All cable (conduits) should be sealed from the device within a distance of 18 in (457 mm).

ABB flowmeters are designed for the worldwide industrial market and are suitable for functions such as the measurement of flammable and combustible liquids and can be installed in process pipes.

Connecting devices with cable (conduits) to the electric installation makes it possible for measuring media to reach the electric system.

To prevent measuring media from seeping into the electric installation, the devices are equipped with process gaskets which meet requirements in accordance with ANSI / ISA 12.27.01.

Coriolis mass flowmeters are designed as 'Single Seal Devices'. With the TE2 order option, 'Extended tower length - insulation capacity with dual gasket', the devices can be used as a 'Dual Seal Devices'.

In accordance with the requirements of standard ANSI / ISA 12.27.01, the existing operating limits of temperature, pressure and pressure bearing parts must be reduced to the following limit values:

Limit values	
Flange or pipe material	No limitations
Nominal sizes	DN 15 to DN 150 (½ to 6 in)
Operating temperature	-50 °C to 205 °C (-58 °F to 400 °F)
Process pressure	PN 100 / Class 600

## ... 2 Use in potentially explosive atmospheres

### Operating instructions

#### Protection against electrostatic discharges

#### **⚠ DANGER**

##### Explosion hazard due to electrostatic charging!

The painted surface of the device can store electrostatic charges.

As a result, the housing can form an ignition source due to electrostatic discharges in the following conditions:

- The device is operated in environments with a relative humidity of  $\leq 30\%$ .
- The painted surface of the device is thereby relatively free from impurities such as dirt, dust or oil.
- Instructions on avoiding ignition in potentially explosive environments due to electrostatic discharges in accordance with PD CLC/TR 60079-32-1 and IEC TS 60079-32-1 must be complied with!

#### Instructions on cleaning

The painted surface of the device must be cleaned only using a moist cloth.

#### Changing the type of protection


If you are installing in Zone 1 / Div. 1, the current outputs and digital outputs of models FCB430/450 and FCH430/450 can be operated with different types of protection:

- Current output and digital output in the 'intrinsically safe ia / IS' design
- Current output and digital output in non-intrinsically safe design

If a device that is already operational is operated with a different type of protection, the following measures must be implemented/insulation checks performed in accordance with applicable standards.

Original installation	New installation	Necessary test steps
<b>Zone 1 / Div. 1:</b> Current outputs and digital outputs in non-intrinsically safe design	<b>Zone 1 / Div. 1:</b> Current outputs and digital outputs in intrinsically safe ia / IS design	<ul style="list-style-type: none"> <li>• 500 V AC/1min or <math>500 \times 1.414 = 710</math> V DC/1min</li> <li>• Test between terminals A / B, <math>U_{FE}</math>, /GND, <math>U_{CO}</math> / 32, 31 / 32, 41 / 42, 51 / 52, V1 / V2 and V3 / V4, and terminals A, B, <math>U_{FE}</math>, GND, <math>U_{CO}</math>, 31, 32, 41, 42, 51, 52, V1, V2, V3, V4 and the housing.</li> <li>• When this test is performed, no voltage flashover is permitted in or on the device.</li> <li>• Optical evaluation particularly of the electronic circuit boards, no visible damage or evidence of explosion.</li> </ul>
<b>Zone 1 / Div. 1:</b> Current outputs and digital outputs in intrinsically safe ia(ib) / IS design	<b>Zone 1 / Div. 1:</b> Current outputs and digital outputs in non-intrinsically safe design	<ul style="list-style-type: none"> <li>• Visual inspection, no damage visible on the threads (cover, <math>\frac{1}{2}</math> in NPT cable glands).</li> </ul>

Devices which are approved for use in potentially explosive atmospheres have an additional warning plate.



① **WARNING!** – Danger due to electrostatic discharge.

Figure 2: Additional warning plate

#### Repair

Devices of type of protection 'd / XP' are equipped with flameproof joints in the housing. Contact ABB before commencing repair work.

### 3 Use in hazardous areas in accordance with EAC TR-CU-012

#### Note

- An additional document with information on EAC-Ex certification is available for measuring systems that are used in potentially explosive atmospheres in accordance with EAC TR-CU-012.
- The information on EAC-Ex certification is an integral part of this instruction. As a result, it is crucial that the installation guidelines and connection values it lists are also observed. The icon on the name plate indicates the following:



Information on EAC-Ex certification is available for free download at the following link. Alternatively simply scan the QR code.



<INF/FCX100/FCX400/EAC-Ex-X8>

## 4 Product identification

### Name plate

**Note**

The name plates displayed are examples. The device identification plates affixed to the device can differ from this representation.




Figure 3: Name plate (sample)

The marking is provided on the name plate and on the sensor itself in accordance with the Pressure Equipment Directive (PED).




Figure 4: PED marking (example)

The marking is dependent on the nominal diameter (> DN 25 or ≤ DN 25) of the sensor (also refer to Pressure Equipment Directive 2014/68/EU).

#### Pressure equipment within the scope of the Pressure Equipment Directive

The number of the notified body is specified underneath the CE mark to confirm that the device meets the requirements of the Pressure Equipment Directive.

The respective fluid group in accordance with the Pressure Equipment Directive is indicated under PED.

Example: Fluid group 1 = hazardous fluids, gaseous.

#### Pressure equipment beyond the scope of the Pressure Equipment Directive

In PED the exception to Article 4 (3) of the Pressure Equipment Directive is specified.

The pressure equipment is classified in the SEP (= Sound Engineering Practice) 'Good Engineering Practice' category.

## 5 Transport and storage

Observe the following instructions:

- Do not expose the device to humidity during transport. Pack the device accordingly.
- Pack the device so that it is protected against vibrations during transport, for example, by using air-cushioned packing.

### Inspection

Check the devices immediately after unpacking for possible damage that may have occurred from improper transport. Details of any damage that has occurred in transit must be recorded on the transport documents. All claims for damages must be submitted to the shipper without delay and before installation.

### Transporting the device

#### **⚠ DANGER**

**Life-threatening danger due to suspended loads.** In the case of suspended loads, a danger of the load falling exists.

- Standing under suspended loads is prohibited.

#### **⚠ WARNING**

**Risk of injury due to device slipping.**

The device's center of gravity may be higher than the harness suspension points.

- Make sure that the device does not slip or turn during transport.
- Support the device laterally during transport.




Figure 5: Transport instructions

Observe the following when transporting the device to the measuring location:

- Observe the weight details of the device in the data sheet.
- Use only approved hoisting slings for crane transport.
- Do not lift devices by the transmitter housing or terminal box.
- The center of gravity of the device may be located above the harness suspension points.

## ... 5 Transport and storage

### Storing the device

Bear the following points in mind when storing devices:

- Store the device in its original packaging in a dry and dust-free location.
- Observe the permitted ambient conditions for transport and storage.
- Avoid storing the device in direct sunlight.
- In principle, the devices may be stored for an unlimited period. However, the warranty conditions stipulated in the order confirmation of the supplier apply.

#### Ambient conditions

The ambient conditions for the transport and storage of the device correspond to the ambient conditions for operation of the device.

Adhere to the device data sheet!

### Returning devices

Address for returns:

Please contact Customer Center Service according to page 5 for nearest service location.

## 6 Installation

### General installation conditions

#### Installation location and assembly

Note the following points when selecting the installation location and when mounting the sensor:

- The ambient conditions (IP rating, ambient temperature range  $T_{\text{ambient}}$ ) of the device must be adhered to at the installation location.
- Sensors and transmitters must not be exposed to direct sunlight. If necessary, provide a suitable means of sun protection on site. The limit values for ambient temperature  $T_{\text{ambient}}$  must be adhered to.
- On flange devices, ensure that the counterflanges of the piping are aligned plane parallel. Only install flange devices with suitable gaskets.
- Prevent the sensor from coming into contact with other objects.
- The device is designed for industrial applications. No special EMC protective measures are required if the electromagnetic fields and interference at the installation location of the device comply with 'Best Practice' (in accordance with the standards listed in the declaration of conformity).  
Maintain a suitable distance from electromagnetic fields and interference that extend beyond the usual dimensions.

#### Seals

Users are responsible for selecting and mounting suitable gaskets (material, shape).

Note the following points when selecting and mounting gaskets:

- Use gaskets made from a material that is compatible with the measuring medium and measuring medium temperature.
- Gaskets must not extend into the flow area, since possible turbulence may influence the accuracy of the device.

#### Calculating pressure loss

Pressure loss depends on the properties of the medium and the flow rate.

A good aid for pressure loss calculation is the Online ABB Product Selection Assistant (PSA) for flow at

[www.abb.com/flow-selector](http://www.abb.com/flow-selector).

### Brackets and supports

No special supports or damping are required for the device when the device is used and installed as intended.

In systems designed in accordance with 'Best Practice', the forces acting on the device are already sufficiently absorbed. This is also true of devices installed in series or in parallel.

For heavier devices, it is advisable to use additional supports / brackets on site. Doing this prevents damage to the process connections and piping from lateral forces.

Please observe the following points:

- Mount two supports or brackets symmetrically in the immediate vicinity of the process connections.
- Do not fasten any supports or brackets to the housing of the flowmeter sensor.

### Note

For increased vibration load, such as for example on ships, the use of the 'CL1' marine design is recommended.

### Inlet section

The sensor does not require any inlet section.

The devices can be installed directly before/after manifolds, valves or other equipment, provided that no cavitation is caused by this equipment.

## Mounting position

The flowmeter operates in any mounting position.

Depending on the measuring medium (liquid or gas) and the measuring medium temperature, certain mounting positions are preferable to others. For this purpose, consider the following examples.

The preferred flow direction is indicated by the arrow on the sensor. The flow will be displayed as positive.


The specified measuring accuracy can be achieved only in the calibrated flow direction (for forward flow calibration, this is only in the direction of the arrow; for the optional forward flow and reverse flow calibration, this can be in both flow directions).

### Liquid measuring media

Observe the following points to avoid measuring errors:

- The meter tubes must always be completely filled with the measuring medium.
- The gases dissolved in the measuring medium must not leak out. To safeguard this, a minimum back pressure of 0.2 bar (2.9 psi) is recommended.
- The minimum vapor pressure of the measuring medium must be maintained when there is negative pressure in the meter tube or when liquids are gently simmering.
- During operation, there must be no phase transitions in the measuring medium.

### Vertical installation



- ① Supply tank
- ② Sensor
- ③ Piping constriction / orifice

- ④ Turn-off device
- ⑤ Filling tank

Figure 6: Vertical installation

## ... 6 Installation

### ... General installation conditions

- (A) For vertical installation in a riser, no special measures are required.
- (B) For vertical installation in a downpipe, a piping constriction or an orifice must be installed below the sensor. Doing this prevents the sensor from draining during the measurement.

#### Horizontal installation




Figure 7: Horizontal installation

- (A) For liquid measuring media and horizontal installation, the transmitter and terminal box must point upward. If a self-draining installation is required, the sensor must be mounted at an incline of  $\geq 30^\circ$ .
- (B) Installing the sensor at the highest point of the piping leads to an increased number of measuring errors due to the accumulation of air or the formation of gas bubbles in the meter tube.

#### Gaseous measuring media

Observe the following points to avoid measuring errors:

- Gases must be dry and free of liquids and condensates.
- Avoid the accumulation of liquids and the formation of condensate in the meter tube.
- During operation, there must be no phase transitions in the measuring medium.

If there is a risk of condensate formation when using gaseous measuring media, note the following:

Ensure that condensates cannot accumulate in front of the sensor.

If this cannot be avoided, we recommend that the sensor is installed vertically with a downward flow direction.

#### Vertical installation

For vertical installation, no special measures are required.

#### Horizontal installation




Figure 8: Horizontal installation

- (A) For gaseous measuring media and horizontal installation, the transmitter and terminal box must point downward.
- (B) Installing the sensor at the lowest point of the piping leads to an increased number of measuring errors due to the accumulation of liquid or the formation of condensates in the meter tube.

### Turn-off devices for the zero point adjustment




Figure 9: Mounting options for turn-off devices (example)

To guarantee the conditions for zero point balancing under operating conditions, turn-off devices are required in the piping:

- Ⓐ At least on the outlet side when the transmitter is mounted in horizontal position
- Ⓑ At least on the inlet side when the transmitter is mounted in vertical position.
- Ⓒ In order to perform balancing during an ongoing process, it is advisable to mount a bypass pipe.

### Sensor insulation




Figure 10: Installation at  $T_{\text{medium}} -50^{\circ}\text{C}$  to  $205^{\circ}\text{C}$  ( $-58$  to  $400^{\circ}\text{F}$ )

The sensor may only be insulated in conjunction with the option TE1 'Extended tower length for sensor insulation' or TE2 'Extended tower length – insulation capacity with dual gasket,' as shown in Figure 10.

### Heat tracing of the sensor

When operating the sensor in conjunction with heat tracing, the temperature at point Ⓒ (Figure 10)  $100^{\circ}\text{C}$  ( $212^{\circ}\text{F}$ ) may not be exceeded at any time!

### Installation in EHEDG-compliant installations

#### ⚠ WARNING

##### Risk of poisoning!

Bacteria and chemical substances can contaminate or pollute pipeline systems and the materials they are made of.

- In EHEDG-compliant installations, the instructions below must be observed.
- The required self-draining functionality of the sensor can only be guaranteed when the vertical mounting position or horizontal mounting position at a  $30^{\circ}$  incline is used. Refer to **Liquid measuring media** on page 31.
- The combination of process connections and gaskets selected by the operator may comprise only EHEDG-compliant components. Please note the information in the latest version of the EHEDG Position Paper: 'Hygienic Process connections to use with hygienic components and equipment' in this regard.

## ... 6 Installation

### ... General installation conditions

#### Devices for legal metrology




Figure 11: Sealing in accordance with MID / OIML R117 (example)

On devices for legal metrology, the hardware write protection must be activated after commissioning in many cases. This prevents a change in the parameterization of the devices.

#### Hardware settings on page 74

To prevent deactivation of the hardware write protection or other manipulations during operation, the transmitter housing and the sensor housing connection box (with remote mount design) must be sealed.

For this purpose, a seal kit is available at ABB.

For the assembly of the seal, please observe the separate 'IN/FCX100/FCX400/MID/OIML-XA' instructions.

### Process conditions

#### Temperature limits °C (°F)

##### Note

When using the device in potentially explosive atmospheres, note the additional temperature data in **Temperature data** on page 13!

#### Measuring medium temperature $T_{\text{medium}}$

- FCx430: -50 to 160 °C (-58 to 320 °F)
- FCx450: -50 to 205 °C (-58 to 401 °F)

In devices with order code 'Extended tower length – TE3', the measuring medium temperature must be limited to a maximum of 140 °C (284 °F) from an ambient temperature of  $\geq 65$  °C (149 °F).

#### Temperature Data

	Standard	Optional
Ambient temperature	-20 to 70 °C (-4 to 158 °F)	-40 to 70 °C (-40 to 158 °F)
Storage temperature	-20 to 70 °C (-4 to 158 °F)	—

##### Note

When operating below -20 °C (-4 °F), the LCD display can no longer be read and the electronics should be operated with as few vibrations as possible.

Full functionality is assured at temperatures above -20 °C (-4 °F). Storage temperature of the devices in the 'Standard' version without cable glands is also -40 to 70 °C (-40 to 158°F).

### Pressure ratings

The maximum permissible operating pressure is determined by the respective process connection, the temperature of the medium to be measured, the screws, and the gasket material. For an overview of available pressure ratings, see Device overview in the data sheet.

### Housing as a protective device (optional)

#### Order code PR5

Maximum burst pressure 60 bar (870 psi)

#### Optional order code PR6 and PR7 on request

- Increased burst pressures up to 100 bar (1450 psi), possible for nominal diameters DN 15 to 100 (½ to 4 in.).
- Increased burst pressures up to 150 bar (2175 psi), possible for nominal diameters DN 15 to 80 (½ to 3 in.).
- Purge connections are available on request.

### Pressure Equipment Directive

Conformity assessment in accordance with Category III, fluid group 1, gas. The pressure equipment is designed for load changes in accordance with the AD2000 specification sheet S1 Chapter 1.4 a) and b).

Note the corrosion resistance of the meter tube materials in relation to the measuring medium.

## Material load for process connections

### Note

You can reference the availability of the different process connections in the Online ABB Product Selection Assistant (PSA) for flow [www.abb.com/flow-selector](http://www.abb.com/flow-selector).

- Not all connections shown here are available in all the devices and designs.
- The permissible material load of the device can additionally differ from the material load of the connection. The permissible limit values (pressure rating / measuring medium temperature  $T_{\text{medium}}$ ) can be found on the name plate.

Design	Nominal diameter	PS <sub>max</sub>	TS <sub>max</sub>	TS <sub>min</sub>
Pipe fitting (DIN 11851)	DN 15 to DN 40 (½ to 1½ in)	40 bar (580 psi)	140 °C (284 °F)	-40 °C (-40 °F)
	DN 50 to DN 100 (2 to 4 in)	25 bar (363 psi)	140 °C (284 °F)	-40 °C (-40 °F)
Pipe fitting (SMS 1145)	DN 25 to DN 80 (1 to 3 in)	6 bar (87 psi)	140 °C (284 °F)	-40 °C (-40 °F)
Tri-Clamp (DIN 32676)	DN 15 to DN 50 (½ to 2 in)	16 bar (232 psi)	140 °C (284 °F)	-40 °C (-40 °F)
	DN 65 to DN 100 (2½ to 4 in)	10 bar (145 psi)	140 °C (284 °F)	-40 °C (-40 °F)
ASME BPE Clamp	< DN 80 (< 3 in)	17,1 bar (248 psi)	121 °C (249,8 °F)	-40 °C (-40 °F)
	DN 80 (< 3 in)	15,5 bar (224,8 psi)	121 °C (249,8 °F)	-40 °C (-40 °F)
	DN 100 (< 4 in)	12,9 bar (187,1 psi)	121 °C (249,8 °F)	-40 °C (-40 °F)
NPT female thread	DN15 stainless steel 1.4404	179 bar (2596,2 psi)	150 °C (302 °F)	-40 °C (-40 °F)
	DN15 stainless steel 1.4404	163 bar (2364,1 psi)	205 °C (401 °F)	-40 °C (-40 °F)
	DN15 HC22 2.4602	267 bar (3872,5 psi)	150 °C (302 °F)	-40 °C (-40 °F)
	DN15 HC22 2.4602	243 bar (3524,4 psi)	205 °C (401 °F)	-40 °C (-40 °F)

## ... 6 Installation

### ... Material load for process connections

#### Material load curves for flange devices




Figure 12: Stainless steel DIN flange 1.4404 (316L) up to DN 200 (8 in.)




Figure 14: Nickel alloy DIN flange up to DN 200 (8 in.)




Figure 13: Stainless steel ASME flange 1.4404 (316L) up to DN 200 (8 in.)




Figure 15: Nickel alloy ASME flange up to DN 200 (in.)




Figure 16: Stainless steel JIS B2220 flange 1.4435 or 1.4404 (AISI 316L) or nickel alloy

## Installing the sensor

Before installation in the piping, observe the installation conditions and instructions on the mounting position!


1. Insert the sensor into the piping centrally and positioned coplanar. Use suitable gaskets to seal the process connections.
2. Tighten flange screws by working on each in a crosswise manner with the maximum permissible torque.
3. Check the seal integrity of the process connections.

## Installing the transmitter in the remote mount design

When selecting a location for the transmitter, consider the following points:

- Observe the information concerning maximum ambient temperature and IP rating on the name plate
- The location must be mostly free from vibration.
- The location must not be exposed to direct sunlight. If necessary provide a sun screen on site.
- Do not up-scale the maximum signal cable length between the transmitter and the sensor.

1. Drill mounting holes at mounting location.
2. Attach transmitter securely to the mounting location using suited fasteners for the base material.



- ① Hole pattern for mounting holes
- ② Female thread (either 1/2 in NPT or M20 x 1.5), see model coding. In the case of a 1/2 in NPT, there is a plug instead of a cable gland.

Figure 17: Mounting dimensions dual-compartment housing





Figure 18: Assembly set for 2" pipe mounting

## ... 6 Installation

### ... Installing the transmitter in the remote mount design



- ① Hole pattern for mounting holes
- ② Female thread (either  $\frac{1}{2}$  in NPT or M20  $\times$  1.5), see model coding. In the case of a  $\frac{1}{2}$  in NPT, there is a plug instead of a cable gland.

Figure 19: Mounting dimensions single-compartment housing

## Opening and closing the housing

### **⚠ DANGER**

**Danger of explosion if the device is operated with the transmitter housing or terminal box open!**

Before opening the transmitter housing or the terminal box, note the following points:

- A valid fire permit must be present.
- Make sure that there is no explosion hazard.
- Switch off the power supply and wait for  $t > 20$  minutes before opening.

### **⚠ WARNING**

**Risk of injury due to live parts!**

When the housing is open, contact protection is not provided and EMC protection is limited.


- Before opening the housing, switch off the power supply.

### **NOTICE**

**Potential adverse effect on the IP rating**

- Check the O-ring gasket for damage and replace it if necessary before closing the housing cover.
- Check that the O-ring gasket is properly seated when closing the housing cover.

### Dual- compartment housing



(A) Integral mount design

(B) Remote mount design

(C) Transmitter, terminal space, signal cable

Figure 20: Cover lock (example)

#### Open the housing:

1. Release the cover lock by screwing in the Allen screw (2).
2. Unscrew cover (1).

#### Close the housing:

1. Screw on the cover (1).
2. After closing the housing, lock the cover by unscrewing the Allen screw (2).

## ... 6 Installation

### ... Opening and closing the housing

#### Single-compartment housing




Figure 21: Open / close single-compartment housing

#### Open the housing:

- Perform steps (A) and (B).

#### Close the housing:

- Perform steps (C) and (D).

### Adjusting the transmitter position

Depending on the installation position, the transmitter housing or LCD display can be rotated to enable horizontal readings.

#### Transmitter housing

#### **⚠ DANGER**

##### **Damaging the device carries a risk of explosion!**

When the screws for the transmitter housing are loosened, the explosion protection is suspended.

- Tighten all screws prior to commissioning.
- Never disconnect the transmitter housing from the sensor.
- Loosen only the screws indicated when rotating the transmitter housing!




Figure 22: Rotate transmitter housing

#### Rotate the housing:

- Perform steps (A) to (C).

**Rotate LCD indicator – dual-compartment housing**

The LCD indicator can be rotated in three increments of 90° each.




Figure 23: Rotating the LCD indicator

**Turn the LCD indicator:**

1. Open housing (A), see **Opening and closing the housing** on page 39.
2. Perform steps (B) to (F).

**Rotate LCD indicator – single-compartment housing**




Figure 24: Possible positions of LCD indicator

The LCD indicator can be rotated to the (A), (B) and (C) positions. The 'upside down' position is not possible. To correct the display for the 'upside down' position, use the menu 'Display / Display Rotation'. This allows the display to be rotated 180° by software.




Figure 25: Rotating the LCD indicator

**Turn the LCD indicator:**

1. Open housing (A), see **Opening and closing the housing** on page 39.
2. Perform steps (B) to (F).

## ... 6 Installation

### Installing the plug-in cards

#### **⚠ WARNING**

##### **Loss of Ex Approval!**



Loss of Ex Approval due to retrofitting of plug-in cards on devices for use in potentially explosive atmospheres.

- Devices for use in potentially explosive atmospheres may not be retrofitted with plug-in cards.
- If devices are to be used in potentially explosive atmospheres, the required plug-in cards must be specified when the order is placed.

#### **Optional plug-in cards**

The transmitter has two slots (OC1, OC2) into which plug-in cards can be inserted to extend inputs and outputs. The slots are located on the transmitter motherboard and can be accessed after removing the front housing cover.

#### **Plug-in cards**



Pos.	Description	Quantity*
①	Current output, 4 to 20 mA passive (red) Order number: 3KQZ400035U0100	2
②	Passive digital output (green) Order no.: 3KQZ400030U0100	1**
③	Passive digital input (yellow) Order no.: 3KQZ400032U0100	2
④	Loop power supply 24 V DC (blue) Order no.: 3KQZ400031U0100	1
⑤	Modbus RTU RS485 (white) Order no.: 3KQZ400028U0100	1
⑥	Profibus DP (white) Order no.: 3KQZ400027U0100	1
⑦	Ethernet Order no.: 3KQZ400037U0100	1
⑧	Power over Ethernet (POE) Order no.: 3KQZ400039U0100	1
⑨	Active digital output (white) Order no.: 3KQZ400056U0100	1**

\* The 'Number' column indicates the maximum number of plug-in cards of the same type that can be used.

\* Only one plug-in card of the active digital output type or passive digital output type can be inserted in Pos. ②.


The following table provides an overview of the possible plug-in card combinations that can be selected when ordering the device. Because of the wide variety of options, not all combinations can be presented. Possible combinations are presented in our Online ABB Product Selection Assistant (PSA) for flow at [www.abb.com/flow](http://www.abb.com/flow).

Main ordering information (outputs)	Additional ordering information		Slot OC1	Slot OC2
	Additional output 1	Additional output 2	Terminals V1 / V2	Terminals V3 / V4
G0	-	-	-	-
G1	-	-	Loop power supply 24 V DC (blue)	-
G2	-	-	-	Current output, 4 to 20 mA passive (red)
G3	-	-	Current output, 4 to 20 mA passive (red)	Current output, 4 to 20 mA passive (red)
G4	-	-	Loop power supply 24 V DC (blue)	Passive current output (red)
D1	-	-	Profibus DP, RS485 (white)	
M1	-	-	Modbus RTU RS485 (white)	
M6	-	-	Modbus RTU RS485 (white)	Active digital output (white)
E2	-	-	Ethernet (green)	
E3	-	-	Ethernet (green)	
E4	-	-	Ethernet (green)	Power over Ethernet (green)
G0	DRT	-	Loop power supply 24 V DC (blue)	-
G0	DRT	DSN	Loop power supply 24 V DC (blue)	Passive digital input (yellow)
G0	DRT	DSG	Loop power supply 24 V DC (blue)	Passive digital output (green)
G0	DRT	DSA	Loop power supply 24 V DC (blue)	Current output, 4 to 20 mA passive (red)
G0	DRN	-	Passive digital input (yellow)	-
G0	DRN	DSG	Passive digital input (yellow)	Passive digital output (green)
G0	DRN	DSA	Passive digital input (yellow)	Current output, 4 to 20 mA passive (red)
G0	DRG	DSN	Passive digital output (green)	Passive digital input (yellow)
G0	DRG	DSA	Passive digital output (green)	Current output, 4 to 20 mA passive (red)
G0	DRA	DSA	Current output, 4 to 20 mA passive (red)	Current output, 4 to 20 mA passive (red)
G0	DRN	DSH	Passive digital input (yellow)	Active digital output (white)
G0	DRA	DSG	Current output, 4 to 20 mA passive (red)	Passive digital output (green)
G0	DRA	DSN	Current output, 4 to 20 mA passive (red)	Passive digital input (yellow)
G0	DRM	-	Modbus RTU RS485 (white)	-
G0	DRA	DSH	Current output, 4 to 20 mA passive (red)	Active digital output (white)
G0	DRD	-	Profibus DP, RS485 (white)	-
G0	DRM	DSN	Modbus RTU RS485 (white)	Passive digital input (yellow)
G0	DRM	DSG	Modbus RTU RS485 (white)	Passive digital output (green)
G0	DRD	DSN	Profibus DP, RS485 (white)	Passive digital input (yellow)
G0	DRA	DSH	Modbus RTU RS485 (white)	Active digital output (white)
G0	DRD	DSG	Profibus DP, RS485 (white)	Passive digital output (green)
G0	DR6	-	Ethernet	-
G0	DR6	DS8	Ethernet (green)	Power over Ethernet (green)
G0	DR6	DSN	Ethernet (green)	Passive digital input (yellow)
G0	DR6	DSG	Ethernet (green)	Passive digital output (green)

## ... 6 Installation

### ... Installing the plug-in cards

#### Dual-compartment housing



- |   |                 |
|---|-----------------|
| ① Cover   | ④ Slot OC2      |
| ② LCD indicator   | ⑤ Slot OC1      |
| ③ Frontend board (FEB, with integral mount design only) | ⑥ Plug-in cards |

Figure 26: Installation of plug-in cards (example, dual-compartment housing)

### **⚠ WARNING**

#### **Risk of injury due to live parts!**

When the housing is open, contact protection is not provided and EMC protection is limited.

- Before opening the housing, switch off the power supply.

### **NOTICE**

#### **Damage to components!**

The electronic components of the printed circuit board can be damaged by static electricity (observe ESD guidelines).

- Make sure that the static electricity in your body is discharged before touching electronic components.

1. Switch off the power supply.
2. Unscrew / remove the cover.
3. Remove the LCD indicator. Ensure that the cable harness is not damaged.  
Insert the LCD indicator into the bracket (only for single-compartment housings)
4. Remove frontend board (only in integral mount design and dual-compartment housing). Ensure that the cable harness is not damaged.
5. Insert the plug-in card in the corresponding slot and engage. Ensure that the contacts are aligned correctly.
6. Attach the frontend board, insert the LCD indicator and screw on / replace the cover.
7. Connect outputs V1 / V2 and V3 / V4 in accordance with **Electrical connections** on page 47.
8. After powering up the power supply, configure the plug-in card functions.

## Single-compartment housing




Figure 27: Installation of plug-in cards (example, single-compartment housing)

### **⚠ WARNING**

#### **Risk of injury due to live parts!**

When the housing is open, contact protection is not provided and EMC protection is limited.

- Before opening the housing, switch off the power supply.

### **NOTICE**

#### **Damage to components!**

The electronic components of the printed circuit board can be damaged by static electricity (observe ESD guidelines).

- Make sure that the static electricity in your body is discharged before touching electronic components.


1. Switch off the power supply.
2. Unscrew / remove the cover.
3. Remove the LCD indicator. Ensure that the cable harness is not damaged.  
Insert the LCD indicator into the bracket (only for single-compartment housings)
4. Remove frontend board (only in integral mount design and dual-compartment housing). Ensure that the cable harness is not damaged.
5. Insert the plug-in card in the corresponding slot and engage. Ensure that the contacts are aligned correctly.
6. Attach the frontend board, insert the LCD indicator and screw on / replace the cover.
7. Connect outputs V1 / V2 and V3 / V4 in accordance with **Electrical connections** on page 47.
8. After powering up the power supply, configure the plug-in card functions.

## ... 6 Installation

### ... Installing the plug-in cards

#### Ethernet card

The Flowmeter has two slots for the components that follow:



(A) Ethernet card (part number 3KQZ400037U0100)

(B) Power over Ethernet (PoE) card (part number 3KQZ400039U0100)

Figure 28: Install the plug-in cards

#### **⚠ DANGER**

##### **Explosion hazard due to improper installation!**

Ethernet Option Cards are designed only for use in hazardous applications Zone 2 / Division 2.

#### **⚠ WARNING**

##### **Risk of injury due to live parts!**

When the housing is open, contact protection is not provided and EMC protection is limited.

- Before opening the housing, switch off the power supply.

#### **NOTICE**

##### **Damage to components!**

The electronic components of the printed circuit board can be damaged by static electricity (observe ESD guidelines).

- Make sure that the static electricity in your body is discharged before touching electronic components.

1. Switch off the power supply.
2. Unscrew / remove the cover.
3. Remove the LCD indicator. Ensure that the cable harness is not damaged.
  - Insert the LCD indicator into the bracket.
4. Insert the plug-in card in the corresponding slot and engage. Ensure that the contacts are aligned correctly.
5. Attach the frontend board, insert the LCD indicator and screw on / replace the cover.
6. Connect the Ethernet plug in card in accordance with **EtherNet/IP™ and PROFINET® communication** on page 65.
7. After powering up the power supply, configure the plug-in card functions.

#### **Note**

For detailed instructions how to plug in and connect the Power over Ethernet (PoE) card, please contact ABB.

## 7 Electrical connections

### Safety instructions

#### **WARNING**

##### **Risk of injury due to live parts.**

Improper work on the electrical connections can result in electric shock.

- Connect the device only with the power supply switched off.
- Observe the applicable standards and regulations for the electrical connection.

The electrical connection may only be established by authorized specialist personnel and in accordance with the connection diagrams.

The electrical connection information in this manual must be observed; otherwise, the IP rating may be adversely affected. Ground the measurement system according to requirements.

### Power supply

#### **Note**

- Adhere to the limit values of the power supply in accordance with the information on the name plate.
- Observe the voltage drop for large cable lengths and small conductor cross-sections. The voltage at the terminals of the device may not down-scale the minimum value required in accordance with the information on the name plate.

The power supply is connected to terminal L (phase), N (zero), or 1+, 2-, and PE.

A circuit breaker with a maximum rated current of 16 A must be installed in the power supply line.

The wire cross-sectional area of the power supply cable and the circuit breaker used must comply with VDE 0100 and must be dimensioned in accordance with the current consumption of the flowmeter measuring system. The cables must comply with IEC 227 and/or IEC 245.

The circuit breaker must be located near the device and marked as being associated with the device.

Connect the transmitter and sensor to functional earth.

## ... 7 Electrical connections


### Installing the connection cables

#### General information on cable installation

Ensure that a drip loop (water trap) is used when installing the connecting cables for the sensor.

When mounting the sensor vertically, position the cable entries at the bottom.

If necessary, rotate the transmitter housing accordingly.



① Drip loop

Figure 29: Laying the connection cable

#### Signal cable specification

The signal cable used for the connection of the transmitter and sensor must fulfill at least the following technical specifications.

##### Cable specification

Impedance	100 to 120 $\Omega$
Withstand voltage	120 V
Outer diameter	6 to 12 mm (0.24 to 0.47 in)
Cable design	Two wire pairs as a star-quad cable
Conductor cross-section	Length-dependent
Shield	Copper braid with approximately 85 % coverage
Temperature range	Application-dependent, for use in potentially explosive atmospheres, observe the information in <b>Temperature resistance for the connecting cable</b> on page 13!

##### Maximum signal cable length

0.25 mm <sup>2</sup> (AWG 24)	50 m (164 ft)
0.34 mm <sup>2</sup> (AWG 22)	100 m (328 ft)
0.5 mm <sup>2</sup> (AWG 20)	150 m (492 ft)
0.75 mm <sup>2</sup> (AWG 19)	200 m (656 ft)

#### Recommended cables


It is recommended to use an ABB signal cable for standard applications. The ABB signal cable fulfills the above-mentioned cable specification and can be utilized unrestrictedly up to an ambient temperature of  $T_{amb.} = 80\text{ }^{\circ}\text{C}$  (176  $^{\circ}\text{F}$ ).

ABB signal cable	Ordering number
5 m (16 ft)	3KQZ407123U0500
10 m (33 ft)	3KQZ407123U1000
20 m (65 ft)	3KQZ407123U2000
50 m (164 ft)	3KQZ407123U5000
100 m (328 ft)	3KQZ407123U1H00
150 m (492 ft)	3KQZ407123U1F00
200 m (656 ft)	3KQZ407123U2H00

For marine applications, an appropriate certified signal cable must be used.

ABB recommends the cable HELKAMA RFE-FRHF 2×2×0,75 QUAD 250V (HELKAMA order number 20522).

## Terminal assignment



(A) Transmitter

(B) Sensor

Figure 30: Electrical connection

### Connections for the power supply

AC voltage	
Terminal	Function / comments
L	Phase
N	Neutral conductor
PE / ⊕	Protective earth (PE)
▽	Potential equalization

DC voltage	
Terminal	Function / comments
1+	+
2-	-
PE / ⊕	Protective earth (PE)
▽	Potential equalization

### Connections for inputs and outputs

Terminal	Function / comments
Uco / 32	Current output 4 to 20 mA- / HART® output, active or
31 / 32	Current output 4 to 20 mA- / HART® output, passive
41 / 42	Passive digital output DO1
51 / 52	Passive digital output DO2
V1 / V2	Plug-in card, slot OC1
V3 / V4	Plug-in card, slot OC2

For details, see **Optional plug-in cards** on page 42.

### Connecting the signal cable

Only for remote mount design.

The sensor housing and transmitter housing must be connected to potential equalization.

Terminal	Function / comments
U <sub>FE</sub>	Sensor power supply
GND	Ground
A	Data line
B	Data line
⊕	Functional earth / Shielding

## ... 7 Electrical connections

### ... Terminal assignment

#### Electrical data for inputs and outputs

##### Note

When using the device in potentially explosive atmospheres, note the additional temperature data in **Use in potentially explosive atmospheres** on page 6!

#### Power supply L / N, 1+ / 2-

AC voltage	
Terminals	L / N
Operating voltage	100 to 240 V AC, 50 / 60 Hz
Power consumption	< 20 VA

DC voltage	
Terminals	1+ / 2-
Operating voltage	19 to 30 V DC
Power consumption	< 20 W

#### Requirements for inputs and outputs

For reasons of electromagnetic compatibility (EMC), shielded cables should be used in certain output configurations; this is presented in the table below.

The cable shielding must be inserted in the device, see

**Connection to integral mount design** on page 58 and

**Connection to remote mount design** on page 60.

#### Use of shielded cables

Transmitter	Plug-in card used	Terminal				
		Uco/31/32	41/42	51/52	V1/V2	V3/V4
<b>Dual-compartment housing</b>	Active digital output V1/V2	—	—	—	X	—
	Active digital output V3/V4	—	—	—	—	X
	Modbus V1/V2	—	—	—	X	—
	Profibus DP V1/V2	—	—	—	X	—
<b>Single-compartment housing</b>	Active digital output V1/V2	X	X	X	—	X
	Active digital output V3/V4	X	X	X	X	—
	Modbus V1/V2*	—	—	—	X	—
	Profibus DP V1/V2*	—	—	—	X	—
	Ethernet V1/V2	X	X	X	X	X
	Ethernet V1/V2, POE V3/V4	X	X	X	X	X

X Use shielded cables

\* Use in remote mount design only

#### Current output 32 / Uco, 31 / 32 (basic device)

Can be configured for outputting mass flow, volume flow, density and temperature via on-site software.





Figure 31: (I = internal, E = external, RB = load)



Permissible source voltage  $U_q$  for passive outputs in relation to load resistance  $R_B$  where  $I_{max} = 22 \text{ mA}$ . ■ = Permissible range

Figure 32: Source voltage for passive outputs

Current output	Active	Passive
Terminals	Uco / 32	31 / 32
Output signal	4 to 20 mA or 4 to 12 to 20 mA switchable	
Load $R_B$	$250 \Omega \leq R_B \leq 300 \Omega$	$250 \Omega \leq R_B \leq 600 \Omega$
Source voltage $U_q^*$	—	$13 \text{ V} \leq U_q \leq 30 \text{ V}$
Measuring error	< 0.1 % of measured value	
Resolution	0.4 $\mu\text{A}$ per digit	

\* The source voltage  $U_q$  is dependent of the load  $R_B$  and must be placed in an additional area.

For information on communication via the HART protocol, refer to **HART® Communication** on page 63.

**Current output  $U_{co} / 32$  as loop power supply for digital output 41 / 42 or 51 / 52**

In the case of digital communication via Modbus / PROFIBUS DP, the current output  $U_{co} / 32$  can be switched to the 'Power Mode' operating mode through the software.

The current output 31/32/ $U_{co}$  is set permanently to 22.6 mA and no longer follows the selected process variable. HART communication is deactivated.


As a result, the passive digital outputs 41 / 42 or 51 / 52 can also be operated as active digital outputs.

The load resistance  $R_B$  needs to be integrated by the customer outside of the transmitter housing.


**Loop power supply 24 V DC operating mode**

Terminals	$U_{co} / 32$
Function	For active connection of passive outputs
Output Voltage	Load dependent, see Figure 34.
Load rating $I_{max}$	22.6 mA, permanently short circuit-proof

**Table 1: Specification current output  $U_{co} / 32$  in power mode**



**Figure 34: Output voltage dependent on load resistance**



- (A) Transmitter FCx400
- (B) Customer wiring
- OC1 Modbus / PROFIBUS DP plug-in card
- $R_B$  Load resistance


**Figure 33: Current output  $U_{co} / 32$  in power mode**

## ... 7 Electrical connections

### ... Terminal assignment

#### Digital output 41 / 42, 51 / 52 (basic device)

Can be configured as pulse, frequency or binary output via on-site software.



- (A) Digital output 41 / 42, 51 / 52 passive as a pulse or frequency output  
 (B) Passive digital output 51 / 52 as binary output

Figure 35: (I = internal, E = external,  $R_B$  = load)

#### Pulse / frequency output (passive)

Terminals	41 / 42, 51 / 52
Output 'closed'	$0 \text{ V} \leq U_{\text{CEL}} \leq 3 \text{ V}$ For $f < 2.5 \text{ kHz}$ : $2 \text{ mA} < I_{\text{CEL}} < 30 \text{ mA}$ For $f > 2.5 \text{ kHz}$ : $10 \text{ mA} < I_{\text{CEL}} < 30 \text{ mA}$
Output 'open'	$16 \text{ V} \leq U_{\text{CEH}} \leq 30 \text{ V DC}$ $0 \text{ mA} \leq I_{\text{CEH}} \leq 0.2 \text{ mA}$
$f_{\text{max}}$	10.5 kHz
Pulse width	0.05 to 2000 ms

#### Binary output (passive)

Terminals	41 / 42, 51 / 52
Output 'closed'	$0 \text{ V} \leq U_{\text{CEL}} \leq 3 \text{ V}$ $2 \text{ mA} \leq I_{\text{CEL}} \leq 30 \text{ mA}$
Output 'open'	$16 \text{ V} \leq U_{\text{CEH}} \leq 3 \text{ V DC}$ $0 \text{ mA} \leq I_{\text{CEH}} \leq 0.2 \text{ mA}$
Switching function	Can be configured using software.


#### Note

- Terminals 42 / 52 have common grounding. Digital outputs 41 / 42 and 51 / 52 are not electrically isolated from each other. An electrically isolated digital output can be made using a plug-in module.
- If using a mechanical counter, it is advisable to set a pulse width of  $\geq 30 \text{ ms}$  and a maximum frequency of  $f_{\text{max}} \leq 3 \text{ kHz}$ .

#### Current output V1 / V2, V3 / V4 (plug-in module)

Up to two additional plug-in modules can be implemented via the 'Passive current output (red)' option module.


Can be configured for outputting mass flow, volume flow, density and temperature via on-site software.



- (A) Current output V1 / V2, passive (B) Current output V3 / V4, passive

Figure 36: (I = internal, E = external,  $R_B$  = load)

The plug-in module can be used in slot OC1 and OC2.



Permissible source voltage  $U_q$  for passive outputs in relation to load resistance  $R_B$  where  $I_{\text{max}} = 22 \text{ mA}$ .  = Permissible range

Figure 37: Source voltage for passive outputs

#### Passive current output

Terminals	V1 / V2, V3 / V4
Output signal	4 to 20 mA
Load $R_B$	$250 \Omega \leq R_B \leq 600 \Omega$
Source voltage $U_q^*$	$13 \text{ V} \leq U_q \leq 30 \text{ V}$
Measuring error	$< 0.1 \%$ of measured value
Resolution	$0.4 \mu\text{A}$ per digit

\* The source voltage  $U_q$  is dependent of the load  $R_B$  and must be placed in an additional area.

**Passive digital output V1 / V2, V3 / V4 (plug-in card)**

An additional binary output can be implemented via the ‘Passive digital output (green)’ plug-in module.

Can be configured as an output for flow direction signaling, alarm output etc. via on-site software.




Figure 38: Plug-in card as binary output (I = internal, E = external, R<sub>B</sub> = load)

The plug-in module can be used in slot OC1 or OC2.

Binary output (passive)	
Terminals	V1 / V2, V3 / V4
Output ‘closed’	0 V ≤ U <sub>CEL</sub> ≤ 3 V 2 mA < I <sub>CEL</sub> < 30 mA
Output ‘open’	16 V ≤ U <sub>CEH</sub> ≤ 30 V DC 0 mA ≤ I <sub>CEH</sub> ≤ 0.2 mA
Switching function	Can be configured using software.

**Active digital output V1 / V2, V3 / V4 (plug-in card)**

An additional binary output can be implemented via the ‘Active digital output (white)’ plug-in card.

Can be configured on-site as a logical output for V1 / V2 (flow direction signaling, alarm output, etc.) via software.

Can be configured on-site for V3 / V4 as a frequency output, pulse output or logical output via software.




Figure 39: Plug-in card V1 / V2

or




Figure 40: Plug-in card V3 / V4

The plug-in module can be used in slot OC1 or OC2.

External voltage cannot be connected to the active binary output.

Only one of the two digital output plug-in cards (passive or active) will be supported at the same time.

**Note**

**Requirements for inputs and outputs**

For reasons of electromagnetic compatibility (EMC), shielded cables should be used in certain output configurations; this is presented in Table .

## ... 7 Electrical connections

### ... Terminal assignment

Dependency of the output voltage  $U$  from the load  $R_B$ .

Load  $R_B$  is the parallel connection of the internal resistance  $R_{int}$  and optional external resistance  $R_{ext}$ .





Figure 41: Dependency of the output voltage  $U$  from the load  $R_B$ .

Permissible ambient temperature single-compartment housing:  
70 °C

Permissible ambient temperature dual-compartment housing  
dependent on the load  $R_B$ :



(A) Ambient temperature (°C)

Figure 42: Permissible ambient temperature dual-compartment housing

#### Binary output (active)

Terminals	V1 / V2, V3 / V4
'Off' output	$U_L \leq 200 \text{ mV}$ $I_L < 0 \text{ mA}$
'On' output	$0 \text{ V} \leq U_H \leq 24 \text{ V}$ (dependent on $R_B$ ) $0 \text{ mA} \leq I_H \leq 22.5 \text{ mA}$ (dependent on $R_B$ )

#### For pulse/frequency output

Terminals	V3 / V4
'Off' output	$U_L \leq 200 \text{ mV}$ $I_L < 0 \text{ mA}$
'On' output	$0 \text{ V} \leq U_H \leq 24 \text{ V}$ (dependent on $R_B$ ) $0 \text{ mA} \leq I_H \leq 22.5 \text{ mA}$ (dependent on $R_B$ )
$f_{max}$	10.5 kHz
Pulse width	0.05 to 2000 ms

#### Digital input V1 / V2, V3 / V4 (plug-in module)

A digital input can be implemented via the 'Passive digital input (yellow)' plug-in module.

Can be configured as an input for external counter reset, external output deactivation etc. via on-site software.




Figure 43: Plug-in card as digital input (I = internal, E = external)

The plug-in module can be used in slot OC1 or OC2.

#### Digital input

Terminals	V1 / V2, V3 / V4
Input 'On'	$16 \text{ V} \leq U_{KL} \leq 30 \text{ V}$
Input 'Off'	$0 \text{ V} \leq U_{KL} \leq 3 \text{ V}$
Internal resistance $R_i$	6.5 kΩ
Function	Can be configured using software.

**24 V DC loop power supply (plug-in card)**

Use of the ‘loop power supply (blue)’ plug-in card allows a passive output on the transmitter to be used as an active output. See also **Connection examples** on page 55.




Figure 44: (I = Internal, E = External)

The plug-in card can only be used in slot OC1.

Loop power supply 24 V DC	
Terminals	V1 / V2
Function	For active connection of passive outputs
Output Voltage	24 V DC at 0 mA, 17 V DC at 25 mA
Load rating $I_{max}$	25 mA, permanently short circuit-proof

**Note**

If the device is used in potentially explosive atmospheres, the plug-in card for the loop power supply may only be used to supply a passive output. It is not allowed, to connect it to multiple passive outputs!

**Modbus® / PROFIBUS DP® interface V1 / V2 (plug-in card)**

A Modbus or PROFIBUS DP interface can be implemented by using the ‘Modbus RTU, RS485 (white)’ or ‘PROFIBUS DP, RS485 (white)’ plug-in cards.




Figure 45: Plug-in card as a Modbus / PROFIBUS DP interface (I = internal, E = external)

The corresponding plug-in card can only be used in slot OC1.

For information on communication through the Modbus or PROFIBUS DP protocols, refer to chapters **Modbus® communication** on page 63 and **PROFIBUS DP® communication** on page 64.

**Connection examples**

Input and output functions are configured via the device software in accordance with the desired application.


**Digital output 41 / 42, 51 / 52, V3 / V4 active**

When the ‘loop power supply 24 V DC (blue)’ plug-in card is used, the digital outputs on the basic device and on the option modules can also be wired as active digital outputs.

**Note**

Each ‘loop power supply (blue)’ plug-in card must only power one output.


It must not be connected to two outputs (for example digital output 41 / 42 and 51 / 52)!



- (A) ‘Loop power supply (blue)’ plug-in card in slot 1
- (B) Digital output, digital output 41 / 42

Figure 46: Active digital output 41 / 42 (example)

The connection example shows usage for digital output 41 / 42; the same applies to usage for digital output 51 / 52.




- (A) ‘Loop power supply (blue)’ plug-in card in slot 1
- (B) ‘Digital output (green)’ plug-in card in slot 2

Figure 47: Active digital output V3 / V4 (example)

## ... 7 Electrical connections

### ... Terminal assignment

Digital output 41 / 42, 51 / 52 passive on distributed control system




- (A) Transmitter
- (B) Distributed control system / Memory programmable controller
- Ex. 1 Input 1
- Ex. 2 Input 2
- $R_x$  Resistor for current limitation
- $R_i$  Distributed control system internal resistance

Figure 48: Digital output 41 / 42 on distributed control system (example)

The  $R_x$  resistors limit the maximum current through the optoelectronic coupler of the digital outputs in the transmitter. The maximum permissible current is 25 mA. An  $R_x$  value of  $1000 \Omega / 1 W$  is recommended at a voltage level of 24 V DC. The input on the distributed control system is reduced from 24 V DC to 0 V DC (falling edge) with '1' at the digital output.

Current output V3 / V4 active

When the 'loop power supply 24 V DC, blue' plug-in card is used, the current output on the plug-in card can also be wired as the active current output.




- (A) 'Loop power supply (blue)' plug-in card in slot 1
- (B) 'Passive current output (red)' plug-in card in slot 2

Figure 49: Active current output V3 / V4 (example)

Digital input V3 / V4 active

When the 'loop power supply 24 V DC, blue' plug-in card is used, the current output on the plug-in card can also be wired as the active current output.



- (A) 'Loop power supply (blue)' plug-in card in slot 1
- (B) 'Passive digital input (yellow)' plug-in card in slot 2

Figure 50: Active digital output V3 / V4 (example)

### Connection versions digital output 41 / 42, 51 / 52

Depending on the wiring of digital outputs DO 41 / 42 and 51 / 52, they can be used parallel or only individually. The electrical isolation between the digital outputs also depends on the wiring.




Figure 51: Connection versions digital output 41 / 42 and 51 / 52




	DO 41 / 42 and 51 / 52 can be used parallel	DO 41 / 42 and 51 / 52 electrically isolated
(A)	Yes	No
(B)	Yes	No
(C)	No, only DO 41 / 42 can be used	No
(D)	No, only DO 51 / 52 can be used	No

# ... 7 Electrical connections

## Connection on the device

### Connection to integral mount design

#### Dual-compartment housing



#### Single-compartment housing

- ① Terminals for power supply
- ② Cover for power supply terminals
- ③ Terminals for inputs and outputs
- ④ Terminal for potential equalization
- ⑤ LCD indicator
- ⑥ Bracket for LCD indicator (park position)
- ⑦ Terminal for protective earth / cable shields

Figure 52: Connection to device (example), PA = potential equalization

## NOTICE

**If the O-ring gasket is seated incorrectly or damaged, this may have an adverse effect on the housing protection class.**

Follow the instructions in **Opening and closing the housing** on page 39 to open and close the housing safely.

Observe the following points when connecting to an electrical supply:

- Lead the power supply cable into the housing through the top cable entry.
- Lead the cables for signal inputs and signal outputs into the housing through the middle and, where necessary, bottom cable entries.
- Connect the cables in accordance with the electrical connection. If present, connect the cable shielding to the earthing clamp provided.
- Use wire end ferrules when connecting.
- After connecting the power supply to the dual-compartment housing, terminal cover ② must be installed.
- Close unused cable entries using suited plugs.

# ... 7 Electrical connections

## ... Connection on the device

### Connection to remote mount design

#### Transmitter




Figure 53: Electrical connection to transmitter in remote mount design [example, dimensions in mm (in)]

Single-compartment housing




Figure 54: Electrical connection to transmitter in remote mount design [example, dimensions in mm (in)]

**NOTICE**

If the O-ring gasket is seated incorrectly or damaged, this may have an adverse effect on the housing protection class. Follow the instructions in **Opening and closing the housing** on page 39 to open and close the housing safely.

Terminal	ABB signal cable 3KQZ407123U0100	HELKAMA signal cable 20522
GND	Blue	Blue (4)
U <sub>FE</sub>	White	white (3)
A	Yellow	Blue (2)
B	Orange	white (1)


Observe the following points when connecting to an electrical supply:

- Lead the cable for the power supply and the signal inputs and outputs into the housing as shown.
- The signal cable to the sensor is connected in the lower connection area of the transmitter.
- Connect the cables in accordance with the electrical connection diagram. If present, connect the cable shielding to the earthing clamp provided.
- Use wire end ferrules when connecting.
- After connecting the power supply, terminal cover (2) must be installed.
- Close unused cable entries using suitable plugs.

## ... 7 Electrical connections


### ... Connection on the device

#### Flowmeter sensor



- (A) Signal cable from the sensor  
 (1) Terminal for potential equalization

Figure 55: Connection to sensor in remote mount design (example)



- (2) Terminals for signal cable

### NOTICE

If the O-ring gasket is seated incorrectly or damaged, this may have an adverse effect on the housing protection class. Follow the instructions in **Opening and closing the housing** on page 39 to open and close the housing safely.

Terminal	ABB signal cable 3KQZ407123U0100	HELKAMA signal cable 20522
GND	Blue	Blue (4)
U <sub>FE</sub>	White	white (3)
A	Yellow	Blue (2)
B	Orange	white (1)

Observe the following points when connecting to an electrical supply:

- Lead the signal cable into the housing as shown.
- Connect the cables in accordance with the electrical connection. If present, connect the cable shielding to the earthing clamp provided.
- Use wire end ferrules when connecting.
- From an ambient temperature of  $T_{amb.} \geq 60 \text{ °C}$  ( $\geq 140 \text{ °F}$ ) additionally insulate the wires with the enclosed silicone hoses.
- Close unused cable entries using suited plugs.

## 8 Digital communication

### HART® Communication

#### Note

The HART® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.

In connection with the DTM (Device Type Manager) available to the device, communication (configuration, parameterization) can be carried out FDT 0.98 or 1.2.

Other tool or system integrations (e.g. Emerson AMS / Siemens PCS7) on request.

The necessary DTMs and other files can be downloaded from [www.abb.com/flow](http://www.abb.com/flow).

#### HART output

Terminals	Active: Uco / 32 Passive: 31 / 32
Protocol	HART 7.1
Transmission	FSK modulation on current output 4 to 20 mA in accordance with the Bell 202 standard
Baud rate	1200 baud
Signal amplitude	Maximum 1.2 mAss

#### Factory setting of the HART process variables

HART process variable	Process value
Primary Value (PV)	$Q_m$ – Mass flow
Secondary Value (SV)	$Q_v$ – Volume flow rate
Tertiary Value (TV)	$\rho$ – Density
Quaternary Value (QV)	$T_m$ – Measuring medium temperature

The process values of the HART variables can be set in the device menu.

### Modbus® communication

#### Note

The Modbus® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.

Modbus is an open standard owned and administrated by an independent group of device manufacturers styled the Modbus Organization ([www.modbus.org/](http://www.modbus.org/)).

Using the Modbus protocol allows devices made by different manufacturers to exchange information via the same communication bus, without the need for any special interface devices to be used.

#### Modbus protocol

Terminals	V1 / V2
Configuration	Via the Modbus interface or via the local operating interface in connection with a corresponding Device Type Manager (DTM)
Transmission	Modbus RTU - RS485 serial connection
Baud rate	2400, 4800, 9600, 19200, 38400, 56000, 57600, 115200 baud Factory setting: 9600 baud
Parity	None, even, odd Factory setting: odd
Stop bit	One, two Factory setting: One
IEEE format	Little endian, big endian Factory setting: Little endian
Typical response time	< 100 ms
Response delay time	0 to 200 milliseconds Factory setting: 10 milliseconds




Figure 56: Communication with the Modbus protocol

## ... 8 Digital communication

### ... Modbus® communication

#### Cable specification

The maximum permissible length is dependent on the baud rate, the cable (diameter, capacity and surge impedance), the number of loads in the device chain, and the network configuration (2-core or 4-core).

- At a baud rate of 9600 and with a conductor cross-section of at least 0.14 mm<sup>2</sup> (AWG 26), the maximum length is 1000 m (3280 ft).
- When using a 4-core cable as a 2-wire wiring system, the maximum length must be halved.
- The spur lines must be short, a maximum of 20 m (66 ft).
- When using a distributor with 'n' connections, each branch must have a maximum length of 40 m (131 ft) divided by 'n.'

The maximum cable length depends on the type of cable used.

The following standard values apply:

- Up to 6 m (20 ft):  
cable with standard shielding or twisted-pair cable.
- Up to 300 m (984 ft):  
double twisted-pair cable with overall foil shielding and integrated earth cable.
- Up to 1200 m (3937 ft):  
double twisted-pair cable with individual foil shielding and integrated earth cables. Example: Belden 9729 or equivalent cable.

A category 5 cable can be used for Modbus RS485 up to a maximum length of 600 m (1968 ft). For the symmetrical pairs in RS485 systems, a surge impedance of more than 100 Ω is preferred, especially at a baud rate of 19200 and above.

### PROFIBUS DP® communication

#### Note

The PROFIBUS DP® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.

#### PROFIBUS DP interface

Terminals	V1 / V2
Configuration	Via the PROFIBUS DP interface or via the local operating interface in connection with a corresponding Device Type Manager (DTM)
Transmission	Based on IEC 61158-2
Baud rate	9.6 kbps, 19.2 kbps, 45.45 kbps, 93.75 kbps, 187.5 kbps, 500 kbps, 1.5 Mbps The baud rate is automatically detected and does not need to be configured manually
Device profile	PA Profile 3.02
Bus address	Address range 0 to 126 Factory setting: 126

For commissioning purposes, you will need a device driver in EDD (Electronic Device Description) or DTM (Device Type Manager) format plus a GSD file.

You can download EDD, DTM and GSD from [www.abb.com/flow](http://www.abb.com/flow).

The files required for operation can also be downloaded from [www.profibus.com](http://www.profibus.com).

ABB provides three different GSD files which can be integrated in the system.

ID number	GSD file name	
0x9741	PA139741.gsd	2xAI, 1xTOT
0x9742	PA139742.gsd	3xAI, 1xTOT
0x3434	ABB_3434.gsd	8xAI, 3xTOT, 2xAO, 1xDI, 3xDO

Users decide at system integration whether to install the full range of functions or only part. Switching is made using the 'Ident Nr. Selector' parameter.

Refer to Parameter description in the operating instruction.

**Limits and rules when using ABB fieldbus accessories**




Figure 57: Bus cable length depends on the transmission rate

**Pro PROFIBUS Line**

(Line = Starts at DP Master and goes to last DP/PA Slave)

- Approximately 4 to 8 DP segments through the repeater (see repeater data sheets)
- Recommended DP transfer rate 500 to 1500 kBit/s
- The slowest DP node determines the transfer rate of the DP line
- Number of PROFIBUS DP and PA nodes ≤ 126 (addresses 0 to 125)

**Per PROFIBUS DP segment**

- Number of DP nodes ≤ 32 (Node = Devices with / without PROFIBUS address)
- Bus termination required at the beginning and end of each DP segment!
- Trunk cable length ( $L_T$ ) see diagram (length dependent on transfer rate)
- Cable length of at least 1 m between two DP nodes at ≥ 1500 kBit/s!
- Spur cable length ( $L_S$ ), at ≤ 1500 kBit/s:  $LS \leq 0.25$  m, at > 1500 kBit/s:  $LS = 0.00$  m!
- At 1500 kBit/s and ABB DP cable type A:
  - Sum of all spur cable lengths ( $L_S$ ) ≤ 6.60 m, trunk cable length ( $L_T$ ) > 6.60 m, total length =  $L_T + (\sum L_S) \leq 200$  m, maximum 22 DP nodes (= 6.60 m / (0.25 m + 0.05 m spare))

**EtherNet/IP™ and PROFINET® communication**

**Note**

You will find detailed information regarding the “Ethernet” in the interface description “COM/FCB400/FCH400/E/MB”.




Figure 58: Plug-in card for Ethernet communication

**Single port connection without Power over Ethernet**

Standard Ethernet 10/100 BASE-T/TX (IEEE802.3) Single port connection.

Terminal designation:			
Connection	Pin	Function	Color codes
1	Pin 1	RD+	White / Orange
	Pin 2	RD-	Orange
	Pin 3	TD+	White / Green
	Pin 4	TD-	Green

**Single port connection with Power over Ethernet**

Standard Ethernet 10/100 BASE-T/TX (IEEE802.3) Single port connection.

Terminal designation:			
Connection	Pin	Function	Color codes
1	Pin 1	RD+	White / Orange
	Pin 2	RD-	Orange
	Pin 3	TD+	White / Green
	Pin 4	TD-	Green
2	Pin 1	PWR+	White / Blue
	Pin 2	PWR+	Blue
	Pin 3	PWR-	White / Brown
	Pin 4	PWR-	Brown

## ... 8 Digital communication

### ... EtherNet/IP™ and PROFINET® communication

#### Dual port connection without Power over Ethernet

Terminal designation:			
Connection	Pin	Function	Color codes
1	Pin 1	RD+	White / Orange
	Pin 2	RD-	Orange
	Pin 3	TD+	White / Green
	Pin 4	TD-	Green
2	Pin 1	RD+	White / Orange
	Pin 2	RD-	Orange
	Pin 3	TD+	White / Green
	Pin 4	TD-	Green

#### Ethernet Communication

The CoriolisMaster is equipped with an Ethernet card has 2 Ethernet connections that support ring, star or daisy chain network configurations.

In addition to the Ethernet card, a plug-in card for 'Power over Ethernet' is available. Using this card, the 24 V DC version of the flowmeter can be supplied with power via the Ethernet without any additional power supply.

#### EtherNet/IP™ and PROFINET® protocol

##### Note

The protocol as such is not secure. The application should be assessed before implementation to determine the suitability of the protocol.

Cyclic communication is supported in the implemented CoriolisMaster Ethernet/IP and PROFINET protocol. Process variables, diagnosis data and information on the device status can be cyclically accessed.

Both protocols support DHCP (Dynamic Host Configuration Protocol), only PROFINET also supports DCP (Discovery and Configuration Protocol).

A web server is available for device configuration with full access to all parameters and diagnosis data.

#### Ethernet/IP interface

Configuration	Via the web server or the local operating interface (display).
Ethernet/IP product code	5001
EDS data	FCB4_FCH4_01_01.eds
Device profile	Profile 0x43, generic device (can be set individually).
Support standards and protocols	Common Industrial Protocol (CIP™) Vol1, Ed. 3.25 EtherNet/IP™ CIP™ adaptation, Vol2, Ed. 1.23
Cable	Cat 5

#### PROFINET interface

Configuration	Via the web server or the local operating interface (display).
Device profile	Manufacturer-specific and PA Profile 4.02MU1*
GSDML data	GSDML-V2.42-ABB_001A-3436_FLOW_CORIOLIS-20230127.xml
Device ID	ABB 0x3436 (manufacturer-specific) or PNO 0xB333 (PA Profile)
Support standards and protocols	Common Industrial Protocol (CIP™) Vol1, Ed. 3.25 EtherNet/IP™ CIP™ adaptation, Vol2, Ed. 1.23 PROFINET PNIO_Version V2.42

\* The standard for this PA Profile has currently not yet been released; the device can however work with the GSDML PA Profile.

#### Additional Ethernet communications protocols

##### Note

The device support the following security modes:

Secure protocol	Non-secure protocol
<b>Websserver https</b>	<b>EtherNet/IP, Modbus TCP and PROFINET</b>
<ul style="list-style-type: none"> <li>Ports used by the web server: TCP 443</li> <li>Security based on .x509 certificates</li> </ul>	<ul style="list-style-type: none"> <li>Ports used by EtherNet/IP: TCP 44818, UDP 2222</li> <li>Ports used by Modbus TCP: TCP 502</li> <li>Ports used by PROFINET: UDP 34964, 49152</li> </ul>

All the protocols can be activated / deactivated in the HMI Menu.

##### Note

For EMC reasons, if an Ethernet output and a current or digital output are used simultaneously, a shielded cable must also be used for the current or digital output. The shield of the cable must be connected in the unit., see **Connection to integral mount design** on page 58 and **Connection to remote mount design** on page 60.

Wiring with different network topologies





Figure 59: Connection topologies


Ethernet Option Cards are designed only for use in hazardous applications Zone 2 / Division 2 or general purpose areas. The output circuits are designed so that different topologies such as daisy chain or point to point can be connected. See Installation diagram for detailed information.

- It is not permitted to combine both topologies.
- Ethernet communication is only available for installations in Zone 2/Division 2 or general purpose
- The rated voltage of these non-intrinsically safe circuits are UM = 57 V.

Topology	No. Ethernet cables connected	No. wires in Ethernet cable	PoE	Port	Clamp	Function	Cable
	1	4	No	1	1	RD+	white / orange
						RD-	orange
						TD+	white / green
						TD-	green
	1	8	No	1	1	RD+	white / orange
						RD-	orange
						TD+	white / green
						TD-	green
					2	Spare 1+	white / blue
						Spare 1-	blue
						Spare 2+	white / brown
						Spare 2-	brown
1	4	Yes	1	1	Recommendation: Use cable with 8 wires		
					2		
					3		
					4		
1	8	Yes	1	1	RD+	white / orange	
					RD-	orange	
					TD+	white / green	
					TD-	green	
				2	Spare 1+	white / blue	
					Spare 1-	blue	
					Spare 2+	white / brown	
					Spare 2-	brown	

## ... 8 Digital communication

### ... EtherNet/IP™ and PROFINET® communication

Topology	No. Ethernet cables connected	No. wires in Ethernet cable	PoE	Port	Clamp	Function	Cable
	2	4*	No	1	1	RD+	white / orange
					2	RD-	orange
					3	TD+	white / green
					4	TD-	green
				2	1	RD+	white / orange
					2	RD-	orange
					3	TD+	white / green
					4	TD-	green

\* If you use 8-wire cables, 4 wires will not be connected.

#### Connect the retractable plug to the Ethernet card





Figure 60: Ethernet card connection

**Preparing the EtherNet Cat5e cable**




- ① 90 mm (3.54 in)
- ② 39 mm (1.54 in)
- ③ 60 mm (2.36 in)
- ④ Tin 10 mm of the end of the braided shield of the cable

Figure 61: Preparing the EtherNet Cat5e cable

**Ground the Ethernet connection cable**

Connect the outer shield of the Ethernet cable to the screw terminal.



- Ⓐ Screw terminal

Figure 62: Ground the Ethernet connection cable

**M12 connector (optional)**

A variety of options are available for the M12 connector through the model code:

- Flowmeter equipped with 1 x M12 (four-wire, connection to Port 1)
- Flowmeter equipped with 2 x M12 (four-wire, connection to Port 1 and 2)
- Flowmeter equipped with 1 x M12 (eight-wire, connection to Port 1 and 2)

These options enable connection to various network topologies:

Topology	Four-wire	Four-wire	Four-wire	Eight-wire
	1 x M12 (four-wire)	2 x M12 (four-wire)	1 x M12 (eight-wire)	
Star	Y	Y	Y	Y
Ring or daisy chain	N	Y	N	N
PoE	N	N	N	Y

**Electrical connections**

You can reference the internal wiring in the transmitter and the corresponding pin assignment in the M12 connector in the following table:

Wiring inside the transmitter	M12 connector pin	Color	Ethernet plug-in card Connector/pin
<p><b>M12 connector four-wire</b></p>	1	Yellow	Port 1 X1
	2	Orange	Port 1 X2
	3	White	Port 1 X3
	4	Blue	Port 1 X4
<p><b>M12 connector eight-wire</b></p>	1	White	Port 1 X1
	2	Blue	Port 1 X2
	3	Brown	Port 1 X3
	4	Green	Port 1 X4
	5	Pink	Port 1 X5
	6	Yellow	Port 1 X6
	7	Grey	Port 1 X7
	8	Red	Port 1 X8

## ... 8 Digital communication

### ... EtherNet/IP™ and PROFINET® communication

#### Use in Potentially Explosive Atmospheres

#### **WARNING**

There are limitations to the M12 connector in combination with an ATEX / IECEx / EAC-Ex approved flowmeter.


	No Ex area	ATEX/IECEX/ EAC-Ex Zone 2	Div 2
Ethernet cable connected directly to the terminals of the Ethernet plug-in card	Y	Y	Y
Ethernet cable connected to the M12 connector on the transmitter housing	Y	Y	N

#### Locking clip

#### **WARNING**

A locking clip must be attached when using the M12 connector in combination with an ATEX / IECEx / EAC-Ex approved flowmeter.

- Use or operation of the device without the M12 locking clip is not permitted.



(A) Locking clip

Figure 63: Fastening the locking clip

#### **DANGER**

#### Explosion hazard

Explosion hazard caused by connecting or disconnecting the M12 connector when the device is in live state.

- Connect or disconnect the M12 connector only if the device is de-energized.

1. Remove the sealing cap of the M12 metal connector on the transmitter housing when delivered.
2. Connect the customer-provided M12 connector cable.
3. Place the enclosed locking clip around the M12 connector and close it until the locking clip engages, then secure the locking clip by closing the pin and pin boss.

#### RJ45 connector (optional)

A variety of options are available for the RJ45 connector through the model code: The RJ45 connector is equipped with an Ethernet cable of a specific length, depending on the model code.

The flowmeter is supplied with an Ethernet cable, which is connected to the terminals in the transmitter at the factory.

- Flowmeter equipped with 1 × RJ45 (four-wire, connection to Port 1)
- Flowmeter equipped with 2 × RJ45 (four-wire, connection to Port 1 and 2)
- Flowmeter equipped with 1 × RJ45 (eight-wire, connection to Port 1 and 2)

These options enable connection to various network topologies:

Topology	Four-wire	Four-wire	Four-wire	Eight-wire
				
	1 x RJ45 (four-wire)	2 x M12 (four-wire)		1 x RJ45 (eight-wire)
Star	Y		Y	Y
Ring or daisy chain	N		Y	N
PoE	N		N	Y

## Electrical connections

You can reference the in the transmitter and the corresponding pin assignment in the RJ45 connector in the following table:

Wiring inside the transmitter	Color	Ethernet plug-in card Port/pin
RJ45 four-wire	Yellow	Port 1 X1
	Orange	Port 1 X2
	White	Port 1 X3
	Blue	Port 1 X4
RJ45 eight-wire	White/orange	Port 1 X1
	Orange	Port 1 X2
	White/Green	Port 1 X3
	Green	Port 1 X4
	White/blue	Port 2 X5
	Blue	Port 2 X6
	White/brown	Port 2 X7
	Brown	Port 2 X8

## Use in potentially explosive atmospheres

### **WARNING**

There are limitations to the RJ45 connector in combination with an ATEX / IECEx / EAC-Ex approved flowmeter.

	No Ex area	ATEX/IECEX/E	Div 2
		AC-Ex	
		Zone 2	
Ethernet cable with RJ45 connector mounted to the transmitter housing	Y	Y	N

## ... 8 Digital communication

### ... EtherNet/IP™ and PROFINET® communication

#### Ethernet card status LEDs

The 8 LEDs on the Ethernet card indicate the status of each port and the network.

To enable card status indication in the upper HMI Line, navigate to 'Display / Display Tag / Ethernet Status'.




Figure 64: Ethernet card status LEDs

#### EtherNet/IP™ communication

LED	Status	HMI display	Description
Ⓐ Port 1	ON		Network connection (link up)
	OFF		No network
Ⓑ Activity 1	Flashing or ON		Traffic
	OFF		No traffic
Ⓒ Port 2	ON		Network connection (link up)
	OFF		No network
Ⓓ Activity 2	Flashing or ON		Traffic
	OFF		No traffic
Ⓔ Module Status (Mod)	green, ON	Mod showing <G> continuously	Device ready for Operation. Working properly
	green, Flashing (1 Hz)	Mod changing between <G> and <>	Standby. Device not configured yet
	green/ red, Flashing (1Hz)		Device performs "Power-On" Test
	red, Flashing (1 Hz)	Mod changing between <R> and <>	A fixable configuration error. For example: an incorrect or incomplete configuration.
	red, ON	Mod showing <R> continuously	Major Error. Non removable serious error, please contact service
	OFF	Mod showing <> continuously	No Power
Ⓕ Network Status (Net)	green, ON	Net showing <G> continuously	Connected. Device has at least one established connection
	green, Flashing (1 Hz)	Net changing between <G> and <>	No Connection. Device did not establish any connections, but was assigned an IP address
	green/ red, Flashing (1Hz)		Device performs "Power-On" Test
	red, ON	Net showing <R> continuously	Duplicated IP address. Device has detected that the device IP address is already in use
	OFF	Net showing <> continuously	No supply voltage or IP Address.
	red, flashing (1 Hz)	Mod changing between <R> and <>	Connection timeout

**PROFINET® communication**

LED	Status	HMI display	Description
Ⓐ Port 1	ON		Network connection (link up)
	OFF		No network
Ⓑ Activity 1	Flashing or ON		Traffic
	OFF		No traffic
Ⓒ Port 2	ON		Network connection (link up)
	OFF		No network
Ⓓ Activity 2	Flashing or ON		Traffic
	OFF		No traffic
Ⓔ Module Status (Mod)	green, ON	Mod showing <G> continuously	PROFINET configuration complete
	green, Flashing (1 Hz)	Mod changing between <G> and < >	Blink Test (Profinet)
	green/ red, Flashing (1Hz)		Device performs "Power-On" Test
	red, Flashing (1 Hz)	Mod changing between <R> and < >	A fixable configuration error. For example: an incorrect or incomplete configuration.
	red, ON	Mod showing <R> continuously	Major Error. Non removable serious error, please contact service
	OFF	Mod showing < > continuously	Startup or Device is turned off. No supply voltage.
	OFF		
Ⓕ Network-Status (Net)	green, ON	Net showing <R> continuously	PLC connected
	green, Flashing (1 Hz)	Net changing between <G> and < >	No Connection. Device did not establish any connections, but was assigned an IP address
	green/ red, Flashing (1Hz)		Device performs "Power-On" Test
	red, ON	Net showing <R> continuously	Duplicated IP address. Device has detected that the device IP address is already in use
	OFF	Net showing < > continuously	No supply voltage or IP Address. Device does not have IP Address or is turned off.
	OFF		
	red, flashing (1 Hz)	Mod changing between <R> and < >	No PLC connection

## 9 Commissioning

### Safety instructions

#### **⚠ DANGER**

##### Explosion hazard

Improper installation and commissioning of the device carries a risk of explosion.

- For use in potentially explosive atmospheres, observe the information in **Use in potentially explosive atmospheres** on page 6!

#### **⚠ CAUTION**


##### Risk of burns due to hot measuring media

The device surface temperature may exceed 70 °C (158 °F), depending on the measuring medium temperature!

- Before starting work on the device, make sure that it has cooled sufficiently.

### Hardware settings

#### Dual- compartment housing



① NAMUR DIP switch

② Write protection DIP switch

Figure 65: Position of the DIP switches

DIP switches are located behind the front housing cover. The DIP switches are used to configure specific hardware functions. The power supply to the transmitter must be briefly interrupted in order for the modified setting to take effect.

#### Write-protect switch

When write protection is activated, device parameterization cannot be changed via the LCD indicator. Activating and sealing the write protection switch protects the device against tampering


Number	Function
On	Write protection active
Off	Write protection deactivated.

#### Configuration of digital outputs 41 / 42 and 51 / 52

The configuration (NAMUR, optoelectronic coupler) for the digital outputs on the basic device is set via DIP switches in the transmitter.

Number	Function
On	Digital output 41 / 42 and 51 / 52 as NAMUR output.
Off	Digital output 41 / 42 and 51 / 52 as optoelectronic coupler output.

**Single-compartment housing**



① DIP switch, Write protection

Figure 66: Position of the DIP switch


The DIP switches are used to configure specific hardware functions. The power supply to the transmitter must be briefly interrupted or the device reset in order for the modified setting to take effect.

**Write-protect switch**

When write protection is activated, device parameterization cannot be changed via the LCD indicator. Activating and sealing the write protection switch protects the device against tampering.

Number	Function
On	Write protection active
Off	Write protection deactivated.

**Configuration of digital outputs V1 / V2 or V3 / V4**



① NAMUR rotary switch

Figure 67: Position of rotary switch on the plug-in card

The configuration (NAMUR, optoelectronic coupler) for the digital output on the plug-in card is set via a rotary switch on the plug-in card.

Number	Function
On	Digital output V1 / V2 or V3 / V4 as NAMUR output.
Off	Digital output V1 / V2 or V3 / V4 as optoelectronic coupler output.

## ... 9 Commissioning

### Checks prior to commissioning

The following points must be checked before commissioning the device:

- Correct wiring in accordance with **Electrical connections** on page 47.
- Correct grounding of the device.
- The ambient conditions must meet the requirements set out in the specification.
- The power supply must meet the requirements set out on the name plate.

### Switching on the power supply

- Switch on the power supply.

The LCD display shows the following display during the startup process:



The process display is displayed after the startup process.

### Parameterization of the device

The CoriolisMaster FCB400, FCH400 can be commissioned and operated via the integral LCD display (see **Menu: Easy Setup** on page 79).

Alternatively, the CoriolisMaster FCB400, FCH400 can also be commissioned and operated via standard HART tools. These include:

- ABB HART handheld terminal DHH805 (FCB4xx EDD)
- ABB Field Information Manager (FIM) combined with the ABB CoriolisMaster Field Device Information Package (FDI package).
- ABB 800xA control system (FCB4xx DTM)
- Other tools supporting standard HART EDDs or DTMs (FDT1.2)

#### Note

Not all tools and frame applications support DTMs or EDDs at the same level. In particular, optional or advanced EDD / DTM functions may not be available on all tools. ABB provides frame applications supporting the full range of functions and performance.

### Installation of the ABB Field Information Manager (FIM)



Download the ABB Field Information Manager (FIM) using the adjacent download link.



Download the ABB FDI package using the adjacent download link.

Installation of the software and connection to the flowmeter:

1. Install ABB Field Information Manager (FIM).
2. Unpack the ABB FDI package into the c:\temp folder.
3. Connect the flowmeter with the PC / laptop, see chapter **Parameterization via the infrared service port adapter** on page 78 or **Parameterization via HART®** on page 78.
4. Power-up the power supply for the flowmeter and start the ABB Field Information Manager (FIM).
5. Drag and drop the 'ABB.FCXxxx.01.00.00.HART.fdx' file to the ABB Field Information Manager (FIM). No special view is needed for this.
6. Right-click ① as shown in **Figure 68**.




Figure 68: Select FIM – 'Device Settings'

7. Select 'DEVICE SETTINGS' ② as shown in **Figure 68**.



Figure 69: Select FIM – COM-Port

8. Select the corresponding COM port. Close the menu by clicking on 'send'.
9. By using the [Menu] menu button on the left side, the flowmeter is displayed under 'TOPOLOGY'.




Illustration70:

All the submenus can be accessed by clicking the three points below the tag name of the flowmeter with the left mouse button ①.

## ... 9 Commissioning

### ... Parameterization of the device

#### Parameterization via the infrared service port adapter

Configuration via the infrared service port adapter on the device requires a PC / notebook and the FZA100 infrared service port adapter.

By combining the FDI package available at [www.abb.com/flow](http://www.abb.com/flow) and the ABB Field Information Manager (FIM), all parameters can be set even without a HART connection.




Figure 71: Infrared service port adapter on the transmitter (example)

1. Position the infrared service port adapter on the front plate of the transmitter as shown
2. Insert USB interface cable into a free USB female connector on the PC / notebook.
3. Switch on the device power supply.
4. Start the ABB Field Information Manager (FIM) and perform parameterization of the device.

#### Parameterization via HART®

Configuration via the HART interface of the device requires a PC / Notebook and a suited HART® Modem.

By combining the HART DTM available at [www.abb.com/flow](http://www.abb.com/flow) and the ABB Field Information Manager (FIM), all parameters can also be set via the HART protocol.




Figure 72: HART Modem on the transmitter (example)

For more detailed information on operating the software and the HART modem, please refer to the relevant operating instructions and the DTM online help.

## Basic Setup

The device can be factory parameterized to customer specifications upon request. If no customer information is available, the device is delivered with factory settings.

Settings for the most common parameters are summarized in the 'Easy Setup' menu.

This menu is the quickest way to perform the initial configuration of the device.

For information on navigating through the transmitter menu, see **Menu navigation** on page 83.

For a detailed description of all menus / parameters see Parameter description in the operating instruction.

### Menu: Easy Setup

Menu / parameter	Description
<b>Easy Setup</b>	
Language	Selection of menu language.
Unit Massflow Qm	Selection of the unit for mass flow rate (for example for the $Q_m$ Max / $Q_m$ MaxDN parameters and for the corresponding process value).
Unit Volumeflow Qv	Selection of the unit for volume flow rate (for example for the $Q_v$ Max / $Q_v$ MaxDN parameters and for the corresponding process value).
Unit Density	Selection of the unit for the density (e.g. for the associated parameters and the corresponding process values).
Unit Temperature	Selection of unit for temperature (e.g. for the associated parameters and the corresponding process values).
Unit Mass Totalizer	Selection of the unit for the mass counters and the pulse outputs.
Unit Vol. Totalizer	Selection of the unit for the volume totalizers and the pulse outputs.
Curr.Out 31 / 32 / Uco	Selection of the process value issued via the current output.
Curr.Out V1/V2	The current outputs V1 / V2 and V3 / V4 are only available if the corresponding plug-in cards are present!
Curr.Out V3/V4	
Dig.Out 41 / 42 Mode	Selection of the operating mode for the digital output 41 / 42. <ul style="list-style-type: none"> <li>• Off: Digital output 41 / 42 deactivated.</li> <li>• Logic: Digital output 41 / 42 as a binary output (e.g. as an alarm output).</li> <li>• Pulse: Digital output 41 / 42 as a pulse output. In pulse mode, pulses per unit are output (e.g. 1 pulse per m<sup>3</sup>).</li> <li>• Frequency: Digital output 41 / 42 as a frequency output. In frequency mode, a frequency is issued that is proportional to the flow rate. The maximum frequency can be configured in accordance with the upper range value.</li> </ul>

## ... 9 Commissioning

### ... Basic Setup

Menu / parameter	Description
Dig.Out 51 / 52 Mode	<p>Selection of the operating mode for the digital output 51 / 52.</p> <ul style="list-style-type: none"> <li>• Off: Digital output deactivated.</li> <li>• Logic: Digital output functions as binary output (for function see parameter '...Setup Logic Output').</li> <li>• Frequency: Digital output 51 / 52 as a frequency output. In frequency mode, a frequency is issued that is proportional to the flow rate. The maximum frequency can be configured in accordance with the upper range value.</li> <li>• Follow DO 41/42: The digital output 51 / 52 follows the function of digital output 41 / 42. Depending on the setting of the parameter 'Input/Output / ...Dig.Out 41/42 / Outp. Flow Direction', digital output 51 / 52 is operated in pulse mode as follows: <ul style="list-style-type: none"> <li>– No pulses are issued if 'Forward &amp; Reverse' is selected. Only digital output 41 / 42 is active.</li> <li>– If 'Forward' is selected, pulses for forward flow are issued on digital output 41 / 42, while pulses for reverse flow are issued on digital output 51 / 52.</li> <li>– When "Reverse" is selected, pulses for reverse flow are output on digital output 41 / 42, while pulses for forward flow are output on digital output 51 / 52.</li> </ul> </li> <li>• 90° Shift: Output of the same pulses as for digital output 41 / 42, phase shifted by 90°. Only if digital output 41 / 42 has been configured as a pulse or frequency output.</li> <li>• 180° Shift: Output of the same pulses as for digital output 41 / 42, phase shifted by 180°. Only if digital output 41 / 42 has been configured as a pulse or frequency output.</li> <li>• Follow DO 41/42 (Frequency): The digital output 51 / 52 follows digital output 41 / 42. Digital output 51 / 52 then also works as a frequency output, the settings under "... / Dig.Out 41 / 42 / ...Setup Freq Output" are accepted. The output of the frequency at digital output 51 / 52 is dependent on the setting of the register "Outp. Flow Direction" for digital output 41 / 42: <ul style="list-style-type: none"> <li>– When "Forward" is selected, a frequency for forward flow is output at digital output 41 / 42 and a frequency for reverse flow is output at digital output 51 / 52</li> <li>– When "Reverse" is selected, a frequency for reverse flow is output at digital output 41 / 42 and a frequency for forward flow is output at digital output 51 / 52</li> </ul> </li> <li>• 180° Shift (Frequency): Output of the same frequency as for digital output 41 / 42, phase shifted by 180°</li> </ul> <p><b>Note</b></p> <p>If digital output 41 / 42 has been configured as pulse or frequency output, digital output 51 / 52 can be configured separately as binary or frequency output.</p> <p>However, digital output 51 / 52 cannot be configured as a second independent pulse output.</p>

Menu / parameter	Description
<b>Easy Setup</b>	
Dig.Out V1 / V2 Mode	<p>Selection of the operating mode for digital output V1 / V2.</p> <p>Digital output V1 / V2 is only available if the corresponding plug-in card is present!</p> <ul style="list-style-type: none"> <li>• Off: Digital output V1 / V2 deactivated.</li> <li>• Logic: Digital output V1 / V2 as a binary output (for example, as an alarm output).</li> </ul>
Dig.Out V3 / V4 Mode	<p>Selection of the operating mode for digital output V3 / V4.</p> <p>Digital output V3 / V4 is only available if the corresponding plug-in card is present!</p> <ul style="list-style-type: none"> <li>• Off: Digital output V3 / V4 deactivated.</li> <li>• Logic: Digital output V3 / V4 as a binary output (for example, as an alarm output).</li> </ul>
Dig.Out 51/52 Freq.	<p>The operating modes are available with an APO card only. When these operating modes are selected, DO51 / 52 is mirrored to V3 / V4.</p> <ul style="list-style-type: none"> <li>• Frequency: Digital output V3 / V4 as a frequency output. In frequency mode, a frequency is issued that is proportional to the flow rate. The maximum frequency can be configured in accordance with the upper range value.</li> <li>• Follow DO 41/42: Digital output V3 / V4 follows the function of digital output 41 / 42. Depending on the setting of the 'Input/Output / ...Dig.Out 41/42 / Outp. Flow Direction' parameter, digital output V3 / V4 is operated in pulse mode as follows: <ul style="list-style-type: none"> <li>– No pulses are issued if 'Forward &amp; Reverse' is selected. Only digital output 41 / 42 is active.</li> <li>– When 'Forward' is selected, pulses for forward flow are output on digital output 41 / 42, while pulses for reverse flow are output on digital output V3 / V4.</li> <li>– When 'Reverse' is selected, pulses for reverse flow are output on digital output 41 / 42, while pulses for forward flow are output on digital output V3 / V4.</li> </ul> </li> <li>• 90° Shift: Output of the same pulses as for digital output 41 / 42, phase shifted by 90°. Only if digital output 41 / 42 has been configured as a pulse or frequency output.</li> <li>• 180° Shift: Output of the same pulses as for digital output 41 / 42, phase shifted by 180°. Only if digital output 41 / 42 has been configured as a pulse or frequency output.</li> <li>• Follow DO 41/42 (Frequency): Digital output V3 / V4 follows digital output 41 / 42. Digital output V3 / V4 then also works as a frequency output, the settings under '... / Dig.Out 41 / 42 / ...Setup Freq Output' are accepted. The output of the frequency at digital output V3 / V4 is dependent on the setting of the register 'Outp. Flow Direction' for digital output 41 / 42: <ul style="list-style-type: none"> <li>– When 'Forward' is selected, a frequency for forward flow is output at digital output 41 / 42 and a frequency for reverse flow is output at digital output V3 / V4</li> <li>– When 'Reverse' is selected, a frequency for reverse flow is output at digital output 41 / 42 and a frequency for forward flow is output at digital output V3 / V4</li> </ul> </li> <li>• 180° Shift (Frequency): Output of the same frequency as for digital output 41 / 42, phase shifted by 180°</li> </ul> <p><b>Note</b></p> <p>Digital output V3 / V4 cannot be configured as an additional independent frequency output (operating mode 'Frequency (=51 / 52)'). Digital output V3 / V4 can be configured separately as a binary or frequency output. However, digital output V3 / V4 cannot be configured as a second independent pulse output.</p>

## ... 9 Commissioning

### ... Basic Setup

Menu / parameter	Description
DO 41/42 Freq.	Selection of process value issued via the frequency or pulse output.
Dig.Out 41/42 Pulse	Only if digital output 41 / 42 has been configured as a frequency or pulse output.
Dig.Out 51/52 Freq.	
FrequencyV3 / V4	
Dig.Out 41 / 42 Logic	Selection of the output function for the relevant binary output.
Dig.Out 51 / 52 Logic	<ul style="list-style-type: none"> <li>• F / R Signal: The binary output signals the flow direction.</li> <li>• Dual Range: The binary output is activated when measuring range 2 (QmMax 2 / QvMax 2) is selected. This selection is only available if the parameter 'Range Mode Config' has been configured to Qm or Qv.</li> <li>• Batch End Contact: The binary output is activated when the set fill quantity is reached (only if the FillMass function is activated).</li> </ul>
Dig.Out V1 / V2 Logic	Only if the relevant digital output has been configured as a binary output.
Dig.Out V3 / V4 Logic	
Qm Max	Sets the upper range value for the mass flow for forward and reverse flow. The value is also used to calculate the corresponding percentage value.
Qv Max	Setting of the upper measuring range value 1 for the volume flow for feed flow and reverse flow. The value is also used to calculate the corresponding percentage value.
Density Max	Sets the maximum / minimum density to be measured. This value is used to calculate the percentage density value. These parameters are only available if the density output 'Density [unit]' was selected when configuring the power and digital outputs.
Density Min	
Pulses per Unit	Set pulses per volume or per mass flow unit, and the pulse width for the digital output operating mode 'Pulse'. Only available if a digital output has been configured as a pulse output, and the volume flow or mass flow has been selected as the process variable to be output.
Pulse Width	
Upper Frequency41 / 42	Sets the upper range value frequency for the digital output operating mode 'Frequency'. The entered value corresponds to 100 % flow.
Upper Frequency51 / 52	
Upper FrequencyV3 / V4	Only available if a digital output has been configured as a frequency output, and the volume flow or mass flow has been selected as the process variable to be output.
System Zero	Starts the automatic zero point balancing using  . Automatic zero point balancing takes approx. 60 seconds.
	<p><b>Note</b></p> <p>Prior to starting the zero point adjustment, make sure that:</p> <ul style="list-style-type: none"> <li>• There is no flow through the sensor (close all valves, shut-off devices etc.)</li> <li>• The sensor must be filled completely with measuring medium for measurement.</li> </ul>

## 10 Operation

### Safety instructions

#### ⚠ CAUTION

##### Risk of burns due to hot measuring media

The device surface temperature may exceed 70 °C (158 °F), depending on the measuring medium temperature!


- Before starting work on the device, make sure that it has cooled sufficiently.

If there is a chance that safe operation is no longer possible, take the device out of operation and secure it against unintended startup.

### Menu navigation

#### Note

For detailed information on the operation and parameterization of the device, consult the associated operating instructions (OI)!



- ① Operating buttons for menu navigation
- ② Menu name display
- ③ Menu number display
- ④ Marker for indicating relative position within the menu
- ⑤ Display showing the current functions of the  and  operating buttons

Figure 73: LCD display

The LCD indicator has capacitive operating buttons. These enable you to control the device through the closed housing cover.

#### Note

The transmitter automatically calibrates the capacitive buttons on a regular basis. If the cover is opened during operation, the sensitivity of the buttons is firstly increased to enable operating errors to occur. The button sensitivity will return to normal during the next automatic calibration.

You can use the  or  operating buttons to browse through the menu or select a number or character within a parameter value.

Different functions can be assigned to the  and  operating buttons. The function ⑤ that is currently assigned to them is shown on the LCD display.


#### Control button functions

	Meaning
Exit	Exit menu
Back	Go back one submenu
Cancel	Cancel a parameter entry
Next	Select the next position for entering numerical and alphanumeric values

	Meaning
Select	Select submenu / parameter
Edit	Edit parameter
OK	Save parameter entered

## ... 10 Operation

### Menu levels



#### Process display

The process display shows the current process values.

From the level of the process display, you can branch out into two menu levels (information level, configuration level).

#### Information level (Operator Menu)


The information level contains the parameters and information that are relevant for the operator.

The device configuration cannot be changed on this level.

#### Configuration level (Configuration)

The configuration level contains all the parameters required for device commissioning and configuration. The device configuration can be changed on this level. For additional information on the parameters, see **Parameter description** in the operating instruction.

## Process display



- ① Measuring point tagging
- ② Current process values
- ③ 'Button function' symbol
- ④ 'Parameterization protected' symbol

Figure 74: Process display (example)

The process display appears on the LCD display when the device is powered on. It shows information about the device and current process values.

The way in which the current process values are shown can be adjusted on the configuration level.

The symbols at the bottom of the process display are used to indicate the functions of the operating buttons  and , in addition to other information.


Symbol	Description
 / 	Call up information level. When Autoscroll mode is activated, the  icon appears here and the operator pages are automatically displayed one after the other.
	Call up configuration level.
	The device is protected against changes in the parametrization.

## Switching to the information level

On the information level, the operator menu can be used to display diagnostic information and choose which operator pages to display.



1. Open the  using Operator Menu.



2. Select the desired submenu using  / .
3. Confirm the selection with .


Menu	Description
... / Operator Menu	
<b>Diagnostics</b>	Selection of sub-menu 'Diagnostics'; see also <b>Error messages on the LCD display</b> on page 86.
Operator Page 1 to n	Selection of operator page to be displayed.
Autoscroll	When 'Autoscroll' is activated, automatic switching of the operator pages is initiated on the process screen.
<b>Signals View</b>	Selection of submenu 'Signals View' (only for service purposes).

## ... 10 Operation

### Error messages on the LCD display

In the event of an error, a message consisting of a symbol and text (e.g. Electronics) appears at the bottom of the process screen.

The text displayed provides information about the area in which the error has occurred.



The error messages are divided into four groups in accordance with the NAMUR classification scheme. The group assignment can only be changed using a DTM or EDD:

Symbol	Description
	Error / failure
	Function check
	Outside of the specification
	Maintenance required

The error messages are also divided into the following areas:

Range	Description
Operation	Error / alarm due to the current operating conditions.
Sensor	Error / alarm of the flowmeter sensor.
Electronics	Error / alarm of the electronics.
Configuration	Error / alarm due to device configuration.

#### Note


For a detailed description of errors and information regarding troubleshooting, refer to the chapter titled "Diagnosis / Error messages" in the operating instruction.

### Switching to the configuration level (parameterization)

The device parameters can be displayed and changed on the configuration level.



1. Switch to the configuration level with



2. Select the desired level of access using / .
3. Confirm the selection with .


#### Note

There are three levels of access. A password can be defined for level 'Standard'.

- There is no factory default password. For security reasons it is recommended to set a password.
- The password prevents access to the parameterization via the buttons on the device. For further access protection via DTM or EDD (HART®, PROFIBUS®, Modbus®) the hardware write protection switch must be set (see **Hardware settings** on page 74).

Access Level	Description
Read Only	All parameters are locked. Parameters are read only and cannot be modified.
Standard	All the parameters can be changed.
Service	Only ABB Customer Service has access to the Service menu.

Once you have logged on to the corresponding access level, you can edit or reset the password. Reset (status 'no password defined') by selecting '☰' as a password.



4. Enter the appropriate password. No password is preset in the factory settings. Users can switch to the configuration level without entering a password.  
The selected access level remains active for 3 minutes. Within this time period you can toggle between the process display and the configuration level without re-entering the password.
5. Use  to confirm the password.

The LCD display now indicates the first menu item on the configuration level.

6. Select a menu using  / .
7. Confirm the selection with .


### Resetting the customer password

If the set password has been forgotten, the password can be reset and reassigned.

A one-time password is needed for this purpose and can be generated by ABB Service upon request.

To reset the password, the password has to be entered incorrectly once for the 'Standard' user level. When the configuration level is called up again, a new entry 'Reset credentials' then appears in the list of access levels.

1. Switch to the configuration level with .



2. Use  /  to select the 'Reset credentials' entry.
3. Confirm the selection with .



4. Contact ABB Service and request a one-time password, stating the 'ID' and 'Pin' shown.
5. Enter the one-time password.

### Note

The one-time password is only valid once and needs to be separately requested with each password reset.

6. Confirm the input with .


After the one-time password has been entered, the password for the 'Standard' access level is reset and can be reassigned.

## ... 10Operation


### Selecting and changing parameters

#### Entry from table

When an entry is made from a table, a value is selected from a list of parameter values.



1. Select the parameters you want to set in the menu.
2. Use to call up the list of available parameter values. The parameter value that is currently set is highlighted.




3. Select the desired value using / .
4. Confirm the selection with .


This concludes the procedure for selecting a parameter value.

#### Numerical entry

When a numerical entry is made, a value is set by entering the individual decimal positions.



1. Select the parameters you want to set in the menu.
2. Use to call up the parameter for editing. The decimal place that is currently selected is highlighted.




3. Use to select the decimal place to change.
4. Use / to set the desired value.
5. Use to select the next decimal place.
6. If necessary select and set additional decimal places in accordance with steps 3 to 4.
7. Use to confirm your setting.


This concludes the procedure for changing a parameter value.

#### Alphanumeric entry

When an alphanumeric entry is made, a value is set by entering the individual decimal positions.



1. Select the parameters you want to set in the menu.
2. Use to call up the parameter for editing. The decimal place that is currently selected is highlighted.



3. Use to select the decimal place to change.
4. Use / to set the desired value.
5. Use to select the next decimal place.
6. If necessary select and set additional decimal places in accordance with steps 3 to 4.
7. Use to confirm your setting.

This concludes the procedure for changing a parameter value.

### Exiting the setup

For some menu items, values must be entered. If you don't want to change the parameter, you can exit the menu as described below.

1. Pressing  (Next) repeatedly moves the cursor to the right. Once the cursor reaches the end position, 'Cancel' is displayed in the lower right of the screen.
2.  terminates editing and exits the menu item. Use  to return to the start.

### Note

The LCD display automatically returns to the process display three minutes after the last button has been actuated.

## 11 Maintenance / Repair

### Safety instructions

#### **WARNING**

##### **Loss of Ex-approval!**

Loss of Ex approval due to replacement of components in devices for use in potentially explosive atmospheres.

- Devices for use in potentially explosive atmospheres may be serviced and repaired by qualified ABB personnel only.
- For measuring devices for potentially explosive atmospheres, observe the relevant operator guidelines. See also **Use in potentially explosive atmospheres** on page 6.

#### **CAUTION**

##### **Risk of burns due to hot measuring media**

The device surface temperature may exceed 70 °C (158 °F), depending on the measuring medium temperature!

- Before starting work on the device, make sure that it has cooled sufficiently.

#### **Note**

For detailed information on the maintenance of the device, consult the associated operating instructions (OI)!

## 12 Dismounting and disposal

### Dismounting

#### **WARNING**

##### **Risk of injury due to process conditions.**

The process conditions, for example high pressures and temperatures, toxic and aggressive measuring media, can give rise to hazards when dismantling the device.

- If necessary, wear suited personal protective equipment during disassembly.
- Before disassembly, make sure that the process conditions do not pose any safety risks.
- Depressurize and empty the device / piping, allow to cool and purge if necessary.

Bear the following points in mind when dismantling the device:

- Switch off the power supply.
- Disconnect electrical connections.
- Allow the device / piping to cool and depressurize and empty. Collect any escaping medium and dispose of it in accordance with environmental guidelines.
- Use suited tools to disassemble the device, taking the weight of the device into consideration.
- If the device is to be used at another location, the device should preferably be packaged in its original packing so that it cannot be damaged.
- Observe the notices in **Returning devices** on page 30.

## Disposal

### Note



Products that are marked with the adjacent symbol may **not** be disposed of as unsorted municipal waste (domestic waste).

They should be disposed of through separate collection of electric and electronic devices.

This product and its packaging are manufactured from materials that can be recycled by specialist recycling companies.

Bear the following points in mind when disposing of them:

- As of 8/15/2018, this product will be under the open scope of the WEEE Directive 2012/19/EU and relevant national laws (for example, ElektroG - Electrical Equipment Act - in Germany).
- The product must be supplied to a specialist recycling company. Do not use municipal waste collection points. These may be used for privately used products only in accordance with WEEE Directive 2012/19/EU.
- If there is no possibility to dispose of the old equipment properly, our Service can take care of its pick-up and disposal for a fee.

## 13 Specification

### Note

The device data sheet is available in the ABB download area at [www.abb.de/flow](http://www.abb.de/flow).

## 14 Additional documents

### Note

All documentation, declarations of conformity, and certificates are available in ABB's download area.

[www.abb.com/flow](http://www.abb.com/flow)

## Trademarks

CIP (Common Industrial Protocol) is a trademark of ODVA Inc.

EtherNet/IP is a trademark of ODVA Inc.

HART is a registered trademark of FieldComm Group, Austin, Texas, USA

Hastelloy is a registered trademark of Haynes International, Inc.

Modbus is a registered trademark of Schneider Automation Inc.

PROFIBUS®, PROFIBUS DP® and PROFINET® are registered trademarks of PROFIBUS & PROFINET International (PI)

## 15 Appendix

### Return form

#### Statement on the contamination of devices and components

Repair and/or maintenance work will only be performed on devices and components if a statement form has been completed and submitted.

Otherwise, the device/component returned may be rejected. This statement form may only be completed and signed by authorized specialist personnel employed by the operator.

#### Customer details:

Company: \_\_\_\_\_

Address: \_\_\_\_\_

Contact person: \_\_\_\_\_

Telephone: \_\_\_\_\_

Fax: \_\_\_\_\_

Email: \_\_\_\_\_

#### Device details:

Type: \_\_\_\_\_

Serial no.: \_\_\_\_\_

Reason for the return/description of the defect: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

#### Was this device used in conjunction with substances which pose a threat or risk to health?

Yes       No

If yes, which type of contamination (please place an X next to the applicable items):

biological

corrosive / irritating

combustible (highly / extremely combustible)

toxic

explosive

other toxic substances

radioactive

Which substances have come into contact with the device?

1. \_\_\_\_\_

2. \_\_\_\_\_

3. \_\_\_\_\_

We hereby state that the devices/components shipped have been cleaned and are free from any dangerous or poisonous substances.

\_\_\_\_\_  
Town/city, date

\_\_\_\_\_  
Signature and company stamp

## Notes

## Notes

## Notes

---

**ABB Measurement & Analytics**

For your local ABB contact, visit:  
**[www.abb.com/contacts](http://www.abb.com/contacts)**

For more product information, visit:  
**[www.abb.com/flow](http://www.abb.com/flow)**

---

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail.  
ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB.