# Summary Operating Instructions
Reset functions 8186/31-500

1. Reset functions for device 8186/31-500

Detail X

2. Reset to factory settings

- Create a bridge during operation for at least 5 to a maximum of 30 seconds (illustration, Detail X)
- The system starts with the factory settings.

ABB