LED INDICATION	STATUS	COMMENTARY
Permanent Green	Everything Working Correctly	
Fast Flashing Green (0.1 Sec ON - 0.1 sec OFF)	Function Test in Progress	
Slow Flashing Green (1 sec ON-1 sec OFF)	Duration Test In Progress	
Permanent Yellow	Load Failure	Open Circuit/Short Circuit/LED Failure
Slow Flashing Yellow (1 sec ON-1 sec OFF)	Battery Failure	Battery Failed Duration or Function Test Battery is Defective/Wrong Battery Voltage
Fast Flashing Yellow (0.1 sec ON-0.1 sec OFF)	Charging Failure	Incorrect Charging Current
Green and Yellow OFF	DC Mode	Battery Operation(Emergency Mode)

TECHNICAL INFORMATION

Model Number	Input Voltage	Charge Duration	Discharge Duration	Battery	Power	LEDS
XT230RS/DALI	220-240V~ 50/60HZ	24 h	3 h	Ni-Mh 3.6V 2.0Ah	3.5 W Max	SMD 2835 14 pcs

Explanations

	Maintained Luminaire	Non-maintained Luminaire	Switched Maintained Luminaire	
				OK ✓
				Emergency mode
				Failure-Battery Charge

XT230RS/DALI

Instruction Leaflet

ABB BV
C/O Thomas & Betts European Centre
Boulevard Millenium 8
B – 7110 Houdeng-Goegnies
Belgium

UK Contact
Telephone +44 (0) 113 281 0600
Sales +44 (0) 113 281 0610
Fax +44 (0) 113 281 0601
Email LV.enquiries@gb.abb.com

Deutschland Kontakt:
Busch-Jaeger Elektro
Ein Unternehmen der ABB Gruppe
Freisenbergerstrasse 2
58513 Lüdenscheid

Zentraler Vertriebsservice
Tel: +49 (0)2351 956 1600
Fax: +49 (0)2351 956 1700

Website: **solutions.abb/led-sicherheitsbeleuchtung**

Other countries:
For more information, please reach out to our ABB local contact center.
Find out on: **new.abb.com/contact-centers**

Note: We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders and/or contracts, the agreed particularsshall prevail. ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein.
Any reproduction, disclosure to third parties or utilisation of its contents - in whole or in parts -is forbidden without prior written consent of ABB.

Copyright © 2020 ABB
All rights reserved

Technical Specifications

Power Supply	: 220-240VAC, 50/60 Hz
Power Consumption	: Max. 3.5W
Ambient Operating Temp	: -5°C...+45°C
Charge Time	: 24 Hours
Operation	: Maintained and non-maintained
Emergency Duration	: 3 Hours
Protection Class	: II
IP Rating	: IP20
Function	: DALI
Installation	: Wall mount or Ceiling mount
Viewing distance	: 30m

PRECAUTIONS

Carefully read this instruction leafet before installing or using the luminaire.
This leafet provides important information about the correct installation, use, maintenance and disposal of this product. Please observe the following guidelines:

1. Installation must be in accordance with European installation requirements HD 60364 and additional local regulations.
2. This product may not be modified in any way what so ever or used for a purpose or in an environment other than for which it is designed. Failing to observe these guidelines will invalidate the warranty and the CE-compliance of this product.
3. The luminaire is suitable for indoor use only
4. Before installing the luminaire, the supply must be isolated.
5.The luminaire should be connected to the voltage equivalent to that indicated on the type label

SERVICE & OPERATION

Normal Operation: The green indicator light on face plate stays on. The LED will go out if the mains supply fails, the internal charger malfunctions, or the unit is in test mode.
Battery: Sealed Ni-Cad or Ni-Mh rechargeable battery pack. Battery should be replaced when the required duration is no longer achieved. To avoid any damage to the fixture and ensure its performance, the battery should be replaced with same brand and type.
Test Switch: Press the test switch button, LED indicator will go out and the sign will be illuminate from its battery pack.

WARNING:

The luminaire must, under no circumstances, be covered with insulating material or similar material only

MOUNTING INSTRUCTIONS

① Dispart mounting plate

ⓐ Insert flat screwdriver into slot on side of unit, pry off and remove the mounting plate from unit.
ⓑ Disconnect AC connector from PCBA.

② Wall mounting or Ceiling mounting

ⓐ Knock out appropriate center cable entry hole and mounting screw hole on the mounting plate.
ⓑ Route AC supply wire through center hole of mounting plate.
ⓒ Fix mounting plate on the mount surface with screws and anchor nuts.

③ Wiring connection
Suitable cable 0.75-2.5mm²

Connect the AC supply wire to terminal block. Refer to wiring instruction showed below.

④ Connect battery

Connect battery male and female connector inside of mounting bracket.

⑤ Change pictogram when necessary

Remove the pictogram on the unit, select other pictogram you need then insert into slot of panel.

⑥ Finish installation

Snap AC supply on PCBA and then snap fixture to mounting plate.

WIRING INSTRUCTIONS

PICTOGRAM STYLES

MOUNTING OPTIONS

Commissioning Test Behaviour

Initial connection of the mains supply will initiate a commissioning sequence where the battery will remain on charge and test for an uninterrupted 60 hours. Any interruption of the mains supply during this period will reset the counter to zero.
The sequence is : to charge for 24hours. Having fully charged the battery, then execute a duration test.
Upon successful completion of the duration test, the gear will perform another full charge period of 24hours.
After this period, it is suggested to perform a function test and then check for successful completion of the function and duration tests.
Therefore, after initial mains power on, it is best to leave the gear alone for 60 hours to allow the gear to complete its pre-programmed commissioning testing. During the 60 hour period, any attempt to have the gear perform a function or duration test will simply result in the requested test being 'pended'.
Following the commissioning test it will then perform whatever tests are pended. Meaning that if you had pressed "start duration test", at the end of commissioning, the gear will perform another duration test and another subsequent charge period before normal operations could be resumed.

Gear Behaviour After Battery Change (meaning Disconnect / Reconnect battery)

After changing the battery, the gear will perform a complete commissioning sequence, as described above, irrespective of the condition of the battery.

Function test

A 5 second functional test is carried out at nominally 1 week interval.

Duration test

The gear switches to battery supply with mains supply off, and runs until the batteries can no longer supply the lamp
The length of time to run out is recorded in memory.
A pass result indicates the battery powered the fitting and lamp for the rated period of this fitting.
A full rated duration test is carried out nominally at 52 weeks intervals.

In DALI mode, the start of the regular duration and function tests, is initiated by the attached controller.
If the DALI controller is not available, the gear will revert to its automated settings.