EXTERNAL

ELECTRIFICATION – SMART BUILDINGS

Configure ReliaGear™ OEM lighting panelboards using ABB empower configuration tool

Quick guide

© Copyright 2021 ABB. All rights reserved.

Document ID.: 1TQC174200E0011

Rev.: REV.A DECEMBER 2021

Proprietary Statement

This presentation and any of its contents, including but not limited to images, information, communications, know-how, etc., is the sole property of ABB and/or its Affiliates ("ABB") and are not to be used by you other than to evaluate ABB's products/services. This presentation and any of its contents are not to be disseminated, distributed or otherwise conveyed throughout your organization to employees without the need for this information or to any third parties without the express written permission of ABB.

ReliaGear™ OEM lighting panelboards

Empower configurator tool selection

This quick guide will help you select ReliaGear OEM lighting lighting panelboards, Type G or Type L on the ABB empower configurator tool. Users must have an ABB empower account with access to the ABB empower Quote module.



©ABB

ReliaGear™ OEM lighting panelboards

Accessing to the Empower configurator tool - Panelboards

1 After you logged in on ABB empower, hit on create a new quote, add a new item, and select **panelboards.**





This presentation contains confidential and proprietary information intended for sole use by ABB or its representatives. ABB reserves all rights in this document and in the subject matter and the illustrations contained therein. Any reproduction, disclosure to a third party, or utilization of its contents—in whole or in part—is forbidden without prior written consent from ABB.

ReliaGear™ OEM lighting Panelboards

Lineup panelboard configuration

2

Hit on the Lineup tab and drop down on the fields available to select the configuration for your **panelboard.**



This presentation contains confidential and proprietary information intended for sole use by ABB or its representatives. ABB reserves all rights in this document and in the subject matter and the illustrations contained therein. Any reproduction, disclosure to a third party, or utilization of its contents—in whole or in part—is forbidden without prior written consent from ABB.

ReliaGear™ OEM lighting Panelboards

Empower configurator tool selection

3

Click the “**Incoming device**” tab to select incoming device type and configuration.



This presentation contains confidential and proprietary information intended for sole use by ABB or its representatives. ABB reserves all rights in this document and in the subject matter and the illustrations contained therein. Any reproduction, disclosure to a third party, or utilization of its contents—in whole or in part—is forbidden without prior written consent from ABB.

ReliaGear™ OEM lighting Panelboards

Empower configurator tool selection

4

Go to the “**Feeders**” tab to select branch breakers



This presentation contains confidential and proprietary information intended for sole use by ABB or its representatives. ABB reserves all rights in this document and in the subject matter and the illustrations contained therein. Any reproduction, disclosure to a third party, or utilization of its contents—in whole or in part—is forbidden without prior written consent from ABB.

ReliaGear™ OEM lighting Panelboards

Selecting ReliaGear OEM lighting panelboards

5

Hit “**Options**” and then “**Add**” a new window will appear.



This presentation contains confidential and proprietary information intended for sole use by ABB or its representatives. ABB reserves all rights in this document and in the subject matter and the illustrations contained therein. Any reproduction, disclosure to a third party, or utilization of its contents—in whole or in part—is forbidden without prior written consent from ABB.

ReliaGear™ OEM lighting Panelboards

Selecting Type L panelboards

6

Select “**OEM – OEM Panel**” for Type L panelboards



This presentation contains confidential and proprietary information intended for sole use by ABB or its representatives. ABB reserves all rights in this document and in the subject matter and the illustrations contained therein. Any reproduction, disclosure to a third party, or utilization of its contents—in whole or in part—is forbidden without prior written consent from ABB.

ReliaGear™ OEM lighting Panelboards

Checking Type L selection in drawings tab



7

Click on “**Drawings**,” a document with a summary will appear, confirm that Type L appears under options and a “**L**” letter on the 3rd character of the interior code shows it is a “**Type L**” panelboard



This presentation contains confidential and proprietary information intended for sole use by ABB or its representatives. ABB reserves all rights in this document and in the subject matter and the illustrations contained therein. Any reproduction, disclosure to a third party, or utilization of its contents—in whole or in part—is forbidden without prior written consent from ABB.

ReliaGear OEM lighting Panelboards

Selecting Type G panelboards

8

Select “**GOEM – Global OEM**” for Type G panelboards



This presentation contains confidential and proprietary information intended for sole use by ABB or its representatives. ABB reserves all rights in this document and in the subject matter and the illustrations contained therein. Any reproduction, disclosure to a third party, or utilization of its contents—in whole or in part—is forbidden without prior written consent from ABB.

ReliaGear OEM lighting Panelboards

Checking Type G selection in drawings tab



9

Click on “**Drawings**,” a document with a summary will appear. Within the panel information table, a “**G**” letter on the 3rd character of the interior code shows it is a “**Type G**” panelboard



This presentation contains confidential and proprietary information intended for sole use by ABB or its representatives. ABB reserves all rights in this document and in the subject matter and the illustrations contained therein. Any reproduction, disclosure to a third party, or utilization of its contents—in whole or in part—is forbidden without prior written consent from ABB.

Thank you for your business!

For more information

electrification.us.abb.com

ABB