

3D Printing PowerPac

Install Instruction

Thank you for using the 3D Printing PowerPac. This document will guide you through the installation process of the PowerPac.


Prerequisites

To install the 3D Printing PowerPac you need to use Windows 10 or Windows 11 with the latest release of RobotStudio. If you need to download RobotStudio you can do so here:


<https://new.abb.com/products/robotics/robotstudio/downloads>

Installation


1. Click on the Add-Ins Tab in RobotStudio



2. Click on Install Package



3. Select the downloaded .rspak file from the uncompressed downloaded file.
4. Ensure that the 3DP PowerPac is installed under Add-Ins.



5. Follow the procedure for installing a licenses as in RobotStudio