

**CPTC-02 ATEX-certified thermistor protection module**Instructions for pairing the module with an ATEX-certified drive

This document instructs how to pair the CPTC-02 module with an ATEX-certified ACS580, ACH580 or ACQ580 drive in the ABB Drive Installed Base (DIP) register. Pairing is mandatory. Otherwise the drive ATEX certification is not valid.

## Requirements

Before you install the module and start the pairing, write down the serial numbers of the drive and the CPTC-02 module. The data is needed in the pairing process. Serial numbers are on the type designation labels.

The installer of the module must do the pairing.

You can pair the CPTC-02 module only when you have the DIB register access. If you do not have it yet, send an access request. See the instructions below.

## Other requirements:


- Make sure that drive serial number starts with 1, 4, 7, 8, M or Y.
- Make sure that you have done the installation and start up (incl. validation test) of the CPTC-02 module and set applicable drive parameters according to the instructions in CPTC-02 user's manual.
- Make sure that you have attached the ATEX label for the Safe Motor Temperature (SMT) function
  to the drive module nearby the standard rating plate to indicate the ATEX compliance of the
  installation. The label is included in the CPTC-02 installation kit.

## **Pairing instructions**


1. Go to the site:

https://businessapps.abb.com/sites/DrivesIB4/Pages/default.aspx.


 If you don't already have access for the ABB Drives Installed Base register, create a new user access request.




3. Click "Drives" on the homepage.




4. Type the serial number of the drive to the "Serial number search" field and and click the search icon.



5. Click the serial number on the search results.



6. Click "Edit drive".



 Select "ATEX" to the "Related serial type" field and type the serial number of the CPTC-02 module.

Click "Save" for ending the process.

