

—
INSTALLATION INSTRUCTION


Auxiliary contact

OA2G11




OA2G11


OT16-40F3
OA2G11 OA2G11



OT63-80F3
OA2G11 OA2G11






OT100-125F3
OA2G11 OA2G11





OA2G11

OT16-40F3




OT63-125F



OT16-125F


OA2G11

OA2G11



83 71 43 31
84 72 44 32
83 71 43 31
84 72 44 32

13 21 53 61
14 22 54 62
13 21 53 61
14 22 54 62



8-10 mm

2 x 0,75...2,5 mm²
2x18...14AWG

0,8 Nm
7 lb.in

POZIDRIVE
M3,5 Form 2



Contact us

ABB Oy

P.O. Box 622
FI-65101 Vaasa
Finland

abb.com/lowvoltage