



—
INSTALLATION INSTRUCTION

Module for auxiliary contacts



OZXXK18




Module for auxiliary contacts




OZXK18 Module can be used with all OT1000-2500 switch disconnector variants.




Early operation





Normal operation



OBEA10
Normal Close
operation
1...9 pcs



OBEA01
Normal Open
operation
1...9 pcs





Contact us

ABB Oy

P.O. Box 622
FI-65101 Vaasa
Finland

abb.com/lowvoltage



UK importer: ABB Limited
Tower Court
Coventry CV6 5NX
United Kingdom