



—
INSTALLATION INSTRUCTION

Neutral link


OSZ1-2



OSZ1



OSZ2





Contact us

ABB Oy

P.O. Box 622
FI-65101 Vaasa
Finland

abb.com/lowvoltage