

SACE Tmax XT

KLC - Blocco chiave Ronis 1228 in posizione aperta XT7

KLC - Ronis 1228 key lock in XT7 open position



KLC - Schlüsselverriegelung Ronis 1228 in Position aus XT7

KLC - Verrouillage par clé Ronis 1228 en position ouverte XT7

KLC - Bloqueo llave Ronis 1228 en posición abierta XT7


KLC - 钥匙 Ronis 1228 被锁定在打开位置 XT7

XT7





A



B






1

2









8

W




9

W




10

W




11

W




12



W




13

W






1SDA105070R1




Posizione chiave estraibile - blocco non attivo
 Key in removable position - lock not activated
 Position Schlüssel abziehbar - Verriegelung nicht aktiv
 Position clé extractible - verrouillage non actif
 Posición llave extraíble - bloqueo inactivo
 可拔取的钥匙位置 - 未激活锁定

1SDA105070R1




Posizione chiave estraibile - blocco attivo
 Key in removable position - lock activated
 Position Schlüssel abziehbar - Verriegelung aktiv
 Position clé extractible - verrouillage actif
 Posición llave extraíble - bloqueo activo
 可拔取的钥匙位置 - 激活锁定

1SDA105071R1
 1SDA105072R1
 1SDA105073R1
 1SDA105074R1
 1SDA105075R1



Posizione chiave non estraibile - blocco non attivo
 Key in not removable position - lock not activated
 Position Schlüssel nicht abziehbar - Verriegelung nicht aktiv
 Position clé non extractible - verrouillage non actif
 Posición llave no extraíble - bloqueo inactivo
 不可拔取的钥匙位置 - 未激活锁定

1SDA105071R1
 1SDA105072R1
 1SDA105073R1
 1SDA105074R1
 1SDA105075R1



Posizione chiave estraibile - blocco attivo
 Key in removable position - lock activated
 Position Schlüssel abziehbar - Verriegelung aktiv
 Position clé extractible - verrouillage actif
 Posición llave extraíble - bloqueo activo
 可拔取的钥匙位置 - 激活锁定