

ReliaGear[™] neXT Panelboard

Low Voltage Power Panel - Bulk Pack/Unassembled Version


WARNING

Danger of electrical shock or injury. Turn OFF power ahead of the panel board or switchboard before working inside the equipment or removing any component. Equipment is to be installed and maintained by properly trained and qualified personnel only.





			H		1X
A		1X	0		1X
B		1X	1	N	1X
G		1X	K		1X
D		1X	C		1X
•		1X	M		1X
F		1X	N		1X
G		1X			






Bus stack









Can be installed in any of the four corners

Grounds

For further information see 1SQC900007M0201




Vertical main - XT7 B-phase components only included for 3-phase assemblies




6a

Vertical main - XT5 B-phase components only included for 3-phase assemblies




Horizontal main - XT7 B-phase components only included for 3-phase assemblies




ReliaGear™ neXT | ABB

6b


Horizontal main - XT6 B-phase components only included for 3-phase assemblies




Horizontal main - XT5 B-phase components only included for 3-phase assemblies



Horizontal main XT1 single mount B-phase components only included for 3-phase assemblies




Horizontal main – Group mounting of 2 adjacent XT1 B-phase components only included for 3-phase assemblies




11


Horizontal main – Group mounting of 5 adjacent XT1 B-phase components only included for 3-phase assemblies




Horizontal main - XT4 B-phase components only included for 3-phase assemblies




12




FB assembly 2P




STEY assembly 1P




STEY assembly 2P






A2 assembly




19

Blanks




21


Fillers and Fronts (for vertical main)




12



Gutter doors and spacers



Standard locking doors and spacers



25





Disclaimer : These instructions do not cover all details or variations in equipment nor do they provide for every possible contingency that may be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise that are not covered sufficiently for the purchaser's purposes, the matter should be referred to the subject matter and illustrations concurrent without prior notice. With regard to urment withole or in parts - is forbiddent without to purchase orders, the agreed particulars or utilization of its contents to third parties or utilization of its contents - is forbiddent without is prior written consent of ABB AG. Copy-riprior Written consent