


Cat. no. A3XGLW

INSTRUCTION SHEET

## A3S oil-tight illuminated selector switch




For replacement parts information or an application guide, visit our website at abb.com/low-voltage or contact your ABB representative.

For more information on optional mounting kits, name plates and other accessories, visit abb.com/low-voltage.



These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise that are not covered sufficiently for the purchaser's purpose, the matter should be referred to ABB Inc.

The contents of this instruction manual shall not become part of or modify any prior or existing agreement, commitment or relationship. The sales contract contains the entire obligation of ABB. The warranty contained in the contract between the parties is the sole warranty of ABB. Any statements contained herein do not create new warranties or modify the existing warranty.



Selector contact and CAM functions

|                       | Contact function |           |     |          |          | Contact block |  |
|-----------------------|------------------|-----------|-----|----------|----------|---------------|--|
| for selector position |                  |           | CAM | Location | Contacts | Cat. no.      |  |
| 2 position            | Left             | Right     |     |          |          |               |  |
|                       | <b>\</b>         | /         |     |          |          |               |  |
|                       | Х                |           | Α   | L        | NC       | A3XC01        |  |
|                       |                  | х         |     | L        | NO       | A3XC10        |  |
| 3 position            | Left Cent        | ter Right |     |          |          |               |  |
|                       | <b>\</b>         |           |     |          |          |               |  |
|                       |                  | Х         | В   | R        | NC       | A3XC01        |  |
|                       |                  | X         |     | R        | NO       | A3XC10        |  |
|                       | Х                |           | С   | L        | NC       | A3XC01        |  |
|                       |                  | Х         |     | L        | NO       | A3XC10        |  |

Legend: X Closed contacts


L = Left side


R = Right side


NO = Normally open

NC = Normally closed

Note: Contact blocks and lens kits are ordered as required.







Name plates



CAM A operation Contact blocks mount on left side. Light module assembly mounts on right side.



CAM B operation
Contact blocks mount on right side.
Light module assembly mounts on left side.



CAM C operation Contact blocks mount on left side. Light module assembly mounts on right side.

Note: CAM is identified by the 5th character of cat. no.

## Replacement bulb chart

|       | Incandescent | _       | LED lamp - | amp – single bulb |         |         |
|-------|--------------|---------|------------|-------------------|---------|---------|
| Volts | bulb         | Red     | Green      | Yellow            | White   | Blue    |
| 6     | #755*        | A3XBL6R | A3XBL6G    | A3XBL6Y           | A3XBL6W | A3XBL6L |
| 24    | #757         | A3XBL2R | A3XBL2G    | A3XBL2Y           | A3XBL2W | A3XBL2L |
| 120   | N/A          | A3XBL4R | A3XBL4G    | A3XBL4Y           | A3XBL4W | A3XBL4L |

<sup>\*</sup>Also flashing lamp #267