


GEJ-7211 Information Label


CR360L Lighting Contactor


60, 100, 200, 300 Ampere











M–LINE CONTACTOR
I–INDICATING LIGHT

Use 75°C. copper conductors only, for field wiring. Torque line and load terminals as shown at right.

Rating	Lb-In
60A	50
100A	150
200A	250
300A	300

FOR SEPARATE CONTROL–Omit wire "A" and connect control ssource to coil and to 1 on control device.

NOTE: Refer to the National Electrical Code. Additional control circuit overcurrent protection may be required.

3-PHASE RATINGS APPLY TO 2-PHASE FORMS

COIL (Order Coil No. plus coil suffix number per table below)

60 Hz	115–120V	200–208V	230–240V	——	460–480V	575–600V
50 Hz	110V	——	220V	380V	440V	550V
Coil Suffix	002	023	003	064	004	005

The following accessory kits may be installed on this device.

	60 Ampere	100 Ampere	200 Ampere	300 Ampere
Aux Contact	CR305X200A, B, C, X100D, E	CR305X300A, B, C, X100D, E	CR305X500A, B, C, X100E, E	CR305X500A, B, C, X100D, E
Control Circuit Fuse	CR305X241A, B	CR305X341A, B	CR341X541A, B	CR305X541A, B
Principal Renewal Parts				
3 Movable & 6 Sta. Cont	546A780G051	55-153677G002	55-154607G051	55-154607G002
Coil (Plus Suffix No. below)	15D23G	55-153608G	55-501493G	55-501493G

For CSA–GND KIT

½-IN CONDUIT	55-213403G001
¾-IN CONDUIT	55-213403G002
1-IN CONDUIT	55-213403G003
1¼-IN CONDUIT	55-213403G004
1½-IN CONDUIT	55-213403G005
2-IN CONDUIT	55-213403G006
2½-IN CONDUIT	55-213403G007
3-IN CONDUIT	55-213403G008

EXTRA AUXILIARY CONTACTS

Final Suffix Letter Of CR Number	Contact Location, See Diagram			
	W	X	†Y	†Z
A (Or None)				
B	⊣⊢			
C	⊣/⊢			
D			⊣/⊢	⊣⊢
E	⊣⊢	⊣⊢		
F	⊣/⊢	⊣/⊢		
G	⊣⊢		⊣/⊢	⊣⊢
H	⊣/⊢		⊣/⊢	⊣⊢
J	⊣⊢	⊣⊢		⊣⊢
‡Z	No Holding Interlock			

† Not available when Control Circuit Fuse Kit is used.

These instructions do not cover all details or variations in equipment nor do they provide for every possible contingency that may be met in connection with installation, operation, or maintenance. Should further information be desired or should particular problems arise that are not covered sufficiently for the purchaser's purposes, the matter should be referred to your local ABB Sales Office.

ABB Inc.
305 Gregson Drive
Cary, NC 27511.
electrification.us.abb.com

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB Inc. does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB Inc.
Copyright© 2020 ABB
All rights reserved

1SQC911022M0201, GEJ-7211E, January 2023