

MEDIUM VOLTAGE PRODUCT

IO1s, IFW

Cable current transformers



Technical specification

Туре	IO1s	IFW
Ratio (typical)	120/1	120/1
	100/1	100/1
Number of secondary winding (typical)	120 or 100	120 or 100
Test winding	5 or 10	5 or 10
	turns	turns
Thermal short-circuit strength 5 s	10 kA	10 kA
Test voltage of the main insulation 50 Hz	33 kV	33 kV
Rated power-frequency withstand voltage at 50 Hz	2 kV	3 kV
Rated frequency	50 Hz	50 Hz
Weight	8.9 kg	9 kg

^{*} Upon agreement with the manufacturer, on customer request, the transformer may be made with a different rated transmission or load resistance at particular earth fault primary current setting.

Description

Earth fault transformers, three-phase, with resin insulation type IO1s and IFW (split core type). They are mainly used for residual current metering together with earth-fault protection relay. Thanks to its construction the transformer can be installed without disconnecting the cable (IFW).

Range of rated earth fault primary currents: 0.1÷150 A.

Properities

- response to zero current (earth fault current) from very low values approx. 0.1 A
- compatible with earth fault protection relays of any type
- the mounting dimensions of the IFW transformer enable alternating with the earth fault transformer type IO1s
- a transformer with split core enables the installation on already installed, as well as already operated electrical energy cables with easy installation and removal

 equipped with special test winding for checking proper functionality of the set: transformer + protection

Operating conditions

An earth fault transformer is designed for operation in indoor equipment, under moderate climate conditions. Minimum transport and storage temperature is -30°C (243 K).

Design and operating principle

An earth fault transformer consists of a toroid magnetic core with two secondary windings. The protection winding is connected to terminals k1-l1 (1S1-1S2) and designed to supply an earth fault protection relay, while the second winding, connected to terminals k2-l2 (2S1-2S2), is a test winding, used to verify the transformer + protection assembly without the necessity of using current input on the primary side of the earth fault transformer (Note: during normal operation of the transformer the secondary winding k2-l2 (2S1-2S2) should remain open).

Compliance with standards

WTO-99/A10-041

Marking

IFW variants:

IFW-120; IFW-120s; IFW-100; IFW-100s; IFW-100e; IFW-100es

s – with metal sheet

e – short variant

IO1s variants:

150, 120, 100, 90, 75, 60 or 50 – number of secondary winding coils

For an earth fault transformer IO1s and IFW in secondary winding k1 –I1 (1S1-1S2), loaded with the resistance of R = 3.5 Ω , the secondary current value I_{sn} depending on the primary current I_{pn} (earth fault current) and corresponds to the values in following table:

I _{pn} [A]	1.0	3.0	5.0	8.0
I _{sn} [mA] for 150/1	5 ÷ 6	15 ÷ 18	26 ÷ 32	42 ÷ 50
I _{sn} [mA] for 120/1	6.1 ÷ 8	22 ÷ 26	37 ÷ 43	59 ÷ 68
I _{sn} [mA] for 100/1	6.1 ÷ 9	26 ÷ 30	44 ÷ 51	72 ÷ 82
I _{sn} [mA] for 75/1	9.3 ÷ 12	34.7 ÷ 40	58.7 ÷ 68	96 ÷ 109
I _{sn} [mA] for 60/1	11.7 ÷ 15	43.3 ÷ 50	73.3 ÷ 85	120 ÷ 136.7
I _{sn} [mA] for 50/1	14 ÷ 18	52 ÷ 60	88 ÷ 102	144 ÷ 164

For earth fault transformers type IFW value of secondary voltage U_{sn} depending on the primary current I_{pn} at the winding load with the resistance of R_{obc} = 0.05 Ω should meet the values in the next table:


I _{pn} [A]	50	75	100	120
U _{sn} [V] for IFW 120e	0.019 ÷ 0.023	0.029 ÷ 0.033	0.040 ÷ 0.044	0.047 ÷ 0.054
U _{sn} [V] for IFW 100e	0.023 ÷ 0.026	0.036 ÷ 0.040	0.047 ÷ 0.043	0.057 ÷ 0.063
U _{sn} [V] for IFW 90e	0.025 ÷ 0.029	0.040 ÷ 0.045	0.052 ÷ 0.059	0.063 ÷ 0.070
U _{sn} [V] for IFW 75e	0.031 ÷ 0.035	0.048 ÷ 0.053	0.063 ÷ 0.071	0.076 ÷ 0.084
U _{sn} [V] for IFW 50e	0.038 ÷ 0.043	0.060 ÷ 0.067	0.078 ÷ 0.088	0.095 ÷ 0.105


The value of electromotive force E in testing winding k2 – I2 (2S1-2S2) at the secondary winding k1 – I1 (1S1-1S2) load with the resistance of 3.5 Ω and primary current of I_{pn}=3 A, should be: 3.2 mV ÷ 4.0 mV. Transformers marked with 120 and 120s have 5 turns of test winding, while other transformers have 10 turns of test winding.

Dimensional Drawings


Note: Unless explicitly stated, all dimensions and tolerances are valid with generally defined tolerance 0,6 %. Tolerance applies to the all geometric characteristics including form variation of the products. All dimensional references representing a diamenter or radius of a circles are defined as the minimal value of a real dimension.


IFW 120 and IFW 100







IFW 120s and IFW 100s







IFW 100e





IFW 100es





Czech Republic
Tel.: +420 547 152 021
+420 547 152 854
Fax: +420 547 152 626
E-mail: kontakt@cz.abb.com

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents in whole or in parts - is forbidden without prior written consent of ABB.

Copyright© 2020 ABB All rights reserved