



SACE Tmax XT

RHL - Blocco a chiave (in aperto e chiuso) per frontale/maniglia rotante XT5-XT6-XT7
RHL - Keylock for XT5-XT6-XT7 front/rotary handle (open-close position)
RHL - Schlüssellverriegelung (AUS-Stellung/AUF-Stellung) für Frontplatte/Drehhebelantrieb XT5-XT6-XT7
RHL - Verrouillage par clé (en position ouverte-fermé) pour frontal/poignée rotative XT5-XT6-XT7
RHL - Bloqueo con llave (posición de abierto-cerrado) para frontal/mando giratorio XT5-XT6-XT7
RHL - 钥匙锁(分闸-合闸位置) 手柄操作机构前面板/旋转手柄操作机构 XT5-XT6-XT7

XT5-XT6-XT7



XT5 RHD XT5 FLD	1	1			1		1								1	1	
XT6-XT7 RHD XT6 FLD	1	1			1	1		1							1		
XT5-XT6-XT7 Panel Door RHE	1			1						1			1		1		





2

XT5-XT6 RHD

3

XT7 RHD





4

XT7 RHD


5

XT5 RHD




6

XT6-XT7 RHD




7

XT5-XT6-XT7 RHD



8

XT5-XT6 FLD



9

XT5 FLD

