

## Changing length of ABB track for static formats

All IRBT Tracks are delivered with max length. The static formats can be used in various software, with various capability to modify the models. So this guide gives the overall idea on how to modify the models

### 1. The basic working method is:

- 1.1 Copy and rename your file to an appropriate name
- 1.2 Open the new model in the software
- 1.4 Delete the mid sections of the track, keeping the end modules.
- 1.5 Move the end module
- 1.6 Move the carriers (if any)

Please revive the documentation on how to modify the simulation formats, to give you more details on how it works in the simulation software, that might give you an idea how to do it in your software.