

ACS800 BIPOLAR VOLTAGE ANALOG INPUT

Note: These instructions assume all mechanical and electrical installation procedures, direction test, and tuning were completed using the ACS800 Hardware and ACS800 Firmware manuals.

Bipolar Voltage Analog Input Configuration using internal + - 10VDC power supplies.

- 1. Select and wire potentiometer; Remove power to the drive.
 - 2k ohm 10k ohm acceptable resistance range
 - Connect Potentiometer across terminal X20 -10VDC Reference voltage Pin 1 and terminal X21 +10VDC Reference voltage Pin 1. Wiper connected to terminal X21 Al1+ Pin 3. Connect X21 GND Pin 2 to X21 Al- Pin 4
- 2. Program the Drive –Default control connections and parameter settings were tested using the Factory Macro
 - 10.03 REF DIRECTION Change to "Request"
 - 11.03 EXT REF 1 SELECT Change Parameter to "Al1 Bipolar"
 - 11.04 EXT REF 1 MINIMUM Leave at the default setting "0 rpm"
 - 11.05 EXT REF 1 MAXIMUM Change Parameter to desired rpm value for your application. Note this will be the REF MAX for both forward and reverse. Group 20 Limits also give scalability to motor rpm's. (see ACS800 firmware manual for examples)
 - 13.01 MINIMUM Al1 Change to "Tune" (Be sure -10VDC is being applied to Al1) Al1 min will now be the applied voltage.
 - 13.02 MAXIMUM Al1 Change to "10V"
 - Any voltage between +-10vdc minimum and maximum values must be tuned to the appropriate voltage.

Motor direction will follow the applied polarity of Al1 Positive Voltage = Fwd Negative Voltage = Rev

Documents or other reference material:

This document is to be used with the ACS800 Firmware Pub # 3AFE64527592 and ACS800 Hardware Pub # 3AFE64382101 Manuals.

Author: Paul Kasper		
RAE		Date: 10-1-14
		Document #:
		LVD-EOTN87U-EN
External		
http://www.abb.us/drives.	Industry – Industrial	Revision: A
Product Categories: ACS800		



Author: Paul Kasper		
RAE		Date: 10-1-14
		Document #:
		LVD-EOTN87U-EN
External		
http://www.abb.us/drives.	Industry – Industrial	Revision: A
Product Categories: ACS800		