Functional safety design tool
Quick installation guide

Power and productivity
for a better world™

INSTALLATION OF THE FUNCTIONAL SAFETY DESIGN TOOL

1. Extract the zip file to a folder.
2. Run the **setup.exe** from the folder where you extracted the zip file and follow the instructions on screen.
3. Once the installation is completed successfully, launch the Functional safety design tool.

4. Read through and accept the license terms, and click **OK** to continue. The tool is now ready to be used. If you are using the tool for the first time please follow the instructions here below for installing the device libraries.

HOW TO INSTALL AND REVISE DEVICE LIBRARIES

1. The installation does not include any device libraries, so the first step is to download them to the PC. Please download the libraries from ABB web site. Link to the website can be found either from the user manual or help *Managing the libraries – Updating the libraries*.

2. In Functional safety design tool expand the library panel from the right by clicking the **Library** tab.

3. Click **Manage libraries** button and after that **Import…** button. Select the appropriate library format (*.xml,*.ABBlibrary) from the droplist. Browse and select the downloaded library and click **Open.**
4. The library content will appear under the **Libraries** list. You can close the Libraries view by clicking the close button in the lower right hand corner.

IMPORTANT NOTICE

We point out that software designations and brand names of companies mentioned are as a rule protected by law as Trade Marks and/or by patents and Copyright or other commercial rights.

LICENSE TERMS

The license terms are included in electronic form in the zip you downloaded and are also shown when launching the tool.

Contact us

For more information please contact your local ABB representative or visit:

ABB Oy
Drives
P.O.Box 184
FI-00381 Helsinki
FINLAND

www.abb.com/drives
www.abb.com/drivespartners

© Copyright 2019 ABB. All rights reserved.
Specifications subject to change without notice.

3AXD10000296788 REV C EN 4.1.2019

Power and productivity
for a better world™