

—  
SAFETY PRODUCTS

# Tina 2A/2B Adapter unit

## Product Manual



## Read and understand this document

Please read and understand this document before using the products. Please consult ABB with any questions or comments.

### Suitability for use

ABB shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the product. Third party certificates for the products are available at <https://new.abb.com/low-voltage/products/safety-products>. This information by itself is not sufficient for a complete determination of the suitability of the products in combination with the end product, machine, system, or other application or use.

The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of the products, nor is it intended to imply that the uses listed may be suitable for the products:

- Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this document.
- Nuclear energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, and installations subject to separate industry or government regulations.
- Systems, machines, and equipment that could present a risk to life or property.

Please know and observe all prohibitions of use applicable to the products.

**NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE ABB PRODUCT IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.**

Descriptions and examples show how the product works and can be used. It does not mean that it fulfills the requirements for all types of machines and processes. The buyer/user is responsible for installing and using the product according to applicable standards and regulations. We reserve the right to make changes to the product and the documentation without prior notice.

## Table of Contents

<b>1</b>	<b>Introduction .....</b>	<b>4</b>
1.1	Purpose of document .....	4
1.2	Intended audience .....	4
1.3	Reading prerequisites.....	4
1.4	Special notes.....	4
<b>2</b>	<b>Safety .....</b>	<b>5</b>
2.1	Safety precautions .....	5
<b>3</b>	<b>Product description.....</b>	<b>6</b>
<b>4</b>	<b>Installation.....</b>	<b>7</b>
4.1	Installation precautions .....	7
4.2	Testing safety functions .....	7
<b>5</b>	<b>Connections .....</b>	<b>8</b>
5.1	Connection examples .....	9
<b>6</b>	<b>Functions .....</b>	<b>10</b>
6.1	LED indications .....	10
6.2	Information output signal attributes.....	10
<b>7</b>	<b>Maintenance .....</b>	<b>11</b>
7.1	Maintenance precautions .....	11
<b>8</b>	<b>Troubleshooting .....</b>	<b>12</b>
8.1	LED indications .....	12
<b>9</b>	<b>Dimensions .....</b>	<b>13</b>
<b>10</b>	<b>Technical data .....</b>	<b>14</b>
<b>11</b>	<b>Declaration of conformity .....</b>	<b>16</b>

# 1 Introduction

## 1.1 Purpose of document

The purpose of this document is to describe the functions and to provide instructions for installation, operation, maintenance and troubleshooting of the product.

## 1.2 Intended audience

This document is intended for authorized personnel.

## 1.3 Reading prerequisites

It is assumed that the reader of this document has knowledge of the following:

- Basic knowledge of ABB safety products
- Knowledge of machine safety

## 1.4 Special notes

Pay attention to special notes in the document:



**Warning!** Risk of severe personal injury!

An instruction or procedure which, if not carried out correctly, may result in injury to the technician or other personnel.



**Caution!** Risk of damage to the equipment!

An instruction or procedure which, if not carried out correctly, may damage the equipment.








**Note!** Important or explanatory information.

## 2 Safety

### 2.1 Safety precautions

The safety precautions must be followed during installation, operation, maintenance and troubleshooting.

It is the responsibility of the user to ensure the correct overall functionality.

-  **Warning!** Carefully read through the entire product manual before using the device.
-  **Warning!** The devices shall be installed by authorized personnel following applicable Safety regulations, standards and the Machinery directive.
-  **Warning!** Failure to comply with instructions, operation that is not in accordance with the use prescribed in the instructions, improper installation or handling of the device can affect the safety of people and the plant.
-  **Warning!** For installation and prescribed use of the product, the special notes in the instructions must be carefully observed and the technical standards relevant to the application must be considered.
-  **Warning!** In case of failure to comply with the instructions or standards, especially when tampering with and/or modifying the product, any liability is excluded.

### 3 Product description

Tina 2A and Tina 2B are used to adapt safety devices with zero-volt contacts to the DYNlink safety circuit monitored by a safety controller or a safety PLC. Examples of such safety devices are emergency stops and switches or light curtains and light beams with internal relay outputs.

Tina 2A is intended for safety devices prepared with a M20 entry. This allows easy installation of the adapter unit within the physical enclosure of the safety device while keeping the status LED visible on the outside of the housing.

Tina 2A/2B is equipped with a LED for visual status information of the safety device and the DYNlink safety circuit.


Tina 2B has a very small form factor which allows installation inside the physical enclosure of small safety devices, or safety devices without a M20 entry.

The Tina 2A/2B adapter unit is intended for use in safety circuits in accordance with EN 60204-1.

## 4 Installation

- The Tina unit shall be attached to the M20 entry (Tina 2A) before the safety cables are connected to the device.
- See max. tightening torque in chapter “Technical data”.

### 4.1 Installation precautions

 **Warning!** All safety functions shall be tested before starting up the system.


### 4.2 Testing safety functions

After each step the status of the input can be read on the monitoring device.

Steps for testing	LED indication	DYNlink signal output
1. Interrupt the DYNlink safety circuit before the unit to be tested	Green/red flashing *	Shall go low
2. Close the DYNlink safety circuit	Green	Shall generate a DYNlink signal

\* If connected as “Emergency stop 3” (see illustration in chapter “Connection examples”) the LED indication on Tina will be “Red”.

## 5 Connections




### Connection cables to DYNlink safety circuit

1	Brown	+24 VDC
2	White	DYNlink signal input
3	Blue	0 VDC
4	Black	DYNlink signal output
5	Grey	Information output

- Note!** See connection cable cross section area and cable length in chapter 'Technical data/General'.
- Warning!** Information output signals shall **never** be used for safety purpose(s).
- Warning!** The connection cables are not monitored and shall therefore be installed within the same physical enclosure as the safety device to maintain the highest safety level (fault exclusion, refer to EN ISO 13849-2:2012, Annex D).
- Warning!** The safety adapter shall **not** be used for purposes other than intended. All tampering with the safety device can lead to serious risk to life.



## 5.1 Connection examples



**Caution!** All cable colors according to ABB standard cables.

## 6 Functions

### 6.1 LED indications

LED indication	Description	DYNlink state
Green	DYNlink input signal	OK
Green/red flashing	DYNlink input open or 0 VDC	Interrupted before this unit
Red	DYNlink input +24VDC	Interrupted before this unit

### 6.2 Information output signal attributes

The information output of the unit is set either high or low according to the following table:

DYNlink input signal status	Information output
DYNlink signal	High
+24 VDC, 0 VDC, open circuit (O/C)	Low

The delay for switching the information output signal:

Information output signal switch	High -> Low	Low -> High
Delay when the DYNlink input signal is connected to +24 VDC	~ 60 ms	~ 10 ms
Delay when the DYNlink input signal is connected to 0 VDC or disconnected	~ 10 ms	~ 10 ms

#### Note!

If the DYNlink input signal is connected to +24 VDC longer than 70 ms the information output is set low for approximately 1.2 s. If the DYNlink input signal stays connected to +24 VDC the information output stays low. If the DYNlink input signal is connected to +24 VDC for less than 50 ms the information output will stay high.

If the DYNlink input signal is connected to 0 VDC or disconnected longer than 15 ms the information output is set low for approximately 1.2 s. If the DYNlink input signal is connected to 0 VDC or disconnected the information output stays low. If the DYNlink input signal is connected to 0 VDC or disconnected for less than 5 ms the information output will stay high.


#### Warning!


Information output signals shall **never** be used for safety purpose(s).

# 7 Maintenance

Maintenance shall be done in accordance with a risk assessment for the individual application.

## 7.1 Maintenance precautions

 **Warning!** The safety functions and the mechanics shall be tested regularly, at least once every year to confirm that all the safety functions are working properly (EN 62061:2005+A1:2013+A2:2015, EN ISO 13849-1:2015).

 **Warning!** In case of breakdown or damage to the product, contact ABB. Do not try to repair the product yourself since it may accidentally cause permanent damage to the product, impairing the safety of the device which in turn could lead to serious injury to personnel.

## 8 Troubleshooting



### 8.1 LED indications

LED indication	Probable cause	Action
Red	+24 VDC connected to DYNlink signal input	Check if there is +24 VDC on DYNlink signal input. If yes, check cable connections or the unit before.
No LED light	Loss of power supply	Check +24 VDC/0 VDC power supply.
Green (but no DYNlink output detected)	Defective DYNlink signal input to unit	Check the DYNlink input or the unit before.
Weak lights	Unit is defective	Replace the unit.



## 9 Dimensions

All dimensions are in mm.

**Tina 2A**



**Tina 2B**



## 10 Technical data

Further information about the product and accessories is found at:

[new.abb.com/low-voltage/products/safety-products](http://new.abb.com/low-voltage/products/safety-products)

Stated technical data apply when power supply voltage is +24 VDC and ambient temperature is +25 °C, unless stated otherwise.

Manufacturer	
Address	ABB Electrification Sweden AB SE-721 61 Västerås Sweden
Order code/Ordering data	2TLA020054R0100: Tina 2A Adapter unit 2TLA020054R1100: Tina 2B Adapter unit
Power supply	
Required power supply type	PELV/SELV, not intended to be connected to a DC distribution network. <b>Note:</b> A DC distribution network is defined in IEC 61326-3-1:2017 as “Local DC electricity supply network in the infrastructure of a certain site or building intended for connection of any type of equipment”.
Operating voltage	+24 VDC +15 %, -25 %
Total current consumption	Maximum: 25 mA <sub>RMS</sub>
<b>Note:</b> Total current consumption is the internal supply current when there is no information output current. Valid over the operating voltage and ambient temperature range.	
DYNlink signal	
DYNlink Input signal voltage	Minimum: 8 V <sub>RMS</sub> Maximum: 15 V <sub>RMS</sub>
DYNlink Output signal voltage	Minimum: 8 V <sub>RMS</sub> Maximum: 15 V <sub>RMS</sub>
<b>Note:</b> The purpose of stating the voltage in RMS is to facilitate the measurement of the square-wave DYNlink signal with a multimeter.	
Time delay between DYNlink input and output signal (T <sub>DELAY</sub> )	Maximum: 70 µs
Information output	
Output voltage high low	Nominal: Operating voltage - 2 VDC Maximum: 2 VDC
Output current	Maximum: 10 mA
General	
Protection class	IP67
Ambient temperature	Operation: -10 to +55 °C Storage: -30 to +70 °C
Humidity range	35 to 85 % (with no icing or condensation)
Housing material	TPU

Cables	Conductor cross section area: 0.34 mm <sup>2</sup> (AWG 22) Length: 300 mm Insulation: PVC Conductor material: Tinned stranded copper
Tightening torque	2-2.3 Nm (Tina 2A)
Size (L x W x H)	Tina 2A: 46 x 27 x 24 mm Tina 2B: 26 x 21 x 7 mm
Weight	Tina 2A: ~ 30 g Tina 2B: ~ 20 g
Color	Black
<b>Directives / Harmonized standards</b>	
Conformity	European Machinery Directive 2006/42/EC EN ISO 12100:2010 EN 62061:2005+Cor.:2010+A1:2013+A2:2015 EN ISO 13849-1:2015 EN 60204-1:2018
IEC/EN 61508-1...7	SIL3, PFH <sub>D</sub> = 4.50·10 <sup>-9</sup>
EN 62061	SIL3
EN ISO 13849-1	PL e, category 4
Certificates	TÜV Nord, cCSAus
<b>Information for use in USA/Canada</b>	
Pollution degree	2
Altitude	2000 m (max)
Humidity	80% max for temperatures up to 31 °C
Indoor use statement	For indoor use only

# 11 Declaration of conformity

## EC Declaration of conformity



### EC Declaration of conformity

(according to 2006/42/EC, Annex 2A)

We	ABB Electrification Sweden AB SE-721 61 Västerås Sweden	declare that the safety components of ABB Electrification Sweden AB make with type designations and safety functions as listed below, is in conformity with the Directives 2006/42/EC – Machines 2014/30/EU – EMC 2011/65/EU – RoHS2 + 2015/863
Authorised to compile the technical file	ABB Electrification Sweden AB SE-721 61 Västerås Sweden	
<b><u>Product</u></b>	<b><u>Certificate</u></b>	
Adaptor unit Tina 1-4, Tina 7-8, Tina 11-12	44 799 161 35516	
Certification body	TÜV NORD CERT GmbH Am TÜV 1 45307 Essen Germany	
Used harmonized standards	EN ISO 12100:2010, EN ISO 13849-1:2015, EN ISO 13849-2:2012, EN 62061:2005+A1:2013+A2:2015, EN 60204-1:2018, EN 60664-1:2007, EN 61000-6-2:2005, EN 61000-6-4:2007	
Other used standards	EN 61508:2010	

A handwritten signature in blue ink, appearing to read 'Viktoria Sakar'.

Viktoria Sakar  
R&D team lead Electronics and Software  
Västerås 2022-09-27

---

[abb.com/lowvoltage](http://abb.com/lowvoltage)

Original



## UK Declaration of conformity



### Declaration of conformity

(according to 2008 No 1597)

We ABB Electrification Sweden AB  
SE-721 61 Västerås  
Sweden declare that the safety components of ABB Electrification Sweden AB  
make with type designations and safety functions as listed below, is  
in conformity with UK Statutory Instruments (and their amendments)

2008 No 1597 – Supply of Machinery (Safety) Regulations (MD)  
2016 No 1091 – Electromagnetic Compatibility Regulations (EMC)  
2012 No 3032 – Restriction of the Use of Certain Hazardous  
Substances in Electrical and Electronic Equipment Regulations  
(RoHS)

Authorized representative ABB Limited  
Tower Court  
Coventry  
CV6 5NX  
United Kingdom

Authorised to compile the technical file ABB Limited  
Tower Court  
Coventry  
CV6 5NX  
United Kingdom

#### **Product**

Adapter unit  
Tina 2A  
Tina 2B

Used designated standards EN ISO 12100:2010, EN ISO 13849-1:2015,  
EN 62061:2005+A1:2013+A2:2015, EN 60204-1:2006+A1:2009,  
EN 60664-1:2007, EN 61000-6-2:2005, EN 61000-6-4:2007

Other used standards EN 61508:2010

A handwritten signature in blue ink, reading 'Magnus Backman'.

Magnus Backman  
R&D Manager  
Västerås 2021-04-09

---

[abb.com/lowvoltage](http://abb.com/lowvoltage)

Original