

Catalog No. Qty

## TRK56A 1 R-Class Fuse Kit

For Rejecting Fuses Other Than Class “R”

### INSTALLATION INSTRUCTIONS:

Using the fuse clips on the load side of the fuse, insert rejector into the hole in the center leg of the fuse clip. Push rejector into the hole until the compression spring is fully compressed.

**⚠ CAUTION:** Turn off power before working inside this equipment.


**Note:** For two pole devices omit third rejector.

---

ABB Inc. 305 Gregson Drive Cary, NC 27511  
electrification.us.abb.com

1SQC920041M0201\_Rev C, GEJ5152 Dec 2023

**ABB**



Catalog No. Qty

## TRK56A 1 R-Class Fuse Kit

For Rejecting Fuses Other Than Class “R”

### INSTALLATION INSTRUCTIONS:

Using the fuse clips on the load side of the fuse, insert rejector into the hole in the center leg of the fuse clip. Push rejector into the hole until the compression spring is fully compressed.

**⚠ CAUTION:** Turn off power before working inside this equipment.


**Note:** For two pole devices omit third rejector.

---

ABB Inc. 305 Gregson Drive Cary, NC 27511  
electrification.us.abb.com

1SQC920041M0201\_Rev C, GEJ5152 Dec 2023

**ABB**



Catalog No. Qty

## TRK56A 1 R-Class Fuse Kit

For Rejecting Fuses Other Than Class “R”

### INSTALLATION INSTRUCTIONS:

Using the fuse clips on the load side of the fuse, insert rejector into the hole in the center leg of the fuse clip. Push rejector into the hole until the compression spring is fully compressed.

**⚠ CAUTION:** Turn off power before working inside this equipment.


**Note:** For two pole devices omit third rejector.

---

ABB Inc. 305 Gregson Drive Cary, NC 27511  
electrification.us.abb.com

1SQC920041M0201\_Rev C, GEJ5152 Dec 2023

**ABB**



Catalog No. Qty

## TRK56A 1 R-Class Fuse Kit

For Rejecting Fuses Other Than Class “R”

### INSTALLATION INSTRUCTIONS:

Using the fuse clips on the load side of the fuse, insert rejector into the hole in the center leg of the fuse clip. Push rejector into the hole until the compression spring is fully compressed.

**⚠ CAUTION:** Turn off power before working inside this equipment.

**Note:** For two pole devices omit third rejector.

---

ABB Inc. 305 Gregson Drive Cary, NC 27511  
electrification.us.abb.com

1SQC920041M0201\_Rev C, GEJ5152 Dec 2023

**ABB**

