



NOTES:

1. Wiring status: Draft - Not tested. The ballast / power pack combination has not been wired up and tested to confirm functional compatibility.

2. This wiring diagram is provided in good faith and the best of our knowledge at the time of publication. Thomas and Betts does not give any warranty or representation as to the accuracy, reliability or completeness of the information. Thomas and Betts shall not be liable for any loss or damage arising in any way from or in connection with any information provided or omitted, or from anyone acting or refraining to act in reliance on this information.

3. Changes to ballast specification by the manufacturer are beyond our control and may cause adverse effect on the performance, EMC issue and compatibility issue. Consult Thomas and Betts for further advise.

DRAWN	G.K.Grover	<div>Thomas&amp;Betts</div> <div><div>©</div><div>ABN 62074810898</div><div>A Member of the ABB Group</div><div>23A NYRANG ST, LIDCOMBE NSW 2141 AUSTRALIA</div></div>			
CHECKED	-----	TITLE			
APPROVED	G.K.Grover	Wiring diagram using IPDC36M with TRIDONIC PC 2x36 T8 PRO sl Art. No. 22185217 Electronic Ballast			
DATE:	19/05/15	ALSO USED ON		DRAWING NUMBER	SHEET SIZE
DRAWING STD AS 1100		SCALE N.T.S.		SHEET 1 OF 1	A3