(II)

NLDX.E191658 - Motor Controllers, Magnetic

Note: We are enhancing our systems and you may notice duplicate entries/missing/autdated data. During this interim period, please contact our Customer Service at https://www.ul.com/about/location

Motor Controllers, Magnetic

ABB Stotz-Kontakt GmbH

Eppelheimer Str 82 Heidelberg, 69123 Germany

Modelis: C579 HTG6-DQL-24VDC, HTG6-DQL-24VDC,

Accessory, Model(s): EH04-11, may be followed by N. EH04-20. may be followed by N

Accessory, Model(s): BSM6-30 followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Accessory bus bar kit, Model(s): WKMIU

Mechanical interlocks, Model(s): MMH0, VB05K

Motor controllers, Model(s): ESB24 followed by -0, 1, 2, 3 or 4, followed by 0, 1, 2, 3 or 4.

 $\textbf{Motor controllers}, \textbf{Model} (s): \underline{\texttt{ESB25}} \text{ followed by -0, -1, -2, -3, or -4, followed by 0, 1, 2, 3, or 4 followed by N} \\ \textbf{Note of the property o$

Motor controllers, Model(s): ESB40 followed by -0, 1, 2, 3 or 4, followed by 0, 1 or 2, may be followed by N

Motor controllers, Model(s): ESB63 followed by -0, 1, 2, 3 or 4, followed by 0, 1 or 2, may be followed by N

Nonreversing contactors, open type, Model(s): LSOSK followed by -30 or -40, followed by -00, -10, or -01, followed by two alphanumeric digits

Nonreversing contactors, open type, Model(s): LS06K followed by -30 or -40, followed by -00, -10, or -01, followed by two alphanumeric digits

Nonreversing contactors, open type, Model(s): MCI followed by A, C, I or K, followed by A, B, 3 or 4, followed by 0 or 1, followed by 0 or 1, followed by A, followed by H or T, followed by one or two additional numbers or letters, may be followed by D, may be followed by -Rail

Nonreversing contactors, open type, Model(s): MC2 followed by A. C., I or K. followed by A. B. 3 or 4, followed by 0 or 1, followed by 0 or 1, followed by A. or 1, followed by A

Open type magnetic motor controllers, Model(s): 86 may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by 1.4 or 2.4.

Open type magnetic motor controllers, Model(s): <u>865</u> may be followed by M, followed by -30, followed by 00, 01 or 10, may be followed by 1.7 or 2.8.

Open type magnetic motor controllers, Model(s): 87 may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Model(s): 87D may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Model(s): BTS may be followed by M, followed by -30, followed by 00, 01 or 10, may be followed by 1.7 or 2.8.

Open type magnetic motor controllers, Model(s): <u>B7W</u> may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Model(s): BC6 may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by L4 or 2.4.

Open type magnetic motor controllers, Model(s): 8C7 may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by 1.4 or 2.4.

Open type magnetic motor controllers, Model(s): BCTW may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by l.4 or 2.4.

Open type magnetic motor controllers, Model(s): VB6 may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Model(s): <u>VB6A</u> may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by 14 or 2.4.

Open type magnetic motor controllers, Model(s): VB6S may be followed by M, followed by -30, followed by 00, 01 or 10, may be followed by 1.7 or 2.8.

Open type magnetic motor controllers, Model(s): VB6SA may be followed by M, followed by -30, followed by 00, 01 or 10, may be followed by 1.7 or 2.8.

Open type magnetic motor controllers, Model(s): <u>VB7</u> may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Model(s): VB7A may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by 14 or 2.4.

Open type magnetic motor controllers, Model(s): <u>VB7D</u> may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by 1.4 or 2.4.

Open type magnetic motor controllers, Model(s): <u>VBTS</u> may be followed by M, followed by -30, followed by 00, 01 or 10, may be followed by 1.7 or 2.8.

Open type magnetic motor controllers, Model(s): <u>VB75A</u> may be followed by M, followed by -30, followed by 00, 01 or 10, may be followed by 1.7 or 2.8.

Open type magnetic motor controllers, Model(s): <u>VBC6</u> may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Model(s): <u>VBC6A</u> may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Model(s): <u>VBC7</u> may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Model(s): VBC7A may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Reversing contactors, open type, Model(s): M11 followed by SOOSA, followed by E, F, G, H, T, U or R, may be followed by D.

 $\textbf{Reversing contactors, open type,} \ \mathsf{Model(s):} \ \underline{\mathsf{MJ1}} \ \mathsf{followed by SOOSA, followed by E, F, G, H, T, U \ \mathsf{or R, may be followed by D.} \\$

 $\textbf{Surge suppressors, for use with B Series contractors,} \ \ \texttt{Model(s):} \ \underline{\texttt{RV-BC6}} \ \ \texttt{may} \ \ \texttt{be followed by -F, followed by /60, /250 or /380.}$

Last Updated on 2022-03-15

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL's Follow-Up Service. Ways look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings), 2. The statement "Reprinted from the Online Certifications Directory with permission from UL" must appear adjacent to the extracted material, In addition, the reprinted material must include a copyright notice in the following format: "0 2022 UL LLC"

NLDX2.E191658 - Motor Controllers, Magnetic - Component

Motor Controllers, Magnetic - Component

E191658

ABB Stotz-Kontakt GmbH Eppelheimer Str 82 Heidelberg, 69123 Germany

Note: For additional marking information, refer to the $\underline{\textit{Guide Information Page}}.$

 $Model(s): \underline{86(g)}, \underline{865(b)}, \underline{87(g)}, \underline{875(b)}, \underline{87W(g)}, \underline{8C6(g)}, \underline{8C7(g)}, \underline{8C7W(g)}, \underline{186}, \underline{V86(g)}, \underline{V864(g)}, \underline{V865(b)}, \underline{V87_{(g)}}, \underline{V87A(g)}, \underline{V875(b)}, \underline{V875(b)}, \underline{V8C6(g)}, \underline{V8C6(g)}, \underline{V8C7_{(g)}}, \underline{V8C7_{(g)}},$ Model(s): MC1 followed by A, C, I or K, followed by A, B, 3 or 4, followed by 0 or 1, followed by 0 or 1, followed by Al, may be followed by additional numbers and/or letters.

Model(s): MC2 followed by A, C, I or K, followed by A, B, 3 or 4, followed by 0 or 1, followed by 0 or 1, followed by AI, may be followed by additional numbers and/or letters.

Model(s): MI1 followed by SOOSA, followed by I or J..

Model(s): MJ1 followed by SOOSA, followed by I or J.

(a) - May be followed by M, followed by 21, 22, 30, 31 or 40, followed by 00, 01 or 10, followed by F or P, may be followed by 1.4 or 2.4. (b) - May be followed by M, followed by -30, followed by 00, 01 or 10, followed by F or P, followed by 1.7 or 2.8.

Last Updated on 2022-03-11

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL's Follow-Up Service. Always look for the Mark on the product. UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings), 2. The statement "Reprinted from the Online Certifications Directory with permission from UL" must appear adjacent to the extracted material, In addition, the reprinted material must include a copyright notice in the following format: "0 2022 UL LLC"

E191658

NLDX7.E191658 - Motor Controllers, Magnetic Certified for Canada

Note: We are enhancing our systems and you may notice duplicate entries/missing/outdated data. During this interim period, please contact our Customer Service at https://www.ul.com/about/location

Motor Controllers, Magnetic Certified for Canada

Heidelberg, 69123 Germany

ABB Stotz-Kontakt GmbH Eppelheimer Str 82 Heidelberg, 69123 Germany

Accessory, Model(s): EH04-11, may be followed by N, EH04-20, may be followed by N

Accessory, Model(s): BSM6-30 followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Accessory bus bar kit, Model(s): WKMIU

Mechanical interlocks, Model(s): MMH0, VB05K

 $\textbf{Motor controllers}, \, \mathsf{Model}(s); \, \underline{\mathsf{ESB100}} \, \mathsf{followed by 40 \,\, or \, 40 \,\, o$

Motor controllers, Model(s): ESB16 followed by -11, -20 or -02, followed by N

Motor controllers, Model(s): ESB20 followed by -11, -20 or -02, followed by N

Motor controllers, Model(s): ESB24 followed by -0, 1, 2, 3 or 4, followed by 0, 1, 2, 3 or 4.

 $\textbf{Motor controllers}, \textbf{Model} (s): \underline{\texttt{ESB25}} \text{ followed by -0, -1, -2, -3, or -4, followed by 0, 1, 2, 3, or 4 followed by N} \\ \textbf{Note of the leaves of the leaves} \\ \textbf{Note of the leaves} \\ \textbf{$

Motor controllers, Model(s): ESB40 followed by -0, 1, 2, 3 or 4, followed by 0, 1 or 2, may be followed by

Motor controllers, Model(s): ESB63 followed by -0, 1, 2, 3 or 4, followed by 0, 1 or 2, may be followed by N

Motor starters provided with overload protection, open type, Model(s): <u>HF0.6-DOL-24VDC</u>, <u>HF0.6-DOLE-24VDC</u>, <u>HF2.4-DOL-24VDC</u>, <u>HF2.4-DOLE-24VDC</u>, <u>HF9-DOL-24VDC</u>, <u>HF9-DOL-24VDC</u>, <u>HF9-DOL-24VDC</u>

Nonreversing contactors, open type, Model(s): LSOSK followed by -30 or -40, followed by -00, -10, or -01, followed by two alphanumeric digits.

Nonreversing contactors, open type, Model(s): LSO6K followed by -30 or -40, followed by -00, -10, or -01, followed by two alphanumeric digits.

Nonreversing contactors, open type, Model(s): MCI followed by A, C, I or K, followed by A, B, 3 or 4, followed by 0 or 1, followed by 0 or 1, followed by A, Followed by H or T, followed by nor or two additional numbers or letters, may be followed by D, may be followed by -Rail

onreversing contactors, open type, Model(s): MC2 followed by A, C, Lor K, followed by A, B, 3 or 4, followed by 0 or 1, followed by 0 or 1, followed by H, Followed by H, T, followed by One or two additional numbers or letters, may be followed by D, may be followed by Rail.

Open type magnetic motor controllers, Model(s): 86 may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Modelis): 865 may be followed by M, followed by -30, followed by 00, 01 or 10, may be followed by 1.7 or 2.8.

Open type magnetic motor controllers, Modelis): 82 may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by 14 or 2.4.

Open type magnetic motor controllers. Model(s): B7D may be followed by M. followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Model(s): 875 may be followed by M, followed by -30, followed by 00, 01 or 10, may be followed by 1.7 or 2.8.

Open type magnetic motor controllers, Model(s): <u>BTW</u> may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by l.4 or 2.4.

Open type magnetic motor controllers, Model(s): 8C6 may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Model(s): <u>8C7</u> may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Model(s): <u>8C7W</u> may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4

Open type magnetic motor controllers, Model(s): VB6 may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Model(s): VB6A may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by 1.4 or 2.4.

Open type magnetic motor controllers, Model(s): <u>VB6S</u> may be followed by M, followed by -30, followed by 00, 01 or 10, may be followed by 1.7 or 2.8.

Open type magnetic motor controllers, Model(s): <u>VB6SA</u> may be followed by M, followed by -30, followed by 00, 01 or 10, may be followed by 1.7 or 2.8.

Open type magnetic motor controllers, Model(s): VB7 may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Model(s): VBTA may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Model(s): <u>VBTD</u> may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by 14 or 24.

Open type magnetic motor controllers, Model(s): <u>VBTS</u> may be followed by M, followed by -30, followed by 00, 01 or 10, may be followed by 1.7 or 2.8.

Open type magnetic motor controllers, Model(s): VBTSA may be followed by M, followed by -30, followed by 00, 01 or 10, may be followed by 1.7 or 2.8.

Open type magnetic motor controllers, Model(s): VBC6 may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4

Open type magnetic motor controllers, Model(s): VBC6A may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by I.4 or 2.4.

Open type magnetic motor controllers, Model(s): <u>VBC7</u> may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by 1.4 or 2.4.

Open type magnetic motor controllers, Model(s): <u>VBC7A</u> may be followed by M, followed by 30, 40, 22 or 31, followed by 00, 01 or 10, may be followed by 14 or 2.4.

 $\textbf{Reversing contactors, open type,} \ \ \text{Model(s):} \ \ \underline{\textbf{M11}} \ \ \text{followed by SOOSA, followed by } \ \xi, F, G, H, T, U \ \text{or } R, \ \text{may be followed by } D.$

Reversing contactors, open type, Model(s): MJI followed by SOOSA, followed by E, F, G, H, T, U or R, may be followed by D.

Reversing motor starters provided with overload protection, open type, Model(s): HF0.6-ROL-24VDC, HF0.6-ROLE-24VDC, HF2.4-ROL-24VDC, HF2.4-ROLE-24VDC, HF9-ROLE-24VDC, HF9-ROL

Surge suppressors, for use with B Series contractors, Model(s): RV-BC6 may be followed by -F, followed by /60, /250 or /380.

ast Updated on 2022-04-2

The appearance of a company's name or product in this database does not in itself assure that products o identified have been manufactured under UL's Follow-Lip Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL's Follow-Lip Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Assembles, Constructions, Designs, Systems, and/or Certifications (Bles) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings), 2. The statement "Repirited from the Online Certifications (Bles) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings), 2. The statement "Repirited from the Online Certifications (Bles) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings), 2. The statement "Repirited from the Online Certifications (Bles) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings), 2. The statement "Repirited from the Online Certifications (Bles) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings), 2. The statement "Repirited from the Online Certifications (Bles) must be presented in their entirety and in a non-misleading manner, without any manufacture of the Mark on the Present Certification (Bles) must be presented in their entirety and in a non-misleading manner, without any manufacture of the Mark on the Present Certification (Bles) must be presented in their entirety and in a non-misleading manner, without any manufacture of the Mark on the Present Certification (Bles) must be presented in their entirety and in a non-misleading manner, without any manufacture of the Mark on the Present Certification (Bl

NLDX8.E191658 - Motor Controllers, Magnetic Certified for Canada - Component

utdated data. During this interim period, please contact our Customer Service at https://www.ul.com/about/locations

Motor Controllers, Magnetic Certified for Canada - Component

ABB Stotz-Kontakt GmbH Eppelheimer Str 82 Heidelberg, 69123 Germany

Marking: Company name or tradename "BBC/CEM", "BBC/PETERCEM", or trademark ABB, model designation, and the Recognized Component Mark for Canada & R Note: For additional marking information, refer to the $\underline{\text{Guide Information Page}}.$

 $Model(s): \underline{86(g)}, \underline{865(b)}, \underline{87(g)}, \underline{875(b)}, \underline{87W(g)}, \underline{8C6(g)}, \underline{8C7(g)}, \underline{8C7W(g)}, \underline{186}, \underline{V86(g)}, \underline{V864(g)}, \underline{V865(b)}, \underline{V87_{(g)}}, \underline{V87A(g)}, \underline{V875(b)}, \underline{V875(b)}, \underline{V8C6(g)}, \underline{V8C6(g)}, \underline{V8C7_{(g)}}, \underline{V8C7_{(g)}},$

Model(s): MC1 followed by A, C, I or K, followed by A, B, 3 or 4, followed by 0 or 1, followed by 0 or 1, followed by AI, may be followed by additional numbers and/or letters.

Model(s): MC2 followed by A, C, I or K, followed by A, B, 3 or 4, followed by 0 or 1, followed by 0 or 1, followed by AI, may be followed by additional numbers and/or letters.

Model(s): MI1 followed by SOOSA, followed by I or J..

Model(s): MJ1 followed by SOOSA, followed by I or J.

(a) - May be followed by M, followed by 21, 22, 30, 31 or 40, followed by 00, 01 or 10, followed by F or P, may be followed by 1.4 or 2.4. (b) - May be followed by M, followed by -30, followed by 00, 01 or 10, followed by F or P, followed by 1.7 or 2.8.

Last Updated on 2022-03-11

E191658

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL's Follow-Up Service. Always look for the Mark on the product. UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings), 2. The statement "Reprinted from the Online Certifications Directory with permission from UL" must appear adjacent to the extracted material, In addition, the reprinted material must include a copyright notice in the following format: "0 2022 UL LLC"